




**System Manual**  
1. Edition



**sirius**



**SIEMENS**



## Safety guidelines

This manual contains notices which you should observe to ensure your own personal safety, as well as to protect the product and connected equipment. These notices are highlighted in the manual by a warning triangle and are marked as follows according to the level of danger:



### Danger

indicates that death, severe personal injury or substantial property damage **will** result if proper precautions are not taken.



### Warning

indicates that death, severe personal injury or substantial property damage **can** result if proper precautions are not taken.



### Caution

indicates that minor personal injury or property damage can result if proper precautions are not taken.

### Caution

indicates that property damage can result if proper precautions are not taken.

### Attention

draws your attention to particularly important information on the product, handling the product, or to a particular part of the documentation.

## Qualified personnel

Only **qualified personnel** should be allowed to install and work on this equipment. Qualified persons are defined as persons who are authorized to commission, to ground, and to tag circuits, equipment, and systems in acc. with established safety practices and standards.

## Correct usage

Note the following:



### Warning

This device and its components may only be used for the applications described in the catalogue or the technical descriptions, and only in connection with devices or components from other manufacturers which have been approved or recommended by Siemens.

This product can only function correctly and safely if it is transported, stored, set up, and installed correctly, and operated and maintained as recommended.

## Brands

SIMATIC®, SIMATIC HMI® and SIMATIC NET® are brands of SIEMENS AG.

Some other designations used in these documents are also brands; the owner's rights may be violated if they are used by third parties for their own purposes.

### Copyright Siemens AG 2001 All rights reserved

The reproduction, transmission or use of this document or its contents is not permitted without express written authority. Offenders will be liable for damages. All rights, including rights created by patent grant or registration of a utility model or design, are reserved.

### Disclaimer of liability

We have checked this manual to ensure that its contents are correct and applicable in relation to the hardware and software it describes. Despite all our endeavors, however, discrepancies cannot be wholly excluded and so we cannot guarantee complete correctness and applicability. However, the data in this manual are reviewed regularly and any necessary corrections included in subsequent editions. Suggestions for improvement are welcomed.

**Technical Assistance:** Telephone: +49 (0) 9131-7-43833 (8<sup>00</sup> - 17<sup>00</sup> CET) Fax: +49 (0) 9131-7-42899

E-mail: [nst.technical-assistance@siemens.com](mailto:nst.technical-assistance@siemens.com)

Internet: [www.siemens.com/lowvoltage/technical-assistance](http://www.siemens.com/lowvoltage/technical-assistance)

**Technical Support:** Telephone: +49 (0) 180 50 50 222

Siemens AG  
Bereich Automatisierungs- und Antriebstechnik  
Geschäftsgebiet Niederspannungs-Schalttechnik  
D-91050 Erlangen

© Siemens AG 2001  
Technical data subject to change without notice.

---

## Contents

<b>1</b>	<b>System overview</b>	<b>1-1</b>
1.1	Specifications/regulations/approvals	1-3
1.2	Overview: Range of devices	1-5
1.3	System features	1-10
1.4	Components and combinations	1-11
1.5	Mounting methods and terminal systems	1-15
1.5.1	Mounting the equipment	1-15
1.5.2	Screw-type terminals	1-17
1.5.3	Cage Clamp terminals	1-18
1.5.4	Connection cross-sections	1-20
1.6	Communication	1-22
1.6.1	Communication-capable low-voltage switching technology	1-22
1.6.2	Parameterization of PROFIBUS-DP and bus-capable low-voltage switching devices	1-23
1.6.3	Actuator-sensor interface (AS-Interface)	1-23
<b>2</b>	<b>3RV1 circuit breakers</b>	<b>2-1</b>
2.1	Specifications/regulations/approvals	2-3
2.2	Device description	2-5
2.2.1	General description	2-6
2.2.2	Operation	2-7
2.2.3	Information on configuration	2-10
2.3	Field of application/variants	2-13
2.3.1	Motor protection	2-13
2.3.2	Transformer protection	2-13
2.3.3	Starter protection	2-13
2.3.4	Circuit breakers with overload relay function	2-14
2.3.5	Fuse monitoring	2-14
2.3.6	Switching direct current	2-16
2.3.7	Main and emergency stop switches	2-17
2.4	Accessories	2-18
2.4.1	Attachable accessories: Overview	2-18
2.4.2	Auxiliary switch, alarm switch, and auxiliary release	2-19
2.4.3	Motorized remote-control mechanism	2-23
2.4.4	Disconnecting module	2-26
2.4.5	Rotary switch extension for door	2-28
2.4.6	Terminals for "Combination Motor Controller Type E" in acc. with UL 508	2-31
2.4.7	Housings and mounting accessories	2-32
2.4.8	Busbar adapter	2-37
2.4.9	Isolated 3-phase busbar system	2-41
2.5	Mounting and connection	2-45
2.5.1	Mounting	2-45
2.5.2	Connection	2-46
2.5.3	Device circuit diagrams	2-48
2.6	Dimensioned drawings (measurements in mm)	2-49
2.7	Technical specifications	2-58
2.7.1	General specifications	2-58
2.7.2	Rated short-circuit breaking capacity $I_{cn}$ in acc. with IEC 60 947-2	2-63
2.7.3	Limiter function with standard devices for 500 VAC and 690 VAC in acc. with IEC 60 947-2	2-65

<b>3</b>	<b>3RT1/3RH1 contactors</b>	<b>3-1</b>
3.1	Specifications/regulations/approvals	3-3
3.1.1	Utilization categories	3-3
3.1.2	Positively driven operation	3-7
3.1.3	Safe isolation	3-7
3.1.4	Explanation of terms	3-9
3.2	Device description	3-10
3.2.1	Actuating systems	3-12
3.2.2	Short-circuit protection of the SIRIUS contactors	3-12
3.2.3	Operation	3-13
3.2.3.1	General information	3-13
3.2.3.2	Contact reliability	3-14
3.3	Application and areas of use	3-20
3.3.1	3RT10 contactors with 3 main contacts for switching motors	3-20
3.3.2	3RT1446 contactors with 3 main contacts for switching resistive loads (AC-1)	3-21
3.3.3	3RT13 and 3RT15 contactors with 4 main contacts	3-22
3.3.4	3RT16 capacitor-switching contactors for switching capacitors	3-25
3.3.5	Contactors with an extended operating range	3-26
3.3.5.1	Contactors with an extended operating range (3RH1...-0LA0/3RT10...-0LA0)	3-27
3.3.5.2	Contactors with an extended operating range (3RH1122-2K.40, 3RT1017-2K.4., 3RT102.-3K.40)	3-29
3.3.6	3RH1 auxiliary contactors	3-29
3.3.7	3RT10 contactor relays for switching motors (interface) and 3RH11 contactor relays for switching auxiliary circuits	3-30
3.3.8	Contactor combinations for reversing	3-32
3.3.9	Star-delta combinations	3-41
3.4	Accessories	3-49
3.4.1	Attachable auxiliary switches for extending the auxiliary contacts	3-52
3.4.1.1	Terminal markings of the contactors (frame sizes S00 to S3)	3-57
3.4.1.2	Terminal markings of the contactors and auxiliary contactors combined with auxiliary switch blocks	3-59
3.4.1.3	Auxiliary switches that can be attached to 3RH1 auxiliary contactors	3-61
3.4.2	Time-delay auxiliary switches	3-64
3.4.2.1	Frame size S00 (3RT1916-2E, -2F, -2G)	3-64
3.4.2.2	Frame sizes S0 to S3 (3RT1926-2E, -2F, -2G)	3-66
3.4.3	Solid-state time relay blocks with semiconductor output	3-67
3.4.3.1	Frame size S00 (3RT1916-2C, -2D)	3-68
3.4.3.2	Frame size S0 to S3 (3RT1926-2C, -2D)	3-69
3.4.4	Additional load module (3RT1916-1GA00)	3-70
3.4.5	Coupling element for frame sizes S0 to S3 (3RH1924-1GP11)	3-71
3.4.6	Surge suppression	3-73
3.4.7	Other accessories	3-78
3.4.7.1	LED module for indicating contactor control (3RT1926-1QT00)	3-78
3.4.7.2	Auxiliary connecting lead terminal, 3-pole (for frame size S3)	3-79
3.4.7.3	EMC module (3RT1916-1P..)	3-79
3.4.7.4	Soldering pin connector for frame size S00	3-81
3.4.7.5	Parallel connections	3-83
3.4.7.6	Covers for frame sizes S2 and S3	3-84
3.5	Mounting and connection	3-86
3.5.1	Mounting	3-86
3.5.2	Connection	3-88
3.5.3	Changing the magnet coils	3-92
3.5.4	Changing the contact piece	3-97

3.6	Dimensioned drawings (dimensions in mm)	3-99
3.7	Technical specifications	3-110
<b>4</b>	<b>3RU11, 3RB10, and 3RB12 overload relays</b>	<b>4-1</b>
4.1	Specifications/regulations/approvals	4-2
4.2	Device description	4-4
4.2.1	Overload relays in motor feeders	4-5
4.2.2	General device description	4-6
4.2.3	Operation	4-13
4.3	Application and use	4-15
4.3.1	3RU11 thermal overload relay and 3RB10 electronic overload relay	4-15
4.3.2	3RB12 electronic overload relays	4-19
4.4	Accessories	4-23
4.4.1	Electromechanical remote reset	4-23
4.4.2	Mechanical remote reset	4-24
4.5	Mounting and connection	4-26
4.5.1	Mounting	4-26
4.5.2	Connection	4-29
4.5.3	Circuit diagrams	4-31
4.6	Dimensioned drawings (dimensions in mm)	4-34
4.7	Technical specifications	4-37
4.7.1	3RU11 thermal overload relays	4-37
4.7.2	3RB10 electronic overload relays	4-43
4.7.3	3RB12 electronic overload relays	4-47
<b>5</b>	<b>3RA1 fuseless load feeders</b>	<b>5-1</b>
5.1	Specifications/regulations/approvals	5-2
5.2	Device descriptions	5-3
5.2.1	Mounting systems	5-4
5.2.2	Mounting kits for self-assembly	5-5
5.2.3	Complete devices	5-5
5.3	Application and areas of use	5-7
5.4	Accessories	5-8
5.4.1	Accessories for the individual devices	5-8
5.4.2	Accessories specifically for the SIRIUS 3RA fuseless load feeder	5-8
5.4.3	Instructions for self-assembly	5-9
5.5	Mounting and connection	5-18
5.5.1	Mounting	5-18
5.5.2	Connection	5-21
5.5.3	Circuit diagrams	5-23
5.6	Dimensioned drawings (dimensions in mm)	5-24
5.7	Technical specifications	5-28
<b>6</b>	<b>3RH, 3TX, LZX coupling links</b>	<b>6-1</b>
6.1	Specifications/regulations	6-2
6.2	Device description	6-3
6.2.1	Relay coupling modules versus semiconductor coupling modules	6-4
6.2.2	Coupling links in two-tier and box terminal format	6-5
6.2.3	Plug-in relay coupling links	6-6
6.2.4	Coupling links for direct attachment	6-7
6.2.5	SIRIUS contactor relays	6-7
6.2.6	Installation	6-7

6.2.7	Notes on configuration . . . . .	6-8
6.2.8	Explanation of terms . . . . .	6-9
6.3	Application and areas of use . . . . .	6-10
6.3.1	General information . . . . .	6-10
6.3.2	Criteria for selection . . . . .	6-10
6.4	Accessories . . . . .	6-12
6.4.1	Accessories for two-tier coupling links . . . . .	6-12
6.4.2	Accessories for LZX plug-in relay coupling links . . . . .	6-13
6.5	Mounting and connection . . . . .	6-14
6.5.1	Mounting . . . . .	6-14
6.5.2	Connection . . . . .	6-14
6.5.3	Device circuit diagrams . . . . .	6-16
6.6	Dimensioned drawings (dimensions in mm) . . . . .	6-20
6.7	Technical specifications . . . . .	6-22
<b>7</b>	<b>3RP10, 3RP15 solid-state time relays . . . . .</b>	<b>7-1</b>
7.1	Specifications/regulations/approvals . . . . .	7-2
7.2	Device description . . . . .	7-3
7.2.1	Device types . . . . .	7-3
7.2.2	Installation . . . . .	7-4
7.2.3	Special features . . . . .	7-5
7.2.4	Notes on configuration . . . . .	7-5
7.2.5	Explanation of terms . . . . .	7-7
7.3	Applications and uses (types of function) . . . . .	7-8
7.3.1	Multifunction (3RP10 00 solid-state time relay) . . . . .	7-8
7.3.2	Multifunctional (3RP15 05 solid-state time relay) . . . . .	7-11
7.3.3	On-delay . . . . .	7-16
7.3.4	Off-delay . . . . .	7-17
7.3.5	Clock pulse generator (3RP15 55 solid-state time relay) . . . . .	7-18
7.3.6	Star-delta function (3RP15 74/76 solid-state time relay) . . . . .	7-19
7.3.7	Star-delta function with overtravel (3RP15 60 solid-state time relay) . . . . .	7-19
7.4	Accessories . . . . .	7-20
7.4.1	Accessories for 3RP10 . . . . .	7-20
7.4.2	Accessories for 3RP15 05 . . . . .	7-20
7.5	Mounting and connection . . . . .	7-22
7.5.1	Mounting . . . . .	7-22
7.5.2	Connection . . . . .	7-23
7.5.3	Circuit diagrams . . . . .	7-24
7.6	Dimensioned drawings (dimensions in mm) . . . . .	7-25
7.7	Technical specifications . . . . .	7-26
<b>8</b>	<b>3RW3 semiconductor motor control unit . . . . .</b>	<b>8-1</b>
8.1	Specifications/regulations/approvals . . . . .	8-3
8.2	Device description . . . . .	8-5
8.2.1	Physical principles . . . . .	8-6
8.2.2	General device description . . . . .	8-10
8.2.3	Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the SIKOSTART 3RW22 and SIKOSTART 3RW34 motor control units . . . . .	8-14
8.2.4	Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the 3RA star-delta combination . . . . .	8-16
8.2.5	Notes on configuration . . . . .	8-16
8.3	Application and use . . . . .	8-18

---

8.3.1	Areas of application and criteria for selection . . . . .	8-18
8.3.2	Installation guidelines . . . . .	8-18
8.3.3	Overview tables: correction factors . . . . .	8-21
8.3.3.1	3RW30/31 soft starters in a stand-alone installation . . . . .	8-21
8.3.3.2	3RW30/31 soft starters in combination with the 3RV1 circuit breaker . . . . .	8-22
8.3.3.3	Combining the 3RT contactor with the 3RU1 thermal overload relay and 3RW3 soft starter . . . . .	8-24
8.3.3.4	Combining the 3RT contactor with the 3RB10 electronic overload relay and 3RW3 soft starter . . . . .	8-26
8.3.4	Circuit example . . . . .	8-29
8.3.5	Commissioning . . . . .	8-30
8.3.6	Event messages and diagnostics . . . . .	8-32
8.3.7	Timing diagram . . . . .	8-33
8.4	Accessories . . . . .	8-35
8.5	Mounting and connection . . . . .	8-37
8.5.1	Mounting . . . . .	8-37
8.5.2	Connection . . . . .	8-37
8.5.3	Circuit diagrams . . . . .	8-38
8.6	Dimensioned drawings (dimensions in mm) . . . . .	8-41
8.7	Technical specifications . . . . .	8-42
8.7.1	Control electronics/power electronics . . . . .	8-42
8.7.2	Short-circuit protection and fuse coordination . . . . .	8-45
8.7.3	Site altitude . . . . .	8-50
8.7.4	Specifications in acc. with IEC . . . . .	8-51
8.7.5	Specifications in acc. with NEMA . . . . .	8-52

Index

Index-1

---

## Figures

Figure 1-1:	SIRIUS system. . . . .	1-5
Figure 1-2:	Circuit breaker, accessories (frame size S00) . . . . .	1-6
Figure 1-3:	Circuit breakers, accessories (frame sizes S0, S2, and S3) . . . . .	1-6
Figure 1-4:	Contactors, accessories (frame size S00) . . . . .	1-7
Figure 1-5:	Contactors, accessories (frame sizes S0 to S3). . . . .	1-8
Figure 1-6:	Device combinations . . . . .	1-13
Figure 1-7:	Contactor combination for reversing . . . . .	1-14
Figure 1-8:	Cage Clamp terminal . . . . .	1-18
Figure 1-9:	Conductor cross-sections $\leq 1 \text{ mm}^2$ . . . . .	1-20
Figure 1-10:	Communication . . . . .	1-22
Figure 2-1:	3RV1 circuit breakers (frame sizes S00 to S3). . . . .	2-5
Figure 2-2:	Setting the current setting $I_e$ (example: frame size S00) . . . . .	2-7
Figure 2-3:	Sealing the adjustment scale (frame size S00) . . . . .	2-8
Figure 2-4:	Tripped position, 3RV (frame size S0). . . . .	2-9
Figure 2-5:	Locking the toggle switch (frame size S00) . . . . .	2-9
Figure 2-6:	Time-current characteristic, chart . . . . .	2-11
Figure 2-7:	Frequency sensitivity of the n-short-circuit releases . . . . .	2-12
Figure 2-8:	Circuit breaker with overload relay function (frame sizes S0 to S3) . . . . .	2-14
Figure 2-9:	Circuit diagrams of circuit breakers for fuse monitoring. . . . .	2-15
Figure 2-10:	Mounting the transverse auxiliary switch (frame size S00) . . . . .	2-19
Figure 2-11:	Mounting/removing the lateral auxiliary switch/undervoltage release (frame size S00) . . . . .	2-20
Figure 2-12:	Mounting the disconnecting module (frame size S0) . . . . .	2-26
Figure 2-13:	Locking the disconnecting module (frame size S0) . . . . .	2-27
Figure 2-14:	Locking the disconnecting module and mounting the cover (frame size S2). . . . .	2-27
Figure 2-15:	Mounting the rotary switch extension for the door (frame size S2) . . . . .	2-28
Figure 2-16:	Operating the rotary switch extension for the door . . . . .	2-29
Figure 2-17:	Locking the rotary switch extension for the door. . . . .	2-30
Figure 2-18:	Terminals for "Combination Motor Controller Type E". . . . .	2-31
Figure 2-19:	Molded-plastic surface casing (frame size S00). . . . .	2-32
Figure 2-20:	Molded-plastic bay (frame size S00). . . . .	2-33
Figure 2-21:	Mounting the front plate (frame size S00) . . . . .	2-34
Figure 2-22:	Mounting the front plate (frame size S0). . . . .	2-34
Figure 2-23:	Accessories for the housings and front plates (frame size S00). . . . .	2-35
Figure 2-24:	Indicator light installation in a molded-plastic housing. . . . .	2-36
Figure 2-25:	Mounting circuit breakers on busbar adapters (frame sizes S00 and S0) . . . . .	2-38
Figure 2-26:	Mounting circuit breakers on busbar adapters (frame sizes S2 and S3) . . . . .	2-39
Figure 2-27:	Accessories for busbar adapters (frame sizes S00 to S2) . . . . .	2-40
Figure 2-28:	3-phase busbar system. . . . .	2-41
Figure 2-29:	Mounting the isolated 3-phase busbar system (frame sizes S00 to S0) . . . . .	2-43
Figure 2-30:	Mounting the isolated 3-phase busbar system (frame size S2) . . . . .	2-44
Figure 2-31:	Mounting the circuit breakers onto the rail. . . . .	2-45
Figure 2-32:	Screw-on mounting of the 3RV1 (example: frame size S00). . . . .	2-45
Figure 2-33:	Circuit breaker, soldering pin connector (frame size S00) . . . . .	2-47
Figure 2-34:	Device circuit diagram (frame size S00). . . . .	2-48
Figure 2-35:	Device circuit diagrams (frame sizes S0 to S3) . . . . .	2-48
Figure 2-36:	Circuit breaker with relay function, device circuit diagrams (frame sizes S0 to S3) . . . . .	2-48
Figure 2-37:	3RV10 11, 3RV16 (frame size S00), 3RV10 21 (frame size S0) . . . . .	2-49
Figure 2-38:	3RV10 31 (frame size S2) . . . . .	2-49
Figure 2-39:	3RV10 4 (frame size S3) . . . . .	2-49
Figure 2-40:	3RV11 21 (frame size S0), 3RV11 31 (frame size S2) . . . . .	2-50



Figure 2-41: 3RV11 42 (frame size S3) . . . . .	2-50
Figure 2-42: 3RV19 28-1A (for frame size S0), 3RV19 38-1A (for frame size S2) . . . . .	2-50
Figure 2-43: 3RV19 13-1. (for frame size S00). . . . .	2-51
Figure 2-44: 3RV19 23-1. (for frame size S0), 3RV19 33-1. (for frame size S2) . . . . .	2-51
Figure 2-45: 3RV19 13-2DA00 (frame size S00), 3RV19 23-2DA00/2GA00 (frame size S0) . . . . .	2-52
Figure 2-46: 3RV19 13-4C (frame size S00) . . . . .	2-52
Figure 2-47: 3RV19 23-4. (frame sizes S0, S2, S3) . . . . .	2-52
Figure 2-48: 3RV19 18-5A/5B (frame size S00) . . . . .	2-53
Figure 2-49: 3RV19 26-0 (frame sizes S0, S2, S3) . . . . .	2-53
Figure 2-50: 3RV19 28-1H (frame size S0) and 3RT19 46-4GA07 (frame size S3) . . . . .	2-53
Figure 2-51: 3RV19. 6-3AP0 for circuit breaker . . . . .	2-54
Figure 2-52: 8US10.1-5DJ07, 8US1061-5FK08 . . . . .	2-55
Figure 2-53: 8US1251-5DM07, 8US1261-5FM08, 8US1923-2AA00 . . . . .	2-55
Figure 2-54: 3RV19 15-1. (frame sizes S00, S0) . . . . .	2-55
Figure 2-55: 3RV19 35-1 (for circuit breakers in frame size S2) . . . . .	2-56
Figure 2-56: 3RV19 35-3 (for circuit breakers in frame size S2) . . . . .	2-56
Figure 2-57: 3RV19 15-5A, 3RV19 15-5B, 3RV19 25-5AB . . . . .	2-56
Figure 2-58: 3RV19 35-5A, 3RV19 15-5D . . . . .	2-57
Figure 3-1: Frame sizes of the 3RT1 contactors. . . . .	3-10
Figure 3-2: Contact areas. . . . .	3-15
Figure 3-3: Characteristic curve of the electrical service life of the main contacts (frame size S00)	3-17
Figure 3-4: Characteristic curve of the electrical service life of the main contacts (frame size S0).	3-17
Figure 3-5: Characteristic curve of the electrical service life of the main contacts (frame size S2).	3-18
Figure 3-6: Characteristic curve of the electrical service life of the main contacts (frame size S3).	3-18
Figure 3-7: Characteristic curve of the electrical service life of the auxiliary contacts . . . . .	3-19
Figure 3-8: Capacitor-switching contactors (frame sizes S0 and S2) . . . . .	3-25
Figure 3-9: Capacitor-switching contactors, circuit diagram . . . . .	3-26
Figure 3-10: Contactors with an extended operating range, circuit diagrams . . . . .	3-28
Figure 3-11: Contactors with an extended operating range, terminal markings . . . . .	3-28
Figure 3-12: Contactors with an extended operating range, circuit diagram . . . . .	3-28
Figure 3-13: Contactor relays: voltage ranges . . . . .	3-31
Figure 3-14: Fully assembled contactor combination for reversing (frame sizes S00 and S0) . . . . .	3-32
Figure 3-15: Star-delta combination, locking device at the front (frame size S0). . . . .	3-34
Figure 3-16: Star-delta combination, locking devices at the front (frame sizes S2/S3) . . . . .	3-34
Figure 3-17: 4-pole contactor combination for reversing (frame size S0) . . . . .	3-38
Figure 3-18: 4-pole contactor combination for reversing (frame size S2) . . . . .	3-39
Figure 3-19: NC contact interlock (frame size S00) . . . . .	3-39
Figure 3-20: Contactor combination for reversing, main circuit (frame sizes S00 to S3) . . . . .	3-40
Figure 3-21: Contactor combination for reversing, control circuit (frame size S00) . . . . .	3-40
Figure 3-22: Contactor combination for reversing, control circuit (frame sizes S0 to S3). . . . .	3-41
Figure 3-23: Star-delta combinations (frame sizes S00, S0, S3) . . . . .	3-42
Figure 3-24: Star-delta combination (frame size S2) . . . . .	3-43
Figure 3-25: Star-delta combination, main circuit (frame sizes S00 to S3) . . . . .	3-47
Figure 3-26: Star-delta combination, control circuit (frame size S00) . . . . .	3-48
Figure 3-27: Star-delta combination, control circuit (frame sizes S0 to S3) . . . . .	3-48
Figure 3-28: Accessories for contactors of frame size S00. . . . .	3-49
Figure 3-29: Accessories for auxiliary contactors/contactors relays of frame size S00. . . . .	3-50
Figure 3-30: Accessories for contactors of frame size S00. . . . .	3-51
Figure 3-31: Auxiliary switch at front . . . . .	3-54
Figure 3-32: Auxiliary switch at side . . . . .	3-55
Figure 3-33: Switching of the auxiliary contact elements. . . . .	3-56
Figure 3-34: Auxiliary contacts, contactors for switching motors (frame size S00) . . . . .	3-58

Figure 3-35: Auxiliary contacts, contactors for switching motors (frame sizes S0 to S3) . . . . .	3-59
Figure 3-36: Graphical symbols for auxiliary contact elements in acc. with EN 50 012 (excerpt) . . .	3-60
Figure 3-37: Device circuit diagrams of the auxiliary switch blocks (DIN EN 50 012) . . . . .	3-60
Figure 3-38: Auxiliary contacts for auxiliary contactors . . . . .	3-61
Figure 3-39: Graphical symbols for auxiliary contactors in acc. with EN 50 011 (excerpt) . . . . .	3-62
Figure 3-40: Device circuit diagrams. . . . .	3-63
Figure 3-41: Position diagrams of the auxiliary switches (frame sizes S0 to S3). . . . .	3-63
Figure 3-42: Time-delay auxiliary switch block (frame size S00). . . . .	3-65
Figure 3-43: Function diagrams of the time-delay auxiliary switches (frame size S00) . . . . .	3-65
Figure 3-44: Time-delay auxiliary switch block (frame sizes S0 to S3) . . . . .	3-66
Figure 3-45: Time-delay auxiliary switches, function diagrams (frame sizes S0 to S3) . . . . .	3-67
Figure 3-46: Control of loads . . . . .	3-68
Figure 3-47: Solid-state time relay block with semiconductor output, installation (frame size S00) .	3-68
Figure 3-48: Solid-state time relay block with semiconductor output, function diagrams (frame size S00) . . . . .	3-69
Figure 3-49: Solid-state time relay with semiconductor output, circuit diagrams (frame size S00) . .	3-69
Figure 3-50: Solid-state time relay with a semiconductor output, installation (frame size S00) . . . .	3-69
Figure 3-51: Solid-state time relay with semiconductor output, circuit diagrams . . . . .	3-70
Figure 3-52: Solid-state time relay with semiconductor output, function diagrams . . . . .	3-70
Figure 3-53: Coupling link (frame sizes S0 to S3) . . . . .	3-71
Figure 3-54: Coupling link, circuit diagram (frame sizes S0 to S3). . . . .	3-72
Figure 3-55: Disconnecting an unused contactor coil . . . . .	3-73
Figure 3-56: Circuit with a varistor (AC/DC operation) . . . . .	3-74
Figure 3-57: Circuit with an RC element (AC/DC operation) . . . . .	3-74
Figure 3-58: Circuit with a diode (AC/DC operation) . . . . .	3-75
Figure 3-59: Surge suppressors, installation. . . . .	3-77
Figure 3-60: RC element/varistor, circuit diagrams. . . . .	3-78
Figure 3-61: LED module . . . . .	3-79
Figure 3-62: EMC suppression module . . . . .	3-80
Figure 3-63: Soldering pin connection, mounting . . . . .	3-81
Figure 3-64: Mounting the soldering pin connection on a 4-pole auxiliary switch block . . . . .	3-81
Figure 3-65: Removing the spring from the soldering pin connection . . . . .	3-82
Figure 3-66: Terminal covers . . . . .	3-85
Figure 3-67: 3RT: Screw-on attachment (frame size S00) . . . . .	3-86
Figure 3-68: Snap-on attachment. . . . .	3-87
Figure 3-69: Installation positions . . . . .	3-87
Figure 3-70: Cage Clamp terminals . . . . .	3-89
Figure 3-71: Insulation stop with Cage Clamp terminals . . . . .	3-89
Figure 3-72: Replacing the magnet coil (frame size S0/AC). . . . .	3-92
Figure 3-73: Replacing the magnet coil (frame size S2/AC). . . . .	3-93
Figure 3-74: Replacing the magnet coil (frame size S2/DC). . . . .	3-94
Figure 3-75: Replacing the magnet coil (frame size S3/AC). . . . .	3-95
Figure 3-76: Replacing the magnet coil (frame size S3/DC). . . . .	3-96
Figure 3-77: Replacing the contact piece (frame size S2). . . . .	3-97
Figure 3-78: Replacing the contact piece (frame size S3). . . . .	3-98
Figure 3-79: Contact pieces (frame sizes S2/S3) . . . . .	3-98
Figure 3-80: 3RT1. 10 1/3RH11 contactors (frame size S00). . . . .	3-99
Figure 3-81: 3RT10 2 contactors, 3RT10 2 contactor relays (frame size S0) . . . . .	3-99
Figure 3-82: 3RT10 3 (frame size S2) . . . . .	3-100
Figure 3-83: 3RT10 4, 3RT14 46 (frame size S3) . . . . .	3-100
Figure 3-84: 3RT10 1 (frame size S00) . . . . .	3-101
Figure 3-85: 3RT13 1, 3RT15 1 (frame size S00) . . . . .	3-101

Figure 3-86: 3RT13 2, 3RT15 2 (frame size S0) . . . . .	3-101
Figure 3-87: 3RT133, 3RT153 (frame size S2) . . . . .	3-102
Figure 3-88: 3RT13 4 (frame size S3) . . . . .	3-102
Figure 3-89: 3RT1626 (frame size S0) . . . . .	3-103
Figure 3-90: 3RT1636 (frame size S2) . . . . .	3-103
Figure 3-91: 3RT1646 (frame size S3) . . . . .	3-103
Figure 3-92: 3RT10 17, 3RH 11 (frame size S00) . . . . .	3-104
Figure 3-93: 3RT10 2, view from right (frame size S0) . . . . .	3-104
Figure 3-94: 3RT103, view from right (frame size S2) . . . . .	3-104
Figure 3-95: 3RT104, view from right (frame size S3) . . . . .	3-104
Figure 3-96: 3RT1916-2E., -2F., -2G.. (frame size S00), 3RT19 26-2E., -2F., -2G.. (frame sizes S0 to S3) . . . . .	3-105
Figure 3-97: 3RT19 16-2 (frame size S00) . . . . . 3RT19 26-2 (frame sizes S0 to S3) . . . . .	3-105
Figure 3-98: 3RH19 11-1AA., 3RH19 11-1BA. . . . .	3-105
Figure 3-99: Contactor combination for reversing (frame size S00) . . . . .	3-107
Figure 3-100: Contactor combination for reversing (frame size S0) . . . . .	3-107
Figure 3-101: Contactor combination for reversing (frame size S2) . . . . .	3-107
Figure 3-102: Contactor combination for reversing (frame size S3) . . . . .	3-107
Figure 3-103: 3RA1924-2B (frame sizes S0 to S3) 3RA1924-1A (frame sizes S0 to S3) . . . . .	3-108
Figure 3-104: Contactor combinations for star/delta (frame sizes S00 - S00 - S00) . . . . .	3-108
Figure 3-105: Contactor combinations for star/delta (frame sizes S0 - S0 - S0) . . . . .	3-108
Figure 3-106: Contactor combinations for star/delta (frame sizes S2 - S2 - S0) . . . . .	3-108
Figure 3-107: Contactor combinations for star/delta (frame sizes S2 - S2 - S2) . . . . .	3-109
Figure 3-108: Contactor combinations for star/delta (frame sizes S3 - S3 - S3) . . . . .	3-109
Figure 4-1: 3RU11 overload relays (frame sizes S00 to S2) . . . . .	4-6
Figure 4-2: 3RU11 overload relay (frame size S3) . . . . .	4-6
Figure 4-3: 3RB12 electronic overload relay . . . . .	4-7
Figure 4-4: 3RU11 front view . . . . .	4-15
Figure 4-5: Setting the rated current . . . . .	4-16
Figure 4-6: Sealing the adjustment scale (frame size S00) . . . . .	4-16
Figure 4-7: Manual/automatic switchover . . . . .	4-17
Figure 4-8: Time-current characteristic, chart for the 3RU11 . . . . .	4-18
Figure 4-9: Time-current characteristics for class 10 and class 20, chart for the 3RB10 . . . . .	4-18
Figure 4-10: Front view of the 3RB12 electronic overload relays . . . . .	4-19
Figure 4-11: Time-current characteristics, chart for the 3RB12 . . . . .	4-21
Figure 4-12: Electronic overload relay with analog output, front view . . . . .	4-21
Figure 4-13: Electrical remote reset, installation/removal. . . . .	4-23
Figure 4-14: Mechanical remote reset: resetting plunger, installation . . . . .	4-24
Figure 4-15: Mechanical remote reset: resetting plunger, removal. . . . .	4-24
Figure 4-16: Mechanical remote reset: wire release, installation . . . . .	4-25
Figure 4-17: Mechanical remote reset: wire release, removal . . . . .	4-25
Figure 4-18: Mounting onto the 3RT contactor/3RW3 soft starter . . . . .	4-26
Figure 4-19: Stand-alone holder, example 3RU11 (frame size S00/S0) . . . . .	4-27
Figure 4-20: Stand-alone holder, example 3RU11 (frame size S2/S3) . . . . .	4-27
Figure 4-21: Snap-on mounting and removal with the 3RT contactor . . . . .	4-27
Figure 4-22: Permissible installation positions for the 3RU11 . . . . .	4-28
Figure 4-23: Loop-through system, 3RB1246 . . . . .	4-29
Figure 4-24: 3RU11: Cage Clamp terminal (frame size S2) . . . . .	4-30
Figure 4-25: 3RU11 circuit diagrams . . . . .	4-31
Figure 4-26: 3RU11 and 3RB10 device circuit diagrams . . . . .	4-31

Figure 4-27: Connection example for the 3RU11 . . . . .	4-32
Figure 4-28: Connection example for the 3RU10 . . . . .	4-32
Figure 4-29: Connection plants for 3RB12 single-phase motors . . . . .	4-33
Figure 4-30: 3RU11 16-..B0, (frame size S00) 3RU11 16, 3RB10 16, (frame size S00) . . . . .	4-34
Figure 4-31: 3RU11 26-..B., 3RB10 26, (frame size S0) 3RU11 36-..B., 3RB10 36, (frame size S2) . . . . .	4-34
Figure 4-32: 3RU11 46-..B., 3RB10 46 . . . . .	4-34
Figure 4-33: 3RB12 46, 3RB12 5. / 3RB12 62 . . . . .	4-35
Figure 4-34: 3RU11 16-..C1 (frame size S00) . . . . .	4-35
Figure 4-35: 3RU11 26-..D0 (frame size S0), 3RU11 36-..D0 (frame size S2) . . . . .	4-35
Figure 4-36: 3RU11 46-..D0 (frame size S3) . . . . .	4-36
Figure 5-1: Rail adapter/busbar adapter . . . . .	5-4
Figure 5-2: Self-assembly of a fuseless load feeder (frame size S00) . . . . .	5-5
Figure 5-3: Self-assembly, rail, reversing operation (frame size S00) . . . . .	5-9
Figure 5-4: Self-assembly, rail, direct starter (frame sizes S00 to S3) . . . . .	5-10
Figure 5-5: Self-assembly, rail, direct starter (frame size S00, Cage Clamp) . . . . .	5-11
Figure 5-6: Self-assembly, rail, reversing operation (frame size S0) . . . . .	5-12
Figure 5-7: Self-assembly, rail, reversing operation (frame sizes S2 and S3) . . . . .	5-13
Figure 5-8: Self-assembly, busbars, direct starters (frame sizes S00 and S2) . . . . .	5-14
Figure 5-9: Self-assembly, busbars, direct starters (frame size S00/S0, Cage Clamp) . . . . .	5-15
Figure 5-10: Self-assembly, busbars, reversing operation (frame sizes S00 and S0) . . . . .	5-16
Figure 5-11: Self-assembly, busbars, reversing operation (frame size S2) . . . . .	5-17
Figure 5-12: Screw-on attachment, fuseless load feeder (frame size S00) . . . . .	5-19
Figure 5-13: Busbar system, mounting/removal (frame sizes S00 to S2) . . . . .	5-20
Figure 5-14: Circuit diagrams, direct starters (frame sizes S00 to S3) . . . . .	5-23
Figure 5-15: Circuit diagrams, reversing starters (frame sizes S00 to S3) . . . . .	5-23
Figure 5-16: 3RA11 10-..A.. for direct-on-line starting 3RA12 10-..A.. for reversing operation . . . . .	5-24
Figure 5-17: 3RA11 10-..C., 3RA11 10-..D.. for direct-on-line starting 3RA12 10-..C., 3RA12 10-..D.. for reversing operation . . . . .	5-24
Figure 5-18: 3RA11 20-..A.. for direct-on-line starting 3RA12 20-..B.. for reversing operation . . . . .	5-25
Figure 5-19: 3RA11 20-..C., 3RA11 20-..D.. for direct-on-line starting 3RA1220-..C., 3RA1120-..D.. for reversing operation . . . . .	5-25
Figure 5-20: 3RA1 direct-on-line starting (frame size S2) 3RA1 reversing operation (frame size S2) . . . . .	5-26
Figure 5-21: 3RA1 direct-on-line starting (frame size S0) 3RA1 reversing operation (frame size S0) . . . . .	5-26
Figure 5-22: 3RA1 direct-on-line starting (frame size S3) 3RA1 reversing operation (frame size S3) . . . . .	5-27
Figure 6-1: Output coupler, Input coupler . . . . .	6-5
Figure 6-2: Basic circuit diagram, line capacitance . . . . .	6-8
Figure 6-3: Application example, coupling links in box terminal format . . . . .	6-10
Figure 6-4: 24-pole connection lead for two-tier coupling links . . . . .	6-12
Figure 6-5: 24-pole connection comb for two-tier coupling links . . . . .	6-12
Figure 6-6: Cage Clamp terminals, coupling links . . . . .	6-14
Figure 7-1: 3RP1000 solid-state time relay, multifunctional . . . . .	7-3
Figure 7-2: 3RP15 solid-state time relay, multifunctional with 2 changeover contacts . . . . .	7-4
Figure 7-3: 3RP10 00 (multifunctional) operating time adjustment . . . . .	7-8
Figure 7-4: 3RP10 00 (multifunctional) function setting . . . . .	7-9
Figure 7-5: 3RP15 05 (multifunctional) operating time adjustment . . . . .	7-11

Figure 7-6:	3RP15 05 (multifunctional) function identification . . . . .	7-12
Figure 7-7:	3RP10 function diagram . . . . .	7-16
Figure 7-8:	3RP15 1. function diagram . . . . .	7-16
Figure 7-9:	3RP15 25 function diagram . . . . .	7-17
Figure 7-10:	3RP15 27 function diagram . . . . .	7-17
Figure 7-11:	3RP15 3. function diagram . . . . .	7-17
Figure 7-12:	3RP15 40 function diagram . . . . .	7-18
Figure 7-13:	3RP15 55 function diagram . . . . .	7-19
Figure 7-14:	3RP15 7. function diagram . . . . .	7-19
Figure 7-15:	Coding plug set (3RP10 00) . . . . .	7-20
Figure 7-16:	Label set (3RP15) . . . . .	7-20
Figure 7-17:	Screw-on attachment . . . . .	7-21
Figure 7-18:	3RP10: mounting on and removal from a 35 mm rail . . . . .	7-22
Figure 7-19:	Rail mounting. . . . .	7-22
Figure 7-20:	Cage Clamp terminals . . . . .	7-23
Figure 8-1:	3RW3 soft starter. . . . .	8-5
Figure 8-1:	Typical current and torque curve of a three-phase asynchronous motor . . . . .	8-6
Figure 8-2:	Current and torque curves for star-delta starting . . . . .	8-7
Figure 8-3:	Method of operation of a frequency converter . . . . .	8-8
Figure 8-4:	Phase firing of the supply voltage by semiconductor elements in the 3RW3 soft starter . . . . .	8-9
Figure 8-5:	Current and torque curves for a soft starter. . . . .	8-10
Figure 8-6:	Time ramp/timing diagram, 3RW30 . . . . .	8-12
Figure 8-7:	Time ramp, 3RW31 . . . . .	8-12
Figure 8-8:	Overview of soft starters . . . . .	8-14
Figure 8-9:	Load and motor torques and motor terminal voltage for operation with soft starter . . . . .	8-17
Figure 8-10:	3RW3 soft starter + 3RV1 circuit breaker . . . . .	8-22
Figure 8-11:	3RT+3RU1+3RW3 combination . . . . .	8-24
Figure 8-12:	3RT+3RB10+3RW3 combination . . . . .	8-26
Figure 8-13:	3RT+3RW3+3RB10 combination . . . . .	8-27
Figure 8-14:	Circuit example, 3RW3. . . . .	8-29
Figure 8-15:	Settings, 3RW3 . . . . .	8-30
Figure 8-16:	Position of the terminals and the potentiometers for adjustment. . . . .	8-32
Figure 8-17:	Starting and coasting-down behavior . . . . .	8-33
Figure 8-18:	Supply interruption in the bypassed state . . . . .	8-34
Figure 8-19:	Accessories: attachment of the fan . . . . .	8-36
Figure 8-20:	Connection example with an RC element . . . . .	8-36
Figure 8-21:	Circuit diagrams, 3RW3 . . . . .	8-38
Figure 8-22:	Circuit diagrams, 3RW30 . . . . .	8-38
Figure 8-23:	Circuit diagrams, 3RW31 . . . . .	8-39
Figure 8-24:	Motor control with an electromechanical brake . . . . .	8-40
Figure 8-25:	Reductions as a function of site altitude . . . . .	8-50

---

## Tables

Table 1-1:	Components and combinations with accessories . . . . .	1-12
Table 1-2:	Mounting methods . . . . .	1-15
Table 1-3:	Mounting the device on the rail . . . . .	1-16
Table 1-4:	Removing the device from the rail . . . . .	1-16
Table 1-5:	How to use a Cage Clamp terminal . . . . .	1-19
Table 1-6:	Connection cross-section for frame size S00 . . . . .	1-20
Table 1-7:	Connection cross-section for frame size S0 . . . . .	1-20
Table 1-8:	Connection cross-section for frame size S2 . . . . .	1-21
Table 1-9:	Connection cross-section for frame size S3 . . . . .	1-21
Table 2-1:	Circuit breakers, frame sizes . . . . .	2-5
Table 2-2:	Contact position indicators of the circuit breakers . . . . .	2-9
Table 2-3:	Testing overload tripping (example: frame size S00) . . . . .	2-10
Table 2-4:	Suggestions for switching direct current . . . . .	2-16
Table 2-5:	Attachable accessories . . . . .	2-19
Table 2-6:	Voltage ranges of the auxiliary releases . . . . .	2-20
Table 2-7:	Testing overload tripping (example: frame size S0) . . . . .	2-21
Table 2-8:	Alarm switch with tripped signal and short circuit signal . . . . .	2-22
Table 2-9:	Mounting the remote-control mechanism (frame size S2) . . . . .	2-25
Table 2-10:	Opening a cubicle door using the rotary switch extension . . . . .	2-29
Table 2-11:	Mounting the extension shaft . . . . .	2-30
Table 2-12:	Housings for circuit breakers . . . . .	2-32
Table 2-13:	Front plates for any housings . . . . .	2-33
Table 2-14:	Busbar systems . . . . .	2-37
Table 2-15:	Dimensions of the busbar adapters and accessories . . . . .	2-37
Table 2-16:	Link modules for connecting circuit breakers to contactors . . . . .	2-38
Table 2-17:	Rated operational voltage/current . . . . .	2-41
Table 2-18:	Types of 3-phase busbars . . . . .	2-41
Table 2-19:	Conductor cross-section of the 3-phase feed-in terminals . . . . .	2-42
Table 3-1:	Utilization categories, test conditions for AC voltage . . . . .	3-4
Table 3-2:	Utilization categories, test conditions for DC voltages . . . . .	3-5
Table 3-3:	Utilization categories, test conditions for AC voltage (auxiliary contact elements) . . . . .	3-5
Table 3-4:	Utilization categories, test conditions for DC voltage (auxiliary contact elements) . . . . .	3-6
Table 3-5:	Safe isolation . . . . .	3-8
Table 3-6:	Performance ranges of the 3RT10 contactors . . . . .	3-10
Table 3-7:	Types of 3RT/3RH contactors . . . . .	3-11
Table 3-8:	Actuating systems . . . . .	3-12
Table 3-9:	Mechanical endurance . . . . .	3-14
Table 3-10:	Comparison between the 3RT1446 and 3RT1046 contactors . . . . .	3-21
Table 3-11:	Applications of 4-pole contactors . . . . .	3-22
Table 3-12:	4-pole contactors and auxiliary contacts . . . . .	3-22
Table 3-13:	4-pole reversing contactor combination with front interlock (frame size S0) . . . . .	3-23

Table 3-14:	4-pole reversing contactor combination with lateral interlock (frame size S0) . . . . .	3-24
Table 3-15:	4-pole reversing contactor combination (frame sizes S2 and S3) . . . . .	3-24
Table 3-16:	Assembling the contactor combination for reversing (frame size S00) . . . . .	3-35
Table 3-17:	Assembling the contactor combination for reversing (frame size S0) . . . . .	3-36
Table 3-18:	Assembling the contactor combination for reversing (frame sizes S2/S3) . . . . .	3-37
Table 3-19:	Configuration of the star-delta combinations . . . . .	3-44
Table 3-20:	Assembly of the star-delta combination in frame size S00 . . . . .	3-45
Table 3-21:	Assembly of the star-delta combinations in frame sizes S0 to S3 . . . . .	3-46
Table 3-22:	Auxiliary switch blocks . . . . .	3-53
Table 3-23:	Expansion options for auxiliary switch blocks . . . . .	3-54
Table 3-24:	Possible auxiliary switch combinations (frame size S0/S2) . . . . .	3-55
Table 3-25:	Possible auxiliary switch combinations (frame size S3) . . . . .	3-55
Table 3-26:	Possible auxiliary switch combinations with 4-pole/capacitor-switching contactors . . . . .	3-56
Table 3-27:	Auxiliary switches with make-before-break contacting . . . . .	3-56
Table 3-28:	Surge suppressor . . . . .	3-75
Table 3-29:	How surge suppressors work . . . . .	3-76
Table 3-30:	Conductor cross-sections of 3-pole auxiliary connecting lead terminals (for frame size S3) . . . . .	3-79
Table 3-31:	Parallel links making and breaking capacity . . . . .	3-83
Table 3-32:	Parallel connections Variants . . . . .	3-84
Table 3-33:	Covers . . . . .	3-84
Table 3-34:	Attachment . . . . .	3-86
Table 3-35:	Vertical installation position . . . . .	3-88
Table 3-36:	Conductor cross-sections (frame sizes S00 to S3) . . . . .	3-91
Table 4-1:	Tripping classes/tripping times . . . . .	4-2
Table 4-2:	Operating limits of time-delayed overload releases in the case of an all-pole load . . . . .	4-2
Table 4-3:	SIRIUS overload relays, configuration and functions . . . . .	4-8
Table 4-4:	Assignment of the overload relays to the contactors . . . . .	4-9
Table 4-5:	3RU11/3RB10 auxiliary contacts . . . . .	4-16
Table 4-6:	Recovery time . . . . .	4-17
Table 4-7:	Failure of the control supply voltage . . . . .	4-20
Table 5-1:	Fuseless load feeder, accessories . . . . .	5-8
Table 5-2:	Self-assembly of the reversing starter for rail (frame size S00) . . . . .	5-9
Table 5-3:	Conductor cross-sections (frame size S00/S0) . . . . .	5-21
Table 5-4:	Conductor cross-sections (frame size S2) . . . . .	5-21
Table 5-5:	Conductor cross-sections (frame size S3) . . . . .	5-22
Table 6-1:	Regulations and specifications . . . . .	6-2
Table 6-2:	3RH, 3TX, LZX coupling links - overview of the device groups with their distinguishing features . . . . .	6-3
Table 6-3:	Comparison: Relay coupling modules and semiconductor coupling modules . . . . .	6-4
Table 6-4:	Selection criteria for the 3RH, 3TX, and LZX coupling links . . . . .	6-11
Table 6-5:	Conductor cross-sections for the 3RH, 3TX, and LZX coupling links . . . . .	6-15
Table 6-6:	Technical specifications, 3TX70 relay coupling links . . . . .	6-22
Table 6-7:	Technical specifications, 3TX7004/3TX7005 semiconductor coupling links . . . . .	6-22

Table 6-8:	Technical specifications, 3TX7002/3TX7003 semiconductor coupling links . . . . .	6-22
Table 6-9:	Technical specifications, LZX: RT/PT . . . . .	6-23
Table 6-10:	Technical specifications, LZX: MT . . . . .	6-23
Table 6-11:	Technical specifications, 3RH1924/3TX7090 . . . . .	6-24
Table 7-1:	3RP10 00 (multifunctional) operating time adjustment . . . . .	7-8
Table 7-2:	3RP10 00 (multifunctional) circuit diagrams and function diagrams . . . . .	7-10
Table 7-3:	3RP15 05 (multifunctional) operating time adjustment . . . . .	7-11
Table 7-4:	3RP15 05 (multifunctional) assignment of the identifying letters . . . . .	7-13
Table 7-5:	Function diagrams and circuit diagrams . . . . .	7-15
Table 7-6:	Sealable cover . . . . .	7-21
Table 7-7:	Permissible conductor cross-sections for control and load current connections: . . .	7-23
Table 7-8:	Technical specifications for the time relay . . . . .	7-26
Table 8-1:	Standards, certificates, and approvals, 3RW3 . . . . .	8-3
Table 8-2:	3RW3, frame sizes . . . . .	8-5
Table 8-3:	Link modules . . . . .	8-13
Table 8-4:	Comparison of 3RW3/3RA . . . . .	8-16
Table 8-5:	Stand-alone installation, minimum clearances at the side, 3RW3 . . . . .	8-19
Table 8-6:	Stand-alone installation, minimum clearances at the side, 3RW3 . . . . .	8-19
Table 8-7:	Correction factors, 3RW30/31 . . . . .	8-22
Table 8-8:	Correction factors: 3RV1 circuit breaker + 3RW3 soft starter . . . . .	8-23
Table 8-9:	3RW3 installation guidelines, minimum clearances/lengths . . . . .	8-24
Table 8-10:	Correction factors, 3RT contactor + 3RU therm. overload relay + 3RW soft starter . .	8-25
Table 8-11:	3RT + 3RB10 + 3RW3 installation guidelines, minimum clearances/minimum lengths	8-26
Table 8-12:	3RT1 + 3RW30/31 + 3RB10 installation guidelines, minimum clearances/minimum lengths . . . . .	8-27
Table 8-13:	Correction factors, 3RT contactor + 3RB10 electronic overload relay + 3RW soft starter . . . . .	8-28
Table 8-14:	3RW30/31 event messages . . . . .	8-32
Table 8-15:	3RW30/31 diagnostics . . . . .	8-33
Table 8-16:	Accessories, 3RW30/31 . . . . .	8-35
Table 8-17:	Conductor cross-sections, 3RW30/31 . . . . .	8-37
Table 8-18:	Fuse configurations (SITOR) . . . . .	8-46
Table 8-19:	Fuse configurations (SITOR) . . . . .	8-47
Table 8-20:	Motor feeder: fuseless configuration . . . . .	8-48
Table 8-21:	Motor feeder: fused configuration . . . . .	8-49
Table 8-22:	3RW3 motor ratings in acc. with IEC at 40° C . . . . .	8-51
Table 8-23:	3RW3 motor ratings in acc. with IEC at 50° C . . . . .	8-51
Table 8-24:	3RW3 motor ratings in acc. with IEC at 60° C . . . . .	8-51
Table 8-25:	3RW3 motor ratings in acc. with NEMA at 40° C . . . . .	8-52
Table 8-26:	3RW3 motor ratings in acc. with NEMA at 50° C . . . . .	8-52
Table 8-27:	3RW3 motor ratings in acc. with NEMA at 60° C . . . . .	8-52



# System overview

Section	Subject	Page
<b>1.1</b>	<b>Specifications/regulations/approvals</b>	<b>1-3</b>
<b>1.2</b>	<b>Overview: Range of devices</b>	<b>1-5</b>
<b>1.3</b>	<b>System features</b>	<b>1-10</b>
<b>1.4</b>	<b>Components and combinations</b>	<b>1-11</b>
<b>1.5</b>	<b>Mounting methods and terminal systems</b>	<b>1-15</b>
1.5.1	Mounting the equipment	1-15
1.5.2	Screw-type terminals	1-17
1.5.3	Cage Clamp terminals	1-18
1.5.4	Connection cross-sections	1-20
<b>1.6</b>	<b>Communication</b>	<b>1-22</b>
1.6.1	Communication-capable low-voltage switching technology	1-22
1.6.2	Parameterization of PROFIBUS-DP and bus-capable low-voltage switching devices	1-23
1.6.3	Actuator-sensor interface (AS-Interface)	1-23

## Introduction

Siemens is one of the leading manufacturers of switchgear. The product range extends from devices that switch a few mA to circuit breakers used in power distribution.

Throughout the continuing development of these products we have always striven to ensure that requirements in terms of fundamental performance features, electrical and mechanical service life, dimensions, and ease of installation and maintenance are met or exceeded.

We have been able to meet the demands resulting from increased environmental awareness, particularly in the last ten years or so, by developing and using environment-friendly and recyclable materials. As a result, we have developed modern industrial switching devices, particularly in the field of low-voltage switchgear, that meet all the relevant demands in terms of environment-friendliness.

Building on decades of experience, we have created a completely new generation of circuit breakers, contactors, auxiliary contactors, overload relays, contactor relays, time relays, and 3RW3 semiconductor motor control devices (referred to below as soft starters) under the name SIRIUS for the large and continuously growing number of motor drives in the range up to 45 kW.

These new SIRIUS devices fulfill all the demands placed on them in practice and can be used as stand-alone devices or modular components of complete load feeders, or integrated in low-voltage distribution cabinets or low-voltage switching stations.

## 1.1 Specifications/regulations/approvals

### Explosion protection

Motor protection devices that protect a motor from overload in a hazardous area must meet certain requirements. These requirements are defined in the following standards:

DIN VDE 0660, DIN VDE 0165, EN 60947-1:1991..+A11:1994, EN 60947-4-1, EN 50014:1994, EN 50019:1978+A1 to A5

Compliance with these standards has up until now been established by means of a test. Compliance could be documented in two ways:

1. By a test certificate from the manufacturer
2. By a test certificate from an independent test laboratory (e.g. PTB, DMT, KEMA, etc.).

### EU directive

Testing of explosion protection has been defined more precisely as a result of the harmonization of the European Union. In addition to the above standards, tests will also be carried out in acc. with the EU directive 94/9/EC or ATEX 100a.

Two procedures are in operation during the transition period up until 2003:

#### Procedure 1

Test certificate from an independent test laboratory as usual (e.g. PTB, DMT, KEMA, etc.).

#### Procedure 2

Special test certificate from certified test laboratories (in acc. with extended European rules). The statutory basis for this is the Official Journal of the European Union (no. 95/C2 15/02 of 19.08.1995).

Siemens SIRIUS switching devices are tested and certified twice:

### Certificate 1

Test certificate from KEMA in the same way as before (valid until 2003) in acc. with:

- DIN VDE 0660, DIN VDE 0165
- EN 60947-1:1991/A11
- EN 60947-4-1:1992, EN 50019:1978+A1 to A5

### Certificate 2

Special test certificate from the DMT-BVS in acc. with:

- DIN VDE 0660, DIN VDE 0165
- EN 60947-1:1991..+A11:1994, EN 60947-4-1
- EN 50014:1994, EN 50019:1978 + A1 to A5
- EU directive 94/9/EC (ATEX 100a - EU directive)

**DMT-BVS**

The DMT-BVS is, like the PTB, a certified German testing organization in compliance with the EU directive 76/117/EEC and EIExV. Like the PTB and other testing institutes in Europe, the DMT-BVS tests and awards certificates in acc. with the explosion protection directive 94/9/EC and is accredited accordingly.

Over 100 years ago, the DMT-BVS became the first testing station for explosion protection in Germany, and it has been a testing station for electrical equipment as well since 1912. DMT-BVS certificates are recognized throughout the world. For support in export matters, the DMT-BVS works with the chemical industry and is of course recognized by it.

**KEMA**

KEMA, which is a testing institute that enjoys worldwide recognition, is a certified European institute with many years of experience of testing for explosion protection.

For support in export matters, KEMA also works with testing stations throughout the world.

## 1.2 Overview: Range of devices

### SIRIUS system

The SIRIUS product range consists of 3RV circuit breakers, 3RT contactors, 3RH/3RT auxiliary contactors and contactor relays, 3RU thermal overload relays, 3RB10/3RB12 electronic overload relays, 3RP time relays, 3RW3 semiconductor motor control devices (referred to below as soft starters), and combinations of these devices, which form the 3RA load feeders.

The individual devices are developed and built in such a way that it is very easy to put them together to make load feeders. This is possible because the devices are all built to work together on both an electrical and a mechanical level.




Figure 1-1: SIRIUS system

**Circuit breaker with a frame size of S00 and attachable accessories:**




Figure 1-2: Circuit breaker, accessories (frame size S00)

**Circuit breakers with frame sizes of S0, S2, and S3 and attachable accessories:**




Figure 1-3: Circuit breakers, accessories (frame sizes S0, S2, and S3)

Attachable accessories for frame sizes S00, S0, S2, and S3:

- 1) Transverse auxiliary switch
- 2) Lateral auxiliary switch with 2 contacts
- 3) Lateral auxiliary switch with 4 contacts
- 4) Shunt release
- 5) Undervoltage release
- 6.1) Undervoltage release with leading auxiliary contacts (S00)
- 6.2) Undervoltage release with leading auxiliary contacts (S0 to S3)
- 7) Alarm switch (S0 to S3)
- 8) Disconnecting module (S0 and S2)


**Contactors with a frame size of S00 and accessories:**

Figure 1-4: Contactors, accessories (frame size S00)

- 1) Contactor
- 2) Contactor relay
- 3) Solid-state time relay block, on-delay
- 4) Solid-state time relay block, off-delay
- 5) Auxiliary switch block, time-delay (on-delay or off-delay or star-delta function)
- 6) 1-pole auxiliary switch block, infeed from above
- 7) 2-pole auxiliary switch block, infeed from above
- 8) 1-pole auxiliary switch block, infeed from below
- 9) 2-pole auxiliary switch block, infeed from below
- 10) 4-pole auxiliary switch block (terminal markings in acc. with DIN EN 50 012 or DIN EN 50 005)
- 11) 2-pole auxiliary switch block, standard or electronic type (terminal markings in acc. with DIN EN 50 005)
- 12) Soldering pin adapter for contactors with 4-pole auxiliary switch block
- 13) Soldering pin adapter for contactors and contactor relays
- 14) Additional load module to increase the permissible residual current
- 15) Surge suppressor with LED
- 16) Surge suppressor without LED
- 17) 3-phase feed-in terminal
- 18) Parallel link (neutral bridge), 3-pole, without terminal
- 19) Parallel link, 3-pole, with terminal
- 20) Parallel link, 4-pole, with terminal

**Contactors with frame sizes of S0 to S3 with accessories:**




Figure 1-5: Contactors, accessories (frame sizes S0 to S3)

- 1) Contactor, frame size S0
- 2) Contactor, frame size S2
- 3) Contactor, frame size S3

**For frame sizes S0 to S3:**

- 4) Solid-state time relay block, on-delay
- 5) Solid-state time relay block, off-delay
- 6) Auxiliary switch block, time-delay (on- or off-delay or star-delta function)
- 7) 2-pole auxiliary switch block, infeed from above
- 8) 2-pole auxiliary switch block, infeed from below
- 9) 4-pole auxiliary switch block  
(terminal markings in acc. with DIN EN 50 012 or DIN EN 50 005)
- 10) Parallel link (neutral bridge), 3-pole, without terminal
- 11) Parallel link, 3-pole, with terminal



- 12) 2-pole auxiliary switch block, attachable on the right or left side  
(terminal markings in acc. with DIN EN 50 012 or DIN EN 50 005)
- 13) 1-pole auxiliary switch block (a maximum of 4 can be snapped on)
- 14) Mechanical interlock, attachable at the side
- 15) Mechanical interlock, attachable at the front
- 16) Wiring blocks above and below (reversing mode)
- 17) Surge suppressor (varistor, RC element, diode combination),  
attachable above or below (varies for S0 and S2/S3)
- 18) Coupling link for direct connection to the contactor coil
- 19) LED block to display contactor function

**For frame sizes S2 and S3 only:**

- 20) Terminal for contactor coil for setting up contactor combinations
- 21) Terminal cover for box terminals

**For frame size S3 only:**

- 22) Terminal cover for terminal end and bar connection
- 23) Auxiliary connecting lead terminal, 3-pole

## 1.3 System features

The entire SIRIUS range of devices is divided up into only four frame sizes (S00 up to 5.5 kW, S0 up to 11 kW, S2 up to 22 kW, and S3 up to 45 kW) with three different widths (45 mm for S00 and S0, 55 mm for S2, and 70 mm for S3) and has a uniform range of accessories for all frame sizes.

### **Modular system**

The individual components of the SIRIUS range are building blocks in a modular system that are harmonized in terms of both their frame size and their technical specifications. This ensures that individual requirements can be met quickly and cost-effectively.

### **Uniformity**

The devices are harmonized with regard to their ratings and their technical specifications:

- The same width ensures rapid installation.
- The terminal systems are standardized, and devices with the same rated current have the same terminals.

### **Performance capability**

All SIRIUS devices can be mounted side by side without derating in an ambient air temperature of up to 60 °C.

### **Accessories**

All accessories, such as the auxiliary switches and surge suppressors, can be mounted and removed without tools.

You can use link modules that connect devices both mechanically and electrically to put together combinations of devices and build fuseless load feeders.

### **Communication**

Direct communication with a higher-level controller is possible using:

- The AS-Interface load feeder module
- The ET 200X distributed I/O devices on the PROFIBUS-DP bus system
- The ET 200S system

## 1.4 Components and combinations

This section describes the components of the SIRIUS system and the device combinations that are possible with these components.

### Components of the SIRIUS system

The following table contains a list of the components of the SIRIUS system together with the most important accessories:


Components	Brief description/features	Accessories
<b>3RV1 circuit breakers</b>	<ul style="list-style-type: none"> <li>- Switch and protect motors and other loads up to 100 A</li> </ul>	<ul style="list-style-type: none"> <li>- Auxiliary switches (transverse, lateral)</li> <li>- Undervoltage releases</li> <li>- Shunt releases</li> <li>- Alarm switches</li> <li>- Housing</li> <li>- 3-phase busbar system</li> </ul>
<b>3RT10 motor contactors</b>	<ul style="list-style-type: none"> <li>- Switch motors up to 4 kW and currents up to 95 A</li> <li>- Types: 3-pole for switching</li> <li>- 4-pole, with 4 NO and 2 S + 2 NC contacts</li> <li>- Soldering pin adapter</li> <li>- Capacitor switching contactor</li> <li>- Reversing and star-delta combinations</li> </ul>	<ul style="list-style-type: none"> <li>- Auxiliary switch blocks</li> <li>- Surge suppressors</li> <li>- Parallel links</li> <li>- Time relay blocks</li> <li>- Link modules</li> <li>- Wiring blocks</li> </ul>
<b>3RH11 contactor relays</b>	<ul style="list-style-type: none"> <li>- Same type of construction as the 3RT</li> <li>- Basic version: 4-pole, expandable to 8 pins by means of auxiliary switch blocks</li> <li>- High contact stability (1 mA; 17 V)</li> </ul>	
<b>3RT10/3RH11 contactor relays</b>	<ul style="list-style-type: none"> <li>- Switch motors and auxiliary contactors with an extended operating range (17 V to 30 V)</li> </ul>	
<b>3RU11 overload relays</b>	<ul style="list-style-type: none"> <li>- CLASS 10</li> <li>- Phase loss sensitivity</li> <li>- Series auxiliary contacts 1 NO + 1 NC contact</li> <li>- Frame size S00: repetition terminal for the auxiliary contact and coil connection for attachment to contactors</li> <li>- Integrated, transparent and sealable cover for the adjusting knob and test function</li> </ul>	<ul style="list-style-type: none"> <li>- Remote RESET, electrical</li> <li>- Mechanical RESET</li> <li>- Terminal bracket for stand-alone installation</li> </ul>
<b>3RB10 overload relays</b>	<ul style="list-style-type: none"> <li>- CLASS 10 and CLASS 20</li> <li>- Rapid tripping operation in the event of phase loss (&lt; 3 s)</li> <li>- Series auxiliary contacts 1 NO + 1 NC</li> <li>- Low power loss, energy-saving</li> <li>- Wide adjustment ranges for simple configuration, selection, and less storage</li> <li>- Extremely low energy requirements, approx. 50 mW</li> </ul>	<ul style="list-style-type: none"> <li>- Remote RESET, electrical</li> <li>- Mechanical RESET</li> <li>- Terminal bracket for stand-alone installation</li> </ul>

Components	Brief description/features	Accessories
<b>3RB12 overload relays</b>	<ul style="list-style-type: none"> <li>- CLASS 5 to CLASS 30 can be set</li> <li>- Phase loss sensitivity</li> <li>- 2 outputs per 1 NO + 1 NC contact</li> <li>- Integrated current transformers in all sizes</li> <li>- Motor protection due to the connection of a thermistor sensor circuit</li> <li>- Internal ground fault monitoring</li> <li>- Overload warning</li> <li>- Remote and automatic reset possible</li> <li>- High tripping accuracy</li> <li>- Wide adjustment ranges</li> <li>- Self-monitoring</li> </ul>	<ul style="list-style-type: none"> <li>- Summation current transformer for external ground fault monitoring</li> <li>- DC adapter</li> <li>- Terminal cover</li> </ul>
<b>3RA1 load feeders</b>	<ul style="list-style-type: none"> <li>- Fuseless load feeder consisting of a circuit breaker and contactor</li> <li>- Simple assembly with link modules and wiring blocks</li> <li>- Reversing combination (link modules)</li> <li>- Star-delta combination</li> </ul>	<ul style="list-style-type: none"> <li>- Accessories for the basic devices (contactors and circuit breakers)</li> <li>- Special accessories: Auxiliary switches connectable from above or below</li> </ul>
<b>3RP10/15 solid-state time relays</b>	<ul style="list-style-type: none"> <li>- 8 adjustable time ranges from 0.05 seconds to 10 hours</li> <li>- Constantly high repeatability</li> <li>- Type with combination voltage (24 VDC and 110 to 240 VAC)</li> <li>- 2 device types: on-delay and multifunctional (7 functions)</li> <li>- Long mechanical and electrical service life</li> </ul>	<ul style="list-style-type: none"> <li>- Coding plug sets</li> <li>- Locking device</li> </ul>
<b>3RW30/31 soft starters</b>	<ul style="list-style-type: none"> <li>- Reduction of the starting current for a smooth start</li> <li>- Soft coasting down function</li> <li>- Only 3 motor supply leads are required</li> <li>- System adaptation using setting options: starting time, starting voltage, coasting down time</li> </ul>	<ul style="list-style-type: none"> <li>- Fans</li> </ul>
<b>Load feeders with communication capability</b>	<p>Complete load feeders</p> <ul style="list-style-type: none"> <li>- At the AS-Interface with the AS-Interface IP65 compact starter</li> <li>- AS-Interface IP20 load feeder module</li> <li>- On the Profibus-DP through the following systems                             <ul style="list-style-type: none"> <li>ET 200X with IP65 protection</li> <li>ET 200S with IP20 protection</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>- Supply modules</li> <li>- Wiring</li> </ul>


Table 1-1: Components and combinations with accessories

**Device combinations**

The following diagrams show you the possible device combinations, using the S00 frame size as an example:



3RA13 reversing combination



3RA14 star-delta combination




Figure 1-6: Device combinations

**Contactor combination for reversing the S00 frame size (with accessories):**




Figure 1-7: Contactor combination for reversing

Individual parts:

1/2) Contactors

4/5/6) Kit

The kit includes:

4) Mechanical interlock

5) 2 connection clips for 2 contactors

6) Wiring blocks above and below to connect the main conducting paths with electrical interlock (NC contact interlock - can be removed if required)

Attachable accessories:

13) Soldering pin adapter

14) Auxiliary switch block, on the front (only an auxiliary switch blocks that complies with DIN EN 50 005 can be used)

16) Surge suppressor

## 1.5 Mounting methods and terminal systems

### 1.5.1 Mounting the equipment

The method of mounting the equipment is uniform within each frame size.

Frame size	Mounting	Removal
S00 to S3	Screwed on	Removed with a screwdriver
S00, S0	Snapped onto a 35 mm rail (in acc. with DIN EN 50 022)	Removed without a tool
S2	Snapped onto a 35 mm rail (in acc. with DIN EN 50 022)	The snap-on spring can be opened with a screwdriver
S3	Snapped onto a 35 mm rail (in acc. with DIN EN 50 022) Snapped onto a 75 mm rail	The snap-on spring can be opened with a screwdriver

Table 1-2: Mounting methods

#### Screw-on mounting

The SIRIUS switching devices can be screwed on to a flat surface.

Please note the following points with some of the devices:

- 3RV1 circuit breaker, frame sizes S00/S0: Push-in lugs are required for screw-type mounting
- 3RP15 time relay: Push-in lugs are required for screw-type mounting
- Coupling links: No screw-type mounting
- Soft starters: No screw-type mounting

#### Snap-on mounting

The SIRIUS switching devices are snapped onto 35 mm rails in acc. with DIN EN 50 022 without a tool.

The devices with a frame size of S3 require a rail with an installation height of 15 mm. Alternatively, they can also be snapped onto 75 mm rails.

The following table shows you how to mount the device onto the rail:



Frame size	Procedure	Illustration
S00/S0	Place the device on the upper edge of the rail, and press it downwards until it snaps onto the lower edge of the rail.	
S2/S3	Place the device on the upper edge of the rail, and tilt it towards the rail until it snaps onto the lower edge of the rail.	

Table 1-3: Mounting the device on the rail

The following table shows you how to remove the device from the rail:



Frame size	Procedure	Illustration
S00/S0	Push the device downwards to release the tension of the mounting spring, and remove the device by tilting it.	
S2/S3	Using a screwdriver, push the clip on the lower rear side of the device downwards to release the tension of the mounting spring (1), and remove the device by tilting it (2).	

Table 1-4: Removing the device from the rail

You will find notes on mounting the different devices on the rail in the relevant parts of section n.5 on mounting methods and terminal systems.



## 1.5.2 Screw-type terminals

The terminals used do not vary within a frame size. The current switched by the different devices of a single frame size does not vary either. This means you can use the same tool, torque, and conductor cross-section for the circuit breakers, contactors, and overload relays of a single frame size. The stripped lengths are also the same. This is important in the case of prefabricated wiring.

### **Screw-type terminals**

All the devices have screw-type terminals, either a terminal with a top washer or a box terminal, depending on the frame size. Devices with frame sizes S00 and S0 have terminals with captive screws and terminal washers that enable you to connect 2 conductors, even if they have different cross-sections. The box terminals of frame size S2 and S3 can also take 2 conductors with different cross-sections.

### **Connection tools**

Use the following tools to make the connection:

- Frame sizes S00 to S2: Screws are available for rated currents of up to 50 A for Pozidriv2 screwdrivers.
- Frame size S3: To obtain the required torques for the frame size for up to 100 A, the screws have a 4 mm hexagon socket.

The screwdriver guides allow screwdriving machines to be used.

### **Lugs and connecting bars**

You can remove the box terminals from the devices with a frame size of S3 to connect conductors with lugs or connecting bars. A terminal cover is available as shock protection and to ensure that you comply with the required creepages and clearances when the box terminals are removed. You can find a detailed description in section n.4 on accessories.

### 1.5.3 Cage Clamp terminals

The Cage Clamp<sup>®</sup> terminal system is now available for circuit breakers, contactors, overload relays, and time relays.

Cage-type clamping units, known as Cage Clamp terminals in the case of SIRIUS products, facilitate quick and maintenance-free wiring.

#### Design

The Cage Clamp terminal consists of two parts:

- A power rail for conducting current
- A sprung cage-type clamp for clamping strength




Figure 1-8: Cage Clamp terminal

#### Conductors

The Cage Clamp terminal on the switching devices clamps all copper wires (single-core, stranded and finely stranded) from 0.25 mm<sup>2</sup> to 2.5 mm<sup>2</sup>. The conductors can be clamped directly or with some protection for splicing. To this end, wire end ferrules or pin-end connectors can be placed on the conductor ends. The best solution is an ultrasonically condensed conductor.

**Safety**

The devices are equipped with a two-wire connection. In other words, there are two independent connections for each conducting path. Only one conductor is connected to each clamping unit. The clamp presses the conductor against the power rail, which is curved at this point. The high specific compressive load thus achieved is gas-tight. The clamp presses its flat surface against the conductor, thus avoiding damage to it. The spring force of the clamp is designed so that it automatically adjusts to the radius of the conductor. This allows any deformation of the conductor to be dealt with. It is not possible for the clamping unit to loosen by itself. This connection is vibration- and shock-proof. These types of stress do not damage the conductor or cause any loss in contact. Machines and systems in which this type of stress occurs, such as vibrators and elevators, are particularly suitable applications for this connection.

**Transfer accuracy**

The contact pressure between the conductor and power rail is optimal, making this clamp terminal suitable for high-voltage installations and also for the transfer of voltages and currents in the mV and mA ranges in measuring technology and electronics.

**Tool**

Screwdrivers can be obtained from the NSK (low-voltage switchgear) catalog for opening the Cage Clamp terminals.

**Procedure**

The following table shows you how to use the Cage Clamp:




Step	Procedure	
1	Insert the screwdriver into the rectangular opening until it stops. The screwdriver head automatically keeps the clamp open.	
2	Insert the conductor into the oval terminal opening.	
3	Remove the screwdriver. The terminal closes, and the conductor is thus securely clamped.	

Table 1-5: How to use a Cage Clamp terminal

**Small conductor cross-sections**

With conductor cross-sections that are  $\leq 1 \text{ mm}^2$ , you have to use an insulating stop to ensure the conductors remain securely clamped. The illustration below shows the procedure:




Figure 1-9: Conductor cross-sections  $\leq 1 \text{ mm}^2$

**1.5.4 Connection cross-sections**

Because SIRIUS is a modular system, the connection cross-sections are the same for all devices of a single frame size. The following tables specify the permissible conductor cross-sections for main and auxiliary conductor connections:

**Frame size S00**





	Main and auxiliary conductors	
 Ø 5 to 6 mm/PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	<b>Cage Clamp</b>
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )
	---	2 x (0.25 to 2.5 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)

Table 1-6: Connection cross-section for frame size S00

**Frame size S0**





	Control conductor: A1/A2 Auxiliary conductor: NO/NC		Main conductor
	Screw-type terminal	Cage Clamp terminal	L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm/PZ2	0.8 1.2 Nm 7 to 10.3 lb.in	---	2 to 2.5 Nm 18 to 22 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
	---	2 x (0.25 to 2.5 mm <sup>2</sup> )	---
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	2 x (14 to 10)

Table 1-7: Connection cross-section for frame size S0

**Frame size S2**








	Control conductor: A1/A2 Auxiliary conductor: NO/NC			Main conductor
	Screw-type terminal	Cage Clamp terminal		L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm/PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	---	 Ø 5 to 6 mm/PZ2	3 to 4.5 Nm 27 to 40 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> ) 1 x (0.75 to 25 mm <sup>2</sup> )
---	---	---		2 x (0.75 to 25 mm <sup>2</sup> ) 1 x (0.75 to 35 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	<b>AWG</b>	2 x (18 to 3) 1 x (18 to 2)

Table 1-8: Connection cross-section for frame size S2

**Frame size S3**









	Control conductor: A1/A2 Auxiliary conductor: NO/NC			Main conductor
	Screw-type terminal	Cage Clamp terminal		L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm/PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	---		4 to 6 Nm 35 to 53 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )		2 x (2.5 to 16 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )		2 x (2.5 to 35 mm <sup>2</sup> ) 1 x (2.5 to 50 mm <sup>2</sup> )
	---	---		2 x (10 to 50 mm <sup>2</sup> ) 1 x (10 to 70 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	<b>AWG</b>	2 x (10 to 1/0) 1 x (10 to 2/0)

Table 1-9: Connection cross-section for frame size S3

## 1.6 Communication




Figure 1-10: Communication

### 1.6.1 Communication-capable low-voltage switching technology

This uniform range of communication-capable Siemens switching devices represents an innovative concept for effective cubicle automation. Communication with the higher-level control system via open, PROFIBUS-DP, and AS-Interface connections.

#### Actuator-sensor interface (AS-Interface)

AS-Interface is a standardized, non-proprietary networking system (IEC 62026-2) for simple and usually binary actuators and sensors. It is possible to connect it to SIMATIC programmable logic controllers via different master modules. A DP/AS-Interface link also ensures direct integration in a PROFIBUS-DP system or connection to other field buses via couplers. Up to 248 sensors and 186 actuators can be connected to an AS-Interface network over a maximum of 500 m. Safety-related signals can now also be networked with AS-Interface, thus dispensing with the wiring of emergency stop signals that was needed previously.

#### PROFIBUS

PROFIBUS is a standardized, non-proprietary field bus system (IEC 61158) to which most PLCs of leading manufacturers can be connected. Up to 125 nodes can be incorporated in one bus segment. Distances of up to 9.6 km can be bridged with copper cables and up to 100 km with fiber-optic cables.

**PROFIBUS-DP**

PROFIBUS-DP (DP being a German abbreviation for distributed I/O) is used for switching devices with higher communication requirements (e.g. the transmission of analog actual values with extremely fast response times). It is also used to link individual AS-Interface segments.

**1.6.2 Parameterization of PROFIBUS-DP and bus-capable low-voltage switching devices**

Before commissioning, PROFIBUS-DP must be configured, and the individual bus nodes must be parameterized. There are user-friendly tools available to the user for configuration and parameter assignment.

**Parameter assignment tools**

- For SIMATIC S7 masters, all the functions are integrated in the STEP 7 programming language.
- For SIMATIC S5 masters and various non-Siemens masters, the COM PROFIBUS parameter assignment software is required.
- Manufacturers of non-Siemens masters offer other configuration and parameter assignment programs.

**Applications**

The above program packages make it easy to carry out the following for PROFIBUS-DP and its nodes:

- Configuration
- Parameter assignment
- Documentation
- Commissioning
- Testing
- Diagnostics

For additional information on communication-capable low-voltage switching devices, as well as system components and accessories, see the following catalogs:

- ST 70 "S7, M7 and C7 Programmable Logic Controllers"
- IK PI "Industrial Communication and Field Devices"

**1.6.3 Actuator-sensor interface (AS-Interface)**

The actuator-sensor interface (AS-Interface) is a modular networking system for sensors and actuators in the lowest field range.

It makes no difference to the program in the programmable controller whether parallel wiring with input/output modules or AS-Interface is used. It is therefore possible for existing systems to change to AS-Interface because you can continue to use the same programs. The entire system can be operated without additional software. It is not necessary to be familiar with the internal workings of AS-Interface.

**Replacement for the cable harness**

Process signals that occur in situ, are normally transferred to the open loop control using extensive parallel wiring and input/output modules. This means that each sensor or actuator in the field is connected to the input/output modules with its own cable. AS-Interface makes it possible to replace this cable harness with a simple two-wire cable for all sensors or actuators.

**Data and power on a two-wire cable**

The master communicates with the nodes via the AS-Interface cable. As well as data, this cable also transfers the supply voltage for the electronic components and sensors. The voltage is supplied to the AS-Interface cable from a special AS-Interface power supply unit with a data link.

**Setting up different structures**

The AS-Interface cable is laid in the same way as for an electrical installation. A new feeder can be inserted at any point. This makes it possible to set up network structures (e.g. tree, star or line structures). No shielding or terminating resistors are required. The wiring can be adapted individually to the system or machine.

**Maximum system configuration**

Detailed configuration and installation guidelines can be found in the installation guideline "Montage des Vernetzungssysteme AS-Interface" (on mounting the AS-Interface networking system).

Up to 62 nodes can be connected to the AS-Interface cable. A node is, for example, an AS-Interface module (digital or analog) or a BERO (proximity switch) with an integrated AS-Interface chip. A maximum of 4 binary standard sensors and/or 4 actuators can be connected to an AS-Interface module.

This produces a maximum configuration of 248 sensors and 186 actuators (62 nodes x 4 inputs and 3 outputs).

**IP 67 degree of protection**

AS-Interface is a networking system for direct use on the machine. The AS-Interface user compact modules have IP 67 protection. They can be used in situ without being enclosed.

There are also AS-Interface modules for use with IP 20 protection in the cubicles or distributed switchboxes.



---

<b>New installation system</b>	All compact modules are placed on a mounting plate. The mounting plate takes the AS-Interface cable and keeps it in place. Polarity reversal is not possible due to the profile of the cable. The compact modules are simply hooked on at the top of the mounting plate and secured with just one screw. When you secure the modules, contact is made with the AS-Interface cable. You do not have to strip or screw on the cable.
<b>Coding prevents errors</b>	All the modules are mechanically and electrically coded. The coding system prevents errors occurring in the event of replacement. At replacement, only one module of the same type can ever be mounted. This stops digital or analog modules (or even inputs or outputs) getting mixed up.
<b>Addressing</b>	To participate in data transfer with the master, each node must be assigned an address before commissioning of the AS-Interface network. Addressing devices are available for this.
<b>Addressing an installed module</b>	<p>There is an additional feature which makes new Siemens modules even more user-friendly: the addressing socket.</p> <p>Using this socket you can address a module after it has been installed. It is not necessary to unscrew the module. Installation can be carried out in the system by personnel who are not familiar with the AS-Interface. The commissioning engineer can address the modules easily when they are already installed. For the first time, this type of addressing is also possible with IP 67 protection.</p>
<b>Diagnostics at a glance</b>	<p>The new generation of AS-Interface modules (compact modules, analog modules, and SlimLine modules) has the new display system developed by Siemens.</p> <p>The status of a module is displayed by two LEDs lighting up continuously or flashing.</p> <p>This simple diagnostic feature directly on the module makes it possible for the user to find the error quickly and efficiently. This in turn reduces down-times.</p>
<b>Certificates of the AS-Interface association</b>	All Siemens AS-Interface products are tested in acc. with the relevant testing regulations in an accredited test laboratory and certified by the AS-Interface association.

**Digital compact modules with IP 67 protection**

The AS-Interface modules in the compact range are characterized by optimized operating features and improved user-friendliness. This can reduce mounting and commissioning times for AS-Interface by up to 40%. Additional LEDs provide information on the most important operating modes of the module, resulting in a considerable increase in system availability.

The modules of the compact range consist of two components: Mounting plate and compact module

The mounting plate mechanically fixes the AS-Interface profile cables, takes the compact module, and serves as a template with drill holes.

The compact module contains the electronic components for communication and the M12 standard connections for inputs/outputs. Up to four sensors and four actuators can be easily and reliably connected to the compact module using the M12 standard connection.

The mounting plate and compact module are only connected to each other by means of a single screw. Contact is established with the AS-Interface cable by means of the proven insulation displacement method.

AS-Interface modules in the compact range that have an M12 connection can have a protective conductor (PE) connected to them.

Using an addressing socket integrated in the compact module, you can also allocate addresses when the module is in place.

**Analog compact modules with IP 67 protection**

The design of the analog modules has been adapted for the compact modules. The analog input and output modules each have two channels. You can connect measuring sensors and analog actuators using standard M12 connectors. The following groups of analog modules exist:

- Input module for two current sensors
- Input module for two voltage sensors
- Input module for two thermal resistors
- Output module for two current actuators
- Output module for two voltage actuators

All the measured values - except for the thermal resistance value of Pt 100 (not linear) - are available in linear form. In other words, the non-linear transmission curve of the thermal resistor sensor is automatically linearized in the analog module, and measured values can be processed directly in the programmable controller.

The input and output channels are isolated. Two-wire and four-wire sensors can be connected. Differential inputs produce considerable suppression of common-mode interference. The integrating sigma-delta converter ensures high measurement accuracy.

**Pneumatic compact modules with IP 65 and IP 67 protection**

The pneumatic compact module is a highly integrated AS-Interface slave. As an input/output module that is entirely suitable for field deployment, it has four electrical inputs and two pneumatic outputs. The electrical inputs behave in the same way as the inputs of the digital input/output compact modules.

Both integrated pneumatic outputs are implemented by means of two pre-set 4/2-way valves (2 to 8 bar; 550 NI/min) with a shared compressed-air supply and separate exhaust air collection and can be operated manually using separate slide valves. Two cylinders that work in tandem, for example, can be connected to a module in this range.

Connections to AS-Interface are made via the standard mounting plate. The AS-Interface cable is inserted into the corresponding cable guides, and the upper part is secured to the mounting plate by means of a screw. The module is ready for use.

**Safety first - emergency stop via AS-i**

AS-Interface is the first system on the market that can transmit both standard signals and safety-related input signals (e.g. emergency stop) via the same cable.

Only an additional safety monitor and safe modules are required to use AS-Interface as a safety bus. This enables category 4 in acc. with EN 954-1 to be achieved. A failsafe programmable controller or special master is not necessary.

The concept and implementation of AS-Interface Safety at Work (AS-Interface SaW) have been tested and certified by TÜV (technical testing association).

This means that the system can be converted to the considerably more flexible AS-Interface network, which is already available, thus obviating the need for the complex, separately implemented emergency stop wiring that has been necessary up to now.

# 3RV1 circuit breakers

Section	Subject	Page
<b>2.1</b>	<b>Specifications/regulations/approvals</b>	<b>2-3</b>
<b>2.2</b>	<b>Device description</b>	<b>2-5</b>
2.2.1	General description	2-6
2.2.2	Operation	2-7
2.2.3	Information on configuration	2-10
<b>2.3</b>	<b>Field of application/variants</b>	<b>2-13</b>
2.3.1	Motor protection	2-13
2.3.2	Transformer protection	2-13
2.3.3	Starter protection	2-13
2.3.4	Circuit breaker with overload relay function	2-14
2.3.5	Fuse monitoring	2-14
2.3.6	Switching direct current	2-16
2.3.7	Main and emergency stop switches	2-17
<b>2.4</b>	<b>Accessories</b>	<b>2-18</b>
2.4.1	Attachable accessories: Overview	2-18
2.4.2	Auxiliary switch, alarm switch, and auxiliary release	2-19
2.4.3	Motorized remote-control mechanism	2-23
2.4.4	Disconnecting module	2-26
2.4.5	Rotary switch extension for door	2-28
2.4.6	Terminals for "Combination Motor Controller Type E" in acc. with UL 508	2-31
2.4.7	Housing and mounting accessories	2-32
2.4.8	Busbar adapter	2-37
2.4.9	Isolated 3-phase busbar system	2-41

<b>Section</b>	<b>Subject</b>	<b>Page</b>
<b>2.5</b>	<b>Mounting and connection</b>	<b>2-45</b>
2.5.1	Mounting	2-45
2.5.2	Connection	2-46
2.5.3	Device circuit diagrams	2-48
<b>2.6</b>	<b>Dimensioned drawings</b>	<b>2-49</b>
<b>2.7</b>	<b>Technical specifications</b>	<b>2-58</b>
2.7.1	General specifications	2-58
2.7.2	Rated short-circuit breaking capacity I <sub>cn</sub> in acc. with IEC 60 947-2	2-63
2.7.3	Limiter function with standard devices for 500 VAC and 690 VAC in acc. with IEC 60 947-2	2-65

## 2.1 Specifications/regulations/approvals

<b>Standards</b>	<ul style="list-style-type: none"> <li>• The 3RV1 circuit breakers comply with the specifications for circuit breakers in acc. with IEC 60947-2/DIN VDE 0660, Part 101.</li> <li>• The circuit breakers for motor protection comply with the specifications in acc. with IEC 60947-4-1/DIN VDE 0660, Part 102.</li> <li>• The auxiliary switches comply with IEC 60947-5-1/DIN VDE 0660 Part 200.</li> </ul>
<b>Approvals/ test reports</b>	Confirmation of approvals, test certificates, and characteristics can be obtained on the Internet/intranet.
<b>Terminal markings</b>	The terminal markings comply with DIN EN 50 011.
<b>Utilization categories</b>	Circuit breaker in acc. with IEC 60947-2: A Motor starter in acc. with IEC 60947-4-1: AC-3 (main conducting paths) DC - 11 / AC - 15 (control and auxiliary conducting paths)
<b>Main and emergency stop switches</b>	The specifications for the main and emergency switches comply with IEC 60204/DIN VDE 0113 Part 1.
<b>Disconnecter specifications</b>	Disconnecter specifications comply with IEC 60947-3.
<b>Shock protection</b>	3RV1 circuit breakers are shockproof in acc. with DIN VDE 0106 Part 100, even without accessories. You can find additional information on the subject of shock protection in the "Switching, Protection and Distribution in Low-Voltage Networks" manual, p. 37 ff.
<b>Degree of protection</b>	The degree of protection of the 3RV1 circuit breaker is IP 20. In the terminal area of frame sizes S2 and S3 the degree of protection is IP 00.
<b>Characteristics</b>	The time-current characteristics, the current limitation characteristics and the $I^2t$ characteristics have been determined in acc. with IEC 60947 and DIN VDE 0660.

**Conditions of application**

**Explosion-proof motors**

KEMA test report no. EX-97.Y.3236 in acc. with EN 50 019:1977 +A1 to A5 and DIN VDE 0165

DMT certificate in acc. with directive 94/9 EC (ATEX) in preparation

**Nuclear power plants**

KTA certificate

**Railway vehicles**

DIN EN 50 155

**Ships and docks**

Shipbuilding certificates of classes GL, LRS or DNV.

## 2.2 Device description

3RV1 circuit breakers are used to switch and protect three-phase induction motors of up to 45 kW at 400 VAC and for loads with rated currents of up to 100 A.

The 3RV1 circuit breakers have 3 poles. To achieve the highest degree of flexibility, auxiliary switches, alarm switches, auxiliary releases, and other accessories can be easily attached to the circuit breakers without tools, as required.

3RV1 circuit breakers and 3RT1 contactors are built to work together on both an electrical level and physically. This enables them to be easily and quickly put together to make load feeders.

### Frame sizes

3RV1 circuit breakers are available in 4 frame sizes (S00 to S3).




Figure 2-1: 3RV1 circuit breakers (frame sizes S00 to S3)

The following table shows you the frame sizes and the corresponding maximum rated operational current at a voltage of 400 VAC. The last column in the table tells you which three-phase induction motor is suitable for which particular size.

Frame size	Width	Max. rated operational current	Output power of the three-phase induction motor
<b>S00</b>	45 mm	12 A	5.5 kW
<b>S0</b>	45 mm	25 A	11 kW
<b>S2</b>	55 mm	50 A	22 kW
<b>S3</b>	70 mm	100 A	45 kW

Table 2-1: Circuit breakers, frame sizes



## 2.2.1 General description

### Fields of application

The 3RV1 circuit breakers are suitable for:

- Motor and plant protection
- Transformer protection
- Starter protection (short-circuit protection)

The 3RV16 11-0BD10 circuit breaker, frame size S00, is used for fuse monitoring.

### Releases

3RV1 circuit breakers have:

- Inverse-time delay, thermal overload releases
- Instantaneous short-circuit releases

The overload releases can be set to the load current.

The short-circuit releases are set permanently to 12 times the rated current, which allows motors to start up without problems. Circuit breakers used for transformer protection are set to 19 times the rated current to avoid being tripped by the high inrush current.

When the circuit breakers are tripped, in the case of frame size S00 the toggle switch goes into the tripped position, and in the case of frame sizes S0 to S3 the rotary switch switches to the tripped position. Before it is switched on again, the rotary switch must be put in the 0 position manually to avoid switching to the fault inadvertently.

In the case of circuit breakers with a rotary switch, the tripping operation can also be reported electrically by means of an alarm switch.

### Tripping classes

In acc. with IEC 947-4-1:

- Frame sizes S00 to S3: class 10
- Frame sizes S2/S3: class 20

### Auxiliary release

The circuit breakers can also be equipped with one of the following auxiliary releases:

- Shunt release
- Undervoltage release
- Undervoltage release with leading auxiliary contacts

### Auxiliary contact elements

The circuit breakers can be equipped with a transverse auxiliary switch, an electronically optimized transverse auxiliary switch or a lateral auxiliary switch (Section 2.4 Accessories).

### Shock protection

Shock protection can be improved by covering the terminals and connections. This can be achieved with the following accessories:

- Frame size S00, S0: protective caps for transverse auxiliary switches
- Frame size S2, S3: terminal covers for box terminals
- Terminal covers for lug and bar connection

**Other accessories**

Other accessories for circuit breakers:

- Alarm switch
- Disconnecting module
- Isolated 3-phase busbar system
- Busbar adapter
- Rotary switches
- Terminals for "Combination Motor Controller Type E" in acc. with UL 508
- Housing and front plates

**2.2.2 Operation****Setting the values**

Using a screwdriver, set the load rated current (current setting)  $I_e$  on the scale of the circuit breaker.

Note the two possible markings:

- Dash marking: marking for a circuit breaker in a stand-alone installation
- Triangle marking: marking for a circuit breaker in a side-by-side installation




Figure 2-2: Setting the current setting  $I_e$  (example: frame size S00)

**Warning**

The adjusting knob can be turned 360° clockwise. You can only turn it counterclockwise within the adjustment range.

**Sealing the  
adjustment scale**

You can prevent unauthorized adjustment of the current setting by placing a transparent cover over it and sealing it.




Figure 2-3: Sealing the adjustment scale (frame size S00)

## Switches

The state of the circuit breakers can be determined by the position of the switches:

Frame size	Switch	STOP	ON	Tripped
S00	Toggle switch	O	I	O
S0, S2, S3	Rotary switch	OFF	ON	Tripped

Table 2-2: Contact position indicators of the circuit breakers




Figure 2-4: Tripped position, 3RV (frame size S0)

## Locking the circuit breakers

You can prevent the circuit breaker from being switched on by unauthorized persons by securing the switch drive (toggle switch or rotary switch) with a padlock (shackle diameter 3.5 to 4.5 mm).




Figure 2-5: Locking the toggle switch (frame size S00)

## Reclosing after a tripping operation

After the circuit breaker has been tripped, the switch goes into the tripped position to indicate this. You use the switch to close the circuit again.

In the case of frame sizes S0 to S3, the rotary switch must be put in the OFF position manually before it is switched on again to avoid switching to the fault inadvertently.

In the case of frame sizes S2 and S3, it is possible to switch on and off using a motorized remote-control mechanism (see Section 2.4, Accessories).

**Testing overload tripping**

The following table shows you how overload tripping of the circuit breaker is tested:


Drawing	Step	Procedure
	<p><b>1</b></p>	<p>Switch the toggle switch/rotary switch from 0 to 1.</p>
	<p><b>2, 3</b></p>	<p>Put a screwdriver in the test opening and push it to the left.</p> <p>Overload tripping is in working order when the toggle switch switches from 1 to 0 (frame size S00) or goes into the tripped position (frame sizes S0 to S3).</p>

Table 2-3: Testing overload tripping (example: frame size S00)

**2.2.3 Information on configuration**

**Short-circuit protection**

The short-circuit releases of the 3RV1 circuit breakers execute a three-phase isolation of the faulty load feeder from the network and prevent any further damage.

With a short-circuit breaking capacity of 50 kA or 100 kA and a voltage of 400 VAC, the switches are considered to be short circuit-proof, since higher short-circuit currents are not to be expected where the switches are installed.

Backup fuses are only required if the short-circuit current at the point of installation exceeds the rated short-circuit breaking capacity of the circuit breakers.

You will find the short-circuit breaking capacity for other voltages and the size of any required fuse listed in Section 2.6, Technical specifications.

**Conditions of application**

3RV1 circuit breakers are climate-proof. They are intended for use in closed areas where there are no hazardous operating conditions such as dust, corrosive fumes or destructive gases.

Appropriate housings are available as an accessory for use in dusty and damp areas (see Section 2.4).

**Inrush current**

Because the operational currents, the starting currents and the current spikes vary on account of the inrush current, even in motors of the same power, the motor powers listed in the tables are only guide values. Most important when selecting the correct circuit breakers are the concrete starting data and rating of the motor to be protected. This also applies to circuit breakers used for transformer protection.

### Phase loss sensitivity

The phase loss sensitivity of the circuit breaker ensures that it is tripped in good time in the event of the loss of a phase and the resulting overcurrents in the other phases.

During normal operation, the device should have a three-pole load. To protect single-phase loads or direct current loads, all 3 main conducting paths should be switched in series.

### Explosion protection

#### Note

In the case of a three-pole load, at 5 to 8 times the set current, the release time deviates by a maximum of  $\pm 20\%$  and therefore complies with the requirement of DIN VDE 0165 and EN 50019: 1977 +A1 to A5 and DIN VDE 0165.

### Characteristics

The tripping characteristic of the inverse-time delayed overload release (thermal overload release, a-release) is valid for direct current and alternating current with frequencies of 0 to 400 Hz.

The characteristics are valid for tripping operations from a cold state. From a warm state, the release times of the thermal releases are reduced to approximately 25 %.

The tripping characteristics of the instantaneous electromagnetic overcurrent releases (short-circuit release, n-release) is based on the rated current  $I_n$ , which in circuit breakers with adjustable overload releases is also the upper value of the adjustment range.

The following is a chart of the time-current characteristic:




Figure 2-6: Time-current characteristic, chart

Time-current characteristics, current-limiting characteristics and  $I^2t$  characteristics can be requested directly from your sales representative, if necessary.

**Frequency sensitivity of the short-circuit releases**

The characteristics of the short-circuit releases apply to frequencies of 50/60 Hz. For lower frequencies, such as  $16 \frac{2}{3}$  Hz, for higher frequencies up to 400 Hz, and for direct current, appropriate correction factors have to be taken into account.

The following characteristic curve illustrates the frequency sensitivity of the short-circuit releases (calibrated to 12 times  $I_u + 20\%$ ):




Figure 2-7: Frequency sensitivity of the n-short-circuit releases

The increase in tripping current is approximately 30% for DC voltage.

**Frequency converters**

The thermal switch disconnectors do not have to be corrected when you use frequency converters.

## 2.3 Field of application/variants

The tripping characteristics of the 3RV1 circuit breakers are designed primarily to protect three-phase induction motors.

The circuit breakers are therefore also referred to as motor protecting switches.

The 3RV1 circuit breakers for motor protection are limited to the protection of systems.

### 2.3.1 Motor protection

#### Set current

The current of the motor that is to be protected is set on the adjustment scale. The short-circuit release is set at the factory to 12 times the value of the rated current of the circuit breaker. This ensures problem-free startup and reliable protection of the motor.

#### Phase loss sensitivity

The phase loss sensitivity of the circuit breaker ensures that it is tripped in good time in the event of the loss of a phase and the resulting overcurrents in the other phases.

#### CLASS10/CLASS20

Circuit breakers of frame sizes S00 to S3 with thermal overload releases comply with tripping class 10 (CLASS 10). Circuit breakers with the CLASS 20 tripping characteristic are available for frame sizes S2 and S3 in difficult startup conditions.

### 2.3.2 Transformer protection

#### Inrush current

In the case of primary protection of control transformers, the high inrush currents that occur when the transformers are switched on often result in the unwanted tripping of the protective devices.

The 3RV1 circuit breakers with frame sizes S0 and S2 therefore have overcurrent releases for the protection of transformers that are set at the factory to approximately 19 times the rated current. This makes it possible to protect transformers in which the inrush currents reach peak values of up to 30 times the rated current with circuit breakers in the primary circuit.

In the case of 4AM control transformers with low inrush current (Siemens control transformers, for example), this is not required. 3RV1 circuit breakers can be used here for motor protection.

### 2.3.3 Starter protection

The 3RV13 starter protection switches are circuit breakers without overload releases. They are used together with a contactor and overload relay if the circuit breaker is not to be triggered in the case of overload tripping.



### 2.3.4 Circuit breakers with overload relay function

Circuit breakers with the 3RV11 overload relay function are available for frame sizes S0, S2, and S3.

#### Description

Circuit breakers with the overload relay function contain overload releases that do not affect the breaker mechanism of the circuit breakers. In the event of an overload, the circuit breaker remains switched on. To protect the following loads, 2 auxiliary contacts (1S + 1Ö) are attached on the right side. These are operated in the event of an overload. The auxiliary switch function can be evaluated or used to disconnect a downstream contactor. After the circuit breaker has cooled down, the auxiliary contacts are reset automatically.



#### Caution

In the overload range, the circuit breaker does not protect itself with the overload relay function. You must therefore ensure that the circuit breaker is safely disconnected by means of a downstream switching device (e.g. a contactor).

#### Fixed link: auxiliary contacts with circuit breaker

#### Note:

The auxiliary contacts are connected to the circuit breaker on the right side and cannot be removed.

#### Diagrams




Figure 2-8: Circuit breaker with overload relay function (frame sizes S0 to S3)

### 2.3.5 Fuse monitoring

The 3RV16 11-0BD10 circuit breaker is used with frame size S00 for fuse monitoring.

A conducting path of the circuit breaker is switched in parallel for each fuse. If one fuse fails, the current flows via the parallel-switched conducting path of the circuit breaker and trips it.



### Warning

Fuse monitoring using the 3RV16 11-0DB10 circuit breaker is not permissible in feeders with power control regulators where a DC feedback with higher values can occur in the event of a fault.

### Auxiliary switch functions

The circuit breaker used for fuse monitoring can be equipped with a transverse or lateral auxiliary switch (Section 2.4, Accessories). The auxiliary switch reports the tripping of the circuit breaker and thus the failure of the fuse and initiates an all-pole disconnection of the problem circuit by a corresponding switching device.

### Safety sign

#### Note

When fuses used for isolation purposes are monitored, a warning sign must be put up next to them. Via the parallel-switched voltage circuit of the monitoring facility, voltage may get into the area that is supposed to be isolated if the monitoring equipment has not been disconnected.

We suggest the following text for the warning:

#### Attention

To ensure isolation, also disconnect the fuse-monitoring device with the item designation .....

### Voltages

The 3RV16 11-0DB10 circuit breaker is suitable for fuse monitoring in the following voltage ranges:

- 24 to 690 VAC, 50/60 Hz
- 24 to 250 VDC, 100 to 600 VDC

Switching capacity  $I_{CN}$  100 kA

### Circuit diagrams




Figure 2-9: Circuit diagrams of circuit breakers for fuse monitoring

**Parallel cables/meshed networks**

**Attention**

In the case of parallel cables and meshed networks, a tripping operation and report only occurs when the voltage difference at the circuit breaker is at least 24 V.

**2.3.6 Switching direct current**

The 3RV1 circuit breakers for alternating current are suitable for switching direct current. However, you must note the maximum permissible DC voltage per conducting path. In the case of higher voltages, series connection of 2 or 3 conducting paths is required.

**Response thresholds**

The response thresholds of the overload releases remain unchanged. The response thresholds of the short-circuit releases are increased with direct current by approximately 40%.

The following table lists suggestions for switching direct current:




Suggestion	Circuit breaker	Frame size	Max. permissible direct voltage $E_I$	Meaning
	3RV1.	S00 to S3	150 VDC	2-pole switching Ungrounded system If a ground fault can be excluded, or if every ground fault is immediately corrected (ground-fault monitoring), the maximum permissible DC voltage can be tripled.
	3RV1.	S00 to S3	300 VDC	2-pole switching Grounded system The grounded pole must always be assigned to the individual conducting path so that in the event of a ground fault there are always 2 conducting paths in series.
	3RV1.	S00 to S3	450 VDC	1-pole switching Grounded system 3 conducting paths in series. The grounded pole should be assigned to the unswitched conducting path.

Table 2-4: Suggestions for switching direct current

**Double ground fault**

**Note**

In the case of the circuit with 2-pole switching and an ungrounded system, it is assumed that even in the event of a double ground fault that bridges two contacts, safe disconnection still occurs.

### **2.3.7 Main and emergency stop switches**

Since the circuit breakers meet the requirements for disconnectors in acc. with IEC 60947-3 and the additional test requirements for circuit breakers with disconnector features in acc. with IEC 60947-2, they can be used with the appropriate accessories as main and emergency stop switches. They must also comply with DIN VDE 0113.

## 2.4 Accessories

### 2.4.1 Attachable accessories: Overview

Auxiliary switches, alarm switches, auxiliary releases and other accessories can be easily attached to the circuit breakers without tools, as required.

Accessories	Function/use	Width	Attach to
<b>Transverse auxiliary switch</b>	The contacts of the auxiliary switches close and open together with the main contacts of the circuit breaker. Variants: <ul style="list-style-type: none"> <li>• 1 changeover contact</li> <li>• 1 NO + 1 NC contact</li> <li>• 2 NO contacts</li> </ul>	Width of the circuit breaker remains the same	Front
<b>Electronically optimized transverse auxiliary switch</b>	One transverse auxiliary switch can be attached for each circuit breaker: Variants: <ul style="list-style-type: none"> <li>• 1 changeover contact</li> </ul>		
<b>Lateral auxiliary switch</b>	One lateral auxiliary switch can be attached for each circuit breaker: <ul style="list-style-type: none"> <li>• 1 NO + 1 NC contact</li> <li>• 2 NO contacts</li> <li>• 2 NC contacts</li> <li>• 2 NO + 2 NC contacts</li> </ul>	9 mm 18 mm	Left side
<b>Alarm switch</b> Frame sizes S0, S2 and S3	One alarm switch can be attached at the side of the circuit breakers with rotary switches.  The alarm switch has two contact systems: <ul style="list-style-type: none"> <li>• One contact system (1 NO + 1 NC) reports a general <b>tripping operation</b>, irrespective of whether it was caused by a short circuit, overload or auxiliary release.</li> <li>• The other contact system (1 NO + 1 NC) only switches in the event of a <b>short circuit</b> tripping operation.</li> </ul> <p>To reclose the circuit breaker after a short circuit, the alarm switch must be reset manually after the cause of the error has been eliminated.</p>	18 mm	
<b>Shunt release</b>	Remote release of the circuit breaker: <ul style="list-style-type: none"> <li>• Via PLC: The coil of the release should be connected to the voltage only briefly</li> <li>• Especially suitable for emergency stop disconnection by means of appropriate emergency stop switches in acc. with DIN VDE 0113</li> </ul>	18 mm	Right side  Accessories cannot be attached on the right of a circuit breaker with a relay function.
<b>Undervoltage release</b>	Trips the circuit breaker in the event of a voltage interruption (e.g. when the power plug is removed) and prevents the motor starting up inadvertently when the voltage returns.		
<b>Undervoltage release with leading auxiliary contacts</b> 2 NO	Function and use, see undervoltage release. Additional function: The auxiliary contacts isolate the undervoltage release from the power system on both sides in the event of breaking or a tripping operation and thus prevent voltage distortion to the control circuit when the switch is in the off position. It is possible to reclose the circuit breaker because the contacts reclose.		

Accessories	Function/use	Width	Attach to
<b>Disconnecting module</b> Frame sizes S0 and S2	The supply is fed to the circuit breaker via the disconnecting module. A connector which can only be removed when the circuit breaker is switched off isolates the circuit breaker from the power system on 3 poles. The shock-protected isolation position is easily visible and is secured by a padlock to ensure that the connector cannot be used during maintenance work, for example.	Width of the circuit breaker remains the same	Upper side
<b>Motorized remote-control mechanism</b> For frame sizes S2 and S3	The circuit breakers can be opened and closed via the remote-controlled mechanism by means of electrical commands. This enables a load or system to be disconnected from and then reconnected to the power system from an operator control panel. The circuit breaker can be disconnected from and reconnected to the remote-control mechanism in situ.		
<b>Rotary switch extension for the door</b>	The rotary switch extension for the door consists of a knob, a drive coupling and an extension shaft. They comply with IP 65. The door interlock prevents the cubicle door being opened inadvertently when the switch is in the on position. The off position can be secured with a maximum of 3 padlocks.		
<b>Emergency stop rotary switch extension</b>	Rotary switch extension with emergency stop function.		

Table 2-5: Attachable accessories

## 2.4.2 Auxiliary switch, alarm switch, and auxiliary release

The maximum configuration for each 3RV1 circuit breaker is one transverse auxiliary switch, one lateral auxiliary switch, one alarm switch, and one auxiliary release.

### Possible combinations

The following combinations of auxiliary switches and alarm switches or of auxiliary switches are possible:

- Auxiliary and alarm switches can be installed individually or together. The lateral auxiliary switch is installed on the left of the alarm switch.
- Transverse and lateral auxiliary switches can be combined.
- One auxiliary release can be attached on the right for each circuit breaker:

### Mounting the auxiliary switches

The auxiliary switches, alarm switches, and auxiliary releases are mounted in the same way for all frame sizes:

#### Transverse auxiliary switch (3RV1901-1D, -1E, -1F)




Figure 2-10: Mounting the transverse auxiliary switch (frame size S00)

**Lateral auxiliary switch (3RV1901-....)  
Undervoltage release (3RV1901-....)**




Figure 2-11: Mounting/removing the lateral auxiliary switch/undervoltage release (frame size S00)

**Voltage ranges of the  
auxiliary releases**

One undervoltage release or shunt release can be installed for each circuit breaker. The following voltage ranges are possible:

Auxiliary release	Frequency	
	AC 50 Hz	AC 60 Hz
Undervoltage release	24 V	
	110 V	120 V
		208 V
	230 V	240 V
	400 V	
	480 V	
Undervoltage release with leading auxiliary contacts	230 V	240 V
	400 V	
	415 V	480 V
Shunt release	<b>AC 50/60 Hz 100% duty cycle <sup>1)</sup></b>	<b>AC 50/60 Hz; DC 5 sec. duty cycle <sup>2)</sup></b>
	20 V - 24 V	20 V - 70 V
	90 V - 110 V	70 V - 190 V
	210 V - 240 V	190 V - 330 V
	350 V - 415 V	330 V - 500 V
	500 V	-

Table 2-6: Voltage ranges of the auxiliary releases

- 1) Transformer operational voltage of the lower mark of the voltage range at 0.85 (Tu = 60 °C) is valid for 100% (continuous) duty cycle only at AC 50/60 Hz
- 2) Transformer operational voltage of the lower mark of the voltage range at 0.9 (Tu = 60 °C) is valid for 5 seconds duty cycle at AC 50/60 Hz and DC

## Mounting the alarm switch

The following table explains how the 3RV19.2-.... alarm switch is mounted onto the circuit breaker:


Drawing	Step	Procedure
 <p>3RV 19.2-....</p>	1	Press and hold down the transport safety button on the inside of the alarm switch.
	2	Then press the blue RESET button on the front of the alarm switch.
	3	Hook the alarm switch onto the circuit breaker.
	4	Move the alarm switch towards the circuit breaker until you hear it click into place.

Table 2-7: Testing overload tripping (example: frame size S0)



**Alarm switch signals**

The alarm switch has two signals:

- Tripped
- Short circuit

The following table lists the signals, the status of the alarm switch, and the procedure required:

Drawing	Status	Procedure
	<p><b>Tripped signal</b>                      Tripped position                      LED: Red                      RESET button (blue):                      remains depressed</p>	<p>Switch off (0 position)                      Switch on again (I position)</p>
	<p><b>Short circuit</b>                      Tripped position                      LED: red                      RESET button (blue):                      not depressed</p>	<p>Switch off (0 position)                      Switch on again (I position)                      RESET button (blue): press</p>

Table 2-8: Alarm switch with tripped signal and short circuit signal



### 2.4.3 Motorized remote-control mechanism



The motorized remote-control mechanism is available for 230 VAC, 50 Hz and 24 VDC

- Frame size S2:  $I_{nmax} = 50 \text{ A}$
- Frame size S3:  $I_{nmax} = 100 \text{ A}$

#### Mounting and connection

The following table shows you how to mount and connect the motorized remote-control mechanism:

Drawing	Step	Procedure
	<b>1</b>	Remove the Allen key from the cover of the circuit breaker.
	<b>2</b>	Use the Allen key to change the selector switch to "Manual".
	<b>3, 4</b>	Undo the 2 screws and remove the cover.
	<b>5, 6</b>	Undo the 4 screws on the remote-controlled mechanism, and remove it. (Pozidriv 2).

Drawing	Step	Procedure
	<p><b>7</b></p>	<p>Screw the frame onto the mounting surface using 4 screws (M5).</p>
	<p><b>8, 9</b></p>	<p>Attach the circuit breaker using 2 screws. Attention: Use screws 14 mm in length.</p>
	<p><b>10</b></p>	<p>Attach the ground wire.</p>
	<p><b>11</b></p>	<p>Connect the main and control wires to the circuit breaker.</p>
	<p><b>12</b></p>	<p>If desired, set MANUAL RESET: Remove the screw from the RESET lever.</p>
	<p><b>13-15</b></p>	<p>Put the remote-control mechanism module into place, making sure that the driver covers the knob on the circuit breaker, and screw it on.</p>

Drawing	Step	Procedure
	16-18	Screw the control wires for the remote-control mechanism onto the connector, and insert it.
	19	Set the current.
	20, 21	Put the cover on, and screw it tightly.
	22	Use the Allen key to switch to AUTOMATIC and replace the Allen key in the cover.

Table 2-9: Mounting the remote-control mechanism (frame size S2)

**Warning**

Do **not** set the "Automatic" position or operate the remote-control mechanism when open! There is a risk of injury!

If used as an emergency stop, it is not permissible to switch on manually.

**Manual RESET**

Remove the screw from the RESET lever (step **12**)

### 2.4.4 Disconnecting module

The disconnecting module is suitable for creating a visible isolating distance. The isolating connector can only be removed in a deenergized state. The isolating distance can be secured with padlocks when open. Disconnecting modules are available for the circuit breakers of frame sizes S0 and S2.

#### Mounting sequence for the disconnecting module and lateral auxiliary switch

#### Attention

The disconnecting module covers the terminal screws of the transverse auxiliary switch. We therefore recommend that you use the lateral auxiliary switches or that you only install the disconnecting module once the transverse auxiliary switch has been wired.

#### Locking

Disconnecting modules can be mounted on the circuit breakers of every frame size. The modules are mounted in the same way for frame sizes S0 and S2. The following diagrams show you how to mount the disconnecting module for frame size S0 (3RV1928-1A):




Figure 2-12: Mounting the disconnecting module (frame size S0)

### Disconnecting and locking

The disconnecting module can be locked and sealed or secured with two padlocks if the connector is removed during maintenance work, for example. The circuit breaker itself can also be secured with a third padlock.




Figure 2-13: Locking the disconnecting module (frame size S0)

### Terminal cover (frame size S2)

A terminal cover (3RT1936-4EA2) is available for the disconnecting module in frame size S2 (3RV1938-1A) that protects the contacts from dirt and provides additional shock protection.




Figure 2-14: Locking the disconnecting module and mounting the cover (frame size S2)

### 2.4.5 Rotary switch extension for door

Rotary switch extensions for doors are available for frame sizes S0, S2, and S3. They consist of a lockable rotary switch with a detachable door coupling, a 150 mm long extension shaft, and a connector for the switch drive. The door handle complies with IP 65.

#### Installation




Figure 2-15: Mounting the rotary switch extension for the door (frame size S2)

## Opening the door

The following table shows you how the cubicle door can be opened using the rotary switch extension for the door:



Drawing	Procedure
	<p>To open the cubicle door, set the circuit breaker to O (OFF). This releases the extension shaft from the rotary switch and allows the door to be opened.</p>
	<p>If you want to open the cubicle door during operation, you can override the procedure by pressing the button at the side of the rotary knob (step <b>1</b>). To close it during operation, press the button again so that the extension shaft snaps into place again.</p>

Table 2-10: Opening a cubicle door using the rotary switch extension

## Opening the door with great force

### Note:

If the circuit breaker is in the ON position and the door is opened with a force  $>150$  N to 200 N, the cap of the extension shaft is separated from the rotary switch of the circuit breaker to prevent the circuit breaker being destroyed.

The circuit breaker remains in the ON position.




Figure 2-16: Operating the rotary switch extension for the door



The extension shaft must then be remounted on the circuit breaker and the rotary switch extension for the door as follows:


Drawing	Procedure
	<ol style="list-style-type: none"> <li><b>1</b> Switch the circuit breaker off, and turn the rotary switch on the door to OFF.</li> <li><b>2</b> Put the cap of the extension shaft on the rotary switch of the circuit breaker, and put the extension shaft in the cap.</li> <li><b>3</b> Close the cubicle door.</li> </ol>

Table 2-11: Mounting the extension shaft

**Security**

When the rotary switch is in the OFF position, it can be secured with up to 3 padlocks (e.g. during maintenance work on the system).




Figure 2-17: Locking the rotary switch extension for the door

## 2.4.6 Terminals for "Combination Motor Controller Type E" in acc. with UL 508

Since July 16, 2001, 1 inch air clearance and 2 inch creepage distance is required for "Combination Motor Controller Type E" on the input side in acc. with UL 508. Use terminal blocks 3RV1928-1H and 3RT1946-4GA07 for the 3RV10 circuit breakers in frame sizes S0 and S3. The 3RV10 circuit breaker in frame size S2 complies with the required air clearance and creepage distance without a terminal block. Terminal blocks are not required for use in acc. with CSA. These terminal blocks cannot be used in the S0 frame size at the same time as the 3RV19.5 3-phase busbars or in the S3 frame size at the same time as a transverse auxiliary switch.




Figure 2-18: Terminals for "Combination Motor Controller Type E"

### 2.4.7 Housings and mounting accessories

Molded-plastic housings (IP 55) are available if you want to install circuit breakers as single units. All the housings are equipped with neutral and ground terminals. Above and below are two openings that can be knocked out for cable glands. On the back of the housing there are 2 precut openings. All the cable bushings have metric dimensions. The surface casings can be sealed. There is space in the housing on the rail for additional modular terminal blocks.

Model	Molded-plastic ...	Width	Frame size
Housing with actuator membrane for toggle switch	Surface casing	54 mm, 72 mm	S00
	Bay	72 mm	S00
Lockable housing with rotary switch	Surface casing	54 mm, 72 mm 82 mm	S0 S2
	Bay	72 mm	S0
Lockable housing with emergency stop rotary switch (red/ yellow)	Surface casing	54 mm, 72 mm 82 mm	S0 S2
	Bay	72 mm	S0

Table 2-12: Housings for circuit breakers

#### Widths

The widths of the housing depend on whether auxiliary releases are used:

- 54 mm: circuit breaker + lateral auxiliary switch
- 72, 82 mm: circuit breaker + lateral auxiliary switch + auxiliary release

#### Mounting the surface casing




Figure 2-19: Molded-plastic surface casing (frame size S00)

## Mounting the bay




Figure 2-20: Molded-plastic bay (frame size S00)

## Front plates

Molded-plastic front plates that have IP 55 protection are suitable for any housing:


Front plates and accessories	Model	Frame size
Front plates	With actuator membrane and support for switch	S00
	With lockable with rotary switch	S0, S2, S3
	With lockable emergency-stop rotary switch (red/yellow)	S0, S2, S3
Accessories	Support for front plate	S0

Table 2-13: Front plates for any housings

### Mounting the front plates

#### Frame size S00

3RV1913-4C



3RV1913-4B





Figure 2-21: Mounting the front plate (frame size S00)

#### Frame size S0

3RV1923-4. + 3RV1923-4G



3RV1923-4.




Figure 2-22: Mounting the front plate (frame size S0)

## Accessories for the housings and front plates (S00)

The following accessories are available for the housings and front plates of the circuit breakers in frame size S00:

- Replacement actuator membrane
- Locking device for 3 padlocks
- Emergency-stop button (red/yellow)
- Emergency-stop button (red/yellow) with safety lock




Figure 2-23: Accessories for the housings and front plates (frame size S00)

### Locking device

The locking device can be used on the inside of the housings or front plates. To do this, remove the frame of the actuator membrane. The locking device can be secured with up to 3 padlocks that can prevent the circuit breaker from being switched on during maintenance work, for example.

### Emergency-stop button

The emergency-stop button is attached to the actuator membrane. When hit, the circuit breaker is switched off and the button locks into position. You can release the button by turning it or using a key. The circuit breaker can then be switched on again.

### Indicator lights

Indicator lights are available for the housings and front plates of circuit breakers in frame sizes S00, S0, and S2. They contain a glow lamp and red, green, yellow, orange, and transparent lenses. Indicator lights are available for the following voltage ranges: 110-120 V, 220-240 V, 380-415 V and 480-500 V.

## Installation

There is a precut opening on the front of the housing that can be knocked out to install an indicator light:




Figure 2-24: Indicator light installation in a molded-plastic housing

## 2.4.8 Busbar adapter

To enable the circuit breakers to be mounted without using up too much space, and to ensure that the infeed is economical in terms of both time and money, the switches are mounted directly onto busbar systems using busbar adapters.

The circuit breakers are snapped onto the adapter and connected at the input side. This prepared unit is mounted directly onto the busbar systems, thus both attaching it mechanically and establishing electrical contact.

### Busbar systems

The adapters are suitable for the following systems:

Busbar systems with center-to-center spacing	For copper busbars in acc. with DIN 46 433	
	Width	Depth
40 mm systems	12 mm and 15 mm	5 mm and 10 mm
60 mm systems	12 mm to 30 mm	5 mm and 10 mm

Table 2-14: Busbar systems

### Accessories

The following accessories are available for busbar adapters:

- Modules that can be mounted on either side to widen the adapters
- Busbar holder for 3 rails
- Molded-plastic covers for 3 terminals (40 mm system)
- Molded-plastic cover profiles for shock protection

### Measurements

The following table lists the dimensions of the busbar adapters and accessories.

System	Busbar adapter and accessories	Length	Width	For circuit breakers in frame size
40 mm	Circuit breaker + lateral auxiliary switch	121 mm	45 mm 55 mm	S00, S0
	Circuit breaker	139 mm	55 mm	S2
	Circuit breaker	182 mm	70 mm 72 mm	S3 (up to 400 V) S3 (up to 690 V)
	Side module	139 mm 182 mm	13.5 mm 13.5 mm	S2 S3
60 mm	Circuit breaker	182 mm	45 mm	S00, S0
		182 mm	55 mm	S2
		182 mm	70 mm 72 mm	S3 (up to 400 V) S3 (up to 690 V)
	Side module	182 mm	13.5 mm	S00 to S3

Table 2-15: Dimensions of the busbar adapters and accessories



**Link module for circuit breaker and contactor**

Link modules are needed to make electrical and mechanical connections between the circuit breaker and contactor to form a load feeder. Link modules are available for the following combinations:

Actuating voltage of contactor	Frame size of contactor	For circuit breakers of frame size
AC and DC	S00	S00
	S00	S0
	S0	S0
	S2	S2
	S3	S3

Table 2-16: Link modules for connecting circuit breakers to contactors

You can find additional information about load feeders on busbar systems in Chapter 5, "Fuseless load feeders".

**Mounting circuit breakers on busbars**

The following illustrations show you how to mount circuit breakers in frame sizes S00 and S0 onto busbar adapters (8US1..1-5D) and how to remove them again, using frame size S00 as an example:




Figure 2-25: Mounting circuit breakers on busbar adapters (frame sizes S00 and S0)

**Mounting circuit breakers on a busbar system**

The following illustrations show you how to mount circuit breakers in frame sizes S2 and S3 onto a busbar adapter:




Figure 2-26: Mounting circuit breakers on busbar adapters (frame sizes S2 and S3)

**Mounting accessories**

The following illustration shows you how to mount accessories for busbar adapters for frame sizes S00 to S2:

- Side module
- Device holder
- Extension piece
- Outgoing terminal rail (for frame sizes S00 and S0 only)




Figure 2-27: Accessories for busbar adapters (frame sizes S00 to S2)

## 2.4.9 Isolated 3-phase busbar system

3-phase busbars are used to snap circuit breakers of frame sizes S00, S0, and S2 quickly and easily in a row onto a rail. There is only one power supply, via a feed-in terminal.

The 3-phase busbar systems are safe from fingers and are shock protected. They are rated for the short-circuit stress that can occur on the output side of the connected circuit breakers.




Figure 2-28: 3-phase busbar system

### Rated operational voltage/current

Rated operational voltage	690 V
Rated current	Frame sizes S00, S0: 63 A
	Frame size S2: 108 A

Table 2-17: Rated operational voltage/current

### Models

The 3-phase busbars take 2 to 5 circuit breakers, depending on the model. There are busbars with more generous spacing for circuit breakers with accessories attached on the side.

Frame size of the circuit breaker	Spacing	Models
S00, S0	45 mm	For 2, 3, 4, or 5 circuit breakers
	55 mm	For 2, 3, 4, or 5 circuit breakers + accessories
	63 mm	For 2 or 4 circuit breakers + accessories
S2	55 mm	For 2, 3, or 4 circuit breakers
	75 mm	For 2, 3, or 4 circuit breakers + accessories

Table 2-18: Types of 3-phase busbars

**Combination of frame sizes S00 and S0**

Circuit breakers in frame sizes S00 and S0 vary in height and depth and therefore **cannot** be combined on one busbar. You can combine two busbars for circuit breakers in frame sizes S0 and S00 using an extension piece.

**Extending the bus**

It is possible to extend the busbars by clamping the connecting lugs of a further bus (turned 180°) under the terminals of the last circuit breaker (see the section on mounting).

**Attention**

Note the current-carrying capacity of the busbars when you extend them.

**Accessories**

The following accessories are available for the isolated 3-phase busbar system:

- Feed-in terminal from above (3RV1915-5A for S00, 3RV1925-5AB for S0, 3RV1935-5A for S2)
- Feed-in terminal from below (3RV1915-5B for S00, S0)
- Connector  
A connector links two 3-phase busbars over a space of 45 mm for circuit breakers in frame sizes S00 and S0.
- Protective cap for connecting lugs (3RV19 15-6AB)  
Protective caps provide shock protection for spare slots. To extend the bus, remove the protective caps.
- Spacer

**Feed-in terminal**

3-phase feed-in terminals make it possible to have greater conductor cross-sections than on the circuit breaker itself.

Tightening torque: 2 to 4 Nm (17.6 to 35.2 LB.IN).

Frame size of the circuit breaker	Connection	Conductors	Conductor cross-section
S00, S0	From above	Single- or multi-core Finely stranded with wire end ferrule AWG	2.5 to 25 mm <sup>2</sup> 2.5 to 25 mm <sup>2</sup> 12 to 4
S00, S0	From below	Single- or multi-core Finely stranded with wire end ferrule AWG	6 to 25 mm <sup>2</sup> 4 to 16 mm <sup>2</sup> 10 to 4
S2	From above	Single- or multi-core Finely stranded with wire end ferrule AWG	2.5 to 50 mm <sup>2</sup> 1.5 to 35 mm <sup>2</sup> 14 to 0

Table 2-19: Conductor cross-section of the 3-phase feed-in terminals


**Feed-in terminal - connection from below**

**Attention**


The feed-in terminal with connection from below is clamped on **instead** of a circuit breaker. Make sure you check how much space you require when you order the 3-phase busbars.

**Mounting the 3-phase busbars**

**S00**



**S00:  
Cage Clamp**



**S0**




Figure 2-29: Mounting the isolated 3-phase busbar system (frame sizes S00 to S0)




Figure 2-30: Mounting the isolated 3-phase busbar system (frame size S2)

## 2.5 Mounting and connection

### 2.5.1 Mounting

#### Mounting position

You can install the 3RV1 circuit breakers anywhere.

#### Snap-on mounting

The circuit breakers are mounted by snapping them onto 35 mm rails that comply with DIN EN 50 022. The circuit breakers with a frame size of S3 require a rail with an installation height of 15 mm. Alternatively, they can also be snapped onto 75 mm rails.




Figure 2-31: Mounting the circuit breakers onto the rail

#### Screw-on mounting

The circuit breakers are attached to a flat surface with 2 screws. For circuit breakers in frame sizes S00 and S0, two push-in lugs (3RB1900-0B) (pack of 10) are also required.

Circuit breakers in frame sizes S2 and S3 can be screwed directly onto a base plate.




Figure 2-32: Screw-on mounting of the 3RV1 (example: frame size S00)



## 2.5.2 Connection

### Tools

You require the following to connect the circuit breakers:

- Frame sizes S00 to S2: Pozidriv 2 screwdriver
- Frame size S3: Allen key (4 mm)

### Conductor cross-sections

The typical SIRIUS conductor cross-sections apply (see Section 1.5.2 "Conductor cross-sections").

### Screw-type terminals

3RV1 circuit breakers with frame sizes S00 and S0 have terminals with captive screws and terminal washers that enable you to connect 2 conductors, even if they have different cross-sections.

The box terminals of the circuit breakers of frame sizes S2 and S3 can also take 2 conductors with different cross-sections. With the exception of circuit breakers of frame size S3, which have terminal screws with a 4 mm Allen screw, all the terminal screws can be tightened using a standard screwdriver or a Pozidriv screwdriver (size 2).

You can remove the box terminals from circuit breakers with a frame size of S3 to connect conductors with lugs or connecting bars. A terminal cover is available as shock protection and to ensure that you comply with the required creepages and clearances when the box terminals are removed.

### Soldering pin connector

Circuit breakers in frame size S00 can be soldered onto printed circuit boards by means of a soldering pin connector. A soldering pin connector is available for the main contacts and the transverse auxiliary switch.

**Mounting the soldering pin adapters**

The soldering pin adapters are clamped above and below in the screw-type terminals of the circuit breakers. Alternatively, the power supply can be taken to the printed circuit boards via cables.




Figure 2-33: Circuit breaker, soldering pin connector (frame size S00)

### 2.5.3 Device circuit diagrams

#### Frame size S00




Figure 2-34: Device circuit diagram (frame size S00)

#### Frame sizes S0 to S3




Figure 2-35: Device circuit diagrams (frame sizes S0 to S3)

#### Circuit breaker with overload relay function Frame sizes S0 to S3




Figure 2-36: Circuit breaker with relay function, device circuit diagrams (frame sizes S0 to S3)

## 2.6 Dimensioned drawings (measurements in mm)

### 3RV1 circuit breakers




Figure 2-37: 3RV10 11, 3RV16 (frame size S00)

3RV10 21 (frame size S0)




Figure 2-38: 3RV10 31 (frame size S2)




Figure 2-39: 3RV10 4 (frame size S3)

- |  |   |
|--|---|
| 1) Lateral auxiliary switch, 2-pole  | 7) Drilling pattern   |
| 2) Alarm switch (S0 to S3) or lateral auxiliary switch, 4-pole (S00 to S3) | 8) 35 mm rail in acc. with EN 50022   |
| 3) Auxiliary release   | 9) Mounting onto 35 mm rail, 15 mm high, in acc. with EN 50 022 or 75 mm rail in acc. with EN 50023 |
| 4) Transverse auxiliary switch   | 10) 4 mm Allen screw  |
| 5) Push-in lugs for screw mounting   | 11) Lockable in 0 position with shackle (5 mm in diameter)  |
| 6) Only with undervoltage release with leading auxiliary switch            |   |

### 3RV11 circuit breaker with overload relay function




Figure 2-40: 3RV11 21 (frame size S0)

3RV11 31 (frame size S2)




Figure 2-41: 3RV11 42 (frame size S3)

- 1) Lateral auxiliary switch, 2-pole
- 2) Alarm switch or lateral auxiliary switch, 4-pole
- 3) Block for overload relay function
- 4) Transverse auxiliary switch
- 5) Push-in lugs for screw-type mounting
- 7) Drilling pattern
- 8) 35 mm rail in acc. with EN 50 022
- 9) Mounting onto 35 mm rails, 15 mm high, in acc. with EN 50 022 or 75 mm rails in acc. with EN 50 023
- 10) 4 mm Allen screw
- 11) Lockable in 0 position with shackle (5 mm in diameter)

### Disconnecting module




Figure 2-42: 3RV19 28-1A (for frame size S0)

3RV19 38-1A (for frame size S2)

**Molded-plastic surface casing**




Figure 2-43: 3RV19 13-1. (for frame size S00)

- a) 3RV19 13-1CA00 85 mm  
3RV19 13-1DA00 105 mm
- b) With 3RV19 13-7D: 146.5 mm  
With 3RV19 13-7E: 166.5 mm  
The dimensions relate to the mounting surface
- c) With 3RV19 13-7D: 64 mm  
With 3RV19 13-7E: 84 mm
- d) The dimensions relate to the mounting surface
- 3) Knockout opening for M25
- 4) Knockout opening for rear M20 cable routing
- 5) With safety lock
- 6) Max. shackle diameter for padlock is 8 mm
- 7) Indicator light 3RV19 03-5
- 8) Locking device 3RV19 13-6B
- 9) Emergency-stop button 3RV19 13-7






Figure 2-44: 3RV19 23-1. (for frame size S0)



3RV19 33-1. (for frame size S2)


- a) 3RV19 23-1CA00 85 mm  
3RV1923-1DA00 105 mm
- 1) Knockout opening for M25
- 2) Knockout opening for rear M20 cable entry
- 3) Opening for padlock with a max. shackle diameter of 8 mm
- 4) Indicator light 3RV19 03-5.
- 1) Knockout opening for M32 (left) and M40 (right)
- 2) Knockout opening for rear M32 cable entry
- 3) Opening for padlock with a max. shackle diameter of 8 mm
- 4) Indicator light 3RV19 03-5.

### Molded-plastic bay



- 1) Indicator light 3RV19 03-5.
- 2) Knockout opening for M25
- 3) Knockout opening for M20


Figure 2-45: 3RV19 13-2DA00 (frame size S00)



- 1) Indicator light 3RV19 03-5.
- 2) Knockout opening for M25
- 3) Knockout opening for M20

3RV19 23-2DA00/-2GA00 (frame size S0)


### Molded-plastic front plate



- 1) Indicator light 3RV19 03-5.

Figure 2-46: 3RV19 13-4C (frame size S00)

### Molded-plastic front plate + support



- 1) Indicator light 3RV19 03-5.

Figure 2-47: 3RV19 23-4. (frame sizes S0, S2, S3)

**Soldering pin connector for main and auxiliary switches**




Figure 2-48: 3RV19 18-5A/-5B (frame size S00)

**Rotary switch extension for the door**




Figure 2-49: 3RV19 26-0 (frame sizes S0, S2, S3)

- 1) Lockable in 0 position with shackle (max. 8 mm in diameter)
- 2) Affixed with screw caps
- 5) Ground terminal 35 mm<sup>2</sup> and support bracket for 330 mm shaft

**Terminals for "Combination Motor Controller Type E" in acc. with UL 508**




Figure 2-50: 3RV19 28-1H (frame size S0) and 3RT19 46-4GA07 (frame size S3)



### Motorized remote-control mechanism




Figure 2-51: 3RV19. 6-3AP0 for circuit breaker

- a) 3RV19 36-3AP0, frame size S2, 211 mm
- b) 3RV19 46-3AP0, frame size S3, 236 mm

**Busbar adapter**




Figure 2-52: 8US10.1-5DJ07

8US1061-5FK08

- 4) For busbars  
Width: 12 to 15 mm  
Depth: 5 mm and 10 mm

- 1) For 40 mm busbar systems
- 2) Side module 8US1998-2KB00




Figure 2-53: 8US1251-5DM07

8US1261-5FM08 8US1923-2AA00

- 1) For 60 mm busbar systems
- 2) Side module 8US1998-2BM00

- 1) For 60 mm busbar systems
- 2) Side module 8US1998-2BM00

- 3) For busbars  
Width: 12 to 30 mm  
Depth: 5 and 10 mm

**3-phase busbar systems**




Figure 2-54: 3RV19 15-1. (frame sizes S00, S0)

- 3RV19 15-1A for 2 circuit breakers (length 83 mm)
- 3RV19 15-1B for 3 circuit breakers (length 128 mm)
- 3RV19 15-1C for 4 circuit breakers (length 173 mm)
- 3RV19 15-1D for 5 circuit breakers (length 218 mm)

- 3RV19 15-3A for 2 circuit breakers with accessories (length 93 mm)
- 3RV19 15-3B for 3 circuit breakers with accessories (length 148 mm)
- 3RV19 15-3C for 4 circuit breakers with accessories (length 203 mm)
- 3RV19 15-3D for 5 circuit breakers with accessories (length 258 mm)




Figure 2-55: 3RV19 35-1 (for circuit breakers in frame size S2)

3RV19 35-1A for 2 circuit breakers (length 111 mm)  
 3RV19 35-1B for 3 circuit breakers (length 166 mm)  
 3RV19 35-1C for 4 circuit breakers (length 221 mm)




Figure 2-56: 3RV19 35-3 (for circuit breakers in frame size S2)

3RV19 35-3A for 2 circuit breakers with accessories (length 121 mm)  
 3RV19 35-3B for 3 circuit breakers with accessories (length 196 mm)  
 3RV19 35-3C for 4 circuit breakers with accessories (length 271 mm)

### 3-phase feed-in terminals




Figure 2-57: 3RV19 15-5A  
 Connection from above (for frame size S00)

3RV19 15-5B  
 Connection from below  
 (frame size S00/S0)

3RV19 25-5AB  
 Connection from above (frame size S0)





Figure 2-58: 3RV19 35-5A  
(for frame size S2)

### Connector



3RV19 15-5D  
(frame size S0 (left) and frame size S00 (right))

## 2.7 Technical specifications

### 2.7.1 General specifications

Type		3RV1. 1	3RV1. 2	3RV1. 3	3RV1. 4	
<b>Specifications</b>						
• IEC 60 947-1, EN 60 947-1 (VDE 0660 Part 100)		Yes				
• IEC 60 947-2, EN 60 947-2 (VDE 0660 Part 101)		Yes				
• IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)		Yes				
<b>Frame size</b>						
		S00	S0	S2	S3	
<b>Pole number</b>						
		3				
<b>Max. rated current <math>I_{nmax}</math> (= max. rated operational current <math>I_e</math>)</b>						
	A	12	25	50	100	
<b>Permissible ambient temperature</b>						
Storage/transportation	°C	-50 to +80				
Operation	°C	-20 to +70 <sup>1)</sup>				
Permissible rated current with the following internal cubicle temperature:						
• +60 °C	%	100				
• +70 °C	%	87				
<u>Circuit breaker in housing</u>						
Permissible rated current with the following ambient housing temperature:						
• +35 °C	%	100				
• +60 °C	%	87				
<b>Rated operational voltage <math>U_e</math></b>						
	V	690 <sup>2)</sup>				
<b>Rated frequency</b>						
	Hz	50/60				
<b>Rated insulation voltage <math>U_i</math></b>						
	V	690				
<b>Rated impulse strength <math>U_{imp}</math></b>						
	kV	6				
<b>Utilization category</b>						
• IEC 60 947-2 (circuit breaker)		A				
• IEC 60 947-4-1 (motor starter)		AC-3				
<b>CLASS</b>						
	In acc. with IEC 60 947-4-1	10		10/20		
<b>Direct current short-circuit breaking capacity</b> (time constant $\tau = 5$ ms) (time constant $t = 5$ ms)						
• 1 conducting path 150 VDC		kA	10			
• 2 conducting paths in series 300 VDC		kA	10			
• 3 conducting paths in series 450 VDC		kA	10			
Power loss (Pv) per circuit breaker	$I_n \rightarrow$ to 1.25 A	W	5	-	-	
Depends on rated current $I_n$	$I_n \rightarrow$ 1.6 A to 6.3 A	W	6	-	-	
(Upper setting range)	$I_n \rightarrow$ 8 A to 12 A	W	7	-	-	
	$I_n \rightarrow$ to 0.63 A	W	-	5	-	
$R_{per\ conducting\ path} = P/I^2 \times 3$	$I_n \rightarrow$ 0.8 A to 6.3 A	W	-	6	-	
	$I_n \rightarrow$ 8 A to 16 A	W	-	7	-	
	$I_n \rightarrow$ 20 A to 25 A	W	-	8	-	
	$I_n \rightarrow$ to 25 A	W	-	-	12	
	$I_n \rightarrow$ 32 A	W	-	-	15	
	$I_n \rightarrow$ 40 A to 50 A	W	-	-	20	
	$I_n \rightarrow$ to 63 A	W	-	-	-	20
	$I_n \rightarrow$ 75 A and 90 A	W	-	-	-	30
	$I_n \rightarrow$ to 100 A	W	-	-	-	38

Type			3RV1. 1	3RV1. 2	3RV1. 3	3RV1. 4
<b>Shock resistance</b>	In acc. with IEC 68 Part 2-27	g/ms	25/11 (rectangular and sine pulse)			
<b>Degree of protection</b>	In acc. with IEC 60 529		IP20		IP 20 <sup>3)</sup>	
<b>Shock protection</b>	In acc. with DIN VDE 0106 Part 100		protected against touching by fingers			
<b>Temperature compensation</b>	In acc. with IEC 60 947-4-1	°C	-20 to +60			
<b>Phase loss sensitivity</b>	In acc. with IEC 60 947-4-1		Yes			
<b>Explosion protection</b>	In acc. with DIN VDE 0165 and EN 50 019		Yes for 3RV10 (KEMA test certificate no. Ex-974.32 36) <sup>4)</sup>			
<b>Isolating function</b>	In acc. with IEC 60 947-2		Yes			
<b>Main and emergency-stop switch features<sup>5)</sup></b>	In acc. with IEC 60 204-1 (VDE 0113)		Yes			
<b>Safe isolation between the main circuit and the auxiliary circuit required for PELV applications</b>	In acc. with DIN VDE 0106 Part 101					
	• to 400 V + 10%		Yes			
	• to 415 V+ 5 % (higher voltage on request)		Yes			
<b>Mechanical life</b>		Operating cycles	100,000		50,000	
<b>Electrical life</b>			100,000		25,000	
<b>Max. switching frequency per hour (motor start-ups)</b>		1/h	15			

1) Reduction in current above +60 °C  
 2) With molded-plastic housing 500 V

3) Connection room IP 00  
 4) ATEX certification in acc. with EU directive 94/9/EC in preparation

5) With corresponding accessories

## Conductor cross-sections - main circuit

Type		3RV1.	3RV1. 2	3RV1. 3	3RV1. 4
Connection type		Screw-type terminal		Screw-type terminal with box terminal	
Terminal screw		Pozidriv size 2		Pozidriv size 2	Allen screw 4 mm
Specified tightening torque	Nm	0.8 to 1.2 Nm	2 to 2.5	3 to 4.5	4 to 6
<b>Conductor cross-sections, 1 or 2 conductors</b>					
Single-core	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 16)	2 x (2.5 to 16)
	mm <sup>2</sup>	2 x (0.75 to 2.5) (max. 4)	2 x (2.5 to 6)	-	-
Finely stranded with wire end ferrule:	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 16)	2 x (2.5 to 35)
	mm <sup>2</sup>	2 x (0.75 to 2.5)	2 x (2.5 to 6) (max. 10)	1 x (0.75 to 25)	1 x (2.5 to 50)
Stranded	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 25)	2 x (10 to 50)
	mm <sup>2</sup>	2 x (0.75 to 2.5) (max. 4)	2 x (2.5 to 6) (max. 10)	1 x (0.75 to 35)	1 x (10 to 70)
AWG cables, single- or multi-core	AWG	2 x (18 to 14)	2 x (14 to 10)	2 x (18 to 3)	2 x (10 to 1/0)
	AWG	-	-	1 x (18 to 2)	1 x (10 to 2/0)
Ribbon cables (number x width x depth)	mm	-	-	2 x (6 x 9 x 0.8)	2 x (6 x 9 x 0.8)
<b>Removable box terminal <sup>1)</sup></b>					
With copper busbars	mm	-	-	-	18 x 10
With lug	mm <sup>2</sup>	-	-	-	To 2 x 70
<b>Cage Clamp connections <sup>2)3)4)</sup></b> (1 or 2 conn. can be connected)					
Single-coil	mm <sup>2</sup>	2 x (0.25 to 2.5)	-	-	-
Finely stranded with wire end ferrule	mm <sup>2</sup>	2 x (0.25 to 1.5)	-	-	-
Finely stranded without wire end ferrule	mm <sup>2</sup>	2 x (0.25 to 2.5)	-	-	-
AWG cables, single-core or stranded	AWG	2 x (24 to 14)	-	-	-

Max. outer diameter of the conductor insulation: 3.6 mm

### Permissible service position

Any  
In acc. with IEC 60 447 start command "I"  
Right or above

## Control switch

Transverse auxiliary switch at front with 1 changeover contact		Switching capacity with different voltages				
Rated operational voltage $U_e$	AC voltage	VAC	<b>24</b>	<b>230</b>	<b>400</b>	<b>690</b>
Rated operational current $I_{th}/AC-15$		A	4	3	1.5	0.5
Rated operational current $I_{th}/AC-12 \hat{=} I_{th}$		A	10	10	10	10
Rated operational voltage $U_e$	DC voltage $L/R$ 200 ms	VDC	<b>24</b>	<b>110</b>	<b>220</b>	
Rated operational current $I_{th}/DC-13$		A	1	0.22	0.1	
<b>Transverse electronically optimized auxiliary switch at front with 1 changeover contact</b>						
Rated operational voltage $U_e$	AC voltage	VAC	<b>3 to 60</b>			
Rated operational current $I_{th}/AC-14$		mA	1 to 300			
Rated operational voltage $U_e$	DC voltage $L/R$ 200 ms	VDC	<b>3 to 60</b>			
Rated operational current $I_{th}/DC-13$		mA	1 to 300			
<b>Transverse auxiliary switch at front with 1 NO + 1 NC, 2 NO contacts</b>						
Rated operational voltage $U_e$	AC voltage	VAC	<b>24</b>	<b>230</b>		
Rated operational current $I_{th}/AC-15$		A	2	0.5		
Rated operational current $I_{th}/AC-12 \hat{=} I_{th}$		A	2.5	2.5		
Rated operational voltage $U_e$	DC voltage $L/R$ 200 ms	VDC	<b>24</b>	<b>48</b>	<b>60</b>	
Rated operational current $I_{th}/DC-13$		A	1	0.3	0.15	
<b>Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC and alarm switch</b>						
Rated operational voltage $U_e$	AC voltage	VAC	<b>24</b>	<b>230</b>	<b>400</b>	<b>690</b>
Rated operational current $I_{th}/AC-15$		A	6	4	3	1
Rated operational current $I_{th}/AC-12 \hat{=} I_{th}$		A	10	10	10	10
Rated operational voltage $U_e$	DC voltage $L/R$ 200 ms	VDC	<b>24</b>	<b>110</b>	<b>220</b>	<b>440</b>
Rated operational current $I_e$		A	2	0,5	0.25	0.1



1) After the box terminals have been removed, lug or busbar connections are possible.

2) For notes on the Cage Clamp system, see pages 1-19.

3) Use an insulation stop for a conductor cross-section  $\leq 1$  mm<sup>2</sup>.

5) Associated opening tool 8WA28 03/8WA28 04


## Permissible rating of approved devices for North America,


The circuit breakers in the SIRIUS 3RV1 series are approved for / and can also be used in acc. with UL 508 and C22.2 No.14 with a contactor as a load feeder. You can use these circuit breakers as a "Manual Motor Starter" for "Group Fusing" or for "Group Installation" or as a "Combination Motor Controller **Type E**".

### 3RV1 circuit breaker as a "Manual Motor Starter"

When the circuit breaker is used as a "Manual Motor Starter", it is always with a device for short-circuit protection (upstream short-circuit protection device). Any fusible link ("group fusing") or circuit breaker ("group installation") can be used as a device for short-circuit protection. The type and size are selected in acc. with the American NFPA 70 standard, Article 430-53 (c) for adequate protection of supply lines.

Accreditation was issued under the following file numbers with the listed data:

 File No. E14705, Product Class NLRV

 File No. LR12730, Product Class 3211 05

Circuit breaker	V	Hp rating		Rated current $I_n$ A	To 240 VAC $I_{cu}^{1)}$ kA	To AC 480 Y/277 V $I_{cu}^{1)}$ kA	To AC 600 Y/347 V $I_{cu}^{1)}$ kA
		For FLA max. 1-phase	3-phase				
				0.11 to 2	50	50	10
<b>3RV10 11</b>				2.5	50	50	10
<b>3RV16 11-0BD10</b>	115	½	-	3.2	50	50	10
	200	1½	3	4	50	50	10
Frame size S00	230	2	3	5	50	50	10
	460	-	7½	6.3	50	50	10
FLA max. 12 A, 600 V	575/600	-	10	8	50	50	10
NEMA Size 00				10	50	50	10
				12	50	50	10
				0.11 to 3.2	50	50	30
<b>3RV10 21/3RV11 21</b>				4	50	50	30
<b>3RV13 21</b>				5	50	50	30
	115	2	-	6.3	50	50	30
Frame size S0	200	3	7½	8	50	50	30
	230	5	7½	10	50	50	30
FLA max. 25 A, 600 V	460	-	15	12.5	50	50	30
NEMA Size 1	575/600	-	20	16	50	50	30
				20	50	50	30
				22	50	50	30
				25	50	50	30
				11 to 16	50	50	25
<b>3RV10 31/3RV11 31</b>				20	50	50	25
<b>3RV13 31</b>				25	50	50	25
	115	3	-	25	50	50	25
Frame size S2	200	7½	15	32	50	50	25
	230	10	20	40	50	50	25
FLA max. 50 A, 600 V	460	-	40	45	50	50	25
NEMA Size 2	575/600	-	50	50	50	50	25
				11 to 16	50	50	30
<b>3RV10 41/3RV10 42</b>				20	50	50	30
<b>3RV11 42</b>				25	50	50	30
<b>3RV13 41/3RV13 42</b>	115	10	-	25	50	50	30
	200	20	30	32	50	50	30
	230	20	40	40	50	50	30
Frame size S3	460	-	75	50	50	50	30
	575/600	-	100	63	50	50	30
FLA max. 99 A, 600 V				75	50	50	30
NEMA Size 3				90	50	50	30
				100 (99)	50	50	30

Hp rating = output power in horse power (maximum motor power)

FLA = full load amps

1) Corresponds to "short circuit breaking capacity" in acc. with UL





**Permissible rating of approved devices for North America,  **

**3RV10.A circuit breaker as "Combination Motor Controller Type E"**

Since 16.07.2001, 1 inch air clearance and 2 inch creepage distance is required for a "Combination Motor Controller Type E" on the input side with UL 508. The 3RV10 circuit breaker in frame sizes S0 and S3 are therefore approved with the terminal blocks listed below in acc. with UL 508.

The 3RV10 circuit breaker in frame size S2 already complies with the required air clearance and creepage distance as a basic unit. These extended air clearances and creepage distances are not required for CSA. The terminal blocks are therefore not required for use as a "Combination Motor Controller Type E" in acc. with CSA. 3RV10 circuit breakers are certified as "Combination Motor Controller Type E" under the following file numbers with the listed data:

 File No. E156943, Product Class NKJH

 File No. LR12730, Product Class 3211 08



Circuit breaker		Hp rating		Rated current	To 240 VAC	To AC 480 Y/277 V	To AC 600 Y/347 V
Type	V	For FLA max. 1-phase	3-phase	$I_n$ A	$I_{cu}^{(1)}$ kA	$I_{cu}^{(1)}$ kA	$I_{cu}^{(1)}$ kA
				0.11 to 1.6	50	50	30
<b>3RV10 21</b>				2	50	50	30
<b>+ 3RV19 28-1H</b>	115	2	-	2.5	50	50	30
	200	3	7½	3.2	50	50	30
Frame size S0	230	3	7½	4	50	50	30
	460	-	15	5	50	50	30
FLA max. 22 A, 480 V	575/600	-	10	6.3	50	50	30
12.5 A, 600 V				8	50	50	30
NEMA Size 1				10	50	50	30
				12.5	50	50	30
				16	50	50	-
				20	50	50	-
				22	50	50	-
				0.9 to 16	50	50	25
<b>3RV10 31</b>				20	50	50	25
	115	3	-	25	50	50	25
Frame size S2	200	7½	15	32	50	50	25
	230	10	20	40	50	50	25
FLA max. 50 A, 600 V	460	-	40	45	50	50	25
NEMA Size 1	575/600	-	50	50	50	50	30
<b>3RV10 31/3RV11 31</b>				11 to 16	50	50	25
<b>3RV13 31</b>				20	50	50	25
	115	3	-	25	50	50	25
Frame size S2	200	7½	15	32	50	50	25
	230	10	20	40	50	50	25
FLA max. 50 A, 600 V	460	-	40	45	50	50	25
	575/600	-	50	50	50	50	25
NEMA Size 2							
				11 to 16	50	50	30
<b>3RV10 41</b>				20	50	50	30
<b>+ 3RT19 46-4GA07</b>	115	10	-	25	50	50	30
	200	20	30	32	50	50	30
Frame size S3	230	20	40	40	50	50	30
	460	-	75	50	50	50	30
FLA max. 100 A, 480 V	575/600	-	75	63	50	50	30
75 A, 600 V				75	50	50	30
				90	50	50	-
NEMA Size 3				100	50	50	-

Hp rating = output power in horse power (maximum motor power)

FLA = full load amps

1) Corresponds to "short circuit breaking capacity" in acc. with UL

**Rating of the control switches and alarm switches**

		Lateral auxiliary switch with 1 NO + 1 NC, 2 NO, 2 NC, 2 NO + 2 NC and alarm switch	Transverse auxiliary switch with 1 changeover contact	Transverse auxiliary switch with 1 NO + 1 NC, 2 NO
Max. rated voltage				
• In acc. with NEMA 	VAC	600		240
• In acc. with NEMA 	VAC	600		240
Continuous current	A	10	5	2.5
Switching capacity		A600 Q300	B600 R300	C300 R300

## 2.7.2 Rated short-circuit breaking capacity $I_{cn}$ in acc. with IEC 60 947-2

The table lists the rated limit short-circuit breaking capacity  $I_{cu}$  and the rated service short-circuit breaking capacity  $I_{cs}$  of 3RV1 circuit breakers with different inception voltages and related to the rated current  $I_n$  of the circuit breakers.

The incoming supply of the circuit breakers is permissible at the upper or lower terminals irrespective of the rating.

If the short-circuit current at the installation location exceeds the rated short-circuit breaking capacity of the circuit breaker specified in the table, a backup fuse is required. You can also use an upstream circuit breaker with a limiter function.

The maximum rated current of this backup fuse is specified in the tables. The rated short-circuit breaking capacity specified for the fuse then applies.

Circuit breaker/contactors combinations for short-circuit currents of up to 50 kA can be used as fuseless load feeders in acc. with Part 5.

Circuit breaker	Rated current $I_n$	To 240 VAC <sup>2)</sup>			To 400 VAC <sup>2)/415 V<sup>3)</sup></sup>			To 440 VAC <sup>2)/460 V<sup>3)</sup></sup>			To 500 VAC <sup>2)/525 V<sup>3)</sup></sup>			To 690 VAC <sup>2)</sup>		
		$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse
		(gL/gG)			(gL/gG)			(gL/gG)			(gL/gG)			(gL/gG)		
Type	A	kA	kA	A	kA	kA	A	kA	kA	A	kA	kA	A	kA	kA	A
<b>3RV10, 3RV16 11-OBD10</b> frame size S00	0.16 to 0.8	100	100	•	100	100	•	100	100	•	100	100	•	100	100	•
	1	100	100	•	100	100	•	100	100	•	100	100	•	100	100	•
	1.25	100	100	•	100	100	•	100	100	•	100	100	•	2	2	20
	1.6	100	100	•	100	100	•	100	100	•	100	100	•	2	2	20
	2	100	100	•	100	100	•	100	100	•	10	10	35	2	2	35
	2.5	100	100	•	100	100	•	100	100	•	10	10	35	2	2	35
	3.2	100	100	•	100	100	•	50	10	40 <sup>1)</sup>	3	3	40	2	2	40
	4	100	100	•	100	100	•	50	10	40 <sup>1)</sup>	3	3	40	2	2	40
	5	100	100	•	100	100	•	50	10	50 <sup>1)</sup>	3	3	50	2	2	50
	6.3	100	100	•	100	100	•	50	10	50 <sup>1)</sup>	3	3	50	2	2	50
	8	100	100	•	50	12.5	80 <sup>1)</sup>	50	10	63 <sup>1)</sup>	3	3	63	2	2	63
	10	100	100	•	50	12.5	80 <sup>1)</sup>	10	10	63	3	3	63	2	2	63
12	100	100	•	50	12.5	80 <sup>1)</sup>	10	10	80	3	3	80	2	2	80	
<b>3RV1. 2</b> Frame size S0	0.16 to 1.25	100	100	•	100	100	•	100	100	•	100	100	•	100	100	•
	1.6	100	100	•	100	100	•	100	100	•	100	100	•	100	100	•
	2	100	100	•	100	100	•	100	100	•	100	100	•	8	8	25
	2.5	100	100	•	100	100	•	100	100	•	100	100	•	8	8	25
	3.2	100	100	•	100	100	•	100	100	•	100	100	•	8	8	32
	4	100	100	•	100	100	•	100	100	•	100	100	•	6	3	32
	5	100	100	•	100	100	•	100	100	•	100	100	•	6	3	32
	6.3	100	100	•	100	100	•	100	100	•	100	100	•	6	3	50
	8	100	100	•	100	100	•	50	25	63 <sup>1)</sup>	42	21	63	6	3	50
	10	100	100	•	100	100	•	50	25	80 <sup>1)</sup>	42	21	63	6	3	50
	12.5	100	100	•	100	100	•	50	25	80 <sup>1)</sup>	42	21	80	6	3	63
	16	100	100	•	50	25	100 <sup>1)</sup>	20	10	80 <sup>1)</sup>	10	5	80	4	2	63
	20	100	100	•	50	25	125 <sup>1)</sup>	50	10	80 <sup>1)</sup>	10	5	80	4	2	63
22	100	100	•	50	25	125 <sup>1)</sup>	50	10	100 <sup>1)</sup>	10	5	80	4	2	63	
25	100	100	•	50	25	125 <sup>1)</sup>	50	10	100 <sup>1)</sup>	10	5	80	4	2	63	
<b>3RV1. 3</b> Frame size S2	16	100	100	•	50	25	100 <sup>1)</sup>	50	25	100 <sup>1)</sup>	12	6	63	5	3	63
	20	100	100	•	50	25	125 <sup>1)</sup>	50	25	100 <sup>1)</sup>	12	6	80	5	3	63
	25	100	100	•	50	25	125 <sup>1)</sup>	50	15	100 <sup>1)</sup>	12	6	80	5	3	63
	32	100	100	•	50	25	125 <sup>1)</sup>	50	15	125 <sup>1)</sup>	10	5	100	4	2	63
	40	100	100	•	50	25	160 <sup>1)</sup>	50	15	125 <sup>1)</sup>	10	5	100	4	2	63
	45	100	100	•	50	25	160 <sup>1)</sup>	50	15	125 <sup>1)</sup>	10	5	100	4	2	63
	50	100	100	•	50	25	160 <sup>1)</sup>	50	15	125 <sup>1)</sup>	10	5	100	4	2	80

## 3RV1 circuit breaker

Circuit breaker	Rated current $I_n$	To 240 VAC <sup>2)</sup>			To 400 VAC <sup>2)</sup> /415 V <sup>3)</sup>			To 440 VAC <sup>2)</sup> /460 V <sup>3)</sup>			To 500 VAC <sup>2)</sup> /525 V <sup>3)</sup>			To 690 VAC <sup>2)</sup>		
		$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse	$I_{cu}$	$I_{cs}$	Max. Fuse
Type	A	kA	kA	A	kA	kA	A	kA	kA	A	kA	kA	A	kA	kA	A
<b>3RV1.41</b>	40	100	100	•	50	25	125 <sup>1)</sup>	50	20	125 <sup>1)</sup>	12	6	100	6	3	63
Frame size S3	50	100	100	•	50	25	125 <sup>1)</sup>	50	20	125 <sup>1)</sup>	12	6	100	6	3	80
	63	100	100	•	50	25	160 <sup>1)</sup>	50	20	160 <sup>1)</sup>	12	6	100	6	3	80
	75	100	100	•	50	25	160 <sup>1)</sup>	50	20	160 <sup>1)</sup>	8	4	125	5	3	100
	90	100	100	•	50	25	160 <sup>1)</sup>	50	20	160 <sup>1)</sup>	8	4	125	5	3	125
	100	100	100	•	50	25	160 <sup>1)</sup>	50	20	160 <sup>1)</sup>	8	4	125	5	3	125
<b>3RV1.42</b>	16	100	100	•	100	50	•	100	50	•	30	15	80	12	7	63
Frame size S3	20	100	100	•	100	50	•	100	50	•	30	15	80	12	7	63
With increased switching capacity	25	100	100	•	100	50	•	100	50	•	30	15	80	12	7	63
	32	100	100	•	100	50	•	100	50	•	22	11	100	12	7	63
	40	100	100	•	100	50	•	100	50	•	18	9	160	12	6	80
	50	100	100	•	100	50	•	100	50	•	15	7.5	160	10	5	100
	63	100	100	•	100	50	•	70	50	200 <sup>1)</sup>	15	7.5	160	7.5	4	100
	75	100	100	•	100	50	•	70	50	200 <sup>1)</sup>	10	5	160	6	3	125
	90	100	100	•	100	50	•	70	50	200 <sup>1)</sup>	10	5	160	6	3	160
	100	100	100	•	100	50	•	70	50	200 <sup>1)</sup>	10	5	160	6	3	160

• No backup fuse required because it is short circuit-proof up to 100 kA.

1 A backup fuse is only required if the short-circuit current at the installation location is  $> I_{cu}$ .

2 10% overvoltage

3 5% overvoltage

### 2.7.3 Limiter function with standard devices for 500 VAC and 690 VAC in acc. with IEC 60 947-2

The table lists the rated limit short-circuit breaking capacity  $I_{cu}$  and the rated service short-circuit breaking capacity  $I_{cs}$  with an upstream standard circuit breaker that fulfills the limiter function at 500 VAC and 690 VAC.

The short-circuit breaking capacity can be significantly increased using the upstream standard circuit breaker with a limiter function. The circuit-breaker connected downstream, should be set to the rated current of the load. Be sure when you set up circuit breaker combinations to note to the distances between the grounded parts and the distances between the circuit breakers.

Make sure that the cabling between the circuit breakers is short circuit-proof. You can set up the circuit breakers side by side.

Standard circuit breaker with limiter function	Standard circuit breaker		To 500 VAC <sup>1)</sup> / 525 V <sup>2)</sup>		To 690 VAC <sup>1)</sup>	
Type	Type	Rated current $I_n$ A	$I_{cu}$ kA	$I_{cs}$ kA	$I_{cu}$ kA	$I_{cs}$ kA
<b>3RV13 21-4DC10</b>	<b>3RV10 2</b>	To 1	•	•	•	•
Rated current $I_n$	Frame size S0	1.25	•	•	•	•
Frame size S0		1.6	•	•	•	•
$I_n = 25$ A		2	•	•	50	25
		2.5	•	•	50	25
		3.2	•	•	50	25
		4	•	•	50	25
		5	•	•	50	25
		6.3	•	•	50	25
		8	100	50	20	10
		10	100	50	20	10
		12.5	100	50	20	10
		16	100	50	20	10
		20	100	50	20	10
		22	100	50	20	10
		25	100	50	20	10
<b>3RV13 31-4HC10</b>	<b>3RV10 3</b>	16	100	50	50	25
Frame size S2	Frame size S2	20	100	50	50	25
$I_n = 50$ A		25	100	50	50	25
		32	100	50	50	25
		40	100	50	50	25
		50	100	50	50	25
<b>3RV13 41-4HC10</b>	<b>3RV10 4</b>	32	100	50	50	25
Frame size S3	Frame size S3	40	100	50	50	25
$I_n = 50$ A		50	100	50	50	25
<b>3RV13 41-4MC10</b>	<b>3RV10 4</b>	50	100	50	50	25
Frame size S3	Frame size S3	63	100	50	50	25
$I_n = 100$ A		75	100	50	50	25
		90	100	50	50	25
		100	100	50	50	25

•No upstream circuit breaker required because it is short circuit-proof up to 100 kA

1)10% overvoltage

2)5% overvoltage

#### Characteristics

You can obtain the characteristics for all the setting ranges from our Technical Assistance team by e-mail: ([nst.technical-assistance@siemens.de](mailto:nst.technical-assistance@siemens.de)).

# 3RT1/3RH1 contactors

Section	Subject	Page
<b>3.1</b>	<b>Specifications/regulations/approvals</b>	<b>3-3</b>
3.1.1	Utilization categories	3-3
3.1.2	Positively driven operation	3-7
3.1.3	Safe isolation	3-7
3.1.4	Explanation of terms	3-9
<b>3.2</b>	<b>Device description</b>	<b>3-10</b>
3.2.1	Actuating systems	3-12
3.2.2	Short-circuit protection of the SIRIUS contactors	3-12
3.2.3	Operation	3-13
3.2.3.1	General information	3-13
3.2.3.2	Contact reliability	3-14
<b>3.3</b>	<b>Application and areas of use</b>	<b>3-20</b>
3.3.1	3RT10 contactors with 3 main contacts for switching motors	3-20
3.3.2	3RT1446 contactors with 3 main contacts for switching resistive loads (AC-1)	3-21
3.3.3	3RT13 and 3RT15 contactors with 4 main contacts	3-22
3.3.4	3RT16 capacitor-switching contactors for switching capacitors	3-25
3.3.5	Contactors with an extended operating range	3-26
3.3.5.1	Contactors with an extended operating range (3RH11...-0LA0/3RT10...-0LA0)	3-27
3.3.5.2	Contactors with an extended operating range (3RH1122-2K.40, 3RT1017-2K.4., 3RT102.-3K.40)	3-29
3.3.6	3RH1 auxiliary contactors	3-29
3.3.7	3RT10 contactor relays for switching motors (interface) and 3RH11 contactor relays for switching auxiliary circuits	3-30
3.3.8	Contactors combinations for reversing	3-32
3.3.9	Star-delta combinations	3-41

<b>Section</b>	<b>Subject</b>	<b>Page</b>
<b>3.4</b>	<b>Accessories</b>	<b>3-49</b>
3.4.1	Attachable auxiliary switches for the auxiliary contacts	3-52
3.4.1.1	Terminal markings (frame sizes S00 to S3)	3-57
3.4.1.2	Terminal markings of the contactors and auxiliary contactors combined with auxiliary switch blocks	3-59
3.4.1.3	Auxiliary switches that can be attached to 3RH1 auxiliary contactors	3-61
3.4.2	Time-delay auxiliary switches	3-64
3.4.2.1	Frame size S00 (3RT1916-2E, -2F, -2G)	3-64
3.4.2.2	Frame sizes S0 to S3 (3RT1926-2E, -2F, -2G)	3-66
3.4.3	Solid-state time relay blocks with semiconductor output	3-67
3.4.3.1	Frame size S00 (3RT1916-2C, -2D)	3-68
3.4.3.2	Frame sizes S0 to S3 (3RT1926-2C, -2D)	3-69
3.4.4	Additional load module (3RT1916-1GA00)	3-70
3.4.5	Coupling element for frame sizes S0 to S3 (3RH1924-1GP11)	3-71
3.4.6	Surge suppression	3-73
3.4.7	Other accessories	3-78
3.4.7.1	LED module for indicating contactor control (3RT1926-1QT00)	3-78
3.4.7.2	Auxiliary connecting lead terminal, 3 pole (for frame size S3)	3-79
3.4.7.3	EMC module (3RT19161P.)	3-79
3.4.7.4	Soldering pin connector for frame size S00	3-81
3.4.7.5	Parallel connections	3-83
3.4.7.6	Covers for frame sizes S2 and S3	3-84
<b>3.5</b>	<b>Mounting and connection</b>	<b>3-86</b>
3.5.1	Mounting	3-86
3.5.2	Connection	3-88
3.5.3	Changing the magnet coils	3-92
3.5.4	Changing the contact piece	3-97
<b>3.6</b>	<b>Dimensioned drawings</b>	<b>3-99</b>
<b>3.7</b>	<b>Technical specifications</b>	<b>3-110</b>

## 3.1 Specifications/regulations/approvals

### Regulations

The following regulations apply to contactors:

- IEC 60 947-1, EN 60 947-1 (VDE 0660 Part 100), which includes the general specifications for low-voltage switching devices.
- IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102), which contains, in particular, the requirements for contactors and motor starters.

The following regulations apply to auxiliary contactors:

- IEC 60 947-1, EN 60 947-1 (VDE 0660 Part 100), which includes the general specifications for low-voltage switching devices.
- IEC 60 947-5-1, EN 60 947-5-1 (VDE 0660 Part 200) which includes, in particular, the requirements for control equipment and switching elements for the control, signaling, locking, etc. of switchgear and controlgear.

### Standards

The following standards apply to the terminal markings of the contactors:

- EN 50 012: terminal markings and identification numbers for auxiliary contact elements of particular contactors (also applies to contactors with a built-on auxiliary switch block)
- EN 50 011: terminal markings, identification numbers, and identification letters for particular auxiliary contactors (also applies to auxiliary contactors with a built-on auxiliary switch block)
- EN 50 005: terminal markings and identification numbers, general rules

### Approvals/ test reports

Confirmation of approvals and test certificates and characteristics can be obtained on the Internet/intranet.

### Shock protection

The shock protection provided is in acc. with DIN VDE 0106 Part 100.

#### 3.1.1 Utilization categories

In acc. with EN 60 947-4-1, the purpose of the contactors and the stress placed on them is indicated by the utilization category together with details of the rated operational current or motor output and the rated voltage.

The following tables list the definitions of the utilization categories for low-voltage switching devices and contactors from IEC 60 947 (VDE 0660) an. The rated operational voltages for the various utilization categories are listed in the low-voltage switching devices catalog.

**Utilization category for AC voltages**

AC Utilization category for AC voltages	Switching capacity $I/I_e$ OnOff	Electrical service life $I/I_e$ OnOff
AC-1 Not an inductive load or a slightly inductive load	1.5 1.5	1 1
AC-2 Slipring motors: switch on, switch off	4 4	2.5 2.5
AC-3 Squirrel-cage motors: switch on, switch off during the run	10 8	6 1
AC-4 Squirrel-cage motors: switch on, plugging or reversing, inching	12 10	6 6

Table 3-1: Utilization categories, test conditions for AC voltage

**Definition of AC-1 to AC-4**

The definitions of the utilization categories AC-1 to AC-4 for main circuits can be found in the relevant regulations.

The main areas of application for contactors are:

- AC-3 operation: switching of squirrel-cage motors
- AC-1 operation: switching of resistive loads
- AC-4 operation: plugging, reversing, inching

**Test conditions**

Test conditions for the various utilization categories:

- In AC-1 operation, the contactor must be able to switch 1.5 times the rated operational current on and off.
- In AC-3 operation, the starting currents of the motors must be controlled. In other words, the contactor must be able to switch on 10 times the rated operational current ( $I_e$ ), and switch off 8 times the  $I_e$ .
- In AC-4 operation, the contactor must be able to switch off 12 times the rated operational current ( $I_e$ ) and 10 times the  $I_e$ . This represents extremely high stress for contactors because the high starting currents of the motors have to be switched off.

The breaking current is decisive in calculating the electrical service life:

- In AC-1 and AC-3 operation,  $1 \times I_e$  must be assumed.
- In AC-4 operation,  $6 \times I_e$  must be assumed because the contactor also has to switch off the motor during startup.



**Utilization category for DC voltages**

DC	Utilization category for DC voltages	Switching capacity $I/I_e$ Make/break	Switching capacity Time constant $L/R$ (ms)
DC-1	Not an inductive load or a slightly inductive load, resistance furnaces	1.5	1.0
DC-3	Shunt motors: switching on, plugging, reversing, inching	4.0	2.5
DC-5	Series motors: switching on, plugging, reversing, inching	4.0	15
DC-6	Switching of incandescent lamps	1.5	(Incandescent lamp test)

Table 3-2: Utilization categories, test conditions for DC voltages

**Definition of DC-1 to DC-6**

The definitions of the utilization categories DC-1 to DC-6 apply to main circuits for switching DC voltage.

The main areas of application for contactors are:

- DC-3/DC-5 operation: switching of shunt or series motors
- DC-1 operation: switching of resistive loads, resistance furnaces

**Note:**

In the information on DC switching capacity in previous documents, the utilization categories DC-2 and DC-4 correspond to the current utilization categories DC-3 and DC-5.

**Utilization category for AC voltage (auxiliary contact elements)**

AC	Utilization category for AC voltage (auxiliary contact elements)	Switching capacity	
		Make $I/I_e$	Break $I/I_e \cos\phi$
AC-12	Control of resistive load and semiconductor load in the input circuits of optocouplers	1	1 0.9
AC-14	Control of a small electromagnetic load (max. 72 VA)	6	1 0.3
AC-15	Control of an electromagnetic load (greater than 72 VA)	10	1 0.3

Table 3-3: Utilization categories, test conditions for AC voltage (auxiliary contact elements)

**Definition of AC-12 to AC-15**

IEC 60 947-5-1/EN 60 947-5-1 (VDE 0660 Part 200) contains the definitions of the utilization categories AC-12 to AC-15 for switching elements for the control, signaling, locking, etc. of switchgear and controlgear.

The main areas of application for auxiliary contactors are:

- AC-14/AC-15 operation: switching of contactor coils, solenoid valves, for example
- AC-14/AC-12 operation: switching of resistive loads, for example

**Rated operational currents**

The rated operational currents for the various utilization categories are listed in the low-voltage switching devices catalog. The test specifications given in the table for each utilization category represent the scale for the making and breaking capacity of the auxiliary contacts.

**Example**

3RT1016 contactor:  
 $I_e/AC-15$  of the auxiliary contact: 6 A/230 V  
 Making capacity:  $10 \times I_e/AC-15 = 60$  A

- This enables the contactor coil with the greatest power consumption (3TF56) to be switched on.
- Current value of the contactor coil when switched on: 10.7 A
- Only the holding current is decisive for switching off the contactor coil: Approximately 0.5 A in the example

According to regulations, the auxiliary contact must normally be able to switch off the rated operational current.

**Utilization category for DC voltage (auxiliary contact elements)**

DC	Utilization category for DC voltage (auxiliary contact elements)	Switching capacity	
		Make $I/I_e$	Break $I/I_e$ $L/R$ (ms)
DC-12	Control of resistive load and semiconductor load in the input circuits of optocouplers	1	1 1
DC-13	Control of solenoids	1	1 300
DC-14	Control of electromagnetic loads with economy resistors in the circuit	10	1 15

Table 3-4: Utilization categories, test conditions for DC voltage (auxiliary contact elements)

**Definition of DC-12 to DC-14**

The DC voltage switching capacity of auxiliary contacts is defined in utilization categories DC-12 to DC-14.

The main areas of application for contactors are:

- DC-12: switching of resistive loads (typical application)
- DC-13: switching of inductive loads, such as contactor coils and solenoid valves

In DC operation, the difference in stress is also determined by the L/R time constant. This must be specified by the user.

### 3.1.2 Positively driven operation

#### Regulations

The regulations for positively driven operation are:

- For contactors IEC 60 947-4-1, Appendix H (draft 17B/996/DC)
- For auxiliary contactors IEC 60 947-5-1, Amendment 2, Annex L, edition 10.1999
- ZH 1/457 Safety rules for controllers on power-operated presses
- SUVA Accident prevention guidelines of the Schweizer Unfallversicherungsanstalt (Swiss institute for accident insurance)

SIRIUS contactors comply with these regulations.

The core message of these regulations is:

Positively driven operation in contactors means that the NO contacts and NC contacts must on no account be closed at the same time.

#### Definition: positively driven contacts

Positively driven contacts are contacts that are mechanically connected with one another in such a way that the NC contacts and NO contacts can never be closed at the same time. This means ensuring that there is a distance between the contacts of at least 0.5 mm throughout the entire service life of the contactor, even when there is a defect, such as when the contact has been wrongly welded (ZH 1/457).

#### Positively driven operation in the case of 3RT1/3RH1

Positively driven operation occurs in:

- 3RT101 contactors and 3 RH11 auxiliary contactors in frame size S00 in both the basic unit and in the auxiliary switch block and also between the basic unit and the built-on auxiliary switch block
- 3RT1 contactors in frame sizes S0 to S3 between the main contacts and the normally closed auxiliary contacts. In other words, if the main contact is welded, the normally closed auxiliary contact will not close.

Positively driven operation does not occur in the case of:

- Electronically optimized auxiliary switch blocks in frame size S00

Positively driven operation is not compulsory for normal controllers. It is, however, imperative for protective circuits.

### 3.1.3 Safe isolation

The term "safe isolation" occurs in connection with safety/protective extra-low voltage (SELV/PELV) and functional extra-low voltage (FELV). Safe isolation reliably prevents voltage that is capable of causing electric shock from transferring to the safely isolated voltage (e.g. to safety extra-low voltage that is applied to or switched to the same device).

Safe isolation is also becoming increasingly important due to the more widespread use of electronic systems in high-voltage installations.

#### Definition

Circuits are safely isolated when a single fault does not result in a transfer of voltage from one circuit to another. Faults to be taken into account are, for example, a bent or loose conductive part, a bent soldering pin, broken winding wire, a screw that has fallen out, or a broken partition wall in a device.

**Regulations**

IEC 61 140 (replacing VDE 0106 Part 101/IEC 536) lists basic requirements that can be met using safe isolation between circuits in electrical equipment.

Basic requirements are, for example:

- Double or reinforced insulation
- Protective screening
- Combination of double or reinforced insulation and protective screening

The insulation must be resistant to aging throughout the expected service life.

Circuits without protective extra-low voltage or functional extra-low voltage do not require safe isolation.

**Safe isolation in the case of 3RT1 and 3RH1 contactors**

If the conducting paths of a contactor are operated with different voltages, the requirements for safe isolation must be met.

In the case of the 3RT1 and 3RH1 contactors, safe isolation is ensured up to the following voltage:

- Safe isolation between the different main conducting paths is always 400 V.
- Safe isolation between the different main conducting paths and the coil connection is always 400 V.
- The following table lists the values for safe isolation between the main and auxiliary conducting paths and the coil connection:

	3RT1 and 3RH1 contactors			
	Frame size S00 Main contact	Frame size S0 Main contact	Frame size S2 Main contact	Frame size S3 Main contact
Aux. switch at front	690 (*)	500	500	500
at side	-	690	500	690
Coil connection	400	400	400	400

Table 3-5: Safe isolation

(\*) Only applies to 4-pole auxiliary switch blocks at the front

All the data are power system specifications with 10% overvoltage in volts [V].

400 V + 10% corresponds to 415 V + 5% and 500 V + 10% corresponds to 525 V + 5%.

**Attention**

In the table, the voltage that can cause electric shock and that must be safely isolated is critical. If the voltages 400 V and 24 V are to be safely isolated from one another, contactors with safe isolation up to 400 V must be used between the two points of connection used.

### 3.1.4 Explanation of terms

**Safety extra-low voltage**

Safety extra-low voltage (SELV) allows circuits with a rated voltage of up to 50 VAC or 120 VDC to be operated ungrounded. The higher voltage is safely isolated from the SELV circuits.

Safety extra-low voltage helps protect people.

**Functional extra-low voltage**

Functional extra-low voltage (FELV) allows circuits with a rated voltage of up to 50 VAC or 120 VDC can be operated. It does not, however, meet the requirements of safety extra-low voltage and is therefore subject to additional conditions. FELV is implemented using a ground terminal.

Functional extra-low voltage helps protect devices (e.g. programmable controllers).

**PELV**

PELV (protective extra-low voltage) has the same requirements as safety extra-low voltage, except for the fact that the circuit and/or exposed conductive part is/are grounded (so it is basically grounded SELV).

### 3.2 Device description

The SIRIUS contactors are components of the SIRIUS modular system and can therefore offer the typical benefits of SIRIUS when it comes to the selection of components and the assembly and operation of controllers and load feeders.

The SIRIUS range of contactors encompasses the following:

- Contactors for switching motors of up to 45 kW/400 V
- Auxiliary contactors with the contact variants 4 NO, 3 NO + 1 NC, and 2 NO + 2 NC
- Contactor relays for system-specific cooperation with electronic controllers
- Contactors for particular applications:
  - Contactors with 4 main contacts
  - Capacitor switching contactors
  - Contactors for switching resistive loads
  - Contactors with an extended operating range
  - Contactor combinations

#### Frame sizes

The SIRIUS range of contactors covers everything up to 45 kW in 4 frame sizes. Each frame size has 3 or 4 standard motor outputs:




Figure 3-1: Frame sizes of the 3RT1 contactors

#### Performance ranges

The following table specifies the performance ranges for the frame sizes of the 3RT10 contactors:

Frame size	S00			S0				S2			S3		
Order number	3RT10..			3RT10..				3RT10..			3RT10..		
	15	16	17	23	24	25	26	34	35	36	44	45	46
At 400 V:													
P/AC-3kW	3	4	5.5	4	5.5	7.5	11	15	18.5	22	30	37	45
I <sub>e</sub> /AC-3 A	7	9	12	9	12	17	25	32	40	50	65	80	95
Width	45 mm			45 mm				55 mm			70 mm		

Table 3-6: Performance ranges of the 3RT10 contactors

The following table provides an overview of the existing variants of the 3RT and 3RH contactors:

Models		Frame size
3RT10 contactors	AC/DC operation To operate motors, 3-pole, up to 45 kW/400 V $I_e$ /AC-1 up to 40 °C: up to 120 A to 690 V $I_e$ /AC-3 up to 60 °C: up to 95 A/400 V	S00 to S3
3RT14 contactors	AC/DC operation To switch resistive loads, 3-pole, up to 92 kW/400 V $I_e$ /AC-1 at 40 °C: up to 140 A to 690 V	S3
3RT13 contactors	AC/DC operation, 4 main contacts (NO contacts) To switch resistive loads, up to 92 kW/400 V $I_e$ /AC-1 up to 40 °C: up to 140 A to 690 V	S00 to S3
3RT15 contactors	AC/DC operation, 4 main contacts (2 NO contacts + 2 NC contacts) To switch three-phase induction motors up to 18.5 kW/400 V $I_e$ /AC-3 up to 60 °C: up to 40 A to 400 V	S00 to S2
3RT16 contactors	AC operation To switch three-phase capacitors up to 50 kvar/400 V	S0 to S3
3RH/3RT contactors	DC operation with an extended operating range: 0.7 to 1.25 x $U_S$ 3RT: to switch motors up to 45 kW/400 V $I_e$ /AC-3 up to °C: 95 A to 400 V 3RH: to switch auxiliary circuits $I_e$ /AC-15/AC-14 up to 70 °C: 6 A/230 V	S00 to S3
3RT contactor relays (interface)	DC operation with an extended operating range: 0.7 to 1.25 x $U_S$ To switch motors, 3-pole, up to 11 kW/400 V $I_e$ /AC-3 up to 60 °C: 25 A to 400 V	S00 and S0
3RA13 contactor combinations	AC/DC operation To reverse up to 45 kW/400 V, $I_e$ /AC-3: 95 A/400 V	S00 to S3
3RA14 contactor combinations	AC/DC operation, for star-delta startup up to 75 kW/400 V, $I_e$ /AC-3: 150 A/400 V	S00-S00-S00 to S3-S3-S2
3RH11 auxiliary contactors	AC/DC operation, to switch auxiliary circuits, 4-pole (basic unit) $I_e$ /AC-15/AC-14 up to 60 °C: 6 A/230 V	S00
3RH14 latched auxiliary contactors	AC/DC operation, to switch auxiliary circuits, 4-pole (basic unit) $I_e$ /AC-15/AC-14 up to 60 °C: 6 A/230 V	S00
3RH11 contactor relays (interface)	DC operation with an extended operating range (0.7 to 1.25 x $U_S$ ) to switch auxiliary circuits, 4-pole $I_e$ /AC-15/AC-14 up to 60 °C: 6 A/230 V	S00
Unwelded contactors 3RT11 24, 3RT11 35	The unwelded contactors are put together using a circuit breaker to make an unwelded feeder. The features are: <ul style="list-style-type: none"> <li>• Standard: IEC 947-6-2 (for feeders with increased requirements)</li> <li>• Compact</li> <li>• Extremely high reliability in the entire current range up to 50 kA</li> </ul>	S0, S2

Table 3-7: Types of 3RT/3RH contactors

**Auxiliary contacts and built-on accessories**

- A uniform and diverse range of auxiliary switches and accessories that can be quickly upgraded and replaced is available for 3RT1 contactors up to 45 kW for various applications.
- The 3RH auxiliary contactors can be extended to form variants with a maximum of 8 poles using attachable 2 or 4-pole auxiliary switch blocks.
- Wiring kits with and without mechanical interlocking are available for putting together 3RA contactor combinations for reversing and for star-delta starting.

The accessories are described in detail in Section 3.4, "Accessories".

**3.2.1 Actuating systems**

AC coil:	<ul style="list-style-type: none"> <li>• Ferromagnetic iron core (due to eddy current losses)</li> <li>• Adequate holding power</li> <li>• Automatic reduction from high closing power to low holding power</li> <li>• Short switching times</li> </ul>
DC coil:	<ul style="list-style-type: none"> <li>• Solid parts are permissible</li> <li>• Larger unit volumes (to achieve a tensile force comparable to that of an AC coil)</li> <li>• High holding power</li> <li>• Closing power = holding power</li> <li>• Longer switching times</li> </ul>

Table 3-8: Actuating systems

**3.2.2 Short-circuit protection of the SIRIUS contactors**

Section 3.7, "Technical specifications", has information on short-circuit protection. Fuses and circuit breakers can be used as short-circuit protective devices for the contactors.

The test criteria that apply in this case are stipulated by EN 60 947-4-1 (VDE 0660 Part 102).

**Coordination types**

Two types of assignment are defined in the standards that correspond to two different levels of damage.

The following applies to both types of assignment:

In the event of a short-circuit, the short-circuit protective device used must be able to disconnect the overcurrent that occurs both safely and successfully. Persons or other parts of the system must not be put at risk.

**Coordination type 1**

The load feeder (e.g. motor starter) can be inoperable after each short-circuit disconnection. Damage to the contactor and the overload relay is permissible, but it is only possible to continue operation after defective devices have been repaired or replaced.



---

<b>Coordination type 2</b>	After short-circuit disconnections, there must be no damage to the load feeder devices. The only exception is if the contactor contacts have been welded and can be easily separated again without distorting the contact pieces.
<b>Contactors with overload relay</b>	<p>If contactors are combined with an overload relay, a smaller fuse as specified in the NSK catalog on permissible short-circuit protection fuses for motor starters should be used.</p> <p>The information required to ensure unwelded fusing of the contactors is contained in the NSK catalog.</p>

### 3.2.3 Operation

#### 3.2.3.1 General information

<b>Ambient temperature</b>	The 3RT10 contactors are designed for use in ambient temperatures of -25 °C to +60 °C. Some variants can be used in temperatures of -35 °C to +70 °C.
<b>Degree of protection</b>	The degree of protection of the SIRIUS contactors is IP20.



#### **Warning**

When the supply voltage and load are present, the contactor must not be actuated by pressing the contact support. It is permissible, however, to carry out tests with an extra-low test voltage (e.g.  $\leq 24$  V).

---

**Mechanical life**

A significant criterion for the economical use of contactors is their mechanical endurance. This is expressed in the number of operations that are possible without placing a load on the conducting path. You cannot expect too much in terms of mechanical endurance from switches that have to work with a relatively high contact load, such as isolators and circuit breakers without neglecting their cost-efficiency. Contactors, on the other hand, are switching devices designed specifically for very high numbers of operations and switching frequency.

The following table shows you the mechanical endurance of 3RT1 contactors:

<b>Device</b>	<b>Mechanical endurance</b>
Basic unit, frame size S00	30 mill. operating cycles
Basic unit, frame size S00 with built-on auxiliary switch block	10 mill. operating cycles
Basic unit, frame sizes S0 to S3	10 mill. operating cycles
Basic units, frame sizes S00 to S3 with built-on, electronically optimized auxiliary switch block	5 mill. operating cycles

Table 3-9: Mechanical endurance

The mechanical endurance can be increased if low current is used (for example, 17 V 5 mA) but only if there is no arcing during switching.

**Display of the contactor function**

The 3RT1926 LED indicator block can be connected to the coil connections of the contactors in frame sizes S00 to S3. It indicates the status of the contactors by means of the yellow LED. The indicator block can be snapped onto the front in the opening intended for the inscription plate.

The advantage is that the LED indicator block can be used for AC/DC voltages of 24 V to 240 V and that it is protected against polarity reversal.

**3.2.3.2 Contact reliability**

Increasingly in industrial control engineering, conventional contactor controls are combined with electronic control systems. Working together in this way gives rise to higher demands than those when used in conventional contactor controls.

An important requirement is that the signal generators (auxiliary contacts of contactors, for example) display high contact reliability at low voltages and currents, while retaining their full switching capacity at high voltages.

### Switching with auxiliary contacts ( $\leq 110\text{ V}$ and $\leq 100\text{ mA}$ )

The following applies to the contactors of the SIRIUS range: If voltages  $\leq 110\text{ V}$  and currents  $\leq 100\text{ mA}$  are to be switched, the auxiliary contacts of the 3RT1 contactors or the 3RH1 auxiliary contactors should be used instead of the main contacts because of their contact reliability. This comes from their high contact stability due, in particular, to the shape of the contact pieces (cross-ribbing).

This ensures that the points of contact remain conductive in spite of surface contamination and the effect of dust.

These auxiliary contacts are suitable for electronic circuits (programmable controllers) with voltages  $> 17\text{ V}$  and currents in the milliampere range (test circuit:  $17\text{ V}$ ,  $5\text{ mA}$ ).

### Cross-ribbing

Surface contamination is the most common cause of contact faults. Cross-ribbing the contact areas is an extremely effective way of increasing contact reliability. All the auxiliary contacts of the SIRIUS contactors have this feature.

The following illustration shows you how cross-ribbing is particularly effective against surface contamination due to the high number of contact areas and high surface pressure:




Figure 3-2: Contact areas

### Contact reliability of the auxiliary contacts

The contact areas of the SIRIUS auxiliary contacts display a high degree of contact reliability. Fault frequency rates of  $H_F \leq 10^{-8}$  (i. e.  $< 1$  fault per 100 mill. operating cycles at  $17\text{ V}$ ,  $1\text{ mA}$ ) have been registered.

These values apply to auxiliary contacts that are either integrated in the contactor housing or can be snapped on as auxiliary switch blocks.

In the case of built-on auxiliary switch blocks at the side, fault frequency rates are between  $10^{-6}$  and  $10^{-8}$ .

The tests are based on the requirements placed on signal generators by electronic controllers.

This means that with the auxiliary contacts of the SIRIUS contactors or auxiliary contactors, the permissible contact resistance is only exceeded once during a total of  $10^8$  (100 million) switching operations. During a long period of operation, therefore, a fault is not expected to occur, irrespective of the number of switching operations.

A restriction applies in the case of auxiliary switch blocks built on at the side.

### Definition of switch fault frequency $H_F$

The fault frequency  $H_F$  is defined as the number of contact faults that occur during a certain number of switching operations.

**Electrical service life of the main contacts**

The rated operational current  $I_e$  is defined in acc. with utilization category AC-4 (switching off 6 times the rated operational current) for a contact service life of approximately 200 000 operating cycles.

If mixed modes are used - in other words, if normal switching mode (the rated operational current is switched off in acc. with utilization category AC-3) is mixed with occasional inching mode (several times the rated operational current is switched in acc. with utilization category AC-4) - the service life of the contact pieces can be roughly calculated with the following formula:

$$X = \frac{A}{1 + \frac{C}{100} \cdot \left(\frac{A}{B} - 1\right)}$$

Key to the formula:

- X Contact service life in mixed mode in operating cycles
- A Contact service life in normal operation ( $I_a = I_e$ ) in operating cycles
- B Contact service life in inching mode ( $I_a = a$  multiple of  $I_e$ ) in operating cycles
- C Percentage of the total number of switching operations accounted for by inching operations

The following characteristic curves illustrate the contact service life of contactors when switching inductive three-phase loads (AC-3), irrespective of the breaking current and rated operational voltage. The prerequisites are arbitrary (i.e. not synchronous with the phase relation of the control station operating the network).

**Characteristic curve:  
contact service life of  
the main contacts**

The characteristic curves illustrate the contact service life of the main contacts of contactors when switching inductive three-phase loads (AC-3).

$I_a$  = breaking current

$I_e$  = rated operational current

$P_N$  = rated output of three-phase induction motors with squirrel cage at 400 V

**Frame size S00**




Figure 3-3: Characteristic curve of the electrical service life of the main contacts (frame size S00)

**Frame size S0**




Figure 3-4: Characteristic curve of the electrical service life of the main contacts (frame size S0)

**Frame size S2**




Figure 3-5: Characteristic curve of the electrical service life of the main contacts (frame size S2)

**Frame size S3**




Figure 3-6: Characteristic curve of the electrical service life of the main contacts (frame size S3)

**Characteristic curve:  
contact service life of  
the auxiliary contacts**

The contact service life depends on the breaking current. The prerequisites are arbitrary (i.e. not synchronous with the phase relation of the control station operating the network).

The characteristic curves apply to:

- Integrated 3RT10 auxiliary contacts
- 3RH1911 auxiliary switch blocks for contactors in frame size S00
- 3RH1921 auxiliary switch blocks for contactors in frame sizes S0 to S3




Figure 3-7: Characteristic curve of the electrical service life of the auxiliary contacts

1) DC-13: built-on auxiliary switch blocks for frame size S00: 6 A

### 3.3 Application and areas of use

Various switching devices are available for switching electrical loads. The contactor is most suitable device for frequent switching operations. Contactors are the most commonly used switching device in industry, mechanical engineering and in switchgear and controlgear. Due to the increased automation of production, contactors have become more important, involving greater and often different types of demands.

Automated production systems are considerably more sensitive to operational malfunctions than manually operated systems. Each fault on an electrical device means downtimes, wastage, loss of production and often considerable outlay in order to get the system up and running again.

For this reason, we concentrated on high reliability when developing the SIRIUS contactor range. This includes, in particular, increased service life, high contact reliability, and the possibility to use the contactors at higher ambient temperatures in the cubicle. It is possible to use the contactors up to 60 °C and also without derating when the devices are installed in a row.

To deal with the variety of possible applications, there are also contactor variants for special applications, such as for switching resistive loads or capacitors, in addition to the main 3RT10 range of contactors (for switching motors).

The different contactor ranges and their possible applications are described in the following subsections.

#### 3.3.1 3RT10 contactors with 3 main contacts for switching motors

<b>Field of application</b>	The 3-pole 3RT10 contactors use 3 NO contacts as main contacts. They are mainly used to switch three-phase induction motors.
<b>Frame sizes</b>	The full performance range from 3 to 45 kW/400 V (utilization categories AC-2 and AC-3) is covered by 4 frame sizes. The frame sizes cover the following levels of standard motor output: <ul style="list-style-type: none"><li>• Frame sizes S00, S2, S3: three standard levels of motor output each</li><li>• Frame size S0: 4 standard levels of motor output</li></ul>
<b>Dimensions</b>	The contactors are provided with alternating or direct current magnetic systems. The required floor areas of the devices of the two operating mechanism types are the same. As of frame size S0, the installation depth for contactors with the DC magnet system is between 10 mm and 15 mm greater than for the variants with the AC magnet system.
<b>Power ratings</b>	All the specified power and current ratings apply to an ambient temperature of 60 °C without derating.



**Increasing the power** The ease of expansion is an advantage for configuration. In many applications there is enough space to insert the contactor with the next higher rating class and thus increase motor output.

### 3.3.2 3RT1446 contactors with 3 main contacts for switching resistive loads (AC-1)

**Field of application** The 3RT14 46 contactors with 3 main contacts for switching resistive loads are used for applications in the AC-1 utilization category:

- Switching of resistive loads such as heating systems or resistance furnaces
- Applications in which a low switching capacity is sufficient
- Applications in which high continuous currents occur without peaks (e.g. as a generator contactor or in the case of variable-speed drives).

**Switching capacity** 1.5 times the  $I_e/AC-1$  can be switched on and off. Switching off higher currents, with the emergency stop, for example, is possible up to 8 times the  $I_e/AC-3$  current.

#### Comparison: 3RT1046/3RT1446

The following table shows you the difference between the 3RT1446 and 3RT1046 contactors for normal AC-3 applications:

	Contact material	Conducting paths
<b>3RT1446</b>	Contact material with high current-carrying capacity and better thermal properties	Larger conducting paths that permit better cooling
<b>3RT1046</b>	Contact material that ensures better switching capacity	

Table 3-10: Comparison between the 3RT1446 and 3RT1046 contactors

**Note on configuration** The 3RT10 range of contactors for switching motors also has a specific AC-1 switching capacity. It is much less costly, however, to use the AC-1 contactor 3RT14 for this specific purpose.

**Accessories** You can use the same accessories for the 3RT14 contactors as you can for the 3RT104 contactors in frame size S3.

### 3.3.3 3RT13 and 3RT15 contactors with 4 main contacts

**Model**

There are two variants of the contactors with 4 main contacts :

- 3RT13 with 4 NO contacts
- 3RT15 with 2 NO and 2 NC contacts

You can use the accessories for both the 3-pole SIRIUS contactors and the 4-pole variants.

**Field of application**

The following table gives the fields of application for the 3RT13 and 3RT15 contactors:

<b>3RT13 contactors with 4 NO contacts</b>	<b>3RT15 contactors with 2 NO + 2 NC contacts</b>
<ul style="list-style-type: none"> <li>• Switching of resistive loads</li> <li>• Isolation of networks with ungrounded or badly grounded neutral conductors</li> <li>• Supply switchovers in the case of alternative AC power supplies</li> <li>• As a contactor - for example, in variable-speed drives that only have to carry the current, not switch it</li> </ul>	<ul style="list-style-type: none"> <li>• Pole switchover in the case of crane-type motors</li> <li>• Switching of 2 separate loads</li> </ul>

Table 3-11: Applications of 4-pole contactors

**Auxiliary contacts**

The following table specifies the maximum number of auxiliary contacts that can be attached:

<b>Frame size S00</b>	<b>Frame size S0</b>	<b>Frame sizes S2 and S3</b>
4 auxiliary contacts	Maximum 2 auxiliary contacts (built on at the side or snapped on at the top)	Maximum of 4 auxiliary contacts (built on at the side or snapped on at the top)

Table 3-12: 4-pole contactors and auxiliary contacts

**Contactor combination with mechanical interlocking**

The 4-pole 3RT13 contactors with 4 NO contacts as main contacts in frame sizes S0 to S3 are suitable for putting together contactor combinations with mechanical locking for use, for example, in supply switchovers.

The following tables show how the contactor combinations are put together in different frame sizes:

### Assembly of the contactors in frame size S0 with front interlocking





Drawing: frame size S0	Step	Procedure
	1/2	Remove the fourth pole of the left contactor by pressing the ribbed surfaces at the top and bottom at the same time <b>(1)</b> and then removing the pole <b>(2)</b> .
	3/4	Attach the pole to the left side of the same contactor.
 <p>3RA1922-2C</p>	5/6	Put the contactors together by inserting two mechanical couplers (3RA1922-2C) in the appropriate openings of the contactor <b>(5)</b> , and then press the other contactor onto these mechanical couplers <b>(6)</b> .
	7/8/9	Mount the mechanical interlock at the front (3RA1924-1A) over the two contactors.

Table 3-13: 4-pole reversing contactor combination with front interlock (frame size S0)

**Assembly of the contactors in frame size S0 with lateral interlocking**


Drawing: frame size S0	Step	Procedure
 <p>3RA1924-2B</p>	<p><b>5/6</b></p>	<p><b>Note:</b> The lateral mechanical interlock (3RA1924-2B) can be used if the contactor combination is to be mounted on a base plate.</p>

Table 3-14: 4-pole reversing contactor combination with lateral interlock (frame size S0)

**Assembly of the contactors in frame sizes S2/S3**


Drawing: frame sizes S2 and S3	Step	Procedure
 <p>3RA19.2-2G</p>	<p><b>1/2</b></p>	<p>Mount the mechanical interlock between the two contactors <b>(1/2)</b>, and insert the 2 connecting clips (10 mm spacing) <b>(3)</b> on the back of the two contactors.</p>

Table 3-15: 4-pole reversing contactor combination (frame sizes S2 and S3)

**Attention**


The mechanical interlock at the front cannot be used in contactors in frame sizes S2 and S3.

### 3.3.4 3RT16 capacitor-switching contactors for switching capacitors

**Field of application** 3RT16 capacitor-switching contactors are used to switch power capacitors that are used in reactive-current compensation.

**Frame sizes** The capacitor-switching contactors are available in frame sizes S00 to S3 with the rating levels 12.5, 15 kvar, 25 kvar, and 50 kvar at 400 V.

#### S00



#### S3




Figure 3-8: Capacitor-switching contactors (frame sizes S0 and S2)

#### Auxiliary switch

The auxiliary switch block snapped onto the capacitor-switching contactor contains three leading NO contacts and a normal NO contact that can be assigned as you wish. A 2-pole auxiliary switch block can also be attached at the side of the capacitor-switching contactors (variants: 2 NO contacts, 2 NC contacts, or 1 NO + 1 NC contact).

#### Switching capacitors/ banks of capacitors

A single capacitor can normally be switched on because the current is limited by the inductance of the upstream transformer and the cables. It is more difficult to switch banks of capacitors (parallel connection of a capacitor to capacitors already present) because the current is now only limited by the low inductance of the connecting leads and the capacitors. This problem is solved in the case of capacitor-switching contactors using precharging resistors.

#### Precharging resistors

The precharging resistors are an integral part of the contactor in 3RT16 capacitor-switching contactors. They are switched on via leading auxiliary contacts before the main contacts close. This results in damping down to approximately 10 % of the undamped peak currents. Damping of peaks in the making current prevents disturbances to the network.

**Important**

Make sure when switching banks of capacitors that you adhere to the specified minimum inductance between the capacitors connected in parallel that are to be provided in addition.

**3RT10. capacitor switching capacity**

The normal 3RT10 contactors for switching motors also have a certain capacitor switching capacity. Details of this can be found in Section 3.7, Technical specifications: Utilization category AC-6b, switching of individual capacitors and switching of low-inductance three-phase capacitors. The tables contain information on the switching of individual capacitors and the switching of banks of capacitors.

**Operation****Caution**

Only switch to discharged capacitors! Do not carry out a function test by hand.

The precharging resistors must not be removed as this will damage the contact pieces in circuits with a load.


**Circuit diagram**

Figure 3-9: Capacitor-switching contactors, circuit diagram

**3.3.5 Contactors with an extended operating range****Field of application**

The contactors with an extended operating range are used in systems with strong fluctuations in the control supply voltage and at the same time high ambient temperatures, such as railway applications in extreme climatic conditions, rolling mills, etc.

**Standards**

Contactors with an extended operating range comply with the following standards:

- IEC 60 947-4-1
- EN 60 947-4-1 (VDE 0660 Part 102)
- The requirements of IEC 60 077

They are shockproof in acc. with DIN VDE 0106 Part 100.  
Exception: the series resistor in frame sizes S0 to S3

<b>Control current circuits and auxiliary current circuits</b>	The magnet coils of the contactors have an extended operating range of 0.7 to $1.25 \times U_s$ and are wired with varistors as standard to provide protection against overvoltage. This increases the time to contact parting compared with standard contactors by 2 ms to 5 ms.
<b>With/without a series resistor</b>	<p>The 3RH11 and 3RT10 contactors with the suffix -0LA0 at digits 13 to 16 in the order number are used particularly where, in addition to a wide operating range and a high ambient temperature of 70 °C, several auxiliary contacts are required. Up to 4 auxiliary contacts can be used in these variants. To ensure that the magnetic system can produce the required amount of power at power-up, the contactors initially require a certain amount of over-excitation. By means of the series resistor, the contactors are switched to the normal hold-in coil level after power-up.</p> <p>If fewer auxiliary contacts are required, contactors with the same extended operating range that work without a series resistor are available up to frame size S0.</p> <p>The two ranges are described in more detail below.</p>
<b>3.3.5.1 Contactors with an extended operating range (3RH11...-0LA0/3RT10...-0LA0)</b>	
	The DC magnetic systems of the contactors must be switched to hold-in coil level via a series resistor.
<b>Arrangement of components in frame size S00</b>	<p>Auxiliary contactors and contactors of frame size S00 are available with the following:</p> <ul style="list-style-type: none"> <li>• A built-on block that contains the series resistor (the NC contact required for the switchover in the basic unit is already wired).</li> <li>• Integrated varistor</li> <li>• A 4-pole auxiliary switch block (in acc. with EN 50 005) can also be built on.</li> </ul>
<b>Arrangement of components in frame sizes S0 to S3</b>	Contactors of frame sizes S0 to S3 are fitted on the front with an auxiliary switch block with 2 NO contacts + 2 NC contacts. The separate series resistor that is attached at the side next to the contactor on the 35 mm rail has connecting leads for contactor attachment. An NC contact of the auxiliary switch block is required for the switchover to hold-in coil level. A circuit diagram with the terminal points is stuck onto each contactor.
<b>Auxiliary contacts</b>	One NC contact of the auxiliary contacts is required for the series resistor. The number of auxiliary contacts that are available beyond this is listed in the selection and order data. With frame size S00, the auxiliary switch block that you may need must be ordered separately.

**Installation**

The following types of installation are permissible for contactors and auxiliary contactors in ambient temperatures of up to 70 °C:  
 Frame size S00: installation in series  
 Frame sizes S0 to S3: The resistor block must be installed on the right next to the contactor because of the connecting leads there.


**Dimensions**

When the resistor is mounted, the contactors of frame sizes S0 to S3 become wider (see Section 3.6, Dimensioned drawings).


**Circuit diagrams**

**Frame size S00**

Terminal markings in acc. with DIN EN 50 012  
 Contactors 3RT1017-2K.42-0LA0



Terminal markings in acc. with DIN EN 50 005  
 Auxiliary contactors 3RH1122-2K.40-0LA0




Series resistor R<sub>v</sub> attached  
 NC contact wired  
 2 NO + 1 NC contacts available

Figure 3-10: Contactors with an extended operating range, circuit diagrams

**Frame sizes S0 to S3**

Terminal markings in acc. with EN 50 012  
 Contactors 3RT102.-, 3RT103.-, 3RT104.-3K.44-0LA0  
 With front-mounted 4-pole auxiliary switch block 3RH1921-1HA22



2 NO + 2 NC contacts  
 Identification number 22

Figure 3-11: Contactors with an extended operating range, terminal markings  
 NC contact 21/22 is required for the wiring of the series resistor.

Circuit diagram for wiring of the series resistor




Figure 3-12: Contactors with an extended operating range, circuit diagram



### 3.3.5.2 Contactors with an extended operating range (3RH1122-2K.40, 3RT1017-2K.4., 3RT102.-3K.40)

Contactors of frame size S00: 3RH11 22-2K.40, 3RT1017-2K.4. and frame size S0: 3RT102.-3K.40 have the following features:

- Extended operating range of  $0.7$  to  $1.25 \times U_s$
- The magnet coils are wired with a varistor; an additional series resistor is not required
- Permissible ambient temperature  $60 \text{ }^\circ\text{C}$

Note the following:

- Frame size S00: an auxiliary switch block cannot be attached
- Frame size S0: a maximum of two 1-pole auxiliary switch blocks can be attached

#### Installation

At an ambient temperature  $> 60 \text{ }^\circ\text{C} \leq 70 \text{ }^\circ\text{C}$ , there must be spacing of 10 mm when installing in series.

#### Ambient temperature

The permissible ambient temperature for operating the contactors at the full operating range of the magnet coils is  $-35 \text{ }^\circ\text{C}$  to  $+70 \text{ }^\circ\text{C}$ . During continuous operation with temperatures  $> +55 \text{ }^\circ\text{C}$ , the mechanical service life, the current-carrying capacity of the conducting paths, and the switching frequency are reduced.

### 3.3.6 3RH1 auxiliary contactors

Auxiliary contactors are switching devices for auxiliary circuits for controlling, reporting, and interlocking. Auxiliary contactors have to meet specific requirements in terms of clear terminal markings and a time- and cost-saving terminal system.

The SIRIUS 3RH1 auxiliary contactors (frame size S00) meet these requirements

#### Terminal markings

The terminal markings comply with EN 50 011 and EN 50 005 (for a more detailed explanation, see Section 3.4.1, Auxiliary switches).

#### Frame size and features

3RH1 auxiliary contactors are available with the following:

- Frame size S00
- With AC and DC operation
- Format as for motor contactor of frame size S00
- 4-pole basic version
- Can be extended to 8 poles with snap-on auxiliary switch blocks
- Screw-type or Cage Clamp terminals

#### Screw-type terminals

The 3RH1 auxiliary contactors have captive screws (cross-tip Pozidriv, size 2), with all the terminal points open on delivery. The screwdriver guides allow screwdriving machines to be used.

<b>Cage Clamp terminals</b>	The 3RH11 auxiliary contactors are also available with Cage Clamp terminals - a screwless terminal system. This type of terminal is particularly suitable if strong shaking or vibrations can be expected at the installation location. These terminals are also suitable for two-conductor connections. All the terminals are accessible from the front and are easily visible.
<b>Soldering pin connections</b>	Both the 4-pole basic version as well as the auxiliary contactors that have an auxiliary switch block attached at the front (see Section 3.4, Accessories) can be soldered onto printed circuit boards using a soldering pin adapter.
<b>Contact reliability</b>	All the switching elements of the 3RH1 auxiliary contactors are equipped with contact pieces that have particularly high contact stability, ensuring high contact reliability even at low voltages and currents. This subject is discussed in detail in Section 3.2.3.2, "Contact reliability".
<b>3RH14 latched auxiliary contactors</b>	<p>If there is a short circuit in the low-voltage network, or when large drive motors are switched on directly, the control supply voltage for the auxiliary contactors may fail briefly or fall under the permissible tolerance level. To ensure continuous operation, the variant with mechanical latching (3RH14) can be used with the auxiliary contactors.</p> <p>These auxiliary contactors latch mechanically after power-up and remain in an energized state even in the event of a power failure. The auxiliary contactor can be unlocked electrically using an interlock release magnet or manually using a button on the front of the attached latched block. When the voltage returns, the production program can be resumed immediately without resetting times due to the storage feature of the auxiliary contactors. The contactor coil and the coil of the release magnet are both designed for continuous operation.</p> <p>The power input is the same for the contactor coil and the release coil. The mechanical service life is 1 million operating cycles.</p>

### **3.3.7 3RT10 contactor relays for switching motors (interface) and 3RH11 contactor relays for switching auxiliary circuits**

Contactor relays are available in the SIRIUS modular system for switching motors and auxiliary circuits for the purpose of smooth interaction with electronic controllers. These are variants of the 3RT10/3RH11 contactor series with the following features:

- Low power input
- Wide operating range of the magnet coil  $0.7$  to  $1.25 \times U_s$
- High contact reliability of the auxiliary contacts
- Integrated or attachable overvoltage damping

**Contact reliability**

The high contact reliability of the auxiliary contacts ensures that false signals do not occur even at low switching capacities. With a voltage of 17 V and a current of 1 mA, there is on average less than one contact fault per 100 million switching operations.

**Overvoltage damping**

Overvoltage damping protects sensitive output levels of electronic controllers against switching overvoltages of the coil.

**Extended operating range**

The operating range of the coil of the contactor relays covers a voltage range from  $0.7$  to  $1.25 \times U_s$  ( $U_s$  = rated control supply voltage). This wide operating range is required for the supply voltage of electronic controllers with the required voltage tolerances.

The supply voltage of electronic controllers with 24 VDC covers the range 20.4 V to 28.8 V in acc. with DIN 19 240. If you take into consideration an additional loss of voltage of up to 3 V during the output phases, the contactor drive must be able to operate perfectly with voltages between 17.4 V and 28.8 V. The 3RT10 and 3RH11 contactor relays for electronic controllers operate safely from 17 V to 30 V, which corresponds to a voltage range of  $0.7 \times U_s$  to  $1.25 \times U_s$ . This is a considerably wider operating range than that of  $0.85$  to  $1.1 \times U_s$  for contactors and auxiliary contactors in acc. with IEC 60 947, DIN EN 60 947 (VDE 0660).

**Voltage ranges**

The following graphic shows you the voltage ranges for electronic controllers and drives of contactors and contactor relays with a rated control supply voltage of  $U_s = 24$  VDC:




Figure 3-13: Contactor relays: voltage ranges

**Auxiliary switch blocks**

Auxiliary switch blocks can be built on as follows:

Frame size S00: none

Frame size S0: a maximum of two 1-pole auxiliary switch blocks

**Power consumption**

**Variant 1:** The power input of the magnet coils for contactor relays in frame size S00 is 2.3 W at 24 VDC (operating range:  $0.7$  to  $1.25 \times U_s$ ).

**Variant 2:** Contactor relays with reduced coil performance in frame size S00,  $P = 1.4$  W at 24 VDC (operating range:  $0.85$  to  $1.85 \times U_s$ ).

The power input of magnet coils for contactor relays in frame size S0 is 4.2 W at 24 VDC (operating range:  $0.7$  to  $1.25 \times U_s$ ).

### 3.3.8 Contactor combinations for reversing

Contactor combinations are available for reversing (3RA1) in frame sizes S00 to S3:

- Installed in the factory  
Frame sizes S2 and S3 are delivered already mounted on a base plate.
- As a kit for self-assembly

The same accessories can be used as for the basic units of the corresponding frame size (see Section 3.4).

For motor protection an overload relay must be attached.

4-pole contactor combinations for reversing can be put together in frame sizes S0 and S2.






Figure 3-14: Fully assembled contactor combination for reversing (frame sizes S00 and S0)

#### Approvals

The  and  approvals only apply to complete contactor combinations and not to combinations you have assembled from separate parts.

#### Switchover time

If the contactors are interlocked by means of their auxiliary switches (electrical interlocking) or by mechanical interlocking, there is no overlapping of the contacting and the arcing time between the contactors at switchover. The switching times of the contactors are not affected by the mechanical interlock.

#### Note for frame size S00:

At voltages of >500 V a switchover pause of 50 ms must be included. AC-operated 3RT10 contactors in reversing or Dahlander mode require an NC contact interlock and a switchover pause of 50 ms.

---

<b>Auxiliary contact elements</b>	Different auxiliary switches can be attached (at the front or the side) to the 3RA1 reversing combination. An integrated auxiliary switch contact is available in frame size S00.
<b>Accessories</b>	<p>The following accessories for the basic units can also be used for contactor combinations for reversing:</p> <ul style="list-style-type: none"><li>• Auxiliary switch blocks (at the front/side)</li><li>• Surge suppressors</li><li>• Soldering pin adapters (frame size S00)</li></ul> <p>The following accessory is designed specifically for contactor combinations for reversing:</p> <ul style="list-style-type: none"><li>• Locking devices for mechanical interlocking</li><li>• Locking devices for mechanical and electrical interlocking (at the front/side)</li><li>• Terminals for contactor coils (for frame sizes S0 to S3)</li><li>• Mechanical connectors</li><li>• Wiring modules</li></ul>
<b>Terminals for contactor coils</b>	<p>To reach the coil terminals A1 and A2 of the contactor combinations for reversing more easily from contactors of frame sizes S2 and S3, you can use terminals for contactor coils.</p> <p>For each combination, 2 x A1 and 1 x A2 are required.</p>
<b>Wiring module</b>	<p>Wiring modules are available to enable you to carry out different types of wiring (Dahlander wiring, for example).</p> <p>You can find out how to mount the wiring modules in the diagrams of the self-assembly kits.</p>
<b>Mechanical interlocking</b>	<p>Mechanical interlocking (for frame sizes S0 to S3) is available in 2 variants:</p> <ul style="list-style-type: none"><li>• Attachable at the front (contactor spacing: 0 mm)</li><li>• Attachable at the side (for frame sizes S0 to S3) with integrated NC contact for electronic interlocking</li></ul>

---

**Note**

If you want NC contact interlocking, you must use contactors with 1 NC contact in the basic unit with the 3RT1 contactors of frame size S00.

---

The following graphics show you how to mount the locking devices at the front for mechanical interlocking in frame size S0:




Figure 3-15: Star-delta combination, locking device at the front (frame size S0)

The following graphics show you how to mount the locking devices at the front for mechanical interlocking with frame sizes S2 and S3:




Figure 3-16: Star-delta combination, locking devices at the front (frame sizes S2/S3)

The following accessories are components of the self-assembly kits and they are described in the diagrams of the relevant kit:

- Lateral locking device
- Mechanical connectors
- Wiring modules

**Kits**

The following table shows you the components of the kit for the contactor combination for reversing in frame size S00 and explains how to put it together:



Drawing: frame size S00	Step	Procedure
	<p><b>1/2/3</b></p> <p><b>4/5</b></p>	<p>Mount the mechanical interlock between the two contactors.</p> <p>Press the two connecting clips from above and below onto the two contactors.</p>
	<p><b>6</b></p>	<p>Attach the wiring modules to connect the main conducting paths and to electrically interlock the two contactors (3RT10.1). Make sure that the wiring modules are flush with the contactor at the side.</p>

Table 3-16: Assembling the contactor combination for reversing (frame size S00)

**Electrical interlock****Note:**

Contactors with an NC contact in the basic unit (3RT101.) are required for the electrical interlock.

The following table shows you the components of the kit for the contactor combination for reversing in frame size S0 and explains how to put it together:




Drawing: frame size S0	Step	Procedure
	<p><b>1/2</b></p>	<p>Mount the mechanical interlock between the two contactors.</p>
	<p><b>3</b></p>	<p>Wire the actuating voltage and the electrical reversing interlock using the auxiliary conducting paths.</p>
	<p><b>4/5</b></p>	<p>Attach the wiring modules (<b>4</b>) in order to connect the main conducting paths and tighten the terminals (<b>5</b>).</p>

Table 3-17: Assembling the contactor combination for reversing (frame size S0)



The following table shows you the components of the kits for the contactor combination for reversing in frame size S2 and S3 and explains how to put it together:




Drawing: frame size S2 (S3)	Step	Procedure
	<b>1/2/3</b>	Mount the mechanical interlock between the two contactors ( <b>1/2</b> ), and insert the 2 connecting clips (10 mm spacing) ( <b>3</b> ) on the back of the two contactors.
	<b>4</b>	Wire the actuating voltage and the electrical reversing interlock using the auxiliary conducting paths.
	<b>5/6</b>	Attach the wiring modules ( <b>5</b> ) in order to connect the main conducting paths and tighten the terminals ( <b>6</b> ).

Table 3-18: Assembling the contactor combination for reversing (frame sizes S2/S3)

**4-pole contactor combination for reversing**

4-pole contactor combinations for reversing are available in frame sizes S0 and S2. You will require the following to mount these combinations:

- Frame size S0: locking device for mechanical interlock
- Frame size S2: locking device for mechanical interlock and 2 connecting clips

The following table shows you how to set up the 4-pole contactor combination for reversing in frame size S0:




Drawing: frame size S0	Step	Procedure
	<p><b>1/2</b></p>	<p>Remove the 4th pole from one of the two contactors by releasing the snap catch <b>(1)</b>.</p>
	<p><b>3/4</b></p>	<p>Put the 4th pole on the other side of the same contactor by placing the catches on the pole into the openings shown on the contactor and snapping the pole onto the contactor.</p>
	<p><b>5/6</b></p>	<p>Mount the mechanical interlock between the two contactors <b>(5/6)</b>.</p>

Figure 3-17: 4-pole contactor combination for reversing (frame size S0)

The following table shows you how to set up the 4-pole contactor combination for reversing in frame size S2:


Drawing: frame size S2	Step	Procedure
	<b>1/2</b>	Mount the mechanical interlock between the two contactors <b>(1/2)</b> .
	<b>3</b>	Press the two connecting clips <b>(3)</b> onto the back of the two contactors.

Figure 3-18: 4-pole contactor combination for reversing (frame size S2)

#### NO contact function not locked

If contactors are used with 1 NO contact that is intended for an auxiliary function (e.g. as a signaling device), the wiring module must be separated. The illustration below shows you the wiring for this function:




Figure 3-19: NC contact interlock (frame size S00)

#### Mounting and connection

The contactor combinations for reversing have screw-type connections that are suitable for both screw-on and snap-on mounting on a 35 mm rail.

#### Conductor cross-sections

The permissible conductor cross-sections of the contactor combinations for reversing correspond to those of the basic units for the corresponding frame size.

Circuit diagrams

Main circuit: S00, S0, S2, S3




Figure 3-20: Contactor combination for reversing, main circuit (frame sizes S00 to S3)

Control circuit: S00

Pushbutton switch control

Continuous contacting






Figure 3-21: Contactor combination for reversing, control circuit (frame size S00)

- S0 "Off" button
- S1 "Clockwise rotation on" button
- S2 "Counterclockwise rotation on" button
- S "Right/off/left" selector switch
  
- K1 Clockwise rotation contactor
- K2 Counterclockwise rotation contactor
  
- F1 Fuses for main circuit
- F2 Overload relay
- F3 Fuses for control circuit

**Control circuit: S0 to S3**

Pushbutton switch control



Continuous contacting




Figure 3-22: Contactor combination for reversing, control circuit (frame sizes S0 to S3)

**Technical specifications**

The technical specifications of the contactor combinations for reversing correspond to those of the basic units for the corresponding frame size.

**3.3.9 Star-delta combinations**

The 3RA1 star-delta combinations in frame sizes S00 to S3 are available as follows:

- Fully assembled with the usual auxiliary switches in the following frame sizes:
  - S00-S00-S00
  - S0-S0-S0
  - S2-S2-S0
  - S2-S2-S2
  - S3-S3-S2


Frame sizes S2 to S3 are delivered already mounted on a base plate.

- As a kit for self-assembly

The same accessories can be used as for the basic units of the corresponding frame size (see Section 3.4, "Contactor accessories").

The following graphics show you the fully assembled star-delta combinations in frame sizes S00 to S2:

**Frame size S00**



**Frame size S2**




Figure 3-23: Star-delta combinations (frame sizes S00, S0, S3)


**Frame size S2**

Figure 3-24: Star-delta combination (frame size S2)

**Field of application**

The star-delta combination is used to start three-phase induction motors which require a low load torque during startup.

**Starting current ratio**

Star-delta starting can only be used when the motor is switched to delta mode, starts with no load, or if the load torque during the star startup is small and does not increase rapidly.

In the star stage, the motors can be loaded with approximately 50 % (torque class KL16) and 30 % (KL10) of its rated torque.

The tightening torque is reduced to approximately 1/3 of the value at direct power-up.

The starting current is approximately 2 to 2.7 times the rated current for the motor.

**Switchover**

Switching from the star to the delta stage can only be carried out once the motor has completed startup to the rated speed.

The required switchover pause and interlock is included in the contactor combination.

**Important**

Drives that require an early switchover are not suitable for star-delta starting.

**Overload protection**

The fully assembled combinations are not equipped with overload protection. Overload relay (3RU11) and tripping devices for thermistor motor protection must be ordered separately.

The overload relays can be attached to the contactor directly or set up separately. The overload relay is set to 0.58 times the set current  $I_e$ . See Chapter 4 on overload relays for further information.

**Features of the star-delta combinations**

The following table shows you the features of the fully assembled star-delta combinations with time-delay auxiliary switch blocks with the star-delta function (3RT19.6-2B...) and solid-state time relays with semiconductor output and the possible configuration if you use the self-assembly kit:

	<b>Frame size S00</b>	<b>Frame sizes S0 to S3</b>
Fully assembled	At front (time-delay auxiliary switch block)	Lateral (time relay)
Kit	At front	<ul style="list-style-type: none"> <li>• Lateral (time relay)</li> <li>• At front (time-delay auxiliary switch block)</li> </ul>

Table 3-19: Configuration of the star-delta combinations

**Important**

If a time-delay auxiliary switch block is mounted on the front of K3, an auxiliary switch block can only be mounted on the side of K3.

**Accessories**

The following basic unit accessories can also be used for star-delta combinations:

- Auxiliary switch blocks (front, side)
- Surge suppressors
- Time-delay auxiliary switch blocks with star-delta function

In addition, there are special accessories available for the star-delta combinations:

- 3-phase feed-in terminals
- Star-point links (parallel links)
- Terminals for contactor coils (S2/S3)
- Mechanical connectors
- Wiring modules

**Terminal for contactor coils**

In order to reach coil terminals A1 and A2 in the star-delta combination better from contactors in frame sizes S2 and S3, terminals for contactor coils can be used.

For each combination, 2 x A1 and 1 x A2 are required.

**Infeed**

With conductor cross-sections  $> 2 \times 2.5 \text{ mm}^2$  and  $1 \times > 4 \text{ mm}^2$ , a feed-in terminal block must be used for the star-delta combination in frame size S00. This makes the following conductor cross-sections possible:

- Frame size S00: up to  $6 \text{ mm}^2$
- Frame size S0: up to  $25 \text{ mm}^2$
- Frame size S2: up to  $50 \text{ mm}^2$



## Kits

The following table shows you the components of the kit for the star-delta combination in frame size S00 and explains how to put it together:




Drawing: frame size S00	Step	Procedure
	<p><b>1/2/3</b></p> <p><b>4/5</b></p>	<p>Mount the mechanical interlocks between the K2 star contactor and the K3 delta contactor <b>(1, 2)</b>.</p> <p>Press the two connecting clips from above and below onto the two contactors <b>(3)</b>. Make sure the clips are on the correct side.</p>
	<p><b>6/7</b></p>	<p>Break the upper link module off at the notches <b>(6)</b>, and attach the wiring modules <b>(7)</b> to connect the main conducting paths (between line contactor K1 and delta contactor (K3) and at the same time to interlock the combination electrically (K3-K2).</p>
	<p><b>8/9</b></p>	<p>Wire A2 <b>(8)</b>, and tighten the terminal screws <b>(9)</b>.</p>

Table 3-20: Assembly of the star-delta combination in frame size S00

The following table shows you the components of the kits for the star-delta combinations in frame sizes S0 to S3 and explains how to put it together:




Drawing: frame size S0	Step	Procedure
		<p>Attach the wiring modules and the star-point link in order to connect the main conducting paths and to interlock the combination electrically.</p>
Drawing: frame size S2 (S3)	Step	Procedure
	<p>1/2</p>	<p>Place the star-point link on the star contactor (1). Tighten the main connections (2).</p>
	<p>3</p>	<p>Place the wiring module on the contactor undersides (3) to connect the main conducting paths.</p>
Drawing: frame sizes S3-S3-S2	Step	Procedure
	<p>1</p>	<p>Attach the star-point link to the star contactor (1).</p>
	<p>2</p>	<p>Attach the wiring module to the contactor undersides (2) to connect the main conducting paths.</p>

Table 3-21: Assembly of the star-delta combinations in frame sizes S0 to S3

### Compensating for different depths

In star-delta combinations with contactors of different frame sizes, it is necessary to compensate for the mounting depth of the smaller contactor. One frame size is the maximum difference possible.

The following depth compensation must be made for a mechanical interlock attached at the side:

- S2-S2-S0: K3: 1.5 mm; K2: 0 mm
- S3-S3-S2: K3: 0 mm; K2: 27.5 mm

### Mounting and connection

The star-delta combinations have screw-type connections that are suitable for both screw-on and snap-on mounting on the 35 mm rail.

### Conductor cross-sections

The permissible conductor cross-sections of the star-delta combinations correspond to those of the basic units for the corresponding frame size.

### Circuit diagrams

#### Main circuit: S00, S0, S2, S3





Figure 3-25: Star-delta combination, main circuit (frame sizes S00 to S3)

**Control circuit: S00**

Pushbutton switch control



Continuous contacting





Figure 3-26: Star-delta combination, control circuit (frame size S00)

**Control circuit: S0 to S3**

Pushbutton switch control



Continuous contacting




Figure 3-27: Star-delta combination, control circuit (frame sizes S0 to S3)

- S0 "Off" button
- S1 "On" button
- S Continuous contact maker
- K1 Line contactor
- K2 Star contactor
- K3 Delta contactor
- K4 Time-delay auxiliary switch block or time relay
- F0 Fuses
- F1 Overload relay

**Technical specifications**

The technical specifications of the star-delta combinations correspond to those of the basic units for the corresponding frame size.

### 3.4 Accessories

#### Accessories for frame size S00

The accessories for contactors that switch motors and for auxiliary contactors are of the same type. The accessories are attached at the front.

#### Accessories for frame sizes S0 to S3

The accessories are (with few exceptions) the same for frame sizes S0 to S3. They can be attached in different ways:

- Auxiliary switches can be attached at the front or the side.
- Surge suppressors can be attached at the top or the bottom.

The following graphic shows you the accessories for the contactors that switch motors and for the contactor relays of frame size S00:




Figure 3-28: Accessories for contactors of frame size S00

- 1 Contactor, frame size S00
- 2 Contactor relay
- 3 Solid-state time relay block, on-delay
- 4 Solid-state time relay block, off-delay
- 5 Auxiliary switch block, time-delay (on-delay or off-delay or star-delta function)
- 6/7 1-pole auxiliary switch block, infeed from above or below
- 8/9 2-pole auxiliary switch block, infeed from above or below
- 10 4-pole auxiliary switch block (terminal markings in acc. with EN 50 012 or EN 50 005)
- 11 2-pole auxiliary switch block, standard or electronic type
- 12 Soldering pin adapter for contactors with 4-pole auxiliary switch block
- 13 Soldering pin adapter for contactors and contactor relays
- 14 Additional load module to increase the permissible residual current
- 15/16 Surge suppressor with and without LED
- 17 3-phase feed-in terminal
- 18 Parallel link (star-point link), 3-pole, without terminal
- 19 Parallel link, 3-pole, with terminal
- 20 Parallel link, 4-pole, with terminal

The following graphic shows you the accessories for the auxiliary contactors and contactor relays for auxiliary circuits of frame size S00:




Figure 3-29: Accessories for auxiliary contactors/contactor relays of frame size S00

- 1 Auxiliary contactor
- 2 Contactor relay for auxiliary circuits
- 3 Solid-state time relay block, on-delay
- 4 Solid-state time relay block, off-delay
- 5 Auxiliary switch block, time-delay (types: on-delay or off-delay)
- 6 1-pole auxiliary switch block, infeed from above
- 7 2-pole auxiliary switch block, infeed from above
- 8 1-pole auxiliary switch block, infeed from below
- 9 2-pole auxiliary switch block, infeed from below
- 10 4-pole auxiliary switch block (terminal markings in acc. with EN 50 011 or EN 50 005)
- 11 2-pole auxiliary switch block, standard or electronic type (terminal markings in acc. with EN 50 005)
- 12 Soldering pin adapter for auxiliary contactors with 4-pole auxiliary switch block
- 13 Soldering pin adapter for auxiliary contactors and contactor relays
- 14 Additional load module to increase the permissible residual current
- 15 Surge suppressor with LED
- 16 Surge suppressor without LED

The following graphic shows you the accessories for the contactors of frame sizes S0 to S3:




Figure 3-30: Accessories for contactors of frame size S00

- 1 Contactor, frame size S0
- 2 Contactor, frame size S2
- 3 Contactor, frame size S3

**For frame sizes S0 to S3:**

- 4 Solid-state time relay block, on-delay
- 5 Solid-state time relay block, off-delay
- 6 Auxiliary switch block, time-delay (on-delay or off-delay or star-delta function)
- 7 2-pole auxiliary switch block, infeed from above
- 8 2-pole auxiliary switch block, infeed from below
- 9 4-pole auxiliary switch block (Terminal markings in acc. with EN 50 012 or EN 50 005)
- 10 Parallel link (star-point link), 3-pole without terminal
- 11 Parallel link, 3-pole, with terminal
- 12 2-pole auxiliary switch block, attachable on the right or left side (Terminal markings in acc. with EN 50 012 or EN 50 005)
- 13 1-pole auxiliary switch block (a maximum of 4 can be snapped on)
- 14 Mechanical interlock, attachable at the side
- 15 Mechanical interlock, attachable at the front
- 16 Wiring modules above and below (reversing operation)
- 17 Surge suppressor (varistor, RC element, diode combination), attachable above or below (different for S0 and S2/S3)
- 18 Coupling link for direct attachment to the contactor coil
- 19 LED block to display the contactor function

**For frame sizes S2 and S3 only:**

- 20 Terminal for contactor coil for assembling contactor combinations
- 21 Terminal cover for box terminals

**For frame sizes S3 only:**

- 22 Terminal cover for lug connection and bar connection
- 23 Auxiliary connecting lead terminal, 3-pole

### 3.4.1 Attachable auxiliary switches for extending the auxiliary contacts

#### Integrated auxiliary contacts

##### Frame size S00

The contactors of frame size S00 have an auxiliary conducting path integrated in the basic unit.

##### Frame size S0 to S3

The contactors of frame sizes S0 to S3 do not have an integrated auxiliary conducting path in the basic unit.

#### Auxiliary switch blocks Formats

Auxiliary switch blocks for extending the auxiliary contacts are available with screw-type or Cage Clamp terminals to attach to contactors to switch motors. They are available in the following formats:

- At the front 1 to 4-pole for frame sizes S00 to S3
- At the side: 2-pole for frame sizes S0 to S3

Different auxiliary switch blocks can be added to the 3RT1 basic units, depending on the application:

The following can be snapped onto the front of the contactors:

- Frame sizes S00 to S3: a 4-pole auxiliary switch block

or

- Frame sizes S0 to S3: up to four 1-pole auxiliary switch blocks

##### Frame sizes S0 to S3

If the depth of the installation space is limited, 2-pole auxiliary switches can be attached on the right and left side in frame sizes S0 to S3.

If 1-pole auxiliary switch blocks are used, note the location ID on the contactor.

#### 1-pole/2-pole auxiliary switch blocks

1 or 2-pole auxiliary switch blocks that can be connected from above or below make the wiring simple and straightforward when setting up feeders. These auxiliary switch blocks are only available with a screw-type terminal. We recommend with the circuit breaker/contactors combination that you use auxiliary switch blocks that are connected from below. In the case of the contactor/overload relay combination, an auxiliary switch connected from above is more suitable.



### Electronically optimized auxiliary switch blocks

The electronically optimized auxiliary switch blocks contain enclosed switching elements that are particularly suitable for switching low voltages and currents (hard gold-plated contacts) as well as for use in dusty atmospheres. The rated operational current is  $I_e/AC-14$  and DC-13: 1 to 300 mA, voltage: 3 to 60 V.

The electronically optimized auxiliary switch blocks are available as screw-type or Cage Clamp terminal types:

- Frame size S00 (3RH1911-.NF.): Has two enclosed auxiliary contacts (1 NO contact + 1 NC contact, 2 NO or 2 NC contacts)
- Frame sizes S0 to S3 (3RH1921-.FE22): Has two enclosed auxiliary contacts and two standard auxiliary contacts, each 1 NO contact + 1 NC contact
- The switched current is in acc. with the VDE 0435 regulation for relays.

### Auxiliary contacts

The following table gives you an overview of all the available auxiliary contacts:

Auxiliary contacts and attachable accessories	Frame size S00	Frame sizes S0 to S3
Integrated auxiliary contact	1 integrated auxiliary contact	---
4-pole auxiliary switch	Attachable at the front	Attachable at the front
2-pole auxiliary switch	Attachable at the front	---
1-pole auxiliary switch	---	Attachable at the front
1-pole auxiliary switch (infeed from 1 side)	Attachable at the front	---
2-pole auxiliary switch (infeed from 1 side)	Attachable at the front	Attachable at the front
2-pole auxiliary switch	---	Attachable at the side
Time-delay auxiliary switch blocks	Attachable at the front	Attachable at the front
Electronically optimized auxiliary switches	Attachable at the front	Attachable at the front

Table 3-22: Auxiliary switch blocks

### Adding to the auxiliary contacts

- The 3RT10 basic units of frame size S00 with an integrated auxiliary contact can be supplemented with up to 4 contacts using attachable auxiliary switches.
- The basic units of frame sizes S0 to S3 do not have any auxiliary switches, but auxiliary switches can be attached at the front or the side.

The following table shows you the expansion options for the different frame sizes:

Frame size	Auxiliary switch block	Connection
S00	1, 3 and 4-pole (attachable at the front)	Screw-type/Cage Clamp terminal
	Feeder auxiliary switch (attachable at the front): <ul style="list-style-type: none"> <li>• 1-pole (1 NO or 1 NC contact)</li> <li>• 2-pole (1 NO + 1 NC or 2 NO contacts)</li> </ul> Infeed from above or below possible	Screw-type terminal
S0 to S3	1, and 4-pole (attachable at the front) 2-pole (attachable at the side)	Screw-type/Cage Clamp terminal Screw-type terminal
	Feeder auxiliary switch (attachable at the front): <ul style="list-style-type: none"> <li>• 2-pole (1 NO + 1 NC contact)</li> <li>• 2-pole (2 NO or 2 NC contacts)</li> </ul> Infeed from above or below possible	Screw-type terminal

Table 3-23: Expansion options for auxiliary switch blocks

**Auxiliary switch at front**

Auxiliary switches that can be attached at the front are hooked into the opening of the contactors and pulled down until they snap into place. They can be removed using the release lever in the middle.




Figure 3-31: Auxiliary switch at front

### Auxiliary switches at side (S0 to S3)

The auxiliary switches are hooked onto the left or right side of the contactor and snapped onto it. They are removed again by pressing the ribbed surfaces.




Figure 3-32: Auxiliary switch at side

### Note

When you use two 2-pole, auxiliary switches at the side, you must attach an auxiliary switch block on the left and right in the interests of symmetry.

### Maximum number of auxiliary switches

The following table shows you the maximum number of auxiliary switches and their combination options:

#### Frame size S0 and S2 (3RT102./3RT103.)




1 auxiliary contact element	4 auxiliary contact elements	2 auxiliary contact elements	A maximum of 4 auxiliary contacts can be attached, and you can use any type of auxiliary switch. When you use two 2-pole, auxiliary switch blocks at the side, you must attach a block on the left and right in the interests of symmetry. In some situations, it is permissible to have more auxiliary contacts in frame size S2 (for more details, please contact Technical Assistance).
			
Max. 4	0	0	
Max. 2	0	1	
0	1	0	
0	0	1+1	

Table 3-24: Possible auxiliary switch combinations (frame size S0/S2)

#### Frame size S3 (3RT104./3RT14)




1 auxiliary contact element	4 auxiliary contact elements	2 auxiliary contact elements	A maximum of 8 auxiliary contacts can be attached. Please note the following: Of these 8 auxiliary contacts, a maximum of four can be NC contacts. Symmetry must be preserved in the case of auxiliary switch blocks attached at the side.
			
4	0	1+1	
0	1	1+1	
0	0	2+2	

Table 3-25: Possible auxiliary switch combinations (frame size S3)

**Contactors with 4 main contacts and capacitor-switching contactors**

	S00	S0	S2/S3
Contactors with 4 main contacts	4 auxiliary contacts	Maximum of 2 auxiliary contacts (attached at the side or snapped on at the top)	Maximum 4 auxiliary contacts (attached at the side or snapped on at the top)
Capacitor-switching contactors	An additional 2-pole auxiliary switch block on each side (3RH1921-1EA.: 2 NO, 2 NC or 1 NO + 1 NC contact)		

Table 3-26: Possible auxiliary switch combinations with 4-pole/capacitor-switching contactors

**Switching of the auxiliary contact elements**

With the standard type of auxiliary switch, when the contactors are switched on, first the NC contacts are opened and then the NO contacts are closed.




Figure 3-33: Switching of the auxiliary contact elements

**Auxiliary contact elements with make-before-break contacting**

S00	Auxiliary switch type	S0 - S3	Auxiliary switch type
3RH1911-1FC22	22U, 2 NO + 2 NC contacts Screw-type terminal	3RH1921-1FC22	22U, 2 NO + 2 NC contacts Screw-type terminal
3RH1911-1FB11	11U, 1 NO + 1 NC contact Screw-type terminal		
3RH1911-1FB22	11/11U. 1 NO+1 NC+1PS 1) +1lagging NC contact Screw-type terminal		
3RH1911-2FC22	22U, 2 NO + NC contact Cage Clamp		
3RH1911-2FB11	11U, 1 NO + 1 NC contact Cage Clamp	3RH1921-1CD10	1 NO contact, leading Screw-type terminal
		3RH1921-1CD01	1 NC contact, lagging Screw-type terminal
		3RH1921-2FC22	22 U, 2 NO + 2 NC Cage Clamp

Table 3-27: Auxiliary switches with make-before-break contacting  
1) Leading NO contact

---

### 3.4.1.1 Terminal markings of the contactors (frame sizes S00 to S3)

In contactors of frame size S00 with an integrated auxiliary contact, the terminal marking complies with EN 50 012. This also applies to contactors of frame sizes S0 to S3 with an attached auxiliary switch block (2 NO + 2 NC contacts) that are available as complete systems.

#### Expanding the contactors of frame size S00

All the contactors of frame size S00 (3 and 4-pole) can be expanded with auxiliary switch blocks with the identification numbers 40 to 02 in acc. with EN 50 005 as follows:

- Frame size S00 with an integrated auxiliary contact (identification number 10E or 01) for contactors with 3 or 5 auxiliary contacts
- Frame size S00 with 4 main contacts for contactors with 2 or 4 auxiliary contacts

---

#### Note

The identification numbers on the auxiliary switch blocks only apply to the attached auxiliary switches.

---

#### Expanding the contactors with 1 integrated NO contact, S00 (3RT101-...01)

Contactors with one NO contact as an auxiliary contact with screw-type or Cage Clamp terminals, identification number 10E, can be expanded with auxiliary switch blocks with terminal markings in acc. with DIN EN 50 012 for contactors with 2, 4, and 5 auxiliary contacts. The terminal markings of the complete contactors comply with EN 50 012. The identification numbers 11E, 22E, 23E, and 32E on the auxiliary switch blocks apply to the complete contactors.

---

#### Important

Auxiliary switch blocks in acc. with EN 50 012 can only be combined with contactors of frame size S00 that have 1 NO contact in the basic unit because they are coded. These auxiliary switch blocks cannot be combined with contactors that have an NC contact in the basic unit (identification number 01).

---

**Auxiliary contacts S00**

The following graphic shows you the auxiliary contacts that can be used to expand the contactors of frame size S00 (terminal marking in acc. with EN 50 012 or EN 50 005):




Figure 3-34: Auxiliary contacts, contactors for switching motors (frame size S00)

**Expanding the contactors of frame sizes S0 to S3**

With contactors of frame sizes S0 to S3, you can also attach 1-pole auxiliary switch blocks instead of 4-pole auxiliary switch blocks. The terminal markings of the 1-pole auxiliary switch blocks consist of sequence numbers (location ID) on the basic unit and function numbers on the auxiliary switch blocks.

### Auxiliary contacts S0 to S3

The following graphic shows you the auxiliary contacts that can be used to expand the contactors of frame sizes S0 to S3 (terminal marking in acc. with EN 50 005 or EN 50 012):

#### 4-pole auxiliary switch blocks

#### 1-pole aux. switch blocks




Figure 3-35: Auxiliary contacts, contactors for switching motors (frame sizes S0 to S3)

### 3.4.1.2 Terminal markings of the contactors and auxiliary contactors combined with auxiliary switch blocks

#### Terminal markings in acc. with EN 50 005

The terminal markings for contactors are defined in EN 50 005 that contains general directives. The following summarizes the basic rules that apply to switching elements of auxiliary circuits:

- The terminals of auxiliary contact elements are designated by two-digit numbers.
- The digit in the unit place is a function number (NC contact: 1 and 2, NO contact: 3 and 4).
- The digit in the tens place is a sequence number (all the switching elements of the same function must have different sequence numbers).

#### Identification numbers (DIN EN 50 005)

The identification numbers mean:

Switching devices with a fixed number of auxiliary contact elements (NO contacts or NC contacts) can be assigned a two-digit identification number. The first digit represents the number of NO contacts and the second one the number of NC contacts.

There is no information on the sequence of NO contacts and NC contacts in the contactor/auxiliary contactor.

#### Note

The identification numbers on the auxiliary switch blocks only apply to the attached auxiliary switches.

**EN 50 012/  
EN 50 011**

For certain equipment such as auxiliary contact elements of contactors and auxiliary contactors, the EN 50 012 and EN 50 011 standards also apply. The EN 50 012 defines the terminal markings and identification numbers for auxiliary contact elements of particular contactors. The terminal markings of the auxiliary contact elements match the terminal markings of corresponding auxiliary contactors with the ID letter E (in acc. with EN 50 011). For auxiliary contact elements of contactors with the same identification number, the terminal marking must correspond to the sequence defined in the standard.

**Graphical symbols for auxiliary contact elements**

Below are some examples of graphical symbols for auxiliary contact elements of contactors that comply with EN 50 012:









Coil	Main contact elem.	ID no.	Auxiliary contact elements	ID no.	Auxiliary contact elements	ID no.	Auxiliary contact elements
		31		22		13	
		41		32		23	


Figure 3-36: Graphical symbols for auxiliary contact elements in acc. with EN 50 012 (excerpt)

**Device circuit diagrams**


The following device circuit diagrams of the auxiliary switch blocks for contactors that switch motors contain the terminal markings in acc. with EN 50 012:

**3RT101 contactors**


2 NO + 2 NC contacts  
Identification number: 22E



2 NO + 3 NC contacts  
Identification number: 23E




3 NO + 2 NC contacts  
Identification number: 32E




**Contactors 3RT102, 3RT103, 3RT104, 3RT1446**

2 NO + 2 NC contacts  
Identification number: 22




**4-pole auxiliary switch blocks 3RH1921-1HA.., can be snapped onto the front**

3 NO contacts + 1 NC contact  
Identification no.: 31E



2 NO + 2 NC contacts



1 NO + 3 NC contacts




Figure 3-37: Device circuit diagrams of the auxiliary switch blocks (DIN EN 50 012)



### 3.4.1.3 Auxiliary switches that can be attached to 3RH1 auxiliary contactors

The 3RH1 auxiliary contactors can be expanded by up to 4 contacts using attachable auxiliary switch blocks.

**Definition:  
EN 50 011**

The main standard for the designation of switching elements for the auxiliary contactors is EN 50 011, which defines the terminal markings, identification numbers, and identification letters of certain auxiliary contactors using a specific sequence of the switching elements. The number, type, and position of the switching elements must be specified using an identification number followed by an identification letter.

In the case of 8-pole auxiliary contactors, the letter "E" means that four NO contacts have to be arranged on the lower (rear) contact level.

**Expansion using auxiliary switch blocks**

The following example of an auxiliary contactor with 4 NO contacts (contact designation in acc. with EN 50 011 and EN 50 005) explains how auxiliary switch blocks are added on:




Figure 3-38: Auxiliary contacts for auxiliary contactors

**Contact designation**

Auxiliary switch blocks - for example, 3RH1911-1GA22 (2 NO + 2 NC contacts) in acc. with EN 50 011 - can only be attached to auxiliary contactors with 4 NO contacts (3RH1140-..... ) because they are coded. The identification number (62E) printed on the auxiliary switch block (6 NO + 2 NC contacts) applies to the whole contactor.

NO and NC contacts are in the same position on all the auxiliary contactors with the identification number 62E (DIN EN 50 011).

This means contactors can be replaced without changing the wiring, which therefore makes wiring very easy. You can attach auxiliary switch blocks that comply with EN 50 005 on all 3RH11 auxiliary contactors and 3RT101 motor contactors. For example, the 3RH1911-1FA22 auxiliary switch block (2 NO + 2 NC contacts) has the identification number 22, and this only applies to the attached auxiliary switch block.

**Graphical symbols of the auxiliary contactors**

Below are some examples of graphical symbols for auxiliary contactors with the identification letter E that comply with EN 50 011:





Figure 3-39: Graphical symbols for auxiliary contactors in acc. with EN 50 011 (excerpt)


**Device circuit diagrams**

The following device circuit diagrams of the auxiliary contactors contain terminal markings in acc. with EN 50 011:


4 NO contacts  
Identification number: 40 E




3 NO contacts + 1 NC contact  
Identification number: 31 E




2 NO + 2 NC contacts  
Identification number: 22 E




8 S  
Identification number: 80 E




7 NO contacts + 1 NC contact  
Identification number: 71 E



6 NO + 2 NC contacts  
Identification number: 62 E



5 NO + 3 NC contacts  
Identification number: 53 E



4 NO + 4 NC contacts  
Identification number: 44 E




Figure 3-40: Device circuit diagrams

**Position diagrams**

The following position diagrams of the auxiliary switches of frame sizes S00 to S3 also apply to leading and lagging contacts:




Figure 3-41: Position diagrams of the auxiliary switches (frame sizes S0 to S3)

### 3.4.2 Time-delay auxiliary switches

**Variants**

The following variants of the time-delay auxiliary switch are available:

- On-delay
- Off-delay without auxiliary supply
- Star-delta function

**On-delay and off-delay functions**

The time-delay auxiliary switch in the on-delay or off-delay variants has the following features:

- It facilitates time-delayed functions up to 100 s
- 3 single time areas
- Contains a relay with 1 NO contact and 1 NC contact that switches the on-delay or off-delay depending on the version.

**Star-delta function**

The time-delay auxiliary switch with star-delta function has the following features:

- Equipped with a delayed and an instantaneous NO contact between which there is an idle time of 50 ms.
- The delay time of the NO contact can be set at between 1.5 s to 30 seconds.
- The contactor on which the time-delay auxiliary switch block is mounted functions instantaneously.

**Conductor cross-sections**

The permissible conductor cross-sections correspond to the auxiliary conductor terminals of the corresponding frame size.

#### 3.4.2.1 Frame size S00 (3RT1916-2E, -2F, -2G)

**Description**

The time-delay auxiliary switch of frame size S00 has the following features:

- The power supply is provided using plug-in contacts directly via the coil connections of the contactors, parallel to A1/A2.
- The time function is activated when the contactor that has the auxiliary switch block mounted on it is switched on.
- The off-delay version functions without an auxiliary supply.
- The minimum on-time is 200 ms.
- To dampen switching overvoltages of the contactor coil, a varistor is integrated in the time-delay auxiliary switch of frame size S00.

**Information on mounting**

---

**Note about the off-delay without auxiliary supply function:**

The position of the output contacts is not defined at shipment (bistable relay). Apply the control supply voltage once, and then switch it off again to set up the initial state of the contacts.

---


**Important**

The time-delay auxiliary switch cannot be built onto contactor relays.

**Installation/removal**

**Caution**

Switch off the supply voltage to A1/A2 before you install or remove the time-delay auxiliary switch block.



The time-delay auxiliary switch is attached to the front of the contactor.

Figure 3-42: Time-delay auxiliary switch block (frame size S00)

**Connection**

When they are attached, the connections for the rated control supply voltage are connected to the contactor below by the integrated spring contacts of the time-delay auxiliary switch.

**Function diagrams**




Figure 3-43: Function diagrams of the time-delay auxiliary switches (frame size S00)

### 3.4.2.2 Frame sizes S0 to S3 (3RT1926-2E, -2F, -2G)

#### Description

The time-delay auxiliary switch for frame sizes S0 to S3 has the following features:


- The power supply of the time-delay auxiliary switch is via 2 terminals (A1/A2).
- The time delay for the time-delay auxiliary switch can be activated by parallel connection to any contactor coil, or by any source of voltage.
- The off-delay version works without an auxiliary supply.
- The minimum on-time is 200 ms.
- In addition to the time-delay auxiliary switch, a 1-pole auxiliary switch block can be snapped onto the front of the contactor.
- The time-delay auxiliary switch does not have any integrated overvoltage damping for the contacted contactor.

#### Information on mounting

##### Note about the off-delay without auxiliary supply function:

The position of the output contacts is not defined at shipment (bistable relay). Apply the control supply voltage once, and then switch it off again to set up the initial state of the contacts.

#### Installation/removal



The time-delay auxiliary switch is attached to the front of the contactor.

Figure 3-44: Time-delay auxiliary switch block (frame sizes S0 to S3)

#### Connection

The A1 and A2 terminals for the rated control supply voltage of the time-delay auxiliary switch are connected to the respective contactor with cables.

#### Terminal markings

Because an additional auxiliary switch block can be snapped onto the contactor, the terminals of the delayed contacts have been designated as -5/-6 (NC contact) and -7/-8 (NO contact).

## Function diagrams




Figure 3-45: Time-delay auxiliary switches, function diagrams (frame sizes S0 to S3)

### 3.4.3 Solid-state time relay blocks with semiconductor output

The solid-state time relay blocks are suitable for AC and DC operation. To dampen switching overvoltages of the contactor coil, a varistor is integrated.

#### Variants

The following variants of the time-delay auxiliary switch are available:

- On-delay (integrated varistor)
- Off-delay with auxiliary supply (integrated varistor)

#### On-delay and off-delay functions

The time-delay auxiliary switch in the on-delay or off-delay with an auxiliary supply variants has the following features:

- It facilitates time-delayed functions up to 100 seconds.
- 3 individual time ranges
- Contactors with a solid-state time relay block close and open with a delay according to the time set.

#### Connection: on-delay time relay block

The on-delay time relay block is connected in series to the contactor coil; the A1 terminal of the contactor coil must not be connected.

#### Connection: off-delay time relay block

When an off-delay time relay block is attached, the contactor coil is contacted via the time relay block; the A1 and A2 terminals of the contactor coil must not be connected.


#### Conductor cross-sections

The permissible conductor cross-sections correspond to the auxiliary conductor terminals of the corresponding frame size.

**Notes on configuration**

The control of loads parallel to the start input is not permissible in AC operation. See the relevant circuit diagram ① below.

The off-delay solid-state time relay blocks (3RT1916-2D.../3RT1926-2D...) have a live start input (B1). With AC voltage, this can imitate the control of a parallel load on the B1 terminal. In this case, an additional load (contactor K3, for example) should be wired as shown in circuit diagram ②.



K1 time relay block  
K2 contactor

Figure 3-46: Control of loads

**3.4.3.1 Frame size S00 (3RT1916-2C, -2D)**

**Caution**

Switch off the supply voltage to A1/A2 before you install or remove the solid-state time relay block.


**Installation/removal**

**Important**

The time-delay auxiliary switch cannot be attached to contactor relays.

The solid-state time relay block of frame size S00 is attached to the front of the contactor and latched into place with a pushing movement.

Installation



Removal




Figure 3-47: Solid-state time relay block with semiconductor output, installation (frame size S00)


**Connection**

When the solid-state time relay block is installed, it is connected at the same time with the A1 and A2 coil connections of the contactor by the plug-in contacts. Coil connections of the contactor that are not required are covered by covers on the housing of the time relay block, thus preventing inadvertent connection.



**Function diagrams**

3RT1916-2C, on-delay



3RT1916-2D, off-delay






Figure 3-48: Solid-state time relay block with semiconductor output, function diagrams (frame size S00)

**Circuit diagrams**

3RT1916-2C  
on-delay



3RT1916-2D  
off-delay with auxiliary supply



K1 Solid-state time relay block  
K2 Contactor  
**X** Connection prohibited!

Figure 3-49: Solid-state time relay with semiconductor output, circuit diagrams (frame size S00)


**3.4.3.2 Frame size S0 to S3 (3RT1926-2C, -2D)**

**Note on configuration**

**Caution**

The solid-state time relay block with a semiconductor output (3RT1926-2C, -2D) must not be used for 3RT104 contactors of frame size S3 with  $U_S \leq 42$  V because the coil current used for the output semiconductor is too high.  
The solid-state time relay block must not be attached to the lower coil connections.

**Installation/removal**




The solid-state time relay block for the contactors of frame sizes S0 to S3 is attached at the top on the A1 and A2 coil connections of each contactor, connecting the time relay electrically and mechanically with pins.

Figure 3-50: Solid-state time relay with a semiconductor output, installation (frame size S00)


**Circuit diagrams**

3RT1926-2C  
on-delay



K2:3RT102.  $U_S = 24\text{ V to }240\text{ VAC/DC}$   
 3RT103.  $U_S = 24\text{ V to }240\text{ VAC/DC}$   
 3RT104.  $U_S = 48\text{ V to }240\text{ VAC/DC}$

3RT1926-2D  
off-delay with auxiliary supply



K2:3RT102.  $U_S = 24\text{ V to }240\text{ VAC/DC}$   
 3RT103.  $U_S = 24\text{ V to }240\text{ VAC/DC}$   
 3RT104.  $U_S = 48\text{ V to }240\text{ VAC/DC}$


✘ Connection prohibited!

- - - Can be connected if required

Figure 3-51: Solid-state time relay with semiconductor output, circuit diagrams

**Function diagrams**

3RT1926-2C..1, on-delay



3RT1926-2D..1, off-delay




Figure 3-52: Solid-state time relay with semiconductor output, function diagrams

**3.4.4 Additional load module (3RT1916-1GA00)**

**Field of application**

The additional load module for the contactors of frame size S00 is used to increase the permissible residual current and to limit the residual voltage of SIMATIC semiconductor outputs.

**Mode of operation**

Malfunctions can sometimes occur when SIRIUS contactors and auxiliary contactors of frame size S00 work together with SIMATIC output modules whose residual current at signal "0" is higher than is permissible for the contactors of frame size S00. The maximum permissible residual current of the electronic components is 3 mA for contactors of frame size S00 with a 230 VAC drive, and in the case of higher residual currents, the contactors no longer drop down.

The additional load module is used to ensure the safe switching off of S00 contactors in the case of direct control by programmable controllers via 230 VAC semiconductor outputs.

The additional load module takes on the function of overvoltage damping at the same time.

<b>Technical specifications</b>	Rated voltage	AC 50/60 Hz 180 V to 255 V
	Rated output power	1.65 W at 230 V
	Permissible contactor types	3RT1.1 3RT1.
	Associated coil type	P0 (230 V, 50/60 Hz) N2 (220 V, 50/60 Hz) P6 (220 V, 50Hz/240 V, 60 Hz)
	Operating range	0.8 to 1.1 Us

**Installation** The additional load is connected in parallel to the contactor coil. It has the same construction as the surge suppressor and is attached on the front of the contactors with or without an auxiliary switch block.

### 3.4.5 Coupling element for frame sizes S0 to S3 (3RH1924-1GP11)


**Field of application** The 3RH1924-1GP11 coupling link is intended for contactors of frame sizes S0 to S3. It can be controlled by a programmable controller output because the operating range of 17 to 30 VDC is permissible.

**Mode of operation** A contactor of frame size S0 to S3 can be controlled, for example, at 24 VDC with a low control level (< 0.5 W) from a programmable controller output. The control voltage for the coupling link and the rated control supply voltage for the contactor are electrically isolated. An LED indicates the switching state of the coupling link. To dampen switching overvoltages of the contactor coil, a varistor is integrated in the coupling link.

#### Installation

#### Caution

Switch off the supply voltage applied to L1 and N before installation.




The coupling link is inserted with its two integrated mounting pins directly onto the coil connections of the contactor.

Figure 3-53: Coupling link (frame sizes S0 to S3)

#### Conductor cross-sections

The permissible conductor cross-sections correspond to the auxiliary conductor terminals of the corresponding frame size.

### Circuit diagram



K1 Coupling link  
K2 Contactor

B1+/B2-: Control voltage 24 VDC

L1/N: Rated control supply voltage for the selected contactor

Figure 3-54: Coupling link, circuit diagram (frame sizes S0 to S3)

### Technical specifications

You can find the technical specifications of the coupling link in Section 3.6, Technical specifications.

### 3.4.6 Surge suppression

When contactor coils are disconnected, overvoltage occurs (inductive load). Voltage peaks of up to 4 kV with a rate of rise in voltage of 1 kV/ms can result (showering arcs).

The consequences of this are:

- Heavy contact erosion and thus premature wearing of the contacts that switch the coil
- Unwanted signals can occur that may cause false signals in electronic controllers.

All contactor coils, therefore, should be damped against switching overvoltages, particularly when working with electronic controllers.

### Oscillograms

The following oscillograms illustrate the behavior at disconnection of contactor coils with and without overvoltage damping:

### Unused coil




Figure 3-55: Disconnecting an unused contactor coil

Oscillogram of a disconnection of the coil of an auxiliary contactor. The coil is not used:

Showering arcs can be clearly seen (voltage peaks of up to approximately 4 kV). After the disconnection procedure has been started, showering arcs occur for approximately 250 microseconds, and after that the oscillation is merely damped.

## Varistor




Figure 3-56: Circuit with a varistor (AC/DC operation)

This is what happens when a coil is disconnected that is connected to a varistor (voltage-dependent resistor):

Voltage peaks still occur. They are cut off at approximately 400 V and have a shorter overall duration (approximately 50 microseconds).

(Note: The oscillogram is cut off, and the voltage is reduced to zero after approximately 3 ms.)

A varistor is suitable for AC and DC operation.

The off-delay of the contactor is extended by approximately 2 to 5 ms.

## RC element




Figure 3-57: Circuit with an RC element (AC/DC operation)

This is what happens when a coil is disconnected that is connected to an RC element:

The amplitude and rate of rise of the switching overvoltage are reduced by the capacitor. Showering arcs no longer occur. The voltage swings briefly to 400 V and then slowly drops down. This represents ideal damping.

Disadvantage: The component is larger and generally more expensive.

RC elements are suitable for AC and DC operation.

Only a minimal off-delay occurs (under 1 ms).

**Diode**




Figure 3-58: Circuit with a diode (AC/DC operation)

This is what happens when a coil is disconnected that is connected to a diode:

Advantages: No overvoltage occurs during disconnection. The diode block becomes effective at 0.6 V.

Disadvantage: The diode can only be used for DC operation.

The break time of the contactor is considerably increased and amounts to 6 to 9 times the off-delay.

This increased break time can be used, if necessary, for control purposes, such as for bridging brief interruptions in voltage.

Zener diodes (diode combinations) are available for shorter break times. The break time then amounts to 2 to 6 times the off-delay.

**Surge suppressors**

The following surge suppressors are available for the 3RT1 contactors:

Surge suppressor	With LED		Without LED	
	For S00	For S00	For S0	For S2, S3
Suppression diode	x	x	--	--
Diode combination: suppression diode and Zener diode	--	x	x	x
Varistor	x	x	x	x
RC element	--	x	x	x

Table 3-28: Surge suppressor

**Selection aid**

The following table gives you a comparison of the effects of the different surge suppressors:





Surge suppressor	Suitable for control supply voltage	Overvoltage is limited	Effect
Suppression diode/ flywheeling diode 	DC	0.6 V	<ul style="list-style-type: none"> <li>Off-delay is considerably greater (6 to 10 times)</li> <li>A two-stage drop<sup>1)</sup> cannot be ruled out in the case of contactors as of frame size S0</li> </ul>
Diode combination: suppression diode Zener diode 	DC	To Zener voltage	<ul style="list-style-type: none"> <li>Off-delay is greater (2 to 6 times)</li> <li>A 2-stage drop no longer occurs</li> </ul>
Varistor 	AC/DC	To varistor voltage (current-dependent)	<ul style="list-style-type: none"> <li>Off-delay is only slightly greater (2 to 5 ms)</li> </ul>
RC element 	AC/DC	Corresponds to the dimensioning	<ul style="list-style-type: none"> <li>Off-delay remains unchanged</li> <li>Rate of rise in voltage is damped</li> </ul>


Table 3-29: How surge suppressors work

- 1) The rate of drop is reduced once or twice to zero for a few ms:
- A safe drop is always ensured in the case of switching without current.
  - The contact pieces are subjected to a greater thermal load when switching with current. When switching at the upper current limit, this can result in overload.




## Installation

### Frame size S00



The surge suppressor is attached on the front of the contactors. There is space next to the attached auxiliary switch block. The direction of for attachment is defined by a code.

### Frame sizes S0 to S3



Varistors, RC elements, and diode combinations can either be inserted and snapped on from above or below directly onto the coil terminals.

To remove them, press the varistors, RC elements, and diode combinations forwards, and remove them from the recess.

Figure 3-59: Surge suppressors, installation

### Installation instructions for frame sizes S0 to S3

#### Important

The 3RT1926-1E.00 diode combination is inserted from above. The direction of attachment is defined by a code.

Alternatively, the 3RT1926-1T.00 diode combination can be inserted from below. The direction of attachment is not coded, but the terminals are marked with "+" and "-" so that the direction is clear.

**Circuit diagrams**




Figure 3-60: RC element/varistor, circuit diagrams

**3.4.7 Other accessories**

**3.4.7.1 LED module for indicating contactor control (3RT1926-1QT00)**

**Description**

The LED module can be connected to the coil terminals of the contactors of frame sizes S0 to S3. It indicates the status of the contactors by means of yellow LEDs.

**Mode of operation**

The LED module can be used for AC/DC voltages of 24 V to 240 V. The LEDs are connected bidirectionally to protect against polarity reversal. Both LEDs light up in AC control, and one lights up in DC control, depending on the polarity.

**Connection**

The LED module is connected to the A1 and A2 coil terminals of the contactor.

**Installation**

The LED module is snapped onto the front in the openings intended for the inscription plate.




Figure 3-61: LED module

**3.4.7.2 Auxiliary connecting lead terminal, 3-pole (for frame size S3)**

Using the 3-pole auxiliary lead terminal, auxiliary and control cables can be connected to the main cable terminals.

Conductor cross-sections of auxiliary connecting leads that can be connected:

Screw-type terminals (1 or 2 conductors can be connected)		
Single-core	mm <sup>2</sup>	2 x (0.5 to 1.5); 2 x (0.75 to 2.5) in acc. with IEC 60 947; Max. 2 x (0.75 to 4)
Finely stranded with wire end ferrule	mm <sup>2</sup>	2 x (0.5 to 1.5); 2 x (0.75 to 2.5)
AWG cables, single- or multi-core	AWG	2 x (20 to 16); 2 x (18 to 4); 1 x 12
Terminal screws	M3	
Tightening torque	Nm	0.8 to 1.2 (7 to 10.3 lb.in)

Table 3-30: Conductor cross-sections of 3-pole auxiliary connecting lead terminals (for frame size S3)

**3.4.7.3 EMC module (3RT1916-1P.)**

In the case of motors or various inductive loads, back-e.m.f (electromotive force) is produced at disconnection. This can produce voltage peaks of up to 4000 V with a frequency range of 1 kHz to 10 MHz and a rate of voltage variation of 0.1 to 20 V/ns.

Capacitive coupling to various analog and digital signals makes suppression necessary in the load circuit.

**Description**

The connection of the main conducting path to the EMC suppression module reduces the contact sparking that is responsible for contact erosion and many of the clicks, which in turn supports an EMC-compatible configuration.

**Mode of operation**

The EMV suppression module reduces through 3 phases the radio-frequency parts and the voltage peaks. The advantages of this are as follows:


- Longer service life of the contact pieces
- Higher operational reliability and high system availability

A fine grading within the performance class is not required because smaller motors have greater inductance due to their construction, and one EMC suppression module is thus sufficient for all non-stabilized drives up to 5.5 kW.

**Variants**

Two electrical variants are available:

- RC circuit
- Varistor switching

**Installation**

The EMC suppression module is attached to the underside of the contactor. To do this, hook the EMC suppression module with both hooks onto the contactor, and push it upward until the connection pins of the EMC module are firmly in place in the terminal openings of the contactor.

Figure 3-62: EMC suppression module

**RC circuit**

The RC circuit is suitable:

- For reducing the rate of rise
- In RF damping

Effective suppression can be achieved for a wide range of applications.

**Varistor circuit**

A varistor circuit can absorb a high level of energy and can be used for frequencies from 10 to 400 Hz (stabilized drives). There is no limit below the buckling stress.

### 3.4.7.4 Soldering pin connector for frame size S00


#### Description

The standard contactors of frame size S00 in the SIRIUS range can be soldered onto printed circuit boards by means of the soldering pin adapter.

Soldering pin connection is possible:

- For contactors with an integrated auxiliary contact
- For contactors with an attached 4-pole auxiliary switch block
- For the reversing wiring of the S00 contactors. This involves carrying out the reversing wiring before soldering it on the printed circuit board

#### Mounting main contacts



The soldering pin connectors are inserted above and below in the screw-type terminals of the contactors.

Figure 3-63: Soldering pin connection, mounting

#### Mounting on 4-pole auxiliary switch block




Figure 3-64: Mounting the soldering pin connection on a 4-pole auxiliary switch block

**Removing the spring**

If necessary, the spring for attachment to the rail can be removed before the soldering pin connection is mounted.




Figure 3-65: Removing the spring from the soldering pin connection

### 3.4.7.5 Parallel connections

If the conducting paths of multipole switching devices are connected in parallel, the total current is distributed to the individual conducting paths according to their ohmic resistance and the inductive effect they have on each other. The ohmic resistance is mainly formed by the transfer resistance at the contact pieces, the value of which can be changed by contact erosion and oxidation. The distribution of current is therefore neither even or stable: Individual conducting paths can be overloaded and the overload release or overload relay may be prematurely triggered (triggering fault).

#### Permanent load in parallel connection

The following applies to permanent loads in the case of parallel connection unless specified otherwise in the catalogs:

- When three conducting paths are connected in parallel, 2.5 times the amount of continuous current can be applied, and when two conducting paths are connected in parallel, 1.8 times the continuous current can be applied. Make sure, however, that the making and breaking capacity do not increase because the contact pieces do not close and open at the same time, and therefore the contact pieces in a conducting path have to switch the entire making and breaking current.
- The wiring must be routed in such a way that each conducting path has the same line length.
- Any short-circuit current is distributed in proportion to the conducting path resistances.

**Important:** The operating current of electromagnetic, instantaneous short-circuit releases is not reached.

#### Making/breaking capacity

You can find out the making and breaking capacity of contactors in relation to the load currents in the parallel connection of two or three conducting paths from the following table:





				
	3-pole switching <sup>1)</sup>	2 conducting paths in parallel <sup>1)</sup>	3 conducting paths in parallel <sup>1)</sup>	4 conducting paths in parallel <sup>1)</sup>
Making capacity:	12 x I <sub>e</sub> (utilization category AC -4)	$\frac{12 \cdot I' e}{1,8} = 6,67 \cdot I' e$	$\frac{12 \cdot I'' e}{2,5} = 4,8 \cdot I'' e$	$\frac{12 \cdot I'' e}{3,1} = 3,9 \cdot I'' e$
Breaking capacity	10 x I <sub>e</sub> (utilization category AC -4)	$\frac{10 \cdot I' e}{1,8} = 5,55 \cdot I' e$	$\frac{10 \cdot I'' e}{2,5} = 4,0 \cdot I'' e$	$\frac{10 \cdot I'' e}{3,1} = 3,2 \cdot I'' e$

Table 3-31: Parallel links making and breaking capacity

1) Voltage at each clearance between open contacts:

$$U = \frac{U_e}{\sqrt{3}}$$

**Variants**

The following variants of parallel connections are available:

Frame size	Variants
S00 to S3	3-pole, without terminal (star-point link) <sup>2)</sup>
S00 to S3	3-pole with terminal
S00	4-pole with terminal

Table 3-32: Parallel connections Variants

2) Accessories for star-delta combinations

**Installation**

The parallel connections can be each shortened by one pole.

**3.4.7.6 Covers for frame sizes S2 and S3**

To increase safety, terminal covers are available for contactors of frame sizes S2 and S3:

Variants	Function	Number required
Terminal cover for box terminals 3RT19.6-4EA2	Offers additional shock protection	2 covers per contactor are required (for the upper and lower main terminals)
Terminal cover for lug and bar connection 3RT1946-4EA1	Ensures that voltage intervals are adhered to Provides shock protection when the box terminal is removed	

Table 3-33: Covers



**Installation**

The following diagrams show you how to mount the covers:




Figure 3-66: Terminal covers

### 3.5 Mounting and connection

#### 3.5.1 Mounting

**Note**

Note the following when mounting the cover:

- If foreign bodies, such as wood shavings, can get into the device, the contactors must be covered during installation.
- If there is a danger that dirt or dust could be present, or if there is a corrosive atmosphere, the contactors must be installed in a housing.
- Dust deposits must be vacuum cleaned.


**Attachment options**

The attachment options for the contactors are uniform.

Frame size	Installation	Removal
S00 to S3	Screw-on attachment	Removed with a screwdriver
S00, S0	Snapped onto a 35 mm rail (in acc. with EN 50 022)	Removed without a tool
S2, S3	Snapped onto a 35 mm rail (in acc. with EN 50 022)	The snap-on spring can be opened with a screwdriver
S3	Snapped onto a 75 mm rail	

Table 3-34: Attachment

**Screw-on attachment**



The 3RT1 contactors can be screwed onto a flat surface.

- With 2 M4 screws, diagonal
- Maximum tightening torque 2 Nm
- Washers and spring lock washers must always be used
- The distance to grounded parts at the side must be more than 6 mm

Figure 3-67: 3RT: Screw-on attachment (frame size S00)

**Snap-on attachment on rails**

Snap-on attachment is possible:

- Frame sizes S00 to S3: on 35 mm rail
- Frame size S3: on 75 mm rail. The height of the rail must be at least 15 mm.

The following illustration shows you how to mount the device onto the rail:



Frame sizes S00 and S0	
	<p>Place the device on the upper edge of the rail, and press it downward until it snaps onto the lower edge of the rail <b>(1)</b>.</p> <p>Push the device downward to release the tension of the mounting spring, and remove the device by tilting it <b>(2)</b>.</p>
Frame sizes S2 and S3	
	<p>Place the device on the upper edge of the rail, <b>(1)</b> and press it downward toward the rail until it snaps onto the lower edge of the rail <b>(2)</b>.</p> <p>Using a screwdriver, push the lug on the lower rear side of the device downward to release the tension of the mounting spring <b>(3)</b>, and remove the device by tilting it <b>(4)</b>.</p>

Figure 3-68: Snap-on attachment

**Installation positions**

The contactors are designed for use on vertical surfaces. The following installation positions are permissible for AC and DC operation:




Figure 3-69: Installation positions

**Vertical installation position**

The following table indicates usage in a vertical installation position:

No.	Size	AC/DC	Output power	Measure
1	S00 coupler 3RT10 1.	DC	3 to 5.5 kW	Without restriction
1	S00 coupler 3RH11	DC	$I_e/AC-15$ 6 A/230 V	With 2 NO + 2 NC contacts: stronger springs, otherwise no restriction
2	S00 3RT10 1.	DC	3 to 5.5 kW	Without restriction
2	S00 3RH11	DC	$I_e/AC-15$ 6 A/230 V	Without restriction
3	S00	AC	3 to 5.5 kW/ and $I_e/AC-15$ 6 A/230 V	Special variant
4	S0 coupler	DC	5.5 to 11 kW	Special variant
5	S0	DC	4 to 11 kW	Special variant
6	S0	AC	4 to 11 kW	Without restriction
8	S2	AC	15 to 22 kW	Special variant
9	S2	DC	15 to 22 kW	Vertical installation position not possible.
10	S3	AC	30 to 45 kW	Special variant
11	S3	DC	30 to 45 kW	Vertical installation position not possible.

Table 3-35: Vertical installation position

Motor and auxiliary contacts (including the contactor relay variants) are included in frame size S00.

**Installation in series**

No derating is necessary up to an ambient temperature of 60 °C for all the contactors, even those in side-by-side installation.

In the case of contactors with an extended operating range ( $0.7$  to  $1.25 \times U_N$ ) that use a series resistor, installation in series is permissible up to an ambient temperature of +70 °C.

**3.5.2 Connection**

The SIRIUS contactors are available with the following terminal types:

- Frame sizes S00 to S3: screw-type terminals
- Contactors and auxiliary contactors of frame size S00: All the terminals are also available as Cage Clamp terminals
- Contactors of frame sizes S0 to S3: The auxiliary switches and coil connections are also available with Cage Clamp terminals.
- Accessories: screw-type and (for most of the range) Cage Clamp terminals
- The contactors of frame size S3 have removable box terminals for the main conductor terminals. This enables the connection of ring lugs or busbars.

### Screw-type terminals

The devices with screw-type terminals have the following features:

- All the connections have captive screws.
- All the terminal points are delivered in the open position.
- The screwdriver guides allow screwdriving machines to be used.
- In frame size S00, all the terminal screws for the main and auxiliary circuits have a uniform screw size (cross-tip Pozidriv 2 screws) and therefore all require the same torque.
- In all the frame sizes (S00 to S3), the terminal screws are identical for the auxiliary conductor terminals (no bit change and uniform torque).

### Cage Clamp terminals

In the variant with Cage Clamp terminals, the devices have the following features:

- The contactors are recommended if strong shaking or vibrations can be expected at the installation location.
- The terminals are also suitable for two-conductor connections
- All the terminals are accessible from the front and are easily visible.
- A maximum of two conductors with a cross-section of  $0.25 \text{ mm}^2$  up to a maximum  $2.5 \text{ mm}^2$  can be used for each terminal point.

### Cage Clamp terminals: Procedure

The following illustration shows you how to use the Cage Clamp terminals:




Figure 3-70: Cage Clamp terminals

### Insulation stop

With a conductor cross-section of  $\leq 1 \text{ mm}^2$ , an insulation stop (3RT1916-4JA02) must be used to hold the conductor insulation securely. An insulation stop line consists of 5 pairs of connection terminals. The following illustration demonstrates insertion into the Cage Clamp infeeds.




Figure 3-71: Insulation stop with Cage Clamp terminals

**Two-conductor connection**





It is possible with all the main, auxiliary, and control cable connections to connect two conductor ends. They can also be used to connect untreated conductors with different cross-sections. Box terminals each with 2 terminal points are provided for the main conductor connection in contactors of frame sizes S2 and S3.

This connection method also promises problem-free looping and parallel connection without intermediate terminals.





**Conductor cross-sections**

Permissible conductor cross-sections for main and auxiliary connections:









**S00**

	Main and auxiliary conductors	
 Ø 5 to 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	<b>Cage Clamp</b>
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )
	—	2 x (0.25 to 2.5 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)

**S0**

	Control conductor: A1/A2 Auxiliary conductor: NO/NC		Main conductor
	Screw-type terminal	Cage Clamp terminal	L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	—	2 to 2.5 Nm 18 to 22 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
	—	2 x (0.25 to 2.5 mm <sup>2</sup> )	—
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	2 x (14 to 10)

**S2**

	Control conductor: A1/A2 Auxiliary conductor: NO/NC			Main conductor
	Screw-type terminal	Cage Clamp terminal		L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	—	 Ø 5 to 6 mm / PZ2	3 to 4.5 Nm 27 to 40 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> ) 1 x (0.75 to 25 mm <sup>2</sup> )
	—	2 x (0.25 to 2.5 mm <sup>2</sup> )		2 x (0.75 to 25 mm <sup>2</sup> ) 1 x (0.75 to 35 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	<b>AWG</b>	2 x (18 to 3) 1 x (18 to 2)

**S3**









	Control conductor: A1/A2 Auxiliary conductor: NO/NC			Main conductor
	Screw-type terminal	Cage Clamp terminal		L1 L2 L3 T1 T2 T3
 Ø 5 to 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	—		4 to 6 Nm 35 to 53 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )		2 x (2.5 to 16 mm <sup>2</sup> )
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )		2 x (2.5 to 35 mm <sup>2</sup> ) 1 x (2.5 to 50 mm <sup>2</sup> )
	—	—		2 x (10 to 50 mm <sup>2</sup> ) 1 x (10 to 70 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	<b>AWG</b>	2 x (10 to 1/0) 1 x (10 to 2/0)

Table 3-36: Conductor cross-sections (frame sizes S00 to S3)

### 3.5.3 Changing the magnet coils

#### 4 coil terminals

Contactors of frame sizes S0 to S3 have 4 coil terminals.  
The advantages of this are as follows:

- Variable connection, depending on the amount of space and cable routing
- Easier wiring of feeders

The connection options are:

- From above with in fuseless configuration with circuit breakers connected above
- From below when fuses are used with an overload relay attached directly below
- Diagonal

#### Changing the magnet coils

The magnet coils can be replaced in the case of contactors of frame sizes S0 to S3.

#### S0 - AC operation

The following illustration shows the replacement of the magnet coil in frame size S0 in AC operation:

	<p>Use screwdrivers to lever up the release clips between the rear and front contactor halves and remove the front part of the contactor.</p>
	<p>Remove the magnet coil from the rear half of the contactor.</p>
	<p>Push in the new magnet coil, and put the front section of the contactor back on again. <b>Important:</b> Make sure that the springs between the magnet coil and the front contactor half sit straight on the mounting <b>(4a)</b>.</p>

Figure 3-72: Replacing the magnet coil (frame size S0/AC)



**S2 - AC operation**




	<p>Loosen the 2 screws between the rear and front contactor halves, and remove the magnet coil from the rear part of the contactor.</p>
	<p>Insert the new magnet coil.</p>
	<p>Replace the front half of the contactor, and tighten the 2 screws again.</p>


Figure 3-73: Replacing the magnet coil (frame size S2/AC)

**S2 - DC operation**


	<p>Loosen the 2 screws between the rear and front contactor halves. Loosen the two screws on the plates that attach the magnet coil to the armature, and remove the magnet coil from the rear half of the contactor.</p>
	<p>Insert the new magnet coil, and screw on the two plates again with the two screws.</p>
	<p>Replace the front half of the contactor, and tighten the 2 screws again. Make sure the springs are in their correct position.</p>

Figure 3-74: Replacing the magnet coil (frame size S2/DC)


## S3 - AC operation



Loosen the 2 screws between the rear and front contactor halves, and remove the magnet coil from the rear part of the contactor.



Insert the new magnet coil.



Replace the front half of the contactor, and tighten the 2 screws again.

Figure 3-75: Replacing the magnet coil (frame size S3/AC)

**S3 - DC operation**

	<p>Loosen the 2 screws between the rear and front contactor halves. Loosen the two screws on the plates that attach the magnet coil on the armature, and remove the magnet coil from the rear half of the contactor.</p>
	<p>Insert the new magnet coil, and screw on the two plates again with the two screws.</p>
	<p>Replace the front half of the contactor, and tighten the 2 screws again. Make sure the springs are in their correct position.</p>

Figure 3-76: Replacing the magnet coil (frame size S3/DC)

### 3.5.4 Changing the contact piece

The contact pieces can be replaced in contactors of frame sizes S2 to S3. When they are replaced for the third time, the arcing chamber also has to be replaced.

#### Frame size S2




	<p>Remove the left identification label, loosen the 2 screws on the frontplate of the contactor, and remove the top section of the contactor <b>(1, 2, 3)</b>. Remove the movable contact piece by gently tipping it upward and then pulling it out <b>(4, 5)</b>. Loosen the screws that attach the two immovable contact pieces <b>(6)</b>.</p>
	<p>Remove the old contact pieces <b>(7)</b>, and screw on the new contact pieces <b>(8)</b>. Push in a new movable contact piece <b>(9)</b>.</p>
	<p>Replace the top section of the contactor, and tighten the 2 screws on the frontplate. Replace the identification label.</p>

Figure 3-77: Replacing the contact piece (frame size S2)

**Frame size S3**




Figure 3-78: Replacing the contact piece (frame size S3)

**Contact pieces**

The following contact pieces can be used for frame sizes S2 and S3 for the different performance classes:

S2			S3			
<b>3RT1034</b> 15 kW	<b>3RT1035</b> 18.5 kW	<b>3RT1036</b> 22 kW	<b>3RT1044</b> 30 kW	<b>3RT1045</b> 37 kW	<b>3RT1046</b> 45 kW	<b>3RT1446</b> 140 A (AC-1)
34	35	36				

Figure 3-79: Contact pieces (frame sizes S2/S3)

### 3.6 Dimensioned drawings (dimensions in mm)

#### 3RT1. / 3RH11 contactors, 3-pole




Figure 3-80: 3RT1. 10 1/3RH11 contactors (frame size S00)

Screw-type terminal with surge suppressor, auxiliary switch block, and attached overload relay

Different dimensions for contactors with Cage Clamp terminals: height 60 mm, mounting depth with auxiliary switch block 110 mm

2) Auxiliary switch block (also electronically optimized variant 3RH19 11-11N...)

3) Surge suppressor (also additional load module 3RT19 16-1GA00)

4) Drilling pattern

Distance to grounded parts at the side 6 mm




Figure 3-81: 3RT10 2 contactors, 3RT10 2 contactor relays (frame size S0) with surge suppressor, auxiliary switch block, and attached overload relay

a = 3 mm at < 240 V

a = 7 mm at > 240 V

b = DC 10 mm deeper than AC

1) Auxiliary switch block, attachable at the side

2) Auxiliary switch block, attachable at the front, 1-, 2-, and 4-pole (also electronically optimized variant 3RH1921-.FE22)

3) Surge suppressor

4) Drilling pattern

Distance to grounded parts at the side 6 mm




Figure 3-82: 3RT10 3 (frame size S2) with surge suppressor, auxiliary switch block, and attached overload relay

a = 0 mm with varistor < 240 V, diode combination  
 a = 3.5 mm with varistor > 240 V  
 a = 17 mm with RC element  
 b = DC 15 mm deeper than AC

- 1) Auxiliary switch block, attachable at the side
  - 2) Auxiliary switch block, attachable at the front (1-, 2-, and 4-pole)
  - 3) Surge suppressor
  - 4) Drilling pattern
- Distance to grounded parts at the side 6 mm




Figure 3-83: 3RT10 4, 3RT14 46 (frame size S3) with surge suppressor, auxiliary switch block, and attached overload relay

a = 0 mm with varistor, diode combination and < 240 V  
 a = 3.5 mm with varistor and > 240 V  
 a = 17 mm with RC element  
 b = DC 13 mm deeper than AC

- 1) Auxiliary switch block, attachable at the side
  - 2) Auxiliary switch block, attachable at the front (1-, 2-, and 4-pole)
  - 3) Surge suppressor
  - 4) Drilling pattern
  - 5) Attachment to 35 mm rails with 15 mm depth in acc. with EN 50 022 or 75 mm rails in acc. with EN 50 023
  - 6) 4 mm Allen screw
- Distance to grounded parts at the side 6 mm



### 3RT10 contactor relays




Figure 3-84: 3RT10 1 (frame size S00) with surge suppressor  
 Different dimensions for contactor relays with Cage Clamp terminal: height 60 mm

- 3) Surge suppressor
  - 4) Drilling pattern
- 3RT10 2. contactor relay, see Figure 3-80

### 3RT13 and 3RT15 contactors, 4-pole




Figure 3-85: 3RT13 1, 3RT15 1 (frame size S00) Screw-type terminal with surge suppressor, auxiliary switch block  
 Different dimensions for contactors with Cage Clamp terminals: height 60 mm, mounting depth with auxiliary switch block 110 mm

- 2) Auxiliary switch block (also electronically optimized variant 3RH19 11-1N...)
  - 3) Surge suppressor (also additional load module 3RT19 16-1GA00)
  - 4) Drilling pattern
- Distance to grounded parts at the side 6 mm




Figure 3-86: 3RT13 2, 3RT15 2 (frame size S0) with surge suppressor and auxiliary switch block

- a = 3 mm at < 250 V and attachment of surge suppressor
- a = 7 mm at > 250 V and attachment of surge suppressor
- b = DC 10 mm deeper than AC

- 1) Auxiliary switch block, attachable at the side (left)
- 2) Auxiliary switch block, attachable at the front, (max. two 1-pole auxiliary switch blocks)
- 3) Surge suppressor
- 4) Drilling pattern




Figure 3-87: 3RT133, 3RT153 (frame size S2) with surge suppressor and auxiliary switch block

- a = 0 mm with varistor < 240 V
- a = 3.5 mm with varistor > 240 V
- a = 17 mm with RC element and diode combination
- b = DC 15 mm deeper than AC

- 1) Auxiliary switch block, attachable at the side (right or left)
  - 2) Auxiliary switch block, attachable at the front, (1-, 2-, and 4-pole, also electronically optimized variant 3RH19 21-1FE22)
  - 3) Surge suppressor
  - 4) Drilling pattern
  - 5) Attachment on 35 mm rails (15 mm deep) in acc. with EN 50 022 or 75 mm rails in acc. with EN 50 023
  - 6) 4 mm Allen screw
- Distance to grounded parts at the side 6 mm




Figure 3-88: 3RT13 4 (frame size S3) with surge suppressor and auxiliary switch block

- a = 0 mm with varistor < 240 V
- a = 3.5 mm with varistor > 240 V
- a = 17 mm with RC element and diode combination
- b = DC 13 mm deeper than AC

- 1) Auxiliary switch block, attachable at the side (right or left)
  - 2) Auxiliary switch block, attachable at the front, (1-, 2-, and 4-pole, also electronically optimized variant 3RH1921-1FE22)
  - 3) Surge suppressor
  - 4) Drilling pattern
  - 5) Attachment on 35 mm rails (15 mm deep) in acc. with EN 50 022 or 75 mm rails in acc. with EN 50 023
  - 6) 4 mm Allen screw
- Distance to grounded parts at the side 6 mm

### 3RT16 capacitor-switching contactors




Figure 3-89: 3RT1626 (frame size S0)




Figure 3-90: 3RT1636 (frame size S2)




Figure 3-91: 3RT1646 (frame size S3)

**Contactors with an extended operating range (3RT1/3RH11)**




Figure 3-92: 3RT110 17, 3RH 11 (frame size S00)




Figure 3-93: 3RT10 2, view from right (frame size S0)




Figure 3-94: 3RT103, view from right (frame size S2)




Figure 3-95: 3RT104, view from right (frame size S3)

### 3RT19 time-delay auxiliary switch block





Figure 3-96: 3RT1916-2E..., -2F., -2G.. (frame size S00)



3RT19 26-2E..., -2F., -2G.. (frame sizes S0 to S3)

### 3RT19 time-delay time relay blocks, on-delay





Figure 3-97: 3RT19 16-2 (frame size S00)  
For attachment to the front of the contactor  
(dimensions also apply to off-delay time relay blocks)



3RT19 26-2 (frame sizes S0 to S3)  
Attachable on the top of the contactor  
(dimensions also apply to off-delay time relay blocks and to coupling links (3RH19 24-1GP11))

### 3RH19 11 auxiliary switch block, 1-pole












Figure 3-98: 3RH19 11-1AA..., 3RH19 11-1BA..  
Infeed from one side

**3RT1916 soldering pin connection**



### 3RA13 contactor combinations for reversing




Figure 3-99: Contactor combination for reversing (frame size S00)




Figure 3-100: Contactor combination for reversing (frame size S0) with mechanical interlock at the side (3RA19 24-2B)

with mechanical interlock at the front (3RA19 24-1A)




Figure 3-101: Contactor combination for reversing (frame size S2)




Figure 3-102: Contactor combination for reversing (frame size S3)

**Locking device for 3RA reversing switch**





Figure 3-103: 3RA1924-2B (frame sizes S0 to S3)



3RA1924-1A (frame sizes S0 to S3)

**3RA14 contactor combinations for star-delta starting**




Figure 3-104: Contactor combinations for star/delta (frame sizes S00 - S00 - S00)




Figure 3-105: Contactor combinations for star/delta (frame sizes S0 - S0 - S0)




Figure 3-106: Contactor combinations for star/delta (frame sizes S2 - S2 - S0)






Figure 3-107: Contactor combinations for star/delta (frame sizes S2 - S2 - S2)




Figure 3-108: Contactor combinations for star/delta (frame sizes S3 - S3 - S3)

## 3.7 Technical specifications

### 3RT10 contactors for switching motors

#### Ⓢ and Ⓞ rating data of the contactors

Contactor	Frame size Type		<b>S00</b> <b>3RT10 15</b>	<b>S00</b> <b>3RT10 16</b>	<b>S00</b> <b>3RT10 17</b>	<b>S0</b> <b>3RT10 23/24</b>	<b>S0</b> <b>3RT10 25</b>	<b>S0</b> <b>3RT10 26</b>
<b>Rated insulation voltage</b>		VAC	600	600	600	600	600	600
<b>Continuous current at 40 °C</b>	Open and enclosed	A	20	20	20	35	35	35
<b>Maximum horsepower ratings</b> (Ⓢ and Ⓞ approved values)								
Rated power		At 200 V hp	1½	2	3	2/3	5	7½
of three-phase induction motors		230 V hp	2	3	3	3/3	5	7½
At 50/60 Hz		460 V hp	3	5	7½	5/7½	10	15
		575 V hp	5	7½	10	7½/10	15	20
<b>Short-circuit protection</b>		kA	5	5	5	5	5	5
(contactor or overload relay)	Fuse or circuit breaker to UL 489	A	60	60	60	70	70	100
		A	50	50	50	70	70	100
<b>NEMA/EEMAC ratings</b>								
	NEMA/EEMAC SIZE		–	–	0	–	–	1
Continuous current	Open	A	–	–	18	–	–	27
	Enclosed	A	–	–	18	–	–	27
Rated power		At 200 V hp	–	–	3	–	–	7½
of three-phase induction motors		230 V hp	–	–	3	–	–	7½
At 60 Hz		460 V hp	–	–	5	–	–	10
		575 V hp	–	–	5	–	–	10
<b>Overload relay</b>	Type		3RU11 16			3RU11 2		
	Adjustment range	A	0.11 to 12			1.8 to 25		

Contactor	Frame size Type		<b>S2</b> <b>3RT10 34</b>	<b>S2</b> <b>3RT10 35</b>	<b>S2</b> <b>3RT10 36</b>	<b>S3</b> <b>3RT10 44</b>	<b>S3</b> <b>3RT10 45</b>	<b>S3</b> <b>3RT10 46</b>
<b>Rated insulation voltage</b>		VAC	600	600	600	600	600	600
<b>Continuous current at 40 °C</b>	Open and enclosed	A	45	55	50	90	105	105
<b>Maximum horsepower ratings</b> (Ⓢ and Ⓞ approved values)								
Rated power		At 200V hp	10	10	15	20	25	30
of three-phase induction motors		230 V hp	10	15	15	25	30	30
At 50/60 Hz		460V hp	25	30	40	50	60	75
		575V hp	30	40	50	60	75	100
<b>Short-circuit protection</b>		kA	5	5	5	10	10	10
(contactor or overload relay)	Fuse or circuit breaker to UL 489	A	125	150	200	250	300	350
		A	125	150	200	250	300	400
<b>NEMA/EEMAC ratings</b>								
	NEMA/EEMAC SIZE		–	–	2	–	–	3
Continuous current	Open	A	–	–	45	–	–	90
	Enclosed	A	–	–	45	–	–	90
Rated power		At 200V hp	–	–	10	–	–	25
of three-phase induction motors		230 V hp	–	–	15	–	–	30
At 60 Hz		460 V hp	–	–	25	–	–	50
		575 V hp	–	–	25	–	–	50
<b>Overload relay</b>	Type		3RU11 3			3RU11 4		
	Adjustment range	A	5.5 to 50			18 to 100		

#### Ⓢ and Ⓞ rating data of the auxiliary contacts

Contactor	Frame size		<b>S00</b> <b>Screw-type terminal and Cage Clamp terminal</b>	<b>S0 to S12</b> <b>Screw-type terminal and Cage Clamp terminal</b>	<b>Screw-type terminal and Cage Clamp terminal</b>	<b>Screw-type terminal and Cage Clamp terminal</b>
			Integrated or snap-on aux. switch block	4-pole snap-on aux. switch block	1-pole snap-on aux. switch block	Laterally attachable aux. switch block
Rated voltage		VAC	600	600	600	600
Switching capacity			A 600, Q 600	A 600, Q 600	A 600, Q 600	A 300, Q 300
	Continuous current at 240 VAC	A	10	10	10	10

## 3RT1 contactors for switching motors

### Auxiliary circuit

#### Rating of the auxiliary contacts in acc. with IEC 60 947-5-1/DIN EN 60 947-5-1 (VDE 0660 Part 200)

Data apply to integrated auxiliary contacts and contacts in the auxiliary switch blocks for contactors in frame sizes S00 to S12

Contactor	Frame sizes	<b>S00 to S12</b>	
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	690
With laterally attachable auxiliary switch blocks 3RH19 21-.EA . . and 3RH19 21-.KA . .		V	Max. 500
<b>Conventional free air thermal current <math>I_{th}</math> = Rated operational current <math>I_e/AC-12</math></b>		A	10
<b>AC loading</b>			
<b>Rated operational current <math>I_e/AC-15/AC-14</math></b>			
With rated operational voltage $U_e$	24 V	A	6
	110 V	A	6
	125 V	A	6
	220 V	A	6
	230 V	A	6
	380 V	A	3
	400 V	A	3
	500 V	A	2
	660 V <sup>2)</sup>	A	1
	690 V <sup>2)</sup>	A	1
<b>DC loading</b>			
<b>Rated operational current <math>I_e/DC-12</math></b>			
With rated operational voltage $U_e$	24 V	A	10
	60 V	A	6
	110 V	A	3
	125 V	A	2
	220 V	A	1
	440 V <sup>2)</sup>	A	0.3
	600 V <sup>2)</sup>	A	0.15
<b>Rated operational current <math>I_e/DC-13</math></b>			
At rated operational voltage $U_e$	24 V	A	10 <sup>1)</sup>
	60 V	A	2
	110 V	A	1
	125 V	A	0.9
	220 V	A	0.3
	440 V	A	0.14
	600 V <sup>2)</sup>	A	0.1
<b>Contact reliability at 17 V, 1 mA</b> in acc. with DIN EN 60 947-5-4			Contact fault frequency < 10 <sup>-8</sup> i. e. < 1 fault in 100 mill. operating cycles

1) DC-13: attachable auxiliary switch blocks for frame size S00: 6 A

2) With laterally attachable auxiliary switch blocks: switching capacity only up to 500 V

Contactor	Frame size Type	<b>S00 3RT1. 1.</b>	
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	690
<b>Rated impulse strength <math>U_{imp}</math></b>		kV	6
<b>Protective separation</b> between the coil and main contacts (in acc. with DIN VDE 0106 Part 101 and A1 [Draft 2/89])		V	400
<b>Permissible ambient temperature</b>	For operation	°C	-25 to +60
	During storage	°C	-55 to +80
<b>Degree of protection</b> in acc. with IEC 60 947-1 and DIN 40 050			IP 20, actuating system IP 40
<b>Shock resistance</b>	Rectangular impulse	AC operation	g/ms 7/5 and 4.2/10
		DC operation	g/ms 7/5 and 4.2/10
	Sine pulse	AC operation	g/ms 9.8/5 and 5.9/10
		DC operation	g/ms 9.8/5 and 5.9/10
<b>Short-circuit protection for contactors without overload relay</b>		Short-circuit protection for contactors with overload relay, see Part 4. Short-circuit protection for fuseless load feeders, see Part 5.	
<b>Main circuit</b>			
Fuse-links, performance class gL/gG			
NH type 3NA, DIAZED type 5SB, NEOZED type 5SE			
- In acc. with IEC 60 947-4/DIN EN 60 947-4 (VDE 0660 Part 102)	Coordination type "1" <sup>1)</sup>	A	35
	Coordination type "2" <sup>1)</sup>	A	20
	Unwelded <sup>2)</sup>	A	10
Or miniature circuit breaker (up to 230 V) with C characteristic		A	10

(Short-circuit current 1 kA, coordination type 1)

**3RT1 contactors for switching motors**

Contactor	Frame size Type	<b>S00 3 RT1.1.</b>
<b>Auxiliary circuit</b>		
Fuse-links, performance class gL/gG	A	10
DIAZED type 5SB, NEOZED type 5SE (unwelded fuse at $I_k \geq 1$ kA)		
Or miniature circuit breaker (up to 230 V) with C characteristic (short-circuit current $I_k < 400$ A)	A	6
1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102): Coordination type "1": The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.		Coordination type "2" The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.
2) Test conditions in acc. with IEC 60 947-4-1		

Contactor	Frame size Type	<b>S00 3 RT1.1.</b>
<b>Drive</b>		
<b>Operating range of the magnet coils</b>	AC	At 50 Hz: 0.8 to 1.1 x $U_s$ At 60 Hz: 0.85 to 1.1 x $U_s$
	DC	At +50 °C: 0.8 to 1.1 x $U_s$ At +60 °C: 0.85 to 1.1 x $U_s$
<b>Power input of the magnet coils</b> (cold coil and at 1.0 x $U_s$ )		<b>Standard version</b>
AC operation	Hz	50/60
	Making capacity	27/24.3
	cos $\varphi$	0.8/0.75
	Holding power	4.4/3.4
DC operation	cos $\varphi$	0.27/0.27
	Making capacity = holding power	3.3
		<b>For USA and Canada</b>
		50
		26.4
		0.81
		4.7
		0.26
		5.1
		0.27

Contactor	Frame size Type	<b>S00 3RT10 15</b>	<b>S00 3RT10 16</b>	<b>S00 3RT10</b>	
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization category AC-1, switching of resistive loads</b>					
Rated operational currents $I_e$	At 40 °C up to 690 V	A	18	22	22
	At 60 °C up to 690 V	A	16	20	20
Rated power of three-phase loads <sup>3)</sup> cos $\varphi = 0.95$ (at 60 °C)	At 230 V	kW	6.3	7.5	7.5
	400 V	kW	11	13	13
	500 V	kW	13.8	17	17
	690 V	kW	19	22	22
	Minimum conductor cross-section loaded with $I_e$	At 40 °C	mm <sup>2</sup>	2.5	2.5
	60 °C	mm <sup>2</sup>	2.5	2.5	2.5

3) Resistance-heated industrial furnaces and electric heating appliances, etc. (increased current consumption at startup of heating taken into account).

Contactor	Frame size Type	<b>S00 3RT10 15</b>	<b>S00 3RT10 16</b>	<b>S00 3RT10 17</b>	
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization categories AC-2 and AC-3</b>					
Rated operational currents $I_e$	To 400 V	A	7	9	12
	500 V	A	5	6.5	9
	690 V	A	4	5.2	6.3
Rated power of motors with slipring or squirrel-cage rotor at 50 Hz and 60 Hz	<b>230 V</b>	kW	2.2	3	3
	<b>400 V</b>	kW	3	4	5.5
	<b>500 V</b>	W	3.5	4.5	5.5
	<b>690 V</b>	kW	4	5.5	5.5
	<b>Thermal stress</b>	10-s current <sup>1)</sup>	A	56	72
<b>Power loss per conducting path</b>	At $I_e/AC-3$	W	0.42	0.7	1.24

### 3RT1.1 contactors for switching motors

Contactor	Frame size Type	S00 3RT1. 15	S00 3RT1. 16	S00 3RT1. 17
<b>Main circuit</b>				
<b>Current carrying capacity with alternating current</b>				
<b>Utilization category AC-4</b> (contact service life of approximately 200,000 operating cycles at $I_a = 6 \times I_e$ )				
Rated operational currents $I_e$	Up to 400 V A	2.6	4.1	4.1
	690 V A	1.8	3.3	3.3
Rated power of motors with squirrel-cage rotor at 50 Hz and 60 Hz	At 127 V kW	0.3	0.5	0.5
	200 V kW	0.6	1.1	1.1
	220 V kW	0.6	1.1	1.1
	230 V kW	0.67	1.1	1.1
	240 V kW	0.67	1.1	1.1
	380 V kW	1.15	2	2
	400 V kW	1.15	2	2
	415 V kW	1.15	2	2
	440 V kW	1.15	2	2
	460 V kW	1.15	2	2
	500 V kW	1.45	2	2
	575 V kW	1.45	2	2
	660 V kW	1.15	2.5	2.5
	690 V kW	1.15	2.5	2.5

1) In acc. with VDE 0660 Part 102. Rated values for different startup conditions, see Part 4.

#### Current carrying capacity with direct current

Contactor	Frame size Type	S00 3RT1. 15			S00 3RT1. 16			S00 3RT1. 17		
<b>Utilization category DC-1, switching of resistive loads (<math>L/R \leq 1</math> ms)</b>										
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>										
		Number of conducting paths in series connection								
		1	2	3	1	2	3	1	2	3
	Up to 24 V A	15	15	15	20	20	20	20	20	20
	60 V A	15	15	15	20	20	20	20	20	20
	110 V A	1.5	8.4	15	2.1	12	20	2.1	12	20
	220 V A	0.6	1.2	15	0.8	1.6	20	0.8	1.6	20
	440 V A	0.42	1.6	0.9	0.6	0.8	1.3	0.6	0.8	1.3
	600 V A	0.42	0.5	0.7	0.6	0.7	1	0.6	0.7	1
<b>Utilization categories DC-3 and DC-5, shunt and series motors (<math>L/R \leq 15</math> ms)</b>										
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>										
		Number of conducting paths in series connection								
		1	2	3	1	2	3	1	2	3
	Up to 24 V A	15	15	15	20	20	20	20	20	20
	60 V A	0.35	3.5	15	0.5	5	20	0.5	5	20
	110 V A	0.1	0.25	15	0.15	0.35	20	0.15	0.35	20
	220 V A	–	–	1.2	–	–	1.5	–	–	1.5
	440 V A	–	–	0.14	–	–	0.2	–	–	0.2
	600 V A	–	–	0.14	–	–	0.2	–	–	0.2

#### Switching frequency

Switching frequency $z$ in operating cycles/hour		AC/DC operation
Contactors without overload relay	No-load operation frequency	1/h 10,000
Dependency of switching frequency $z'$ on operating current $I'$ and operating voltage $U'$ :	Rated operation	
$z' = z \cdot \frac{I_e}{I'} \cdot \left(\frac{400 V}{U'}\right)^{1.5}$ 1/h	In acc. with AC-1	1/h 1,000
	In acc. with AC-2	1/h 750
	In acc. with AC-3	1/h 750
	In acc. with AC-4	1/h 250
Contactors with overload relay (average value)		1/h 15

**3RT10 2. contactors for switching motors**

Contactor	Frame size Type	<b>S0 3RT10 2.</b>		
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	690	
<b>Protective separation</b> between the coil and main contacts (in acc. with DIN VDE 0106 Part 101 and A1 [Draft 2/89])		V	400	
<b>Permissible ambient temperature</b>	For operation	°C	-25 to +60	
	During storage	°C	-55 to +80	
<b>Degree of protection</b> in acc. with IEC 60 947-1 and DIN 40 050			IP 20, actuating system IP 20	
<b>Shock resistance</b>	Rectangular impulse	AC operation	g/ms	8.2/5 and 4.9/10
		DC operation	g/ms	10/5 and 7.5/10
	Sine pulse	AC operation	g/ms	12.5/5 and 7.8/10
		DC operation	g/ms	15/5 and 10/10

**Short-circuit protection for contactors without overload relay**

Short-circuit protection for contactors with overload relay, see Chapter 4. Short-circuit protection for unwelded contactors, see Chapter 5 (overload and short-circuit protection only with the 3RV10 circuit breaker). Short-circuit protection for fuseless load feeders, see Chapter 5.

Contactor	Frame size Type	<b>S0 3RT10 23, 3RT10 24</b>		<b>S0 3RT10 25</b>	<b>S0 3RT10 26</b>
<b>Main circuit</b>					
Fuse-links, performance class gL/gG					
NH type 3NA, DIAZED type 5SB, NEOZED type 5SE					
With fuse-links					
– In acc. with IEC 60 947-4/DIN EN 60 947-4 (VDE 0660 Part 102)	Coord. type "1" <sup>1)</sup>	A	63	63	100
	Coord. type "2" <sup>1)</sup>	A	25	25	35
	Unwelded <sup>2)</sup>	A	10	10	16
Or miniature circuit breaker with C characteristic (Short-circuit current 3 kA, coordination type 1) <sup>1)</sup>		A	25	25	32

**Auxiliary circuit**

Fuse-links, performance class gL/gG	A	10	10	10
DIAZED type 5SB, NEOZED type 5SE (unwelded fuse at $I_k \geq 1$ kA)				
Or miniature circuit breaker with C characteristic (short-circuit current $I_k < 400$ A)	A	10	10	10

1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102):

Coordination type "1":

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Coordination type "2":

The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.

2) Test conditions in acc. with IEC 60 947-4-1.

Unwelded 3RT11 contactors, see Chapter 5 (overload and short-circuit protection only with the 3RV10 circuit breaker).

Contactor	Frame size Type	<b>S0 3RT10 2.</b>				
<b>Drive</b>						
<b>Operating range of the magnet coils</b>	AC/DC	0.8 to 1.1 x $U_s$				
<b>Power input of the magnet coils</b> (cold coil and at 1.0 x $U_s$ )		<b>Standard version</b>		<b>For USA and Canada</b>		
AC operation		Hz	50	50/60	50	60
	Making capacity	VA	61	64 /63	61	69
	cos $\phi$		0.82	0.72/ 0.74	0.82	0.76
	Holding power	VA	7.8	8.4 / 6.8	7.8	7.5
DC operation	making capacity = holding power	cos $\phi$	0.24	0.24/ 0.28	0.24	0.28
			W	5.4		

**3RT102. contactors for switching motors**

Contactor	Frame size Type		<b>S0</b> <b>3RT10 23, 3RT10 24</b>	<b>S0</b> <b>3RT10 25</b>	<b>S0</b> <b>3RT10 26</b>
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization category AC-1, switching resistive loads</b>					
Rated operational currents $I_e$	At 40 °C up to 690 V	A	40	40	40
	At 60 °C up to 690 V	A	35	35	35
Rated power of three-phase loads <sup>2)</sup>	At 230 V	kW	13.3	13.3	13.3
	400 V	kW	23	23	23
	500 V	kW	29	29	29
	690 V	kW	40	40	40
cos $\varphi$ = 0.95 (at 60 °C)					
Minimum conductor cross-section loaded with $I_e$	At 40 °C	mm <sup>2</sup>	10	10	10
	60 °C	mm <sup>2</sup>	10	10	10

2) Resistance-heated industrial furnaces and electric heating appliances, etc. (increased current consumption at startup of heating taken into account).

Contactor	Frame size Type		<b>S0</b> <b>3RT10 23</b>	<b>S0</b> <b>3RT10 24</b>	<b>S0</b> <b>3RT10 25</b>	<b>S0</b> <b>3RT10 26</b>
<b>Main circuit</b>						
<b>Current carrying capacity with alternating current</b>						
<b>Utilization categories AC-2 and AC-3</b>						
Rated operational currents $I_e$	Up to 400 V	A	9	12	17	25
	500 V	A	6.5	12	17	18
	690 V	A	5.2	9	13	13
Rated power of motors with slipring or squirrel-cage rotor at 50 Hz and 60 Hz	At 110 V	kW	1.1	1.5	2.2	3
	120 V	kW	1.1	1.5	2.2	3
	127 V	kW	1.1	1.5	2.2	3
	200 V	kW	2.2	3	4	5.5
	220 V	kW	3	3	4	5.5
	230 V	kW	3	3	4	5.5
	240 V	kW	3	3	4	5.5
	380 V	kW	4	5.5	7.5	11
	400 V	kW	4	5.5	7.5	11
	415 V	kW	4	5.5	7.5	11
	440 V	kW	4	5.5	9	11
	460 V	kW	4	5.5	9	11
	500 V	kW	4.5	7.5	10	11
	575 V	kW	4.5	7.5	10	11
	660 V	kW	5.5	7.5	11	11
690 V	kW	5.5	7.5	11	11	
<b>Thermal stress</b>	10-s current <sup>1)</sup>	A	80	110	150	200
<b>Power loss per conducting path</b>	At $I_e/AC-3$	W	0.4	0.5	0.9	1.6
<b>Utilization category AC-4</b> (contact service life of approximately 200,000 operating cycles at $I_a = 6 \times I_e$ )						
Rated operational currents $I_e$	Up to 400 V	A	4.1	5.5	7.7	9
	690 V	A	3.3	5.5	7.7	9
Rated power of motors with squirrel-cage rotor at 50 Hz and 60 Hz	At 110 V	kW	0.5	0.73	1	1.2
	120 V	kW	0.5	0.8	1.1	1.3
	127 V	kW	0.5	0.85	1.15	1.4
	200 V	kW	1.1	1.3	1.8	2.2
	220 V	kW	1.1	1.4	2	2.4
	230 V	kW	1.1	1.5	2	2.5
	240 V	kW	1.1	1.6	2.1	2.6
	380 V	kW	2	2.5	3.5	4.2
	400 V	kW	2	2.6	3.5	4.4
	415 V	kW	2	2.7	3.5	4.6
	440 V	kW	2	2.9	4	4.9
	460 V	kW	2	3	4.2	5.1
	500 V	kW	2	3.3	4.6	5.6
	575 V	kW	2	3.8	5.2	6.4
	660 V	kW	2.5	4.4	6	7.4
690 V	kW	2.5	4.6	6	7.7	

1) In acc. with VDE 0660 Part 102, rated value for different startup conditions, see Chapter 4.

### 3RT10 2. contactors for switching motors

**Current carrying capacity with direct current**

Contactor	Frame size Type	S0 3RT10 23, 3RT10 24	S0 3RT10 25	S0 3RT10 26
-----------	-----------------	--------------------------	----------------	----------------

**Utilization category DC-1, switching of resistive loads (L/R ≤ 1 ms)**

**Rated operational current I<sub>e</sub> (at 60 °C)**

Number of conducting paths in series connection

	1	2	3	1	2	3	1	2	3
up to 24 V A	35	35	35	35	35	35	35	35	35
60 V A	20	35	35	20	35	35	20	35	35
110 V A	4.5	35	35	4.5	35	35	4.5	35	35
220 V A	1	5	35	1	5	35	1	5	35
440 V A	0.4	1	2.9	0.4	1	2.9	0.4	1	2.9
600 V A	0.25	0.8	1.4	0.25	0.8	1.4	0.25	0.8	1.4

**Utilization categories DC-3 and DC-5, shunt and series motors (L/R ≤ 15 ms)**

**Rated operational current I<sub>e</sub> (at 60 °C)**

Number of conducting paths in series connection

	1	2	3	1	2	3	1	2	3
Up to 24 V A	20	35	35	20	35	35	20	35	35
60 V A	5	35	35	5	35	35	5	35	35
110 V A	2.5	15	35	2.5	15	35	2.5	15	35
220 V A	1	3	10	1	3	10	1	3	10
440 V A	0.09	0.27	0.6	0.09	0.27	0.6	0.09	0.27	0.6
600 V A	0.06	0.16	0.6	0.06	0.16	0.6	0.06	0.16	0.6

**Switching frequency**

**Switching frequency z** in operating cycles/hour

Contactor	Frame size Type	S2 3RT10 3.	S2 3RT10 34	S2 3RT10 35	S2 3RT10 36			
Contactor without overload relay	No-load operation frequency	1/h	5000	1500	5000	1500	5000	1500
Dependency of switching frequency z' on operating current and operating voltage U':			AC/DC	AC/DC	AC/DC			
	With AC-1	1/h	1000	1000	1000			
	With AC-2	1/h	1000	1000	750			
	With AC-3	1/h	1000	1000	750			
	With AC-4	1/h	300	300	250			
Contactor with overload relay (average value)		1/h	15	15	15			

$$z' = z \cdot \frac{I_e}{I_r} \cdot \left( \frac{400 \text{ V}}{U'} \right)^{1.5} \text{ 1/h}$$

### 3RT10 3. contactors for switching motors

Contactor	Frame size Type	S2 3RT10 3.
-----------	-----------------	----------------

**Mechanical life**

Basic units	Operational cycles	10 mill.
Basic unit with attached auxiliary switch block	Operational cycles	10 mill.
Electronically optimized auxiliary switch block	Operational cycles	5 mill.

**Rated insulation voltage U<sub>i</sub>** (pollution degree 3)

V	690
---	-----

**Protective separation** between the coil and main contacts (in acc. with DIN VDE 0106 Part 101 and A1 [Draft 2/89])

V	400
---	-----

**Permissible ambient temperature**

For operation	°C	-25 to +60
During storage	°C	-55 to +80

**Degree of protection** in acc. with IEC 60 947-1 and DIN 40 050 IP 20 (terminal housing IP 00), actuating system IP 40

**Shock resistance**

Rectangular impulse	AC and DC operation	g/ms	10/5 and 5/10
Sine pulse	AC and DC operation	g/ms	15/5 and 8/10

Contactor	Frame size Type	S2 3RT10 34	S2 3RT10 35	S2 3RT10 36
-----------	-----------------	----------------	----------------	----------------

**Short-circuit protection for contactors without overload relay** Short-circuit protection for contactors with overload relay, see Chapter 4. Short-circuit protection for unwelded contactors, see Chapter 5 (overload and short-circuit protection only with circuit breaker 3RV10). Short-circuit protection for fuseless load feeders, see Chapter 5.

**Main circuit**

Fuse-links, performance class gL/gG

NH type 3NA, DIAZED type 5SB, NEOZED type 5SE

- In acc. with IEC 60 947-4/DIN EN 60 947-4 (VDE 0660 Part 102)	Coordin. type "1" <sup>1)</sup>	A	125	125	160
	Coordin. type "2" <sup>1)</sup>	A	63	63	80
	Unwelded <sup>2)</sup>	A	16	16	50



**3RT10 3. contactors for switching motors**

Contactor	Frame size Type		<b>S2 3RT10 34</b>	<b>S2 3RT10 35</b>	<b>S2 3RT10 36</b>
<b>Auxiliary circuit</b>					
Fuse applications, performance class gL/gG DIAZED type 5SB, NEOZED type 5SE (unwelded fuse at $I_k \geq 1$ kA)	A	10	10	10	10
Or miniature circuit breaker with C characteristic (short-circuit current $I_k < 400$ A)	A	10	10	10	10
1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102): Coordination type "1": The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary. Coordination type "2": The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.					
2) Test conditions in acc. with IEC 60 947-4-1. Unwelded 3RT11 contactors, see Chapter 5 (overload and short-circuit protection only with the 3RV10 circuit breaker).					

Contactor	Frame size Type		<b>S2 3RT10 34</b>	<b>S2 3RT10 35</b>	<b>S2 3RT10 36</b>	
<b>Drive</b>						
<b>Operating range of the magnet coils</b>	AC/DC		0.8 to 1.1 x $U_s$			
<b>Power input of the magnet coils</b> (cold coil and at 1.0 x $U_s$ )						
<b>Standard version</b>						
AC operation		Hz	50	50/60	50	
	Making capacity cos $\phi$	VA	104	127 /113 0.78 0.73/ 0.69	145	170 /155 0.79 0.76/ 0.72
	Holding power cos $\phi$	VA	9.7	11.3 / 9.5 0.42 0.41/ 0.42	12.5	15 / 11.8 0.36 0.35/ 0.38
<b>For USA and Canada</b>						
		Hz	50	60	50	60
	Making capacity cos $\phi$	VA	90	118 0.76 0.8	160	127 0.82 0.85
	Holding power cos $\phi$	VA	11	12 0.38 0.41	13.5	14.2 0.34 0.37
DC operation	making capacity = holding power	W	13.3		13.3	13.3

**Main circuit****Current carrying capacity with alternating current****Utilization category AC-1, switching of resistive loads**

Rated operational currents $I_e$	At 40 °C up to 690 V	A	50	60	55
	At 60 °C up to 690 V	A	45	55	50
Rated power of three-phase loads <sup>2)</sup>	At 230 V	kW	18	22	20
	400 V	kW	31	38	35
	500 V	kW	39	46	43
	690 V	kW	54	66	60
Minimum conductor cross-section loaded with $I_e$	At 40 °C	mm <sup>2</sup>	16	16	16
	60 °C	mm <sup>2</sup>	10	16	10

2) Resistance-heated industrial furnaces and electric heating appliances, etc. (increased current consumption at startup of heating taken into account).

**3RT103. contactors for switching motors**

Contactor	Frame size Type		<b>S2 3RT10 34</b>	<b>S2 3RT10 35</b>	<b>S2 3RT10 36</b>
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization categories AC-2 and AC-3</b>					
Rated operational currents $I_e$	Up to 400 V	A	32	40	50
	500 V	A	32	40	50
	690 V	A	20	24	24
Rated power of motors with slipping or squirrel-cage rotor at 50 Hz and 60 Hz	at 127 V	kW	4	5.5	7.5
	200 V	kW	7.5	7.5	11
	220 V	kW	7.5	11	11
	230 V	kW	7.5	11	15
	240 V	kW	7.5	11	15
	380 V	kW	15	18.5	22
	400 V	kW	15	18.5	22
	415 V	kW	15	18.5	22
	440 V	kW	18.5	18.5	22
	460 V	kW	18.5	22	30
	500 V	kW	18.5	22	30
	575 V	kW	18.5	22	22
	660 V	kW	18.5	22	22
690 V	kW	18.5	22	22	
<b>Thermal stress</b>	10-s current <sup>1)</sup>	A	320	400	400
<b>Power loss per conducting path</b>	With $I_e/AC-3$	W	1.8	2.6	5
<b>Utilization category AC-4</b> (contact service life of approximately 200,000 operating cycles at $I_a = 6 \times I_e$ )					
Rated operational currents $I_e$	Up to 400 V	A	15.6	18.5	24
	690 V	A	15.6	18.5	24
Rated power of motors with squirrel cage rotor at 50 Hz and 60 Hz	At 127 V	kW	2.6	3	3
	200 V	kW	4.1	4.7	4.7
	220 V	kW	4.5	5.2	5.2
	230 V	kW	4.7	5.4	7.3
	240 V	kW	4.9	5.7	5.7
	380 V	kW	7.8	9	9
	400 V	kW	8.2	9.5	12.6
	415 V	kW	8.2	9.5	12.6
	440 V	kW	8.2	9.5	12.6
	460 V	kW	8.2	9.5	12.6
	500 V	kW	9.8	11.8	15.8
575 V	kW	8.3	11.8	15.8	
660 V	kW	9.6	13.5	18	
690 V	kW	13	15.5	21.8	

1) In acc. with VDE 0660 Part 102. Rated values for different startup conditions, see Part 4.

**Current carrying capacity with direct current**

Contactor	Frame size Type	S2 3RT10 34			S2 3RT10 35			S2 3RT10 36					
<b>Utilization category DC-1, switching of resistive loads (L/R ≤ 1 ms)</b>													
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>													
		Number of conducting paths in series connection			1	2	3	1	2	3	1	2	3
	Up to 24 V	A	45	45	45	55	55	55	50	50	50		
	60 V	A	20	45	45	23	45	45	23	45	45		
	110 V	A	4.5	45	45	4.5	45	45	4.5	45	45		
	220 V	A	1	5	45	1	5	45	1	5	45		
	440 V	A	0.4	1	2.9	0.4	1	2.9	0.4	1	2.9		
	600 V	A	0.25	0.8	1.4	0.25	0.8	1.4	0.25	0.8	1.4		

**Utilization categories DC-3 and DC-5,  
shunt and series motors (L/R ≤ 15 ms)**

<b>Rated operational current <math>I_e</math> (at 60 °C)</b>													
		Number of conducting paths in series connection			1	2	3	1	2	3	1	2	3
	Up to 24 V	A	35	45	45	35	55	55	35	50	50		
	60 V	A	6	45	45	6	45	55	6	45	50		
	110 V	A	2.5	25	45	2.5	25	55	2.5	25	50		
	220 V	A	1	5	25	1	5	25	1	5	25		
	440 V	A	0.1	0.27	0.6	0.1	0.27	0.6	0.1	0.27	0.6		
	600 V	A	0.06	0.16	0.35	0.06	0.16	0.35	0.06	0.16	0.35		

**Switching frequency**

<b>Switching frequency <math>z</math> in operating cycles/hour</b>			AC	DC	AC	DC	AC	DC
Contactor without overload relay	No-load operation frequency	1/h	5000	1500	5000	1500	5000	1500
Dependency of switching frequency $z'$ on operating current $I'$ and operating voltage $U'$ :			AC/DC		AC/DC		AC/DC	
$z' = z \cdot \frac{I_e}{I'} \cdot \left(\frac{400 \text{ V}}{U'}\right)^{1.5} \text{ 1/h}$	With AC-1	1/h	1200		1200		1000	
	With AC-2	1/h	750		600		400	
	With AC-3	1/h	1000		1000		800	
	With AC-4	1/h	250		300		300	
Contactor with overload relay (average value)		1/h	15		15		15	

### 3RT10 4. contactors for switching motors

Contactor	Frame size Type	<b>S3 3RT10 4.</b>	
<b>Mechanical life</b>	Basic units	Operating cycles	10 mill.
	Basic unit with attached auxiliary switch block		10 mill.
	Electronically optimized auxiliary switch block		5 mill.
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	1000
<b>Protective separation</b> between the coil and main contacts (in acc. with DIN VDE 0106 Part 101 and A1 [Draft 2/89])		V	690
<b>Permissible ambient temperature</b>		For operation	°C -25 to +60
		During storage	°C -55 to +80
<b>Degree of protection</b> in acc. with IEC 60 947-1 and DIN 40 050		IP 20 (terminal housing IP 00), actuating system IP 40	
<b>Shock resistance</b>	Rectangular impulse	AC and DC operation	g/ms 6.8/5 and 4/10
	Sine pulse	AC and DC operation	g/ms 10.6/5 and 6.2/10
<b>Short-circuit protection for contactors without overload relay</b>		Short-circuit protection for contactors with overload relay, see Part 4. Short-circuit protection for fuseless load feeders, see Chapter 5.	

Contactor	Frame size Type	<b>S3 3RT10 44</b>	<b>S3 3RT10 45</b>	<b>S3 3RT10 46</b>
<b>Main circuit</b>				
Fuse applications, performance class gL/gG				
NH type 3NA, DIAZED type 5SB, NEOZED type 5SE				
- In acc. with IEC 60 947-4/DIN EN 60 947-4 (VDE 0660 Part 102)	Coordin. type "1" <sup>1)</sup>	A 250	250	250
	Coordin. type "2" <sup>1)</sup>	A 125	160	160
	Unwelded <sup>2)</sup>	A 63	100	100

<b>Auxiliary circuit</b>				
Fuse applications, performance class gL/gG (unwelded fuse at $I_k \geq 1$ kA)				
DIAZED type 5SB, NEOZED type 5SE				
Or miniature circuit breaker with C characteristic (short-circuit current $I_k < 400$ A)	A	10	10	10

1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102):

Coordination type "1":

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Coordination type "2":

The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.

2) Test conditions in acc. with IEC 60 947-4-1

Contactor	Frame size Type	<b>S3 3RT10 44</b>	<b>S3 3RT10 45</b>	<b>S3 3RT10 46</b>
<b>Drive</b>				
<b>Operating range of the magnet coils</b> AC/DC		0.8 to 1.1 x $U_s$		
<b>Power input of the magnet coils</b> (cold coil and at 1.0 x $U_s$ )		<b>Standard version</b>		
AC operation		Hz	50 50/60	50 50/60
	Making capacity	VA	218 247 /211	270 298 /274
	cos $\phi$		0.61 0.62/ 0.57	0.68 0.7 / 0.62
	Holding power	VA	21 25 / 18	22 27 / 20
	cos $\phi$		0.26 0.27/ 0.3	0.27 0.29/ 0.31
		<b>For USA and Canada</b>		
DC operation		Hz	50 60	50 60
	Making capacity	VA	218 232	270 300
	cos $\phi$		0.61 0.55	0.68 0.52
	Holding power	VA	21 20	22 21
	cos $\phi$		0.26 0.28	0.27 0.29
	making capacity = holding power	W	15	15

**3RT10 4. contactors for switching motors**

Contactor	Frame size Type		<b>S3 3RT10 44</b>	<b>S3 3RT10 45</b>	<b>S3 3RT10 46</b>
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization category AC-1, switching of resistive loads</b>					
Rated operational currents $I_e$	At 40 °C up to 690 V	A	100	120	120
		1000 V A	50	60	70
	At 60 °C up to 690 V	A	90	100	100
		1000 V A	40	50	60
Rated power of three-phase loads <sup>2)</sup>	At 230 V	kW	34	38	38
		400 V kW	59	66	66
		500 V kW	74	82	82
		690 V kW	102	114	114
cos $\varphi$ = 0.95 (at 60 °C)	1000 V	kW	66	82	98
Minimum conductor cross-section loaded with $I_e$	At 40 °C	mm <sup>2</sup>	35	50	50
		60 °C	mm <sup>2</sup>	35	35
<b>Utilization categories AC-2 and AC-3</b>					
Rated operational currents $I_e$	Up to 400 V	A	65	80	95
		500 V A	65	80	95
		690 V A	47	58	58
		1000 V A	25	30	30
Rated power of motors with slipring or squirrel-cage rotor at 50 Hz and 60 Hz	at 230 V	kW	18.5	22	22
		400 V kW	30	37	45
		500 V kW	37	45	55
		690 V kW	55	55	55
		1000 V kW	30	37	37
<b>Thermal stress</b>	10-s current <sup>1)</sup>	A	600	760	760
<b>Power loss per conducting path</b>	With $I_e/AC-3$	W	4.6	7.7	10.8

Contactor	Frame size Type		<b>S3 3RT10 44</b>	<b>S3 3RT10 45</b>	<b>S3 3RT10 46</b>
<b>Main circuit</b>					
<b>Current carrying capacity with alternating current</b>					
<b>Utilization category AC-4 at <math>I_a = 6 \times I_e</math></b>					
Rated operational current $I_e$	Up to 400 V	A	55	66	80
		At 400V	kW	30	37
Rated power of motors with squirrel-cage rotor at 50 Hz and 60 Hz					
The following applies for a contact service life of approximately 200,000 operating cycles:					
Rated operational currents $I_e$	Up to 400 V	A	28	34	42
		690 V A	28	34	42
		1000 V A	20	23	23
Rated power of motors with squirrel-cage rotor at 50 Hz and 60 Hz	At 230 V	kW	8.7	10.4	12
		400 V kW	15.1	17.9	22
		500 V kW	18.4	22.4	27
		690 V kW	25.4	30.9	38
		1000 V kW	22	30	30

1) In acc. with VDE 0660 Part 102, rated values for different startup conditions, see Chapter 4.

2) Resistance-heated industrial furnaces and electric heating appliances, etc. (increased current consumption at startup of heating taken into account).

### 3RT10 4. contactors for switching motors

Contactor	Frame size Type	S3 3RT10 44			S3 3RT10 45			S3 3RT10 46					
<b>Current carrying capacity with direct current</b>													
<b>Utilization category DC-1, switching of resistive loads (L/R ≤ 1 ms)</b>													
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>													
		Number of conducting paths in series connection			1			2			3		
Up to 24 V A		90	90	90	100	100	100	100	100	100	100		
60 V A		23	90	90	60	100	100	60	100	100			
110 V A		4.5	90	90	9	100	100	9	100	100			
220 V A		1	5	70	2	10	80	2	10	80			
440 V A		0.4	1	2.9	0.6	1.8	1.8	0.6	1.8	4.5			
600 V A		0.26	0.8	1.4	0.4	1	1	0.4	1	2.6			
<b>Utilization categories DC-3 and DC-5, shunt and series motors (L/R ≤ 15 ms)</b>													
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>													
		Number of conducting paths in series connection			1			2			3		
Up to 24 V A		40	90	90	40	100	100	40	100	100			
60 V A		6	90	90	6.5	100	100	6.5	100	100			
110 V A		2.5	90	90	2.5	100	100	2.5	100	100			
220 V A		1	7	35	1	7	35	1	7	35			
440 V A		0.15	0.42	0.8	0.15	0.42	0.8	0.15	0.42	0.8			
600 V A		0.06	0.16	0.35	0.06	0.16	0.35	0.06	0.16	0.35			
<b>Switching frequency</b>													
<b>Switching frequency <math>z</math> in operating cycles/hour</b>													
Contactors without overload relay		No-load operation frequency		1/h	AC	DC	AC	DC	AC	DC			
					5000	1000	5000	1000	5000	1000			
Dependency of switching frequency $z'$ on operating current $I'$ and operating voltage $U'$ :					AC/DC		AC/DC		AC/DC				
$z' = z \cdot \frac{I_e}{I'} \cdot \left(\frac{400 V}{U'}\right)^{1.5} 1/h$		With AC-1		1/h	1000		900		900				
		With AC-2		1/h	400		400		350				
		With AC-3		1/h	1000		1000		850				
		With AC-4		1/h	300		300		250				
Contactors with overload relay (average value)				1/h	15		15		15				

### 3RT14 contactors, 3-pole

Contactor	Frame size Type	S3 3RT14 46				
<b>Mechanical life</b>		Operating cycles	10 mill.			
<b>Service life</b> Utilization category AC-1 at $I_e$		Operating cycles	0.5 mill.			
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	1000			
<b>Rated impulse strength <math>U_{imp}</math></b>		kV	6			
<b>Protective separation</b> between the coil and main contacts (in acc. with DIN VDE 0106 Part 101 and A1 [Draft 2/89])		V	690			
<b>Permissible ambient temperature</b>		For operation	°C -25 to +60			
		During storage	°C -55 to +80			
<b>Degree of protection</b> in acc. with IEC 60 947-1 and DIN 40 050		IP 20 (terminal housing IP 00), actuating system IP 40				
<b>Operating range of the magnet coils</b>		AC/DC	0.8 to 1.1 x $U_s$			
<b>Power input of the magnet coils</b> (cold coil and at 1.0 x $U_s$ )		Standard version		For USA and Canada		
AC operation		Hz	50	50/60	50	60
Making capacity		VA	270	298 / 274	270	300
cos $\phi$			0.68	0.7 / 0.62	0.68	0.52
Holding power		VA	22	27 / 20	22	21
cos $\phi$			0.27	0.29/ 0.31	0.27	0.29
DC operation		making capacity = holding power	W	15		
<b>Shock resistance</b>						
Rectangular impulse		With AC and DC operation	g/ms	6.8/5 and 4/10		
Sine pulse		With AC and DC operation	g/ms	10.6/5 and 6.2/10		

### 3RT14 contactors, 3-pole

Contactors	Frame size Type	<b>S3 3RT14 46</b>		
<b>Short-circuit protection for contactors without overload relay</b>				
<b>Main circuit</b>				
Fuse applications, performance class gL/gG	NH	Type 3NA		
		Coordination type "1" 2)	A	250
Fuse-links, performance class gR	SITOR	Type 3NE		
		Coordination type "2" 2)	A	250
<b>Control circuit</b>				
Fuse-links, performance class gL/gG	DIAZED	Type 5SB	A	10
(unwelded fuse at $I_k \geq 1$ kA)	NEOZED	Type 5SE	A	10
Miniature circuit breaker with C characteristic ( $I_k < 400$ A)			A	10

#### Switching frequency

Switching frequency z in operating cycles/hour			AC operation	DC operation
Contactors without overload relay	No-load operation frequency	1/h	5000	1000
Rated operation	In acc. with AC-1	1/h	650	650
	In acc. with AC-3	1/h	1000	1000

Dependency of switching frequency  $z'$  on operating current  $I'$  and operating voltage  $U'$ :

$$z' = z \cdot \frac{I_e}{I'} \cdot \left( \frac{400 \text{ V}}{U'} \right)^{1.5} \text{ 1/h}$$

2) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102):

Coordination type "1":

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Coordination type "2":

The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.

Contactors	Frame size Type	<b>S3 3RT14 46</b>		
<b>Current carrying capacity with alternating current</b>				
<b>Utilization category AC-1, switching of resistive loads</b>				
Rated operational currents $I_e$	At 40 °C up to 690 V	A	140	
	At 60 °C up to 690 V	A	130	
	At 1000 V	A	60	
Rated power of three-phase loads $\cos \varphi = 0.95$ (at 60 °C)	At 230 V	kW	50	
	400 V	kW	86	
	500 V	kW	107	
	690 V	kW	148	
	1000 V	kW	98	
Minimum conductor cross-section loaded with $I_e$	At 40 °C	mm <sup>2</sup>	50	
	At 60 °C	mm <sup>2</sup>	50	

#### Utilization categories AC-2 and AC-3

with an electrical service life of 1.3 mill. operating cycles

Rated operational current $I_e$	Up to 690 V	A	44	
Rated power of motors with slipring or squirrel-cage rotor at 50 Hz and 60 Hz (at 60 °C)	At 230 V	kW	12.7	
	400 V	kW	22	
	500 V	kW	29.9	
	690 V	kW	38.2	

#### Current carrying capacity with direct current

##### Utilization category DC-1, switching of resistive loads $L/R \leq 1$ ms)

Rated operational currents $I_e$ (at 60 °C)	Number of conducting paths in series connection			
		1	2	3
Up to 24 V	60 V A	130	130	130
	80 V A	80	130	130
	110 V A	12	130	130
	220 V A	2.5	13	130
	440 V A	0.8	2.4	6
	600 V A	0.48	1.3	3.4

### 3RT14 contactors, 3-pole

Contactor	Frame size Type	<b>S3 3RT14 46</b>		
<b>Utilization categories DC-3 and DC-5, shunt and series motors</b>				
Number of conducting paths in series connection		1	2	3
Rated operational currents $I_e$ (at 60 °C)	Up to 24 V A	6	130	130
	60 V A	3	130	130
	110 V A	1.25	130	130
	220 V A	0.35	1.75	4
	440 V A	0.15	0.42	0.8
	600 V A	0.1	0.27	0.45
<b>Power loss per conducting path</b>		At $I_e/AC-1$ W	12.5	

### 3RT13 contactors, 4-pole (4 NO contacts), for switching resistive loads

<b>Technical specifications</b>								
Contactor	Frame size Type	<b>S00 3RT13 16/17</b>	<b>S0 3RT13 25/26</b>	<b>S2 3RT13 36</b>	<b>S3 3RT13 44</b>	<b>S3 3RT13 46</b>		
<b>General specifications</b>								
Mechanical life		Operating cycles	30 mill.	10 mill.				
Electrical service life with $I_e/AC-1$		Operating cycles	Approx. 0.5 mill.					
Rated insulation voltage $U_i$ (pollution degree 3)		V	690					
Permissible ambient temperature	For operation	°C	-25 to +60					
	During storage	°C	-55 to +80					
Degree of protection in acc. with IEC 60 947-1 and DIN 40 050	Terminal housing		IP20	IP 20				
				IP 00				
<b>Short-circuit protection for contactors without overload relay</b>								
Main circuit								
Fuse-links, performance class gL/gG NH type 3NA, DIAZED type 5SB, NEOZED type 5SE – In acc. with IEC 60 947-4/ DIN EN 60 947-4 (VDE 0660 Part 102)								
	Coord. type "1" <sup>1)</sup>	A	35	63	160	250	250	
	Coord. type "2" <sup>1)</sup>	A	20	25/35	63	125	160	
	Unwelded <sup>2)</sup>	A	10	16	50	63	100	
<b>Drive</b>								
Operating range of the magnet coils	AC	At 50 Hz:	0.8 - 1.1 x $U_s$				AC/DC: 0.8 - 1.1 x $U_s$	
		At 60 Hz:	0.85 - 1.1 x $U_s$					
	DC	At +50 °C:	0.8 - 1.1 x $U_s$					
		At +60 °C:	0.85 - 1.1 x $U_s$					
Power input of the magnet coils (cold coil and at 1.0 x $U_s$ )								
AC operation	Making capacity	Hz	50/60	50	50/60	50	50/60	
		VA	26.5/24.3	61	64/ 63	145	170/ 155	298/ 274
		cos $\phi$	0.79/0.75	0.82	0.82 0.74	0.79	0.76/ 0.72	0.68 0.72/ 0.62
	Holding power	VA	4.4/3.4	7.8	8.4/ 6.8	12.5	15/ 11.8	27/ 20
		cos $\phi$	0.27/0.27	0.24	0.24/ 0.28	0.36	0.35/ 0.38	0.27 0.29/ 0.31
		W	3.3	5.6	13.3	15		
DC operation	Making capacity = holding power	W	3.3	5.6	13.3	15		

1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102):

Coordination type "1":

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Coordination type "2":

The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can be easily separated again from the contactor.

2) Test conditions in acc. with IEC 90 947-4-1.



**3RT13 contactors, 4-pole (4 NO contacts), for switching resistive loads**

Contactor	Frame size Type		S00 3RT13 16	S00 3RT13 17	S0 3RT13 25	S0 3RT13 26	S2 3RT13 36	S3 3RT13 44	S3 3RT13 46					
<b>Main circuit</b>														
<b>Current carrying capacity with alternating current</b>														
Utilization category AC-1, switching of resistive loads														
Rated operational currents $I_b$	(at 40 °C)	Up to 690 V	A	18	22	35	40	60	110	140				
		(at 60 °C)	A	16	20	30	35	55	100	120				
Rated power of three-phase loads $\cos \varphi = 0.95$ (at 40 °C)	At 230 V 400 V	kW	7	8.5	12.5	15	23	42	53					
		kW	12	14.5	22	26	39	72	92					
Minimum conductor cross-section loaded with $I_b$	At 40 °C and 60 °C	mm <sup>2</sup>	2.5	2.5	10	10	16	50	50					
Utilization categories AC-2 and AC-3														
Rated operational currents $I_b$	(at 60 °C)	At 400 V	A	9	12	17	25	26						
Rated power of slipping or squirrel-cage motors at 50 Hz and 60 Hz	At 230 V 400 V	kW	3	3	4	5.5	5.5							
		kW	4	5.5	7.5	11	11							
<b>Current carrying capacity with direct current</b>														
Utilization category DC-1, switching of resistive loads ( $L/R \leq 1$ ms)														
Rated operational currents $I_b$ (at 40 °C)														
Number of conducting paths in series connection			1	2	3	4	1	2	3	4				
Up to 24 V	A	18	18	18	18	22	22	22	22	35	35	35	35	
	60 V	A	18	18	18	18	22	22	22	20	35	35	35	
	110 V	A	2.1	12	18	18	2.1	12	22	22	4.5	35	35	
	220 V	A	0.8	1.6	18	18	0.8	1.6	22	22	1	5	35	35
	440 V	A	0.6	0.8	1.3	1.3	0.6	0.8	1.3	1.3	0.4	1	2.9	2.9
Utilization categories DC-3 and DC-5 shunt and series motors ( $L/R \leq 15$ ms)														
Rated operational currents $I_b$ (at 40 °C)														
Number of conducting paths in series connection			1	2	3	4	1	2	3	4				
Up to 24 V	A	18	18	18	18	20	20	20	20	20	35	35	35	
	60 V	A	0.5	5	18	18	0.5	5	20	20	5	35	35	
	110 V	A	0.15	0.35	18	18	0.15	0.35	20	20	2.5	15	35	
	220 V	A	—	—	1.5	1.5	—	—	1.5	1.5	1	3	10	
	440 V	A	—	—	0.2	0.2	—	—	0.2	0.2	0.09	0.27	0.6	
<b>Current carrying capacity with direct current</b>														
Utilization category DC-1, switching of resistive loads ( $L/R \leq 1$ ms)														
Rated operational currents $I_b$ (at 40 °C)														
Number of conducting paths in series connection			1	2	3	4	1	2	3	4				
Up to 24 V	A	50	50	50	50	70	70	70	70	80	80	80	80	
	60 V	A	23	45	45	45	23	70	70	70	60	80	80	
	110 V	A	4.5	45	45	45	4.5	70	70	70	9	80	80	
	220 V	A	1	5	45	45	1	5	70	70	2	10	80	
	440 V	A	0.4	1	2.9	2.9	0.4	1	2.9	2.9	0.6	1.8	4.5	
Utilization categories DC-3 and DC-5 shunt and series motors ( $L/R \leq 15$ ms)														
Rated operational currents $I_b$ (at 40 °C)														
Number of conducting paths in series connection			1	2	3	4	1	2	3	4				
Up to 24 V	A	20	45	45	45	20	70	70	70	20	80	80	80	
	60 V	A	6	45	45	45	6	70	70	70	6.5	80	80	
	110 V	A	2.5	25	45	45	2.5	70	70	70	2.5	80	80	
	220 V	A	1	5	25	45	1	7	35	70	1	7	35	
	440 V	A	0.1	0.27	0.6	0.6	0.15	0.42	0.8	0.8	0.15	0.42	0.8	

**3RT15 contactors, 4-pole (2 NO contacts + 2 NC main contacts)**

Contactor	Frame size Type		<b>S00</b> <b>3RT15 16/17</b>	<b>S0</b> <b>3RT15 26</b>	<b>S2</b> <b>3RT15 35</b>		
<b>General specifications</b>							
<b>Mechanical life</b>		Operating cycles	30 mill.	10 mill.	10 mill.		
<b>Electrical service life with <math>I_e/AC-1</math></b>		Operating cycles	Approx. 0.5 mill.				
<b>Rated insulation voltage <math>U_i</math></b> (pollution degree 3)		V	690				
<b>Permissible ambient temperature</b>		For operation °C	-25 to +60				
		During storage °C	-55 to +80				
<b>Degree of protection</b> in acc. with IEC 60 947-1 and DIN 40 050			IP20		IP 20 (terminal housing IP 00)		
<b>Short-circuit protection for contactors without overload relay</b>							
<b>Main circuit</b>							
Fuse-links, performance class gL/gG NH type 3NA, DIAZED type 5SB, NEOZED type 5SE – In acc. with IEC 60 947-4/ DIN EN 60 947-4 (VDE 0660 Part 102)							
		Coordination type *1* <sup>1)</sup>	A	35	63	160	
		Coordination type *2* <sup>1)</sup>	A	20	35	80	
		Unwelded <sup>2)</sup>	A	10	16	50	
<b>Drive</b>							
<b>Operating range of the magnet coils</b>	AC	at 50 Hz:	0.8 to 1.1 x $U_s$		AC/DC: 0.8 to 1.1 x $U_s$		
		at 60 Hz:	0.85 to 1.1 x $U_s$				
	DC	at +50 °C	0.8 to 1.1 x $U_s$				
		at +60 °C	0.85 to 1.1 x $U_s$				
<b>Power input of the magnet coils</b> (cold coil and at 1.1 x $U_s$ )							
AC operation		Hz	50/60	50	50/60	50	50/60
	Making capacity	VA	26.5/24.3	61	64/63	145	170/155
	cos $\varphi$		0.79/0.75	0.82	0.82/0.74	0.79	0.76/0.72
	Holding power	VA	4.4/3.4	7.8	8.4/6.8	12.5	15/11.8
	cos $\varphi$		0.27/0.27	0.24	0.24/0.28	0.36	0.35/0.38
DC operation	Making capacity = holding power	W	3.3	5.6	13.3		

1) Corresponds to section from IEC 60 947-4 (VDE 0660 Part 102):

Coordination type \*1\*:

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Assignment \*2\*:

The overload relay must not be damaged. Contactwelding on the contactor is permissible, if it can be easily separated again from the contactor.

2) Test conditions in acc. with IEC 60 947-4-1

**3RT15 contactors, 4-pole (2 NO contacts + 2 NC main contacts)**

Contactor	Frame size Type		S00 3RT15 16	S00 3RT15 17	S0 3RT15 26	S2 3RT15 35					
<b>Current carrying capacity with alternating current</b>											
<b>Utilization category AC-1, switching of resistive loads</b>											
Rated operational currents $I_e$ (at 40 °C)	(at 60 °C)	Up to 690 V A	18	22	40	55					
		Up to 690 V A	16	20	35	50					
Rated power of three-phase loads $\cos \varphi = 0.95$ (at 40 °C)	At 230 V kW	6.5	7.5	15	20						
		400 V kW	11	13	26	36					
		Minimum conductor cross-section loaded with $I_e$	At 40 °C and 60 °C	mm <sup>2</sup>	2.5	2.5	10	16			
<b>Utilization categories AC-2 and AC-3</b>											
Rated operational currents $I_e$ (at 60 °C)	Up to 400 V A	9	12	25 <sup>1)</sup>	40						
Rated power of motors with slipping or squirrel-cage rotor at 50 Hz and 60 Hz and	At 230 V kW	3	3	5.5	9.5						
	400 V kW	4	5.5	11	18.5						
<b>Current carrying capacity with direct current</b>											
<b>Utilization category DC-1, switching of resistive loads (L/R ≤ 1 ms)</b>											
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>											
Number of conducting paths in series connection	Up to 24 V A	A	1	2	1	2	1	2			
			16	16	20	20	35	35	50		
			60 V A	16	16	20	20	20	35	23	45
			110 V A	2.1	12	2.1	12	4.5	35	4.5	45
			220 V A	0.8	1.6	0.8	1.6	1	5	1	5
			440 V A	0.6	0.8	0.6	0.8	0.4	1	0.4	1
<b>Utilization categories DC-3 and DC-5<sup>2)</sup>, shunt and series motors (L/R ≤ 15 ms)</b>											
<b>Rated operational current <math>I_e</math> (at 60 °C)</b>											
Number of conducting paths in series connection	Up to 24 V A	A	1	2	1	2	1	2			
			16	16	20	20	20	35	35	50	
			60 V A	0.5	5	0.5	5	5	35	6	45
			110 V A	0.15	0.35	0.15	0.35	2.5	15	2.5	25
			220 V A	0.75	1.5	0.75	1.5	1	3	1	5
			440 V A	—	—	—	—	0.09	0.27	0.1	0.27

1) With AC drive: 25 A  
DC drive: 20 A.

2) At  $U_s > 24$  V the rated operational currents  $I_e$  for the conducting paths of the NC contacts are 50% of the values for the conducting paths of the NO contacts.





### 3RT16 capacitor-switching contactors

The technical specifications for frame size S0 correspond, unless listed below, to those of the 3RT10 26 contactors, for frame size 2 to those of the 3RT10 36 contactors, and for frame size S3 to those of the 3RT10 45 contactors.

Contactor	Frame size Type	<b>S0 3RT16 26</b>	<b>S2 3RT16 36</b>	<b>S3 3RT16 46</b>
<b>Capacitor power at operating voltage</b>	230 V 50/60 Hz	kvar 8.5	14	29
	400 V 50/60 Hz	kvar 15	25	50
	525 V 50/60 Hz	kvar 20	32	65
	690 V 50/60 Hz	kvar 25	32	65
Auxiliary contacts attached (freely available)		1 NO contact		
Additional auxiliary contacts that can be attached (lateral)		2 NC contacts, 2 NO contacts, or 1 NO + 1 NC		
Operating range of the magnet coil		0.85 to 1.1 x U <sub>s</sub>		
Max. switching frequency	1/h	180	100	100
Electrical life		Operating cycles > 100,000		
Ambient temperature	°C	60	55	55
Regulations		IEC 60 947/DIN EN 60 947 (VDE 0660)		

### 3RT10 contactor relays (interface)

The technical specifications correspond to those of the 3RT10 contactors used to switch motors, unless listed below. Auxiliary switch blocks cannot be added to 3RT10 1. contactor relays. Two, 1-pole auxiliary switch blocks can be built on to the 3RT10 2. contactor relays.

Contactor	Frame size Type	<b>S00 3RT10 1.-1HB4.</b>	<b>S00 3RT10 1.-1JB4.</b>	<b>S00 3RT10 1.-1KB4.</b>	<b>S0 3RT10 2.-1KB40</b>	
<b>Mechanical life</b>		Operating cycles 30 mill.	30 mill.	30 mill.	10 mill.	
<b>Operating range of the magnet coils</b>		0.7 to 1.25 x U <sub>s</sub> q (17 V to 30 V)				
<b>Power input of the magnet coil</b>						
(with a cold coil)	With U <sub>s</sub> 17 V	W 1.2	1.2	1.2	2.1	
	24V	W 2.3	2.3	2.3	4.2	
Making capacity = holding power	30V	W 3.6	3.6	3.6	6.6	
<b>Permissible residual current</b>						
of the electronic components (at 0 signal)		mA < 10 mA x $\left(\frac{24 V}{U_s}\right)$	< 10 mA x $\left(\frac{24 V}{U_s}\right)$	< 10 mA x $\left(\frac{24 V}{U_s}\right)$	< 6 mA x $\left(\frac{24 V}{U_s}\right)$	
<b>Suppressor circuit of the magnet coil</b>		Without overvoltage damping	With diode	With varistor	With varistor	
						
<b>Switching times of the contactor relays</b>						
<b>Making</b>	At 17 V	On delay	NO ms 40 to 120	40 to 120	40 to 120	93 to 270
		Off delay	NC ms 30 to 70	30 to 70	30 to 70	83 to 250
	At 24 V	On delay	NO ms 30 to 60	30 to 60	30 to 60	64 to 87
		Off delay	NC ms 20 to 40	20 to 40	20 to 40	55 to 78
	At 30 V	On delay	NO ms 20 to 50	20 to 50	20 to 50	53 to 64
		Off delay	NC ms 15 to 30	15 to 30	15 to 30	45 to 56
<b>Breaking</b>	At 17 V to 30 V	On delay	NO ms 7 to 17	40 to 60	7 to 17	18 to 19
		Off delay	NC ms 22 to 30	60 to 70	22 to 30	24 to 25
Protective separation between coil and contacts (in acc. with DIN VDE 0106 Part 101 A1 [Draft 02/89])	V	400	400	400	400	

## Accessories for 3RT1. contactors

Type	Solid-state time relay blocks with semiconductor output		Time-delay auxiliary switch blocks
	3RT19 .6-2C 2D		3RT19 .6-2E 2F 2G
<b>Rated insulation voltage</b>	VAC	250	250
Pollution degree 3 Overvoltage category III in acc. with DIN VDE 0110			
<b>Energizing operating range</b>		0.8 to 1.1 x $U_s$ 0.95 to 1.05 times the rated frequency	0.85 to 1.1 x $U_s$ 0.95 to 1.05 times the rated frequency
<b>Rated power</b>	W	1	2
Power input at 230 VAC, 50 Hz	VA	1	4
<b>Rated operational currents <math>I_g</math></b>			
AC-140, DC-13	A	0.3 in the case of the 3RT19 16 0.5 in the case of the 3RT19 26	–
AC-15 at AC 230 V, 50 Hz	A	–	3
DC-13 at 24 V	A	–	1
DC-13 at 110 V	A	–	0.2
DC-13 at 230 V	A	–	0.1
<b>DIAZED fuse</b>			
Performance class	gL/gG	A –	4
<b>Switching frequency</b>			
Loaded with $I_g$ 230 VAC	1/h	2500	2500
Loaded with 3RT1016 contactor, 230 VAC	1/h	2500	5000
<b>Recovery time</b>	ms	50	150
<b>Minimum on-time</b>	ms	35	200 (off-delay)
<b>Residual current</b>	mA	≤ 5	–
<b>Voltage drop</b>	V	≤ 3.5	–
in switched state			
<b>Short-term current carrying capacity</b>	A	10 (to 10 ms)	–
<b>Setting accuracy</b> in relation to the value at the end of the scale		≤ ± 15%	≤ ± 15%
<b>Repeatability</b>		≤ ± 1%	≤ ± 1%
<b>Mechanical life</b>	Operating cycles	100 x 10 <sup>6</sup>	30 x 10 <sup>6</sup>
<b>Permissible ambient temperature</b>	For operation	°C –25 to +60	–25 to +60
	During storage	°C –40 to +85	–40 to +85
<b>Degree of protection</b> in acc. with DIN EN 60 529		IP 40 IP 20 terminals	IP 40 IP 20 terminals
<b>Terminal type</b>	Single-core	mm <sup>2</sup> 2 x (0.5 to 1.5) 2 x (0.75 to 4)	2 x (0.5 to 1.5) 2 x (0.75 to 4)
	Finely stranded with wire end ferrule:	mm <sup>2</sup> 2 x (0.5 to 2.5)	2 x (0.5 to 2.5)
	Single or multi-core	AWG 2 x (18 to 14)	2 x (18 to 14)
<b>Terminal screw</b>		M3	M3
<b>Tightening torque</b>	Nm	0.8 to 1.2	0.8 to 1.2
<b>Permissible installation</b>		Any	Any

**Accessories for 3RT1. contactors**

Type		<b>Solid-state time relay blocks with semiconductor output</b>	<b>Time-delayed auxiliary switch blocks</b>
		<b>3RT19 .6- 2C 2D</b>	<b>3RT19 .6- 2E 2F 2G</b>
<b>Shock resistance</b> half-sine in acc. with IEC 60 068-2-27	g/ms	15/11	15/11
<b>Vibration resistance</b> in acc. with IEC 60 068-2-6	Hz/mm	10 to 55/0.35	10 to 55/0.35
<b>EMC tests</b>	Basic specification	EN 50081-1; IEC 61 000-6-2	EN 50081-1; IEC 61 000-6-2
<b>Overvoltage protection</b>		Varistor integrated in the time relay	-

**3RA13 contactor combinations for reversing**

The technical information corresponds to that of the 3RT10 ... contactors.  
The © and ® approvals only apply to complete contactor combinations and not to combinations you have put together from separate parts.

**3RA14 contactor combinations for star-delta starting**

The technical specifications correspond to those of the 3RT individual contactor and the 3RU time relay, unless listed below.

starter	Frame sizes Type	<b>S...S...S.. 3RA... ..</b>	<b>00-00-00 14 15</b>	<b>00-00-00 14 16</b>	<b>0-0-0 14 23</b>	<b>0-0-0 14 25</b>	<b>2-2-0 14 34</b>	<b>2-2-2 14 35</b>	<b>2-2-2 14 36</b>	<b>3-3-2 14 44</b>	<b>3-3-2 14 45</b>
<b>Mechanical life</b>		Operating 3 mill. cycles									
<b>Short-circuit protection without overload relay</b>		Short-circuit protection with overload relay, see Part 4									
Highest rated current of the fuse											
<b>Main circuit<sup>1)</sup></b>											
Fuse-links, performance class gL/gG NH type 3NA, DIAZED type 5SB, NEOZED type 5SE											
Single or double incoming supply											
-In acc. with IEC 60 947-4-1/ DIN VDE 0660 Part 102	Coordination type "1" <sup>1)</sup> Coordination type "2" <sup>1)</sup>	A A	35 20	35 20	63 25	100 35	125 63	125 63	160 80	250 125	250 160
<b>Control circuit</b>											
Fuse-links, performance class gL/gG DIAZED type 5SB, NEOZED type 5SE		A A	10, 10,								
(Short-circuit current $I_k \geq 1$ kA)											
Circuit breaker with C characteristic		A A	10, 6 <sup>2)</sup> , if the auxiliary contact of the overload relay is in the circuit of the contactor coil.								
<b>Size of the individual contactors</b>	Line contactor K1 Delta contactor K3 Star contactor K2	Type 3RT Type 3RT Type 3RT	10 15 10 15 10 15	10 17 10 17 10 15	10 24 10 24 10 24	10 26 10 26 10 24	10 34 10 34 10 26	10 35 10 35 10 34	10 36 10 36 10 34	10 44 10 44 10 35	10 45 10 45 10 36
<b>Unassigned auxiliary contacts of the individual contactors</b>	See circuit diagram for the control circuit, page 3/93.										
<b>Current carrying capacity for the AC-3 utilization category</b>											
<b>Switchover time up to 10 s</b>											
Rated operational current	At 400 V 500 V 690 V	A A A	12 8.7 6.9	17 11.3 9	25 20.8 20.8	40 31.2 22.5	65 55.4 53.7	80 69.3 69.3	86 86 69.3	115 112.6 98.7	150 138.6 138.6
Rated power of three-phase induction motors at 50 Hz and	At 230 V 400 V 500 V 690 V 1000 V	kW kW kW kW kW	3.3 5.8 5.3 5.8 -	4.7 8.2 6.9 7.5 -	7.2 12.5 13 18 -	12 21 20.5 20.4 -	20.4 35 38 51 -	25.5 44 48 66 -	278 48 60 67 -	37 65 80 97 -	49 85 98 136 -
<b>Switching frequency with overload relay</b>		1/h	15	15	15	15	15	15	15	15	15
<b>Current carrying capacity for utilization category AC-3</b>											
<b>Switchover time to 15 s</b>											
Rated operational current	At 400 V 500 V 690 V	A A A	12 8.7 6.9	17 11.3 9	25 20.8 20.8	31 31 22.5	44 44 44	57 57 57	67 67 67	97 97 97	106 106 106
Rated power of three-phase induction motors at 50 Hz and	At 230 V 400 V 500 V 690 V 1000 V	kW kW kW kW kW	3.3 5.8 5.3 5.8 -	4.7 8.2 6.9 7.5 -	7.2 12.5 13 18 -	9.4 16.3 20.4 20.4 -	13.8 24 30 42 -	18.2 31.6 40 55 -	21.6 38 47 65 -	32 55 69 95 -	35 60 75 104 -
<b>Switching frequency with overload relay</b>		1/h	15	15	15	15	15	15	15	15	15

**3RA14 contactor combinations for star-delta starting**

Starter	Frame sizes Type	S... - S... - S... 3RA... ..	00-00-00 14 15	00-00-00 14 16	0-0-0 14 23	0-0-0 14 25	2-2-0 14 34	2-2-2 14 35	2-2-2 14 36	3-3-2 14 44	3-3-2 14 45
<b>Current carrying capacity for the AC-3 utilization category</b>											
<b>Switchover time to 20 s</b>											
Rated operational current	At 400 V	A	12	17	25	28	39	51	57	85	92
	500 V	A	8.7	11.3	20.8	28	39	51	57	85	92
	690 V	A	6.9	9	20.8	22.5	39	51	57	85	92
Rated power of three-phase induction motors at 50 Hz and	At 230 V	kW	3.3	4.7	7.2	8.5	12.2	16.3	18.4	28	30
	400 V	kW	5.8	8.2	12.5	14.7	21.3	28	32	48	52
	500 V	kW	5.3	6.9	13	18.4	26.7	35	40	60	65
	690 V	kW	5.8	7.5	18	20.4	37	49	55	83	90
	1000 V	kW	–	–	–	–	–	–	–	–	–
<b>Switching frequency</b> with overload relay		1/h	15	15	15	15	15	15	15	15	15

1) Corresponds to IEC 60 947-4 (VDE 0660 Part 102):

Coordination type "1":

The destruction of the contactor and the overload relay is permissible. The contactor and/or overload relay must be replaced, if necessary.

Coordination type "2":

The overload relay must not be damaged. Contact welding on the contactor is permissible, if it can easily be separated again from the contactor.

2) Up to  $I_k \leq 0.5 \text{ kA}$ ;  $\leq 260 \text{ V}$ .

## 3RU11, 3RB10, and 3RB12 overload relays

Section	Subject	Page
<b>4.1</b>	<b>Specifications/regulations/approvals</b>	<b>4-2</b>
<b>4.2</b>	<b>Device description</b>	<b>4-4</b>
4.2.1	Overload relays in motor feeders	4-5
4.2.2	General device description	4-6
4.2.3	Operation	4-13
<b>4.3</b>	<b>Application and use</b>	<b>4-15</b>
4.3.1	3RU11 thermal overload relay and 3RB10 electronic overload relay	4-15
4.3.2	3RB12 electronic overload relays	4-19
<b>4.4</b>	<b>Accessories</b>	<b>4-23</b>
4.4.1	Electromechanical remote reset	4-23
4.4.2	Mechanical remote reset	4-24
<b>4.5</b>	<b>Mounting and connection</b>	<b>4-26</b>
4.5.1	Mounting	4-26
4.5.2	Connection	4-29
4.5.3	Circuit diagrams	4-31
<b>4.6</b>	<b>Dimensioned drawings</b>	<b>4-34</b>
<b>4.7</b>	<b>Technical specifications</b>	<b>4-37</b>
4.7.1	3RU11 thermal overload relays	4-37
4.7.2	3RB10 electronic overload relays	4-43
4.7.3	3RB12 electronic overload relays	4-47



## 4.1 Specifications/regulations/approvals

### Standards

- The 3RU11 thermal overload relays and the 3RB10 and 3RB12 electronic overload relays comply with the following standards:  
IEC 60947-1/DIN VDE 0660 Part 100  
IEC 60947-4-1/DIN VDE 0660 Part 102  
IEC 60947-5-1/DIN VDE 0660 Part 200  
IEC 60801-2, -3, -4, -5; UL 508/CSA C 22.2.
- The 3RB10 and 3RB12 electronic overload relays also comply with the EMC standards.

### Tripping classes

The tripping classes describe time intervals within which the overload relays have to trip from a cold state with 7.2 times the set current in the case of a symmetrical, three-pole load. You will find the tripping classes in which the 3RU11, 3RB10, and 3RB12 overload relays are available in Section 4.2. The following table indicates the tripping classes and tripping times in acc. with the IEC 60947-4-1 standard:

Tripping class	Tripping time $t_A$ in sec at $7.2 \times I_e$ from a cold state
10A	$2 < T_A \leq 10$
10	$4 < T_A \leq 10$
20	$6 < T_A \leq 20$
30	$9 < T_A \leq 30$

Table 4-1: Tripping classes/tripping times

### Time-delayed overload release

The following table contains the operating limits of time-delayed overload releases in the case of an all-pole load:

Overload release type	Multiple of the set current				Reference ambient temperature
	A	B	C	D	
Ambient temperature-compensated	1.05	1.2	1.5	7.2	+ 20 °C
	Not tripped < 2 h	Tripped < 2 h	Tripped < 4 min	Tripped from a cold state in 4 to 10 sec.	
			CLASS 10		
	< 2 h	< 2 h	< 8 min	6 to 20 sec	
			CLASS 20		

Table 4-2: Operating limits of time-delayed overload releases in the case of an all-pole load

### Resistance to extreme climates

The 3RU11, 3RB10, and 3RB12 overload relays are climate-proof in acc. with IEC 721.

### Shock protection

The 3RU11, 3RB10, and 3RB12 overload relays are shockproof in acc. with DIN VDE 0106 Part 100. Depending on assignment to other devices, extended terminal covers are to be attached to the connecting bars.

**Ships' systems**

The 3RU11, 3RB10, and 3RB12 overload relays are suitable for use in ships' systems.

The overload relays have been submitted to:

- GL (Germany)
- LRS (Great Britain)
- DNV (Norway)

**Explosion-proof motors**

The 3RU11 thermal overload relays and the 3RB10 and 3RB12 electronic overload relays comply with the regulations for the overload protection of explosion-proof motors of "increased safety" protection types (EEx d and EEx e) in acc. with EN 50 019/DIN VDE 0165 and DIN VDE 0170/0171:

- 3RU11: KEMA test certificate no. Ex-97.Y.3235  
DMT certificate in acc. with directive 94/9/EC: DMT 98 ATEX G001
- 3RB10: PTB test rules: PTB test report no. 3 43-8803/98
- 3RB12: PTB test rules: PTB test report no. 3 53-3907/96  
EC special test certificate in acc. with directive 94/9/EC:  
PTB 01 ATEX 3220

In the case of tripping devices with DC operation, electrical isolation must be secured by means of a battery network or a safety transformer in compliance with DIN VDE 0551.

When the 3RB12...1 electronic overload relays (no change to the switching state of the auxiliary contact elements in the event of the failure of the control supply voltage) are used to protect EEx d and EEx e motors, separate monitoring of the control supply voltage is recommended.

## 4.2 Device description

Overload relays are used to protect electrical equipment such as three-phase induction motors and transformers from overheating. Overheating can be caused by overload, asymmetric current consumption, loss of a phase in the main supply conductor, or a blocked rotor.

### Models

There are 3 overload relay models available:

- **3RU11 thermal overload relays**

The 3RU11 thermal overload relays up to 100 A are designed for the current-dependent protection of loads with normal starting (tripping class 10) against impermissible overheating.

Impermissible overheating as a result of the above-mentioned causes leads to an increase in the motor current beyond the set rated current for the motor. This increase in current heats up the bimetal strips inside the device by means of heating elements. The strips are deflected and operate the auxiliary contact elements by means of a tripping mechanism. The auxiliary contact elements switch the load off by means of a contactor.

- **3RB10 electronic overload relays**

The 3RB10 self-supplying electronic overload relays up to 100 A are designed for the current-dependent protection of loads with normal and heavy starting (tripping classes 10 and 20) against impermissible overheating.

Impermissible overheating as a result of the above-mentioned causes leads to an increase in the motor current beyond the set rated current for the motor. This increase in current is detected by the current transformers integrated in the devices and evaluated by an appropriate electronic circuit, which then sends a pulse to the auxiliary contact elements. These switch the load off by means of a contactor.

- **3RB12 electronic overload relays**

The 3RB12 externally supplied electronic overload relays up to 820 A are designed for the current-dependent protection of loads with normal to heavy starting (tripping classes 5, 10, 15, 20, 25, and 30, which can be set on the device) against impermissible overheating. Impermissible overheating as a result of the above-mentioned causes leads to an increase in the motor current beyond the set rated current for the motor. This increase in current is detected by the current transformers integrated in the devices and evaluated by an appropriate electronic circuit, which then sends a pulse to the auxiliary contact elements. These switch the load off by means of a contactor. In addition to the current-dependent protection of the loads against impermissible overheating, the 3RB12 electronic overload relay allows the temperature of the motor winding to be monitored by connecting a PTC thermistor detector circuit in order to protect the load against overtemperature. This can be caused indirectly, for example, if the flow of the coolant is hindered and cannot be detected.

#### 4.2.1 Overload relays in motor feeders

There are two categories of motor feeder:

##### **Fuseless motor feeders**

Fuseless motor feeders consist of combinations of circuit breakers for motor protection and contactors. These combinations are described in Chapter 5, "3RA1 fuseless load feeders".

##### **Fused motor feeders**

Fused motor feeders consist of combinations of contactors and overload relays, often referred to as starter combinations, with upstream short-circuit protection (e.g. fuses, circuit breakers for starter protection).

##### **The advantages of fused motor feeders are as follows:**

- It is easy to distinguish between tripping caused by an overload and tripping caused by a short circuit. In the event of a short circuit, the fuses limit the short-circuit current; in the event of an overload, the overload relay switches off the contactor and thus the motor.
- At voltages > 400 V, fuses have a short-circuit breaking capacity of up to 100 kA. As a result, in 690 V systems, in particular, fused motor feeders are often preferred.
- If automatic RESET is set, the overload relay resets itself automatically and does not have to be switched on again locally.
- A remote reset can be implemented very easily by means of attachable electrical and mechanical RESET modules for the 3RU11 and 3RB10 overload relays. The electrical remote RESET is already integrated in the 3RB12 multifunctional devices.
- Group fusing can be used with a circuit breaker to protect several motor feeders against short circuit simultaneously, which has a positive effect on the costs of a single feeder.
- If there are already outgoing feeders that are protected against short circuits in the cubicle, additional short-circuit protection is often unnecessary.
- Combinations of a circuit breaker for starter protection, a contactor, and an overload relay also have the advantage that the feeder can be easily isolated and that, in the event of a short circuit, it is disconnected in three poles. 3RV13 circuit breakers for started combinations are available in the SIRIUS modular system for building these combinations. These circuit breakers do not have any overload releases.

#### 4.2.2 General device description

The 3RU11 and 3RB10 overload relays are electrically and mechanically compatible with the 3RT10 contactors and 3RW30/31 soft starters in the corresponding frame size.

##### Frame sizes

The 3RU11 thermal overload relays and the 3RB10 electronic overload relays are available in 4 frame sizes:


- Frame size S00: width 45 mm; up to 12 A
- Frame size S0: width 45 mm; up to 25 A
- Frame size S2: width 55 mm; up to 50 A
- Frame size S3: width 70 mm; up to 100 A

The 3RB12 electronic overload relay is available with the following dimensions:


- 3RB12 46: width 70 mm; up to 100 A
- 3RB12 53: width 120 mm; up to 205 A
- 3RB12 57: width 145 mm; up to 500 A
- 3RB12 62: width 230 mm; up to 820 A

##### 3RU11

##### S00



##### S0



##### S2




Figure 4-1: 3RU11 overload relays (frame sizes S00 to S2)

##### S3





Figure 4-2: 3RU11 overload relay (frame size S3)

##### 3RB10


The construction of the 3RB10 is the same as that of the 3RU11.

**3RB12**


**3RB12 46**  
Stand-alone installation  
with bar-type transformer



**3RB12 53**



**3RB12 57**



**3RB12 62**




Figure 4-3: 3RB12 electronic overload relay

**Overload relay: comparison**

The following table compares the thermal and electronic overload relays in terms of their configuration and functionality:

	<b>3RU11</b>	<b>3RB10</b>	<b>3RB12</b>
Tripping classes	CLASS 10	CLASS 10 or 20	CLASS 5/10/15/20/ 25/30 Switchable
Current range	0.1 to 100 A	0.1 to 100 A	1.25 to 820 A
Permissible operating temperature	-20 to +70 °C <sup>1)</sup> derating	-20 to +70 °C	-25 to +70 °C
Auxiliary contact elements	1 NO + 1 NC	1 NO + 1 NC	1 NO + 1 NC over- load 1 NO + 1 NC ground fault
Manual/auto RESET	Switchable	Switchable	Switchable
Electrical remote RESET	Accessories	Accessories	Integrated
Mechan. remote RESET	Accessories	Accessories	No
Stop button (only effects NC contact)	Yes	Yes	No
Test function	Yes	Yes	Yes, electronic
Protection of direct-current machines	Yes	No	No
Protection of single-phase motors	Yes	No	Only in the case of devices without internal ground fault protection
Screw-type terminal	Yes	Yes	Yes
Main conductor connec- tion	Screw-type termi- nal	Screw-type termi- nal	Up to 100 A with Bar-type trans- former
Cage Clamp terminal	Yes (S00) S0 to S3: auxiliary conducting leads only	No	No

Table 4-3: SIRIUS overload relays, configuration and functions

1)With 13 % current reduction, up to 60 °C without restrictions

**Overview: Performance ranges**

The following table provides an overview of the assignment of the overload relays to the contactors together with their ratings:

			<b>3RU1116 3RB1016</b>	<b>3RU1126 3RB1026</b>	<b>3RU1136 3RB1036</b>	<b>3RU1146 3RB1046</b>	<b>3RB1246</b>	<b>3RB125 3RB126</b>
		Max. set current	12A	25 A	50A	100 A	100 A	820 A
	Contactor	Frame size Width	S00 45 mm	S0 45 mm	S2 55 mm	S3 70 mm	70 mm	
3 kW	3RT1015	S00	X				①	
4 kW	3RT1016	S00	X				①	
5.5 kW	3RT1017	S00	X				①	
5.5 kW	3RT1024	S0		X			①	
7.5 kW	3RT1025	S0		X			①	
11 kW	3RT1026	S0		X			①	
15 kW	3RT1034	S2			X		①	
18.5 kW	3RT1035	S2			X		①	
22 kW	3RT1036	S2			X		①	
30 kW	3RT1044	S3				X	①	
37 kW	3RT1045	S3				X	①	
45 kW	3RT1046	S3				X	①	
>45 kW	3TF5/ 3TF6	6-12					①	X

Table 4-4: Assignment of the overload relays to the contactors

X = direct attachment

① = stand-alone installation (device with bar-type transformer)

Snapped onto a 35 mm rail

**Fuses**

The maximum permissible fuse values for overload relays are dependent on:

- The selected setting range (the smaller the setting range, the lower the fuse value).
- The maximum permissible fusing of the contactor or other devices in the circuit (e.g. soft starter or even the motor supply lead).

In the case of fuse values in acc. with coordination type 2, the contactor and overload relay can be reused after a short circuit.

The type plates on the devices provide information on the permissible fuse values. In addition, you will find detailed information in part 4 of the low-voltage switching technology (NSK) catalog.

**Starter protection switch**

The operating current of the instantaneous short-circuit release should be 12 times the value of the rated motor current (the current set on the overload relay). The corresponding 3RV13 starter circuit breakers can be selected from part 2 of the low-voltage switching technology (NSK) catalog.



**Heavy starting**

Heavy starting is when the motor requires longer than 10 seconds to reach the nominal speed. Given such long starting times, the switching devices and capacities have to be configured appropriately because the thermal load increases. The permissible AC-3 currents of motor contactors only take into account 10-second starts. In the case of longer starting times, derating must be carried out or a larger contactor used. You can determine the corresponding configuration on the basis of the tables of different starting times and motor currents in part 4 of the low-voltage switching technology (NSK) catalog.

**Setting ranges with thermal overload relays**

The setting ranges can be used up to the maximum value when there are temperatures of up to 60 °C inside the cubicle. At temperatures of 60 °C to 70 °C, derating is required. In other words, the maximum permissible set value must be reduced. The reduction at 70 °C is 13 % and thus so negligible that due to the overlapping of the different current setting ranges no gaps occur between the setting ranges. A uniform current range of 0.11 to 87 A can thus also be used at 70 °C.

**Overload relays in star-delta combinations**

When overload relays are used in star-delta combinations, it must be taken into consideration that only  $1/\sqrt{3}$  of the motor current flows through the line contactor. An overload relay built onto the line contactor must be set to this level (i.e. 0.58 of the motor current). A second overload relay must be built onto the star contactor if your load is to receive optimal protection in star operation as well. The star current is  $1/3$  of the rated current of the motor. The corresponding overload relay must be set to this current. The 3RB12 electronic overload relays with internal ground fault detection are not suitable for use in star-delta combinations, since transient current spikes occur at switchover from star to delta operation. These can result in the triggering of ground fault detection.

**3RU11 thermal overload relays****Description**

- Tripping class 10
- For motor currents of up to 100 A
- For three-phase, single-phase, or DC motors
- Insensitive to "untidy" power systems

Thermal, time-delayed overload relays are the usual way of providing motor protection with overload relays. The technology has been tried and tested and continuously improved over a period of decades. They are reasonably priced and provide reliable protection, particularly in the case of normal starting times (class 10) and motor ratings of up to 45 kW (100 A).

Thermal overload relays work with bimetals and heater coils through which the motor current flows. Thermal overload relays record true root-mean-square values and direct currents as a result of their current measuring method (Joule heat). Compatible heating coils and bimetals are used for the different setting ranges. Single-phase and direct-current motors can also be protected against overload by looping the motor line. Thermally time-delayed overload relays can also be used after frequency converters.

### 3RB10 electronic overload relays

#### Description

- Tripping classes 10 and 20
- For motor currents of up to 100 A
- Low waste heat, energy-saving
- Wide setting ranges for simple configuration, selection, and less storage
- Extremely low energy requirements: approx. 50 mW

Electronic overload relays work with current transformers that provide a measurement signal that is evaluated by an electronic circuit. They are designed for sinusoidal 50/60 Hz supply voltages.

The 3RB10 electronic overload relay, like the 3RU11 thermal overload relay, can be built directly into the motor feeder but hardly causes any heat loss thanks to the electronic measurement system. The tripping classes 10 (for normal starting) and 20 (for heavy starting) are implemented with the 3RB10 electronic overload relay.

The current range of the electronic overload relays can be set to the motor current at a ratio of 1:4 (lower to upper current mark). Up to 6 motor ratings are covered by a single range, and a current range of 0.1 to 100 A is covered by only 7 setting ranges.

### 3RB12 electronic overload relays

#### Description

The 3RB12 electronic overload relays are suitable when there are high motor protection requirements on account of the following features:

- Tripping classes 5/10/15/20/25/30 settable
- For motor currents of up to 820 A
- Evaluation of PTC thermistors
- Analog output signal of 4 mA to 20 mA for current detection (insensitive to harmonics)
- High accuracy of the tripping characteristic with a tolerance of  $< \pm 10 \%$
- Ground fault detection internally and externally through summation current transformer
- Insensitive to external influences such as vibrations, different cable cross-sections, temperature fluctuations, corrosive environments or aging

The 3RB12 electronic overload relay can be used for everything from easy starting (CLASS 5) to very heavy starting (CLASS 30). The tripping class can be set in steps to the relevant motor starting time. In addition, the 3RB12 is equipped with inputs for PTC thermistors, which make it a fully protected motor device. Additional functions such as ground fault detection and an analog output signal are also possible. It is available in 4 sizes from 1.25 to 820 A.

It is triggered in the event of an overload, current imbalance, phase loss, or a blocked rotor.

**Variants**

The 3RB12 electronic overload relays are available in the following variants:

- Output relay with monostable behavior
- Output relay with bistable behavior
- For the following control supply voltages:
  - 24 VDC
  - 110 VAC to 120 VAC
  - 220 VAC to 240 VAC

**Auxiliary contact elements**

The 3RB12 electronic overload relays have electrically isolated auxiliary contact elements with the following functions (depending on the variant):

- 1 NO contact/1 NC contact for overload tripping through current and/or thermistor
- 1 NO contact/1 NC contact for ground fault tripping
- 1 NO contact/1 NC contact for overload tripping through current and/or thermistor and ground fault; 1 NO contact/1 NC contact for overload warning

**Overload protection**

The currently flowing motor current is detected in each motor supply line by current transformers and constantly monitored by a microprocessor.

An overload warning occurs as of:

- $1.15 \times I_e$  in the case of a symmetric load
- $0.85 \times I_e$  in the case of an asymmetric load

The overload warning is indicated by the flashing "Overload" LED on the overload relay or externally by means of 1 NO contact/1 NC contact.

**Thermistor motor protection**

The continuous evaluation of a PTC thermistor detector ensures thermistor motor protection.

Additional thermistor motor protection (full motor protection) is implemented by connecting a PTC thermistor detector (PTC sensor circuit in the motor winding). This is important for stator-critical motors, motors with long starting and braking, and motors with cooling systems problems or with high ambient temperatures.

No additional equipment is required for evaluation purposes.

Full motor protection is deactivated on delivery by means of a wire jumper. The monitoring of the thermistor is secure against a wire break. In other words, tripping occurs in the event of a wire break.

**Ground fault protection**

**Internal ground fault monitoring**

The ground fault protection integrated in the overload relay monitors motors with a three-conductor terminal. Ground faults are detected in the event of fault currents  $> 30\%$  of the set current  $I_e$  in rated service.

**External ground fault monitoring**

External ground fault protection is implemented by connecting a 3UL220.-A summation current transformer and monitors motors with three- and four-conductor terminals. Ground faults are detected reliably in the event of fault currents of 0.3 A, 0.5 A and 1 A. These values refer to sinusoidal fault currents 50/60 Hz.

### 4.2.3 Operation

<b>Short-circuit protection</b>	For short-circuit protection of starter combinations consisting of a contactor and an overload relay, fuses or 3RV13 circuit breakers are required for starter combinations.
<b>Use with external current transformers</b>	<p>If external current transformers are to be used to operate the 3RB12, the following things should be taken into consideration. The 3RB12 with the current setting range from 1.25 to 6.3 A must be selected.</p> <p>The secondary current of the 1 A or 5 A current transformer becomes the primary current of the 3RB12. In the case of 5 A current transformers, the 3RB12 can be set from 1.25 to 5 A (i.e. from 1/4 of to 1 times the transformer's rated current). In the case of 1 A current transformers, a signal &gt; 1.25 A must be generated by looping the line. If the line is looped five times, a 5 A signal is generated for the 3RB12.</p>
<b>Environmental conditions</b>	<p><b>3RU11</b> The 3RU11 overload relays can be used without restrictions at ambient temperatures of up to 60 °C. This is the result of new bimetals and continuous temperature compensation (up to 70 °C with derating).</p> <p><b>3RB10</b> A special coating on the PCB and the electronic components ensures reliable operation even in corrosive and tropical environmental conditions.</p>
<b>Auxiliary contact elements</b>	<p>The 3RU11 and 3RB10 overload relays are equipped with a normally closed contact for switching off the contactor and a normally open contact for the tripped signal.</p> <p>The switching contacts have a high switching capacity so that they can switch contactor coils directly. The overload relays are therefore suitable for use with a PLC (17 V, 5 mA).</p>
<b>Coil and auxiliary switch repetition terminal</b>	<p><b>Frame size S00</b> In the case of direct mounting onto contactors, the auxiliary switch and coil repeat terminals (A2) are passed through the 3RU1116 and 3RB1016 overload relays. This makes wiring much simpler.</p> <p><b>Frame sizes S0 - S3</b> The contactors of these frame sizes are equipped with 4 coil connections. It is therefore not necessary to pass through the auxiliary switch and coil terminals (A2) of the contactor.</p>

**Tripping classes**

**3RU11**

The 3RU11 thermal overload relays are available for normal starting in tripping class 10.

**3RB10**

The 3RB10 electronic overload relays are available in 2 tripping classes:

Tripping class 10 for normal starting

Tripping class 20 for heavy starting

**3RB12**

The 3RB12 electronic overload relays can be set to different tripping classes (5/10/15/20/25/30) on the device.

**Phase loss sensitivity**

The 3RU11/3RB10/3RB12 overload relays are sensitive to phase imbalance.

---

**Note on explosion protection**

For releases and relays with current-sensitive delayed tripping, tripping characteristics must be available at the installation location.

The releases or relays for machines with cage rotors must be selected in such a way that the release time in the case of a 3-pole load, which is obtained from the characteristic for the  $I_A/I_N$  ratio of the machine to be protected, is not greater than the safe locked-rotor time  $t_E$  specified on the machine's test label.

Motors must have equipment that protects them even in the event of the failure of a line conductor.

---

## 4.3 Application and use

### 4.3.1 3RU11 thermal overload relay and 3RB10 electronic overload relay

#### 3RB10

The 3RB10 electronic overload relays are developed for use in sinusoidal 50/60 Hz voltage networks. No additional supply voltage is required for operation. The current transformers are integrated in the devices for the purpose of current detection. An ASIC checks the current values of each phase and causes tripping in the event of an overload or phase loss.

#### 3RU11

3RU11 front view:




Figure 4-4: 3RU11 front view

#### Functions

- 1 Scale for setting the load rated current
- 2 Reset button (blue):  
Press the RESET button to get the relay ready before putting it into operation or after tripping.
- 3 Stop button (red):  
The stop button opens the normally closed contact, which remains open until the button is released again. The downstream contactor and thus the motor can be switched off.  
Press the STOP button to switch the relay off when it is in operation. The normally closed contact of the auxiliary switch opens. The relay remains ready for operation.
- 4 Device type plate
- 5 Terminals for three motor supply lines
- 6 Terminals for normally closed/normally open contacts (95/96 for normally closed contacts, 97/98 for normally open contacts)
- 7 Contact position indicator/test  
The slider for the contact position indicator also serves as a test function. When it is operated, tripping of the overload relay is simulated. The normally closed contact (95/96) opens, and the normally open contact (97/98) closes. The switching position is indicated.
- 8 Switch for manual/auto RESET:  
By pressing and turning the blue button you can select automatic or manual reset.  
In the case of the relay setting M (manual reset), the switching position of the relay is indicated:  
I = ready for operation  
O = tripped
- 9 Only in the case of frame size S00:  
Terminal A2: repetition terminal of the contactor coil  
Terminal 14/22: repetition terminal of the contactor auxiliary switch

**Auxiliary contacts**

The following table shows the behavior of the auxiliary contacts when the TEST/STOP and RESET buttons are pressed:

	TEST	STOP	RESET
NC 95/96			
NO 97/98			

Table 4-5: 3RU11/3RB10 auxiliary contacts

**Setting the rated current**

The following figure shows how the rated current is set, using the example of the 3RU11, frame size S00.





Figure 4-5: Setting the rated current

**Important**

When the sealing cover (transparent sliding window) is closed (3RU11) or mounted (3RB10), it is not possible to use the blue reset button for a switchover between M (manual reset) and A (automatic reset).

**Sealing the adjustment scale**

**3RU11**



**3RB10**




Figure 4-6: Sealing the adjustment scale (frame size S00)

**Recovery time**

	<b>3RU11</b>	<b>3RB10</b>
Automatic reset	3 to 5 min <sup>1)</sup>	4 min
Manual reset	3 to 5 min <sup>1)</sup>	Immediate

Table 4-6: Recovery time

1) Dependent on the setting range

**Manual-automatic**

The following figure shows how to switch between manual and automatic for the 3RU11 and 3R10 using the example of the 3RU11, frame size S00:




Figure 4-7: Manual/automatic switchover

**Resetting**

The 3RU11 thermal overload relay can also be reset manually after the bimetals have cooled down (after approx. 3 to 5 minutes), or it can reset itself automatically after this time when the AUTO position is set. The 3RB10 electronic overload relay can be reset at any time by pressing the RESET button. The recovery time for the automatic reset is 4 minutes.

**3RU11****Tripping characteristics**

The time-current characteristics show the dependency of the tripping time from a cold state on the multiple of the set current  $I_e$ . When the relay is at operating temperature, preloaded with  $1 \times I_e$ , the tripping times are reduced to around 25 %. In the case of a single-pole load, the tripping characteristics lie between the characteristics. In normal operation, all three bimetal strips of the overload relay must be heated. The 3RU overload relays are suitable for protecting motors with phase control. To protect single-phase or direct current loads, all three main conducting paths must be connected in series. The minimum tripping current in the case of a three-pole symmetric load lies between 105 % and 120 % of the set current.






Figure 4-8: Time-current characteristic, chart for the 3RU11

### 3RB10

#### Tripping characteristic

The time-current characteristics show the behavior at starting, with a three-pole load

- ① from a cold state
- ② from a warm state
- ③ in the event of phase loss or current imbalance (the phase loss protection function triggers the overload relay after 3 seconds)




Figure 4-9: Time-current characteristics for class 10 and class 20, chart for the 3RB10

### 4.3.2 3RB12 electronic overload relays

3RB12 front view:




Figure 4-10: Front view of the 3RB12 electronic overload relays

#### Functions

- 1 Terminals of the control supply voltage
- 2 Green "Ready" LED
- 3 Red "Ground Fault" LED
- 4 Red "Overload" LED
- 5 Combined test/reset button with function test
- 6 1 NO contact/1 NC contact for overload/thermistor tripping or 1 NO contact/1 NC contact for overload/thermistor or ground fault tripping
- 7 Terminals for thermistor
- 8 Terminals for external summation current transformer
- 9 Terminals for remote or automatic reset
- 10 Rotary switch for current setting
- 11 Rotary switch for the class
- 12 1 NO contact/1 NC contact for ground fault tripping or 1 NO contact/1 NC contact for overload warning

#### Overload

In the event of an overload  $> 110\%$  of the current  $I_e$  set using the rotary switch on the front of the device, of current imbalance of  $40\% I_e$ , or of phase loss, tripping occurs through the switchover of two auxiliary contact elements (1 NO contact: 97/98 / 1 NC contact: 95/96) after the tripping time set by means of the six-step rotary switch (CLASS 5/10/15/20/25/30). After overload tripping, the overload relay can be reset either by pressing the test/reset button on the device or by remote or automatic reset after the recovery time of 5 minutes elapses.

#### Thermistor detector

A tripping operation as a result of the thermistor detector responding takes place via the same auxiliary contact elements as for overload tripping (1 NO contact: 97/98 / 1 NC contact: 95/96), except that it is instantaneous.

The overload relay cannot be reset until the temperature in the motor winding 5 K has sunk to under the operating temperature of the thermistor.

**Ground fault** In the event of a ground fault, the device trips instantaneously; depending on the device variant, this may occur via a separate output (1 NO contact/1 NC contact).

**Remote/automatic reset** Remote or automatic resetting can be implemented by means of external wiring (Y1-Y2 terminals).

---

**Important**

In the case of ground fault tripping, an automatic reset is not possible.

---

**Test** The device functions of current detection, thermistor input, and ground fault input and the tripping functions of the auxiliary contact elements can be tested by pressing the test/reset button.  
The device functions can also be tested during operation. The LEDs indicate the status.

**Internal failure** Self-monitoring causes the device to trip in the event of an internal fault. In this case, the overload relay cannot be reset.

**Failure of the control supply voltage** In the event of the failure of the control supply voltage for any length of time (> 0.2 seconds), the output relays respond in either a monostable or bistable manner, depending on the variant involved.  
The following table shows the behavior of the output relays in the event of the failure of the control supply voltage:

Behavior of the <b>output relays</b> given:	<b>Monostable</b> 3RB12...-....0	<b>Bistable</b> 3RB12...-....1
Failure of the control supply voltage	Device trips	No change to the switching status of the auxiliary contact elements
Return of the control supply voltage without prior tripping	Device resets	
Return of the control supply voltage after prior tripping	Device remains tripped Reset at: - Overload tripping after 5 minutes - Thermistor tripping when 5 K under the operating temperature reached - Ground fault tripping immediately	


Table 4-7: Failure of the control supply voltage

**Tripping characteristics**


The time-current characteristic for three-pole symmetric loading shows the dependency of the tripping time from a cold state on the multiple of the set current.

When the overload relay is preloaded with 100 % of the set current, the tripping times are reduced.

In the case of two-pole loading (loss of a phase) or current imbalance > 40 % of the set current, the corresponding characteristic applies.



Three-pole loading



Two-pole loading

Figure 4-11: Time-current characteristics, chart for the 3RB12

**3RB12 electronic overload relay with analog output**

**Field of application**

The electronic overload relay with analog output is used for measuring instruments and analog modules with 4 to 20 mA input.




Figure 4-12: Electronic overload relay with analog output, front view

For automatic resetting, jumper B is attached between terminals Y1 and Y2.

**Analog output**

4 mA to 20 mA  
 1 % x I<sub>e</sub> = 0.128 mA

$$I/I_e [\%] = (I_{out} - 4 \text{ mA}) / 0.128 \text{ mA}$$

$$I_{Motor} [A] = (I_{out} - 4 \text{ mA}) \times I_e / 12.8 \text{ mA}$$

I<sub>out</sub>     Output current of the analog output  
 I<sub>Motor</sub>     Motor current, max. phase  
 I<sub>e</sub>     Set current (rated current for motor)

I <sub>out</sub> [mA]	I/I <sub>e</sub> [%]
0	No connection, wire break!
4.000	Device in operation
4.128	
5.280	0
7.200	1
10.40	10
15.52	25
16.80	50
18.08	90
20.00	100
	110
	125

Example:     I<sub>out</sub> = 10.40 mA; I<sub>e</sub> = 6.0 A  
                  I = 50% v. I<sub>e</sub>  
                  I<sub>Motor</sub> = 3 A

**Technical specifications**

Max. output current     23 mA  
 Terminals     "+" and "-"  
 Max. load     100 Ω  
 Accuracy     +/- 10%  
 Short circuit-proof and idling-proof

## 4.4 Accessories

### 4.4.1 Electromechanical remote reset

The electromechanical remote reset is suitable as an accessory for the 3RU11 and 3RB10 overload relays in frame sizes S00 to S3. It is used to reset the overload relay from control rooms after overload tripping.

The coil of the module is designed for an operation duration of 0.2 to 4 seconds. Maintained-contact control is not permissible.

#### Installation/removal

The following figure shows how the electrical remote reset is installed and removed, using the example of the 3RU11 in frame size S00.




Figure 4-13: Electrical remote reset, installation/removal

#### Voltages

24 VDC to 30 VDC 50/60 Hz  
110 VDC 127 VDC 50/60 Hz  
220 VDC to 250 VDC 50/60 Hz

#### Operating range

The operating range of the coil is:  $0.85$  to  $1.1 \times U_S$

#### Power consumption

The power consumption of the electromagnetic remote reset is:  
80 VA AC, 70 W DC

#### Manual reset

A manual reset is possible by means of the blue repeat button on the remote reset module.

#### Connection cross-sections

The values for the screw-type terminals of terminals E1 and E2 correspond to the cross-sections of the auxiliary connecting leads of the 3RU11/3RB10 overload relays.

#### 4.4.2 Mechanical remote reset

The mechanical remote reset is available in 2 variants:

- A resetting plunger with a support and funnel (3RU1900-1A) for operation from the cubicle door.  
The plunger must be cut to the required length.
- A wire release with a support (3RU1900-1B, -1C) for built-in overload relays that are hard to reach.  
The wire is available in two lengths:  
3RU1900-1B: 400 mm  
3RU1900-1C: 600 mm

##### Resetting plunger

##### Installation

The following graphics show how to install and remove the resetting plunger or the wire release for the 3RU11, frame size S00.

Example 3RU11, frame size S00:




Figure 4-14: Mechanical remote reset: resetting plunger, installation

##### Removal




Figure 4-15: Mechanical remote reset: resetting plunger, removal

### Wire release

Example 3RU11, frame size S00:

#### Installation




Figure 4-16: Mechanical remote reset: wire release, installation

#### Removal




Figure 4-17: Mechanical remote reset: wire release, removal

#### Sealable cover

A sealable cover is available as an accessory for the 3RB10 electronic overload relay.

In the case of the 3RU11 thermal overload relay, the cover is integrated in the device.



## 4.5 Mounting and connection

### 4.5.1 Mounting

#### 3RU11/3RB10

The 3RU11 and 3RB10 overload relays can be attached directly to the 3RT contactors and 3RW30/31 soft starters in the corresponding frame size. In stand-alone installation they are suitable for being snapped onto a 35 mm rail in acc. with DIN EN 50 022 or for screw-on mounting. The overload relay in the frame size S3 is suitable for 35 mm and 75 mm rails.

#### 3RB12

##### 70 mm width

The 3RB12 electronic overload relays are either snapped onto a 35 mm rail in acc. with DIN EN 50 022 or screwed onto a mounting plate by means of push-in lugs, which are available as accessories.

The devices with current setting ranges < 100 A are designed for stand-alone installation on account of the bar-type system of the primary current lines.

##### 120 mm/145 mm/230 mm width

In the case of the current setting ranges > 50 A to 820 A of the device widths 120 mm, 145 mm, and 230 mm, the 3RB12 electronic overload relays can be mounted directly onto the contactors by means of connecting bars.

A screw-on attachment is integrated in the housing of these devices.

For the 3RB1253 devices (120 mm width) there is also a base plate available for snap-on attachment to a 75 mm rail.

#### Mounting onto contactors/soft starters

The following illustration shows how overload relays (in this case the 3RU11) in frame size S00 are attached to the 3RT contactor and the 3RW30/31 soft starter:




Figure 4-18: Mounting onto the 3RT contactor/3RW3 soft starter

**Stand-alone installation**

The following illustrations show how the holder for stand-alone installation is mounted.

**Frame size S00/S0:**




Figure 4-19: Stand-alone holder, example 3RU11 (frame size S00/S0)

**Frame size S2/S3:**




Figure 4-20: Stand-alone holder, example 3RU11 (frame size S2/S3)

**Snap-on mounting**

The 3RU11 and 3RB10 overload relays can either be mounted onto the contactor or snapped onto a 35 mm rail by means of the holder for stand-alone installation.

The frame size S3 can be snapped onto a 35 mm rail or a 75 mm rail.




Figure 4-21: Snap-on mounting and removal with the 3RT contactor

**Removing the device from the rail**

**Contactor/overload relay combination**

S00/S0:

Push the contactor downward, and swing it forward (without a tool)

S2/S3:

- 1 Remove the overload relay from the contactor.
- 2 Use a screwdriver to release the snap-on mounting on the contactor (this is shown in Section 3.5 on the installation and removal of contactors).

**Screw-on mounting**

**Overload relay with holder for stand-alone installation**

The overload relay is screwed on by means of 2 M4 screws in the openings in the holder for stand-alone installation using the maximum tightening torque of 1.5 to 2 Nm. The screws are secured with washers and spring lock washers.

**Contactor/overload relay combination**

- 1 Mount the contactor on a flat surface with 2 M4 screws.
- 2 Mount the overload relay on the contactor.

**Minimum clearance**


Maintain a minimum clearance from grounded parts at the side of > 6.5 mm.

**Installation positions**

**3RU11**

The drawings below show the permissible installation positions for the 3RU11 overload relays for mounting on contactors and stand-alone installation. If the installation position is in the shaded area, an adjustment of 10% must be made.

Contactor + overload relay



Overload relay in stand-alone installation




Figure 4-22: Permissible installation positions for the 3RU11

**3RB10/3RB12**

Any installation position is possible for the 3RB10 and 3RB12.

## 4.5.2 Connection

### 3RU11

The 3RU11 overload relays are equipped with the following terminal system:

- S00 to S3: Screw-type terminal for the main and auxiliary connecting leads
- S00: Cage Clamp terminal for the main and auxiliary connecting leads (only stand-alone installation possible)
- S0 to S3: Screw-type terminal for main contacts and Cage Clamp terminal for auxiliary connecting leads (contactor mounting and stand-alone installation possible)

### 3RB10/3RB12

The 3RB10 and 3RB12 electronic overload relays have screw-type terminals. The 3RB1246 electronic overload relays are equipped with a bar-type transformer.

### Bar-type system

In the case of the 3RB1246 electronic overload relays with current setting ranges  $< 100$  A (70 mm width), the main lines are connected in a bar-type system. The main lines are connected through the current transformer integrated in the housing at rated currents for the motor of 1.25 A to 100 A.

The advantages are:

- No additional installation costs
- No power loss at the transfer resistors of the clamping units that would otherwise be necessary

### Looping through

At motor rated currents  $I_N < 1.25$  A, the motor supply leads can be fed through the loop-through openings several times ( $n$  times) in each phase.

The set current  $I_e$  of the device is calculated as follows:

$$I_e = 3 \times I_N$$

Example:

$$I_N = 0.5 \text{ A}$$

$$n = 3$$

$$I_e = 3 \times 0.5 \text{ A} = 1.5 \text{ A}$$

$n = 5$  is recommended as a good upper limit in practice.

The following graphics illustrate the loop-through system:




Figure 4-23: Loop-through system, 3RB1246

**Screw-type terminal**

The screws are captive, and the screwdriver guides allow the use of power screwdrivers.

**Cage Clamp terminal**

The following illustration shows a Cage Clamp terminal with the 3RU11, using the example of frame size S2:




Figure 4-24: 3RU11: Cage Clamp terminal (frame size S2)

Conductors with a cross-section of 0.5 mm<sup>2</sup> (with insulation stop) to 2.5 mm<sup>2</sup> can be used.

1. Insert the screwdriver into the opening until the stop.

---

**Note**

The 8WA280 screwdriver is recommended for opening the Cage Clamp terminal.

---

The screwdriver head automatically keeps the clamp open.

---

**Caution**

When clamping and unclamping, the screwdriver must be inserted in the rectangular opening until the stop. You must not make any levering or turning movements, because these might break the cage clamp.

2. Insert the conductor in the oval terminal opening.

3. Remove the screwdriver.

The terminal clamp closes, and the conductor is thus securely clamped.

**Connection cross-sections**

You can obtain the permissible connection cross-sections for the main and auxiliary connections of the overload relays from Section 4.7, "Technical specifications".

### 4.5.3 Circuit diagrams

#### Device circuit diagrams Protection of single-phase and DC motors

##### 3RU11




Figure 4-25: 3RU11 circuit diagrams

#### Circuit diagrams

##### 3RU11 and 3RB10




Figure 4-26: 3RU11 and 3RB10 device circuit diagrams

**Connection example 3RU11**




Figure 4-27: Connection example for the 3RU11

In the case of single-pole loads, the 3 main conducting paths must be connected in series.



**Warning**

In the case of an automatic reset and maintained-contact operation, the motor restarts automatically.

**Connection example 3RB10**




Figure 4-28: Connection example for the 3RU10

### 3RB12 electronic overload relays

#### Connection plans for single-phase motors




Figure 4-29: Connection plans for 3RB12 single-phase motors

#### Important

The electronic overload relays with integrated ground fault detection (3RB12...2./3RB12...3.) are not suitable for use with single-phase motors.



## 4.6 Dimensioned drawings (dimensions in mm)

### 3RU11/3RB10/3RB12 overload relays - screw-type terminals




Figure 4-30: 3RU11 16-..B0, (frame size S00) with accessories

3RU11 16, 3RB10 16, (frame size S00) with terminal bracket for stand-alone installation with accessories



Figure 4-31: 3RU11 26-..B., 3RB10 26, (frame size S0) with terminal bracket for stand-alone installation

3RU11 36-..B., 3RB10 36, (frame size S2) with terminal bracket for stand-alone installation




Figure 4-32: 3RU11 46-..B., 3RU11 46, 3RB10 46 with terminal bracket for stand-alone installation

- 1) Mechanical reset
  - 2) Wire release (400 mm or 600 mm long, mounting on front or side on bracket)
  - 3) Bracket for reset
  - 4) Module for remote reset
  - 5) Attachment to rail (35 mm, 15 mm depth to DIN EN 50 022 or 75 mm to DIN EN 50 023)
- The clearance from grounded parts at the side must be at least 6 mm.




Figure 4-33: 3RB12 46

3RB12 5. / 3RB12 62

Overload relay	a	b	c	d	e	Overload relay	a	b	c	d	e	g	h	i	j	k	l	m	n	o	p	
3RB12 46-1E	15	29	24	47	-	3RB12 53-0F	120	85	155	110	40	∅7	42	37	125	41	20	131	7.2	13	145	4
3RB12 46-1P	10	34	29	46	48	3RB12 57-0K	145	85	175	105	50	∅9	52	48	130	46	30	151	7.2	-	160	6
3RB12 46-1Q	10	34	29	46	48	3RB12 62-0L	230	85	190	120	70	∅1	70	-	135	55	40	166	7.2	-	175	8

### 3RU11 overload relays - Cage Clamp terminal




Figure 4-34: 3RU11 16...C1 (frame size S00)  
with accessories (same construction as for frame sizes S00 to S3)




Figure 4-35: 3RU11 26...D0 (frame size S0)

3RU11 36...D0 (frame size S2)




Figure 4-36: 3RU11 46-.D0 (frame size S3)

- 1) Mechanical reset
- 2) Wire release (400 mm or 600 mm long, mounted on front or side on bracket)
- 3) Bracket
- 4) Remote reset

The clearance from grounded parts at the side must be at least 6 mm.

- 5) Attached to rail (35 mm, 15 mm depth to DIN EN 50 022 or 75 mm to DIN EN 50 023).

## 4.7 Technical specifications

### 4.7.1 3RU11 thermal overload relays

Type	3RU11 16	3RU11 26	3RU11 36	3RU11 46
Frame size	S00	S0	S2	S3
Width	45 mm	45 mm	55 mm	70 mm
<b>General specifications</b>				
Tripped at	Overload and phase loss			
Tripping class	In acc. with IEC 60947-4-1	CLASS 10		
Phase loss sensitivity	Yes			
Overload warning	No			
<b>Resetting and recovery</b>				
Resetting options after tripping	Manual, remote, and automatic resetting <sup>1)</sup>			
Recovery time	With automatic reset	min	Depends on the height of the tripping current and the tripping characteristic	
	With manual reset	min	Depends on the height of the tripping current and the tripping characteristic	
	With remote reset	min	Depends on the height of the tripping current and the tripping characteristic	
<b>Configuration</b>				
Indication of operating status on device	Yes, by means of the "test function/contact position indicator" slider			
Test function	Yes			
Reset button	Yes			
Stop button	Yes			
<b>For the safe operation of motors with increased safety protection</b>	EC special test certificate number in compliance with directive 94/9/EC	KEMA test certificate no. EX-97.Y.3235 DMT 98 ATEX G001		
<b>Ambient temperatures</b>				
Storage/transportation		°C	-55 to +80	
Operation		°C	-20 to +70	
Temperature compensation		°C	To 60	
Permissible rated current at	Internal cubicle temperature of 60 °C	%	100 (current reduction is required at above +60 °C)	
	Internal cubicle temperature of 70 °C	%	87	
<b>Repetition terminals</b>				
Terminal for contactor coil		Yes	Not required	
Auxiliary switch repetition terminal		Yes	Not required	
<b>Degree of protection</b>	In acc. with IEC 60529/DIN VDE 0470 Part 1	IP 20	IP 20 <sup>2)</sup>	
<b>Shock protection</b>	In acc. with DIN VDE 0106 Part 100	Protected against touching by fingers		
<b>Sinus shock resistance</b>	In acc. with IEC 68 Part 2-27	g/ms	810	
<b>EMC noise immunity</b>				
Conducted disturbance neutralization - burst	In acc. with IEC 61 000-4-4: (corresponds to severity grade 3)	kV	EMC noise immunity is not relevant to thermal overload relays	
Conducted disturbance neutralization - surge	In acc. with IEC 61 000-4-5: (corresponds to severity grade 3)	kV	EMC noise immunity is not relevant to thermal overload relays	
Electrostatic discharge	In acc. with IEC 61 000-4-2: (corresponds to severity grade 3)	kV	EMC noise immunity is not relevant to thermal overload relays	
Field-related disturbance neutralization	In acc. with IEC 61 000-4-3: (corresponds to severity grade 3)	V/m	EMC noise immunity is not relevant to thermal overload relays	
<b>EMC emitted interference</b>	EMC noise immunity is not relevant to thermal overload relays			
<b>Resistance to extreme climates (atmospheric humidity)</b>		%	100	
<b>Site altitude</b>		m	Up to 2000 above sea level; above on request	
<b>Construction type/mounting</b>			Direct mounting <sup>3)</sup> /stand-alone installation with terminal bracket	Direct mounting/stand-alone installation with terminal bracket <sup>4)</sup>

1) Remote reset in conjunction with suitable accessories

2) Terminal compartment: IP 00 degree of protection

3) Only stand-alone installation is possible for the 3RU11 16 overload relay with the Cage Clamp terminal system.

4) For screw-on and snap-on attachment to 35 mm rail  
Frame size S3 also for 75 mm rail

## 3RU11, 3RB10, and 3RB12 overload relays

Type		3RU11 16	3RU11 26	3RU11 36	3RU11 46
<b>Frame size</b>		<b>S00</b>	<b>S0</b>	<b>S2</b>	<b>S3</b>
<b>Width</b>		<b>45 mm</b>	<b>45 mm</b>	<b>55 mm</b>	<b>70 mm</b>
<b>Main circuit</b>					
<b>Rated insulation voltage <math>U_i</math> (pollution degree 3)</b>	V	690			1000
<b>Rated impulse strength <math>U_{imp}</math></b>	kV	6			8
<b>Rated operating voltage <math>U_e</math></b>	V	690			1000
<b>Current type</b>	Direct current	Yes			
	Alternating current	Yes, frequency range up to 400 Hz			
<b>Current setting</b>	A	0.11 - 0.16	1.8 - 2.5	5.5 - 8	18 - 25
		Up to 9 - 12	Up to 20 - 25	Up to 40 - 50	Up to 80 - 100
<b>Power loss per device (max.)</b>	W	3.9 to 6.6	3.9 to 6	6 to 9	10 to 16.5
<b>Short-circuit protection</b>	With fuse, without contactor With fuse and contactor	See the selection and ordering data in the NSK catalog as of page 4/4 See the technical specifications (short-circuit protection with fuses/ circuit breakers for motor feeders)			
<b>Safe isolation between main and auxiliary conducting paths</b>	In acc. with DIN VDE 0106 Part 101 IEC 60 947-1-A1	V	500	690	
<b>Connection of the main circuit</b>					
<b>Connection type</b>		Screw-type terminal/ Cage Clamp terminal <sup>1)</sup>	Screw-type terminal	Screw-type terminal with box terminal	Screw-type terminal with box terminal <sup>2)</sup> /bar connection
<b>Screw-type terminal</b>					
• Terminal screw		Pozidriv 2			Allen screw 4 mm
• Tightening torque		Nm	0.8 to 1.2	2 to 2.5	3 to 4.5
• Connection cross-section (min./max.), 1 or 2 conductors	Single-core	mm <sup>2</sup>	2 x (0.5 to 1.5) 2 x (0.75 to 2.5) max. 2 x (1 to 4)	2 x (1 to 2.5) 2 x (2.5 to 6) max. 2 x (2.5 to 10)	2 x (0.75 to 16) - -
	Finely stranded without wire end ferrule	mm <sup>2</sup>	-		
	Finely stranded with wire end ferrule	mm <sup>2</sup>	2 x (0.5 to 1.5) 2 x (0.75 to 2.5)	2 x (1 to 2.5) 2 x (2.5 to 6)	2 x (0.75 to 16) 1 x (0.75 to 25)
	Stranded	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 25)
		mm <sup>2</sup>	2 x (0.75 to 2.5) max. 2 x (1 to 4)	2 x (2.5 to 6) max. 2 x (2.5 to 10)	1 x (0.75 to 35)
	AWG cables, single- or multi-core	AWG	2 x (18 to 14)	2 x (14 to 10)	2 x (18 to 3)
		AWG	-	-	1 x (18 to 1)
	Ribbon cables (number x width x depth)	mm	-	-	2 x (6 x 9 x 0.8)
<b>Bar connection</b>					
• Terminal screw					M 6 x 20
• Tightening torque		Nm			4 to 6
• Connection cross-section (min./max.)	Finely stranded with cable lug	mm <sup>2</sup>	-		2 x 70
	Stranded with cable lug	mm <sup>2</sup>	-		2 x 70
	AWG cables, single-core or stranded with cable lug	AWG	-		2/0
	With connecting bars (max. width)	mm	-		12

1) For the connection cross-sections for the Cage Clamp terminal system, see "Connecting the auxiliary circuit".

2) The box terminal can be removed. After the box terminal has been removed, busbar and cable-lug connections are possible.

Type	3RU11 16	3RU11 26	3RU11 36	3RU11 46
Frame size	S00	S0	S2	S3
Width	45 mm	45 mm	55 mm	70 mm
<b>Auxiliary circuit</b>				
Auxiliary contact elements (number x (variant))	1 x (1 NO contact + 1 NC contact)			
Assignment of the auxiliary contact elements	1 NO contact for the "tripped by overload" signal 1 NC contact for switching off the contactor			
Rated insulation voltage $U_i$ (pollution degree 3)	V	690		
Rated impulse strength $U_{imp}$	kV	6		
<b>Contact rating of the auxiliary contact elements</b>				
NC contact with alternating current AC-14/AC-15	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	4	
	• 120 V	A	4	
	• 125 V	A	4	
	• 230 V	A	3	
	• 400 V	A	2	
	• 600V	A	0.6	
	• 690V	A	0.5	
NO contact with alternating current AC-14/AC-15	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	3	
	• 120 V	A	3	
	• 125 V	A	3	
	• 230 V	A	2	
	• 400 V	A	1	
	• 600V	A	0.6	
	• 690 V	A	0.5	
NC contact, NO contact with direct current DC-13	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	1	
	• 60 V	A	On request	
	• 110 V	A	0.22	
	• 125 V	A	0.22	
	• 220 V	A	0.11	
Conventional free air thermal current $I_{th}$		A	6	
Contact reliability (suitable for PLC; 17 V, 5 mA)			Yes	
<b>Short-circuit protection</b>				
With fuse	Performance class	gL/gG	A	6
		rapid	A	10
With miniature circuit breaker (C characteristic)			A	6 <sup>1)</sup>
<b>Safe isolation between auxiliary conducting paths</b> in acc. with			V	415
DIN VDE 0106 Part 101				
<b>Connection of the auxiliary circuit</b>				
<b>Connection type</b>	Screw-type terminal or Cage Clamp terminal			
<b>Connection characteristics</b>			Screw-type terminal	Cage Clamp terminal
•Terminal screw			Pozidriv 2	-
•Tightening torque		Nm	0.8 to 1.2	-
•Connection cross-sections (min./max.) 1 or 2 conductors	Single-core	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (0.25 to 2.5)
		mm <sup>2</sup>	2 x (0.75 to 2.5)	
	Finely stranded without wire end ferrule	mm <sup>2</sup>	-	2 x (0.25 to 2.5)
	Finely stranded with wire end ferrule	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (0.25 to 1.5)
		mm <sup>2</sup>	2 x (0.75 to 2.5)	
	Stranded	mm <sup>2</sup>	2 x (0.5 to 1.5)	-
		mm <sup>2</sup>	2 x (0.75 to 2.5)	
	AWG cables, single- or multi-core	AWG	2 x (18 to 14)	2 x (24 to 14)
<b>® , ® , ⚡ rating data</b>				
<b>Auxiliary circuit</b>	Switching capacity		B600, R300	

1)  $U_D$  to  $I_K \leq 0.5$  kA;  $\leq 260$  V

<b>Terminal bracket for stand-alone installation</b>						
<b>Type</b>		<b>3RU19 16-3AA01</b>	<b>3RU19 26-3AA01</b>	<b>3RU19 36-3AA01</b>	<b>3RU19 46-3AA01</b>	
<b>For overload relays</b>		<b>3RU11 16</b>	<b>3RU11 26</b>	<b>3RU11 36</b>	<b>3RU11 46</b>	
<b>Mounting type</b>		For screw-on and snap-on attachment to a 35 mm rail; frame size S3 also on 75 mm rail				
<b>Connection of the main circuit</b>						
<b>Connection type</b>		Screw-type terminal		Screw-type terminal with box terminal		
•Terminal screw		Pozidriv 2		Allen screw 4 mm		
•Connection cross-section (min./max.) 1 or 2 conductors	Single-core	mm <sup>2</sup>	1 x (0.5 to 2.5) max. 1 x (up to 4)	1 x (1 to 6) max. 1 x (up to 10)	2 x (0.75 to 16)	2 x (2.5 to 16)
	Finely stranded without wire end ferrule	mm <sup>2</sup>	-			
	Finely stranded with wire end ferrule	mm <sup>2</sup>	1 x (0.5 to 2.5)	1 x (1 to 6)	2 x (0.75 to 16) 1 x (0.75 to 25)	2 x (2.5 to 35) 1 x (2.5 to 50)
	Stranded	mm <sup>2</sup>	1 x (0.5 to 2.5) max. 1 x (up to 4)	1 x (1 to 6) max. 1 x (up to 10)	2 x (0.75 to 25) 1 x (0.75 to 35)	2 x (10 to 50) 1 x (10 to 70)
	AWG cables, single- or multi-core	AWG	1 x (18 to 14)	1 x (14 to 10)	2 x (18 to 3) 1 x (18 to 1)	2 x (10 to 1/0) 2 x (10 to 2/0)
	Ribbon cables (number x width x thickness)	mm	-	-	2 x (6 x 9 x 0.8)	2 x (6 x 9 x 0.8)

**Short-circuit protection with fuses for motor feeders with short-circuit currents of up to 70 kA at 50/60 Hz 690 VAC**  
**Permissible short-circuit protection for motor starters consisting of an overload relay and a contactor of the coordination type "2"**

Adjustment range	Frame size S00									UL fuse RK5	Circuit breaker for starter protection at $I_q = 50 \text{ kA} / 400 \text{ VAC}$
	3 kW $\cong$ 3RT10 15 $I_{e \text{ max}} = 7 \text{ A}$ (at 50 Hz 400 VAC)			4 kW $\cong$ 3RT10 16 $I_{e \text{ max}} = 9 \text{ A}$ (at 50 Hz 400 VAC)			5.5 kW $\cong$ 3RT10 17 $I_{e \text{ max}} = 12 \text{ A}$ (at 50 Hz 400 VAC)				
A	gL/gG	aM	BS88T	gL/gG	aM	BS88T	gL/gG	aM	BS88T	A	
0.11 to 0.16	0.5	-	-	0.5	-	-	0.5	-	-	1	-
0.14 to 0.2	1	-	-	1	-	-	1	-	-	1	3RV1321-0BC10
0.18 to 0.25	1	-	-	1	-	-	1	-	-	1	3RV1321-0CC10
0.22 to 0.32	1.6	-	2	1.6	-	2	1.6	-	2	1	3RV1321-0DC10
0.28 to 0.4	2	-	2	2	-	2	2	-	2	1.6	3RV1321-0EC10
0.35 to 0.5	2	-	2	2	-	2	2	-	2	2	3RV1321-0FC10
0.45 to 0.63	2	-	4	2	-	4	2	-	4	2.5	3RV1321-0GC10
0.55 to 0.8	4	-	4	4	-	4	4	-	4	3	3RV1321-0HC10
0.7 to 1	4	-	6	4	-	6	4	-	6	4	3RV1321-0JC10
0.9 to 1.25	4	-	6	4	-	6	4	-	6	5	3RV1321-0KC10
1.1 to 1.6	6	-	10	6	-	10	6	-	10	6	3RV1321-1AC10
1.4 to 2	6	-	10	6	-	10	6	-	10	8	3RV1321-1BC10
1.8 to 2.5	10	-	10	10	-	10	10	-	10	10	-
2.2 to 3.2	10	-	16	10	-	16	10	-	16	12	-
2.8 to 4	16	-	16	16	-	16	16	-	16	16	-
3.5 to 5	20	6	20	20	6	20	20	6	20	20	-
4.5 to 6.3	20	6	20	20	6	20	20	6	20	25	-
5.5 to 8	20	10	20	20	10	20	20	10	20	30	-
7 to 10				20	16	20	20	16	20	40	-
9 to 12							20	16	25	45	-

Adjustment range	Frame size S0									UL fuse RK5	Circuit breaker for starter protection at $I_q = 50 \text{ kA} / 400 \text{ VAC}$
	5.5 kW $\cong$ 3RT10 24 $I_{e \text{ max}} = 12 \text{ A}$ (at 50 Hz 400 VAC)			7.5 kW $\cong$ 3RT10 25 $I_{e \text{ max}} = 17 \text{ A}$ (at 50 Hz 400 VAC)			11 kW $\cong$ 3RT10 26 $I_{e \text{ max}} = 25 \text{ A}$ (at 50 Hz 400 VAC)				
A	gL/gG	aM	BS88T	gL/gG	aM	BS88T	gL/gG	aM	BS88T	A	
1.8 to 2.5	10	-	10	10	-	10	10	-	10	10	3RV1321-1CC10
2.2 to 3.2	10	-	16	10	-	16	10	-	16	12	3RV1321-1DC10
2.8 to 4	16	-	16	16	-	16	16	-	16	16	3RV1321-1EC10
3.5 to 5	20	6	20	20	6	20	20	6	20	20	3RV1321-1FC10
4.5 to 6.3	20	6	25	20	6	25	20	6	25	25	3RV1321-1GC10
5.5 to 8	25	10	25	25	10	25	25	10	25	30	3RV1321-1HC10
7 to 10	25	16	25	25	16	25	32	16	35	40	3RV1321-1JC10
9 to 12.5	25	20	25	25	20	25	35	20	35	45	3RV1321-1KC10
11 to 16	25	20	25	25	20	25	35	20	35	60	3RV1321-4AC10
14 to 20				25	20	25	35	20	35	80	3RV1321-4BC10
17 to 22							35	20	35	80	3RV1321-4CC10
20 to 25							35	20	35	100	



**Short-circuit protection with fuses for motor feeders with short-circuit currents of up to 70 kA at 50/60 Hz 690 VAC**

Adjustment range	Frame size S2									UL fuse RK5	Circuit breaker for starter protection at $I_q = 50 \text{ kA} / 400 \text{ VAC}$
	15 kW $\hat{=}$ 3RT10 34 $I_{e \text{ max}} = 32 \text{ A}$ (at 50 Hz 400 VAC)			18.5 kW $\hat{=}$ 3RT10 35 $I_{e \text{ max}} = 40 \text{ A}$ (at 50 Hz 400 VAC)			22 kW $\hat{=}$ 3RT10 36 $I_{e \text{ max}} = 50 \text{ A}$ (at 50 Hz 400 VAC)				
A	gL/gG	aM	BS88T	gL/gG	aM	BS88T	gL/gG	aM	BS88T	A	
5.5 to 8	25	10	25	25	10	25	25	10	25	30	–
7 to 10	32	16	32	32	16	32	32	16	32	40	–
9 to 12.5	35	16	35	35	16	35	35	16	35	50	–
11 to 16	40	20	40	40	20	40	40	20	40	60	–
14 to 20	50	25	50	50	25	50	50	25	50	80	–
18 to 25	63	32	63	63	32	63	63	32	63	100	3RV1331-4DC10
22 to 32	63	35	63	63	35	63	80	35	80	125	3RV1331-4EC10
28 to 40	63	50	63	63	50	63	80	50	80	150	3RV1331-4FC10
36 to 45				63	50	80	80	50	80	175	3RV1331-4GC10
40 to 50							80	50	80	200	3RV1331-4HC10

Adjustment range	Frame size S3									UL fuse RK5	Circuit breaker for starter protection at $I_q = 50 \text{ kA} / 400 \text{ VAC}$
	30 kW $\hat{=}$ 3RT10 44 $I_{e \text{ max}} = 65 \text{ A}$ (at 50 Hz 400 VAC)			37 kW $\hat{=}$ 3RT10 45 $I_{e \text{ max}} = 80 \text{ A}$ (at 50 Hz 400 VAC)			45 kW $\hat{=}$ 3RT10 46 $I_{e \text{ max}} = 95 \text{ A}$ (at 50 Hz 400 VAC)				
A	gL/gG	aM	BS88T	gL/gG	aM	BS88T	gL/gG	aM	BS88T	A	
18 to 25	63	32	63	63	32	63	63	32	63	100	–
22 to 32	80	35	80	80	35	80	80	35	80	125	–
28 to 40	80	50	80	80	50	80	80	50	80	150	–
36 to 50	125	50	125	125	50	125	125	50	125	200	–
45 to 63	125	63	125	160	63	160	160	63	160	250	3RV1341-4JC10
57 to 75				160	80	160	160	80	160	300	3RV1341-4KC10
70 to 90							160	100	160	350	3RV1341-4LC10
80 to 100							160	100	160	350	3RV1341-4MC10

## 4.7.2 3RB10 electronic overload relays

Type		3RB10 16	3RB10 26	3RB10 36	3RB10 46
Frame size		S00	S0	S2	S3
Width		45 mm	45 mm	55 mm	70 mm
<b>General specifications</b>					
Tripped at		Overload, phase loss, and phase imbalance (>40% in acc. with NEMA)			
Tripping class	In acc. with IEC 60 947-4-1	CLASS 10 and 20, depending on the variant			
Phase loss sensitivity		Yes, tripped from a warm state < 3 seconds			
Overload warning		no			
<b>Resetting and recovery</b>					
Resetting options after tripping		Manual, remote, and automatic resetting <sup>1)</sup>			
Recovery time	With automatic reset	min	Approx. 4		
	With manual reset	min	Immediate		
	With remote reset	min	Immediate		
<b>Configuration</b>					
Indication of operating status on device		Yes, by means of the "test function/contact position indicator" slider			
Test function		yes			
Reset button		yes			
Stop button		yes			
For the safe operation of motors with increased safety protection	EC special test certificate number in compliance with directive 94/9/EC	On request			
<b>Ambient temperatures</b>					
Storage/transportation		°C	-55 to +80		
Operation		°C	-20 to +70		
Temperature compensation		°C	Up to 70		
Permissible rated current at	Internal cubicle temperature of 60 °C	%	100 (current reduction is required at above +60 °C)		
	Internal cubicle temperature of 70 °C	%	100 (current reduction is required at above +60 °C)		
<b>Repetition terminals</b>					
Terminal for contactor coil		Yes	Not required		
Auxiliary switch repetition terminal		Yes	Not required		
Degree of protection	In acc. with IEC 60 529/DIN VDE 0470 Part 1	IP 20	IP 20 <sup>2)</sup>		
Shock protection	In acc. with DIN VDE 0106 Part 100	protected against touching by fingers			
Sinus shock resistance	In acc. with IEC 68 Part 2-27	g/ms	8/10 and 15/11		
<b>EMC noise immunity</b>					
Conducted disturbance neutralization - burst	In acc. with IEC 61 000-4-4: (corresponds to severity grade 3)	kV	2		
Conducted disturbance neutralization - surge	In acc. with IEC 61 000-4-5: (corresponds to severity grade 3)	kV	2/1 (line to ground/line to line)		
Electrostatic discharge	In acc. with IEC 61 000-4-2: (corresponds to severity grade 3)	kV	6/8 (contact/air discharge)		
Field-related disturbance neutralization	In acc. with IEC 61 000-4-3: (corresponds to severity grade 3)	V/m	3	10 <sup>3)</sup>	10
EMC emitted interference		Limit value class B in acc. with CISPR 11			
Resistance to extreme climates (atmospheric humidity)		%	100		
Dimensions		See dimensioned drawings			
Site altitude		m	Up to 2000 above sea level		
Installation position		Any			
Construction type/mounting		Direct mounting/stand-alone installation with terminal bracket <sup>4)</sup>			

1) Remote reset in conjunction with suitable accessories

2) Terminal compartment: IP 00 degree of protection

3) For the setting ranges 0.1 to 0.4 A, 0.4 to 1.6 A, and 1.5 to 6 A, it is 3 V/m.

4) For screw-on and snap-on attachment to 35 mm rail  
Frame size S3 also for 75 mm rail

## 3RU11, 3RB10, and 3RB12 overload relays

Type		3RB10 16	3RB10 26	3RB10 36	3RB10 46	
<b>Frame size</b>		<b>S00</b>	<b>S0</b>	<b>S2</b>	<b>S3</b>	
<b>Width</b>		<b>45 mm</b>	<b>45 mm</b>	<b>55 mm</b>	<b>70 mm</b>	
<b>Main circuit</b>						
<b>Rated insulation voltage <math>U_i</math> (pollution degree 3)</b>	V	690			1000	
<b>Rated impulse strength <math>U_{imp}</math></b>	kV	6			8	
<b>Rated operating voltage <math>U_e</math></b>	V	690			1000	
<b>Current type</b>	Direct current	No				
	Alternating current	Yes, 50/60 Hz $\pm$ 3 (other frequencies on request)				
<b>Current setting</b>	A	0.1 - 0.4	0.1 - 0.4	6 - 25	13 - 50	
		Up to 3 - 12	Up to 6 - 25	Up to 13 - 50	Up to 25 - 100	
<b>Power loss per device (max.)</b>	W	Approximately 0.5				
<b>Short-circuit protection</b>	With fuse, without contactor With fuse and contactor	See the selection and ordering data in the NSK catalog as of page 4/4 See the technical specifications (short-circuit protection with fuses for motor feeders)				
<b>Safe isolation between main and auxiliary conducting paths</b>	In acc. with DIN VDE 0106 Part 101 IEC 60 947-1-A1	V	On request			
<b>Connection of the main circuit</b>						
<b>Connection type</b>		Screw-type terminal		Screw-type terminal with box terminal	Screw-type terminal with box terminal <sup>1)</sup> /bar connection	
<b>Screw-type terminal</b>						
•Terminal screw		Pozidriv 2			Allen screw 4 mm	
•Tightening torque		Nm	0.8 to 1.2	2 to 2.5	3 to 4.5	4 to 6
•Connection cross-sections (min./max.), 1 or 2 conductors	Single-core	mm <sup>2</sup>	2 x (0.5 to 1.5) max. 2 x (1 to 4)	2 x (1 to 2.5) 2 x (2.5 to 6) (2.5 to 10)	2 x (0.75 to 16) -	2 x (2.5 to 16) -
	Finely stranded without wire end ferrule	mm <sup>2</sup>	-			
	Finely stranded with wire end ferrule	mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 16)	2 x (2.5 to 35)
	Stranded	mm <sup>2</sup>	2 x (0.75 to 2.5)	2 x (2.5 to 6)	1 x (0.75 to 25)	1 x (2.5 to 50)
		mm <sup>2</sup>	2 x (0.5 to 1.5)	2 x (1 to 2.5)	2 x (0.75 to 25)	2 x (10 to 50)
		mm <sup>2</sup>	2 x (0.75 to 2.5) max. 2 x (1 to 4)	2 x (2.5 to 6) max. 2 x (2.5 to 10)	1 x (0.75 to 35)	1 x (10 to 70)
	AWG cables, single- or multi-core	AWG	2 x (18 to 14)	2 x (14 to 10)	2 x (18 to 3)	2 x (10 to 1/0)
		AWG	-	-	1 x (18 to 1)	2 x (10 to 2/0)
	Ribbon cables (number x width x depth)	mm	-	-	2 x (6 x 9 x 0.8)	2 x (6 x 9 x 0.8)
<b>Bar connection</b>						
•Terminal screw					M 6 x 20	
•Tightening torque		Nm			4 to 6	
•Connection cross-section (min./max.)	Finely stranded with cable lug	mm <sup>2</sup>	-		2 x 70	
	Stranded with cable lug	mm <sup>2</sup>	-		2 x 70	
	AWG cables, single-core or stranded with cable lug	AWG	-		2/0	
	With connecting bars (max. width)	mm	-		12	

1) The box terminal can be removed. After the box terminal has been removed, busbar and cable-lug connections are possible.

**3RB10 electronic overload relays**

Type	3RB10 16	3RB10 26	3RB10 36	3RB10 46
Frame size	S00	S0	S2	S3
Width	45 mm	45 mm	55 mm	70 mm
<b>Auxiliary circuit</b>				
Auxiliary contact elements (number x (variant))	1 x (1 NO contact + 1 NC contact)			
Assignment of the auxiliary contact elements	1 NO contact for the "tripped by overload" signal 1 NC contact for switching off the contactor			
Rated insulation voltage $U_i$ (pollution degree 3)	V	690		
Rated impulse strength $U_{imp}$	kV	6		
<b>Contact rating of the auxiliary contact elements</b>				
NC contact with alternating current AC-14/AC-15	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	4	
	• 120 V	A	4	
	• 125 V	A	4	
	• 230 V	A	3	
	• 400 V	A	2	
	• 600V	A	1	
	• 690V	A	1	
NO contact with alternating current AC-14/AC-15	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	4	
	• 120 V	A	4	
	• 125 V	A	4	
	• 230 V	A	3	
	• 400 V	A	2	
	• 600V	A	1	
	• 690 V	A	1	
NC contact, NO contact with direct current DC-13	Rated operational current $I_e$ at $U_e$ :			
	• 24 V	A	1	
	• 60 V	A	0.22	
	• 110 V	A	0.22	
	• 125 V	A	0.22	
	• 220 V	A	0.11	
Conventional free air thermal current $I_{th}$		A	6	
Contact reliability (suitable for PLC; 17 V, 5 mA)			yes	
<b>Short-circuit protection</b>				
With fuse	Performance class	gL/gG	A	6
		rapid	A	10
With miniature circuit breaker (C characteristic)			A	6 <sup>1)</sup>
Safe isolation between auxiliary conducting paths in acc. with DIN VDE 0106 Part 101	V	300		
<b>Connection of the auxiliary circuit</b>				
Connection type	Screw-type terminal			
<b>Connection characteristics</b>				
•Terminal screw				Pozidriv 2
•Tightening torque			Nm	0.8 to 1.2
•Connection cross-sections (min./max.) 1 or 2 conductors	Single-core		mm <sup>2</sup>	2 x (0.5 to 1.5)
			mm <sup>2</sup>	2 x (0.75 to 2.5)
	Finely stranded without wire end ferrule		mm <sup>2</sup>	-
	Finely stranded with wire end ferrule		mm <sup>2</sup>	2 x (0.5 to 1.5)
			mm <sup>2</sup>	2 x (0.75 to 2.5)
	Stranded		mm <sup>2</sup>	2 x (0.5 to 1.5)
			mm <sup>2</sup>	2 x (0.75 to 2.5)
	AWG cables, single- or multi-core	AWG	2 x (18 to 14)	
<b>®, ®, ⚡ rating data</b>				
Auxiliary circuit	Switching capacity	B600, R300		

1) Up to  $I_k \leq 0.5$  kA;  $\leq 260$  V

**Short-circuit protection with fuses for motor feeders with short-circuit currents of up to 50 kA at 690 VAC**

Overload relay Adjustment range	Contactor	CLASS		690 V			Fuse links <sup>1)</sup>		415 V		600 V		
		10	20	Rated operating current I <sub>e</sub> AC-3 in A at			NH	Type 3NA	NH	British	U <sub>L</sub> -listed fuses		
Type	Type	400 V	500 V	690 V	400 V	500 V	690 V	"1"	"2"	"2"	"1"	"2"	CLASS R K5
<b>Frame size S00</b>													
0.1 A to 0.4 A 3RB10 16	3RT10 15 <sup>3)</sup>	0.4	0.4	0.4	0.4	0.4	0.4	25	2		25	2	1.6
0.4 A to 1.6 A 3RB10 16	3RT10 15 <sup>3)</sup>	1.6	1.6	1.6	1.6	1.6	1.6	25	6		35	6	6
1.5 A to 6 A 3RB10 16	3RT10 15 <sup>3)</sup>	6	5	4	6	5	4	35	20		35	20	25
3 A to 12 A 3RB10 16	3RT10 17 <sup>3)</sup>	6	6	6	6	6	6	35	20		35	20	
3 A to 12 A 3RB10 16	3RT10 17 <sup>3)</sup>	12	9	6.3	10	6	6.3	35	20		35	25	45
<b>Frame size S0</b>													
0.1 A to 0.4 A 3RB10 26	3RT10 24 <sup>3)</sup>	0.4	0.4	0.4	0.4	0.4	0.4	63	2		63	2	1.6
0.4 A to 1.6 A 3RB10 26	3RT10 24 <sup>3)</sup>	1.6	1.6	1.6	1.6	1.6	1.6	63	6		63	6	6
1.5 A to 6 A 3RB10 26	3RT10 24 <sup>3)</sup>	6	6	6	6	6	6	63	25	20	63	25	25
3 A to 12 A 3RB10 26	3RT10 24 <sup>3)</sup>	12	12	12	12	12	12	63	25	20	63	25	45
6 A to 25 A 3RB10 26	3RT10 24 <sup>3)</sup>	12	12	12	12	12	12	63	25	20	63	25	70
	3RT10 25 <sup>3)</sup>	17	17	13	16	16	13	63	25	20	63	25	70
	3RT10 26 <sup>3)</sup>	25	18	13	16	16	13	100	35	20	63	25	100
<b>Frame size S2</b>													
6 A to 25 A 3RB10 36	3RT10 34 <sup>3)</sup>	25	25	25	22	22	22	125	63	50	125	63	100
	3RT10 35 <sup>3)</sup>	25	25	25	25	25	25	125	63	50	125	63	100
13 A to 50 A 3RB10 36	3RT10 34 <sup>3)</sup>	32	32	31	22	22	22	125	63	50	125	63	125
	3RT10 35 <sup>3)</sup>	40	40	40	29	29	29	125	63	50	125	80	150
	3RT10 36 <sup>3)</sup>	50	50	40	32	32	33	160	80	50	125	80	200
<b>Frame size S3</b>													
13 A to 50 A 3RB10 46	3RT10 44 <sup>3)</sup>	50	50	50	49	49	49	250	100	63	250	100	200
	3RT10 45 <sup>3)</sup>	50	50	50	50	50	50	250	100	80	250	100	200
25 A to 100 A 3RB10 46	3RT10 44 <sup>3)</sup>	65	65	57	49	49	49	250	125	63	250	125	250
	3RT10 45 <sup>3)</sup>	80	80	80	53	53	53	250	160	80	250	160	350
	3RT10 46 <sup>3)</sup>	95	95	95	59	59	59	250	160	100	250	160	350

- 1) Please note the operating voltage.
- 2) Assignment and short-circuit facilities in acc. with IEC 60 947-4-1/DIN VDE 660 Part 102  
**Coordination type "1"**: Contactors or starters must not endanger people or the system in the event of a short circuit. They do not have to be suitable for further operation without repair and part replacement.  
**Coordination type "2"**: Contactors or starters must not endanger people or the system in the event of a short circuit and must be suitable for further use. There is a danger of contact welding.
- 3) Mounting on the contactor is possible after removal of the box terminal block.

### 4.7.3 3RB12 electronic overload relays

Type			3RB12 46	3RB12 53	3RB12 57	3RB12 62
Width			70 mm	120 mm	145 mm	230 mm
<b>General specifications</b>						
<b>Tripped at</b>			Overload, phase loss, phase imbalance (>40% in acc. with NEMA), ground fault, and operation of thermistor motor protection <sup>1)</sup>			
<b>Tripping class</b>	In acc. with IEC 60 947-4-1	CLASS	5, 10, 15, 20, 25, and 30; adjustable by means of a 6-way rotary switch			
<b>Phase loss sensitivity</b>			Yes			
<b>Overload warning</b>			Yes, as of $1.5 \times I_e$ given a symmetric load, and as of $0.85 \times I_e$ given an asymmetric load			
<b>Resetting and recovery</b>						
Resetting options after tripping			Manual, remote, and automatic resetting <sup>1)</sup>			
Recovery time	With automatic reset	min	When tripped by overcurrent: 5 (stored permanently) When tripped by thermistor: time until the motor temperature 5K sinks under the operating temperature When tripped by ground fault: no automatic reset			
	With manual reset	min	When tripped by overcurrent: 5 (stored permanently) When tripped by thermistor: time until the motor temperature 5K sinks under the operating temperature When tripped by ground fault: immediate			
	With remote reset	min	When tripped by overcurrent: 5 (stored permanently) When tripped by thermistor: time until the motor temperature 5K sinks under the operating temperature When tripped by ground fault: immediate			
<b>Configuration</b>						
Indication of operating status on device			Yes, with 3 LEDs; green "Ready" LED, red "Overload" LED, and red "Ground fault" LED <sup>2)</sup>			
Test function			Yes, with combined TEST/RESET button <sup>2)</sup>			
Reset button			Yes, with combined TEST/RESET button <sup>2)</sup>			
Stop button			Yes, with combined TEST/RESET button <sup>2)</sup>			
<b>For the safe operation of motors with increased safety protection</b>	EC special test certificate number in compliance with directive 94/9/EC		PTB 01 ATEX 3220			
<b>Ambient temperatures</b>						
Storage/transportation		°C	-40 to +80			
Operation		°C	-25 to +70			
Temperature compensation		°C	Up to 70			
Permissible rated current at	Internal cubicle temperature of 60 °C	%	100 (current reduction is not required at above +60 °C)			
	Internal cubicle temperature of 70 °C	%	100 (current reduction is not required at above +60 °C)			
<b>Repetition terminals</b>						
Terminal for contactor coil			Not required			
Auxiliary switch repetition terminal			Not required			
<b>Degree of protection</b>	In acc. with IEC 60 529/DIN VDE 0470 Part 1		IP 20 ( $\leq 100$ A max. set current $I_e$ ) IP 00 ( $\leq 100$ A max. set current $I_e$ )			
<b>Shock protection</b>	In acc. with DIN VDE 0106 Part 100		Protected against finger touch	Protected against finger touch with cover		
<b>Sinus shock resistance</b>	In acc. with IEC 68 Part 2-27	g/ms	15/11			
<b>EMC noise immunity</b>						
Conducted disturbance neutralization - burst	In acc. with IEC 61 000-4-4: (corresponds to severity grade 3)	kV	2			
Conducted disturbance neutralization - surge	In acc. with IEC 61 000-4-5: (corresponds to severity grade 3)	kV	2			
Electrostatic discharge	In acc. with IEC 61 000-4-2: (corresponds to severity grade 3)	kV	8			
Field-related disturbance neutralization	In acc. with IEC 61 000-4-3: (corresponds to severity grade 3)	V/m	10			
<b>EMC emitted interference</b>			Limit value class B in acc. with EN 55 011			
<b>Resistance to extreme climates (atmospheric humidity)</b>			%	100		
<b>Dimensions</b>						
<b>Site altitude</b>			m	Up to 2000 above sea level		
<b>Construction type/mounting</b>			Stand-alone installation <sup>3)</sup>	Direct mounting/stand-alone installation without additional terminal bracket <sup>4)</sup>		

1) Tripped at ground fault only in the case of devices with the order number suffixes 20 and 30 or in conjunction with the external summation current transformer

2) For a detailed explanation, see "Description".

3) Snap-on attachment to 35 mm rail or screw-on attachment with accessories

4) For screw-on attachment

## 3RU11, 3RB10, and 3RB12 overload relays

Type		3RB12 46	3RB12 53	3RB12 57	3RB12 62
<b>Width</b>		<b>70 mm</b>	<b>120 mm</b>	<b>145 mm</b>	<b>230 mm</b>
<b>Main circuit</b>					
<b>Rated insulation voltage <math>U_i</math> (pollution degree 3)</b>	V	690 (for bare/ uninsulated conductors) 1000 (for insula- ted conductors)	1000		
<b>Rated impulse strength <math>U_{imp}</math></b>	kV	6	8		
<b>Rated operating voltage <math>U_e</math></b>	V	690	1000		
<b>Current type</b>	Direct current Alternating current	No Yes, 50/60 Hz			
<b>Current setting</b>	A	1.25 - 6.3 Up to 25 - 100	50 - 205	125 - 500	200 - 820
<b>Power loss per device (max.)</b>	W	Approx. 2			
<b>Short-circuit protection</b>	With fuse, without contactor With fuse and contactor		See the selection and ordering data in the NSK catalog as of page 4/4 See the technical specifications (short-circuit protection with fuses for motor feeders)		
<b>Safe isolation between main and auxiliary conducting paths</b>	In acc. with DIN VDE 0106 Part 101 IEC 60 947-1-A1	V	Up to 690 V (using main cir- cuit cables with an impulse with- stand voltage of 6 kV)	Up to 690	
<b>Connection of the main circuit</b>					
<b>Connection type</b>		Bar-type trans- former connec- tion	Bar connection		
<b>Screw-type terminal</b>					
• Terminal screw		-			
• Tightening torque	Nm	-			
• Connection cross-section (min./max.), 1 or 2 conductors	Single-core	mm <sup>2</sup>	-		
	Finely stranded without wire end ferrule	mm <sup>2</sup>	-		
	Finely stranded with wire end ferrule	mm <sup>2</sup>	-		
		mm <sup>2</sup>	-		
	Stranded	mm <sup>2</sup>	-		
		mm <sup>2</sup>	-		
	AWG cables, single- or multi-core	AWG	-		
		AWG	-		
	Ribbon cables (number x width x depth)	mm	-		
<b>Bar connection</b>					
• Terminal screw		-	M8	M10	M 10 or M 12
• Tightening torque	Nm	-	10 to 14	14 to 24	14 to 24 (with M10) 20 to 25 (with M12)
• Connection cross-section (min./max.)	Finely stranded with cable lug	mm <sup>2</sup>	-	35 to 95	50 to 240
	Stranded with cable lug	mm <sup>2</sup>	-	50 to 120	70 to 240
	AWG cables, single-core or stranded with cable lug	AWG	-	1/0 to 250 kcmil	2/0 to 500 kcmil
	With connecting bars (max. width)	mm	-	20 x 4	30 x 6
			-	40 x 8	
<b>Bar-type transformer connection</b>					
• Opening diameter		mm	10 (devices ≤ 25 A max. set current $I_b$ ) 15 (devices with max. 100 A set current $I_b$ )	-	
• Conductor cross-section	NYN	mm <sup>2</sup>	-	-	
•	H07RN-F	mm <sup>2</sup>	10/16	-	

Type	3RB12 46	3RB12 53	3RB12 57	3RB12 62
<b>Width</b>	<b>70 mm</b>	<b>120 mm</b>	<b>145 mm</b>	<b>230 mm</b>
<b>Auxiliary circuit</b>				
<b>Auxiliary contact elements: number x (variant)</b>	2 x (1 NO contact + 1 NC contact)			
<b>Assignment of the auxiliary contact elements</b>	1 NO contact for the "tripped by overload and/or thermistor" signal 1 NC contact for tripping the contactor  1 NO contact for the "tripped by ground fault" signal 1 NC contact for tripping the contactor  Or <sup>1)</sup> 1 NO contact for the "tripped by overload and/or thermistor and/or ground fault" signal 1 NC contact for switching off the contactor  1 NO contact for the "tripped by ground fault" signal 1 NC contact for tripping the contactor			
<b>Rated insulation voltage <math>U_i</math> (pollution degree 3)</b>	V	300		
<b>Rated impulse strength <math>U_{imp}</math></b>	kV	4		
<b>Contact rating of the auxiliary contact elements</b>				
NC contact with alternating current AC-14/AC-15	Rated operational current $I_{\theta}$ at $U_{\theta}$ :			
	• 24 V	A	6	
	• 120 V	A	6	
	• 125 V	A	2)	
	• 230 V	A	3	
	• 400 V	A	1.5	
	• 600 V	A	2)	
	• 690 V	A	2)	
NO contact with alternating current AC-14/AC-15	Rated operational current $I_{\theta}$ at $U_{\theta}$ :			
	• 24 V	A	6	
	• 120 V	A	6	
	• 125 V	A	2)	
	• 230 V	A	3	
	• 400 V	A	1.5	
	• 600 V	A	2)	
	• 690 V	A	2)	
NC contact, NO contact with direct current DC-13	Rated operational current $I_{\theta}$ at $U_{\theta}$ :			
	• 24 V	A	2	
	• 60 V	A	0.55	
	• 110 V	A	0.25	
	• 125 V	A	0.25	
	• 220 V	A	0.14	
Conventional free air thermal current $I_{th}$		A	6	
Contact reliability (suitable for PLC; 17 V, 5 mA)			2)	
<b>Short-circuit protection</b>				
With fuse	Performance class	gL/gG	A	6
		fIink	A	10
With miniature circuit breaker (C characteristic)			A	1.6 <sup>3)</sup>
<b>Safe isolation between auxiliary conducting paths</b>			V	300
in acc. with DIN VDE 0106 Part 101				



**Connection of the auxiliary circuit**

<b>Connection type</b>		Screw-type terminal	
<b>Connection characteristics</b>			
•Terminal screw			Pozidriv 2
•Tightening torque		Nm	0.8 to 1.2
•Connection cross-sections (min./max.) 1 or 2 conductors	Single-core	mm <sup>2</sup>	1 x (0.5 to 4)
		mm <sup>2</sup>	2 x (0.5 to 2.5)
	Finely stranded without wire end ferrule	mm <sup>2</sup>	1 x (0.5 to 2.5)
		mm <sup>2</sup>	2 x (0.5 to 1.5)
	Finely stranded with wire end ferrule	mm <sup>2</sup>	1 x (0.5 to 2.5)
		mm <sup>2</sup>	2 x (0.5 to 1.5)
	Stranded	mm <sup>2</sup>	-
	AWG cables, single- or multi-core	AWG	Without wire end ferrule 2 x (20 to 14) 1 x (20 to 12)
		With wire end ferrule: 2 x (20 to 15) 1 x (20 to 14)	
<b>Ⓢ, Ⓜ, Ⓜ rating data</b>			
<b>Auxiliary circuit</b>	Switching capacity		B600, R300

- 1) The assignment of the auxiliary contact elements depends on the order number suffix
- 2) On request
- 3) Up to  $I_K \leq 1000$  A

**Short-circuit protection with fuses for motor feeders for short-circuit currents of up to 50 kA at 690 V for 3RB12 and 3UF50**

Overload relay Overload relay Adjustment range	Contactor Contactor	CLASS															690 V			415 V		600 V												
		CLASS															Fuse links <sup>1)</sup>			British standards fuses		UL-listed fuses												
(Type)		5 and 10					15					20					25					30					NH	Type 3NA	NH	Type 3ND	aM	Type T	BS88	RK5
		400 V	500 V	690 V	400 V	500 V	690 V	400 V	500 V	690 V	400 V	500 V	690 V	400 V	500 V	690 V	400 V	500 V	690 V	400 V	500 V	690 V	1	2	2	2								
<b>1.25 - 6.3 A</b>																																		
3RB1246-1P	3RT1015	6.3	5	4	6.3	5	4	6.3	5	4	6.3	5	4	6.3	5	4	6.3	5	4	35	20	-	20	25										
	3RT1016	6.3	6.3	5.2	6.3	6.3	5.2	6.3	6.3	5.2	6.3	6.3	5.2	6.3	6.3	5.2	6.3	6.3	5.2	35	20	-	20	25										
	3RT1017	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	6.3	35	20	-	20	25										
<b>6.3 - 25 A</b>																																		
3RB1246-1Q	3RT1015	7	-	-	7	-	-	7	-	-	7	-	-	7	-	-	7	-	-	35	20	-	20	60										
	3RT1016	9	6.5	-	9	6.5	-	9	6.5	-	9	6.5	-	9	6.5	-	9	6.5	-	35	20	-	20	60										
	3RT1017	12	9	6.3	11	9	6.3	10	9	6.3	9.5	9	6.3	9	9	6.3	9	9	6.3	35	20	-	20	60										
	3RT1024	12	12	9	12	12	9	12	12	9	12	12	9	12	12	9	12	12	9	63	25	20	25	70										
	3RT1025	17	17	13	17	17	13	16	16	13	15	15	13	14	14	13	14	13	63	25	20	25	70											
	3RT1026	25	18	13	18	18	13	16	16	13	15	15	13	14	14	13	100	25	20	25	100													
	3RT1034	25	25	25	25	25	25	22.3	22.3	22.3	20.3	20.3	20.3	19.1	19.1	19.1	125	63	50	63	100													
	3RT1035	-	-	-	-	-	-	25	25	25	25	25	25	25	25	25	125	63	50	63	100													
	<b>25 - 100 A</b>																																	
3RB1246-1E	3RT1034	32	32	-	25	25	-	-	-	-	-	-	-	-	-	-	-	-	125	63	50	63	125											
	3RT1035	40	40	-	33	33	-	29	29	-	28	28	-	26	26	-	125	63	50	63	150													
	3RT1036	50	50	-	38	38	-	32	32	-	29	29	-	26	26	-	160	80	50	80	200													
	3RT1044	65	65	47	56	56	47	49	49	47	45	45	41	41	41	250	125	63	125	250														
	3RT1045	80	80	58	61	61	58	53	53	58	47	47	47	45	45	45	250	160	80	160	250													
	3RT1046	95	95	58	69	69	58	59	59	58	53	53	53	50	50	50	250	160	100	160	350													
<b>50 - 205 A</b>																																		
3RB1253-0F	3RT1054	115	115	115	93	93	93	81	81	81	74	74	74	69	69	69	355	315	160	250	450													
	3RT1055	150	150	150	121	121	121	106	106	106	97	97	97	90	90	90	355	315	200	315	500													
	3RT1056	185	185	185	149	149	149	131	131	131	120	120	120	111	111	111	355	315	200	315	500													
<b>125 - 500 A</b>																																		
3RB1257-0K	3RT1064	225	225	225	182	182	182	159	159	159	146	146	146	135	135	135	500	400	250	-	700													
	3RT1065	265	265	265	214	214	214	188	188	188	172	172	172	159	159	159	500	400	315	-	800													
	3RT1066	300	300	280	243	243	243	213	213	213	195	195	195	180	180	180	500	400	315	-	800													
	3RT1075	400	400	400	324	324	324	284	284	84	260	260	260	240	240	240	630	400	400	-	800													
	3RT1076	500	500	450	405	405	405	355	355	355	325	325	325	300	300	300	630	500	500	-	1200													
	3RT1264	225	225	225	225	225	225	225	225	225	193	193	193	173	173	173	500	500	400	-	800													
	3RT1265	265	265	265	265	265	265	265	265	265	227	227	227	204	204	204	500	500	400	-	800													
	3RT1266	300	300	300	300	300	300	300	300	300	258	258	258	231	231	231	500	500	400	-	800													
	3RT1275	400	400	400	400	400	400	400	400	400	344	344	344	308	308	308	800	800	630	-	1200													
	3RT1276	500	500	500	500	500	500	500	500	500	430	430	430	385	385	385	800	800	630	-	1200													
	3TF68	500	500	500	500	500	500	440	440	440	408	408	408	376	376	376	800	500 <sup>3)</sup>	630	500	1200													
	3TF69	-	-	-	-	-	-	500	500	500	500	500	500	500	500	500	800	630 <sup>3)</sup>	630	500	2000													
	<b>200 - 820 A</b>																																	
	3RB1262-0L	3TF68 <sup>4)</sup>	630	630	630	502	502	502	440	440	440	408	408	408	376	376	376	1000	500 <sup>3)</sup>	630	500	1200												
3TF69 <sup>4)</sup>		820	820	820	662	662	662	572	572	572	531	531	531	500	500	500	1250	630 <sup>3)</sup>	630	630	2000													

1) Please note the operating voltage

3) Please ensure that the safety clearance between the max. 3 AC operating current and the fuse rated current is maintained.

4) Mounting onto contactor possible

2) Assignment and short-circuit facilities in acc. with IEC 60947-4-1/DIN VDE 660 Part 102

**Coordination type "1"**: The contactor or starter must not endanger people or the system in the event of a short circuit. They do not have to be suitable for further operation without repair and part replacement.

**Coordination type "2"**: The contactor or starter must not endanger people or the system in the event of a short circuit and must be suitable for further operation. There is a danger of contact welding.

## 3RA1 fuseless load feeders

Section	Subject	Page
<b>5.1</b>	<b>Specifications/regulations/approvals</b>	<b>5-2</b>
<b>5.2</b>	<b>Device description</b>	<b>5-3</b>
5.2.1	Mounting systems	5-4
5.2.2	Kits for self-assembly	5-5
5.2.3	Complete devices	5-5
<b>5.3</b>	<b>Application and areas of use</b>	<b>5-7</b>
<b>5.4</b>	<b>Accessories</b>	<b>5-8</b>
5.4.1	Accessories for the individual devices	5-8
5.4.2	Accessories specifically for the SIRIUS SIRIUS 3RA1 fuseless load feeder	5-8
5.4.3	Instructions for self-assembly	5-9
<b>5.5</b>	<b>Mounting and connection</b>	<b>5-18</b>
5.5.1	Mounting	5-18
5.5.2	Connection	5-21
5.5.3	Circuit diagrams	5-23
<b>5.6</b>	<b>Dimensioned drawings</b>	<b>5-24</b>
<b>5.7</b>	<b>Technical specifications</b>	<b>5-28</b>

## 5.1 Specifications/regulations/approvals

### Coordination types

The fuseless load feeders are manufactured and tested in acc. with IEC 60947 Part 1 and Part 2.

An important selection criterion for the fuseless load feeders are the coordination types.

IEC 60947-4-1/DIN VDE 0660 Part 102 draws a distinction between two coordination types, known as coordination type 1 and coordination type 2. They describe what happens at a short circuit and the device status after a short circuit. In both coordination types, the short circuit to be dealt with is reliably disconnected. There must be no damage to systems or injury to persons. The differences lie only in the degree to which the device is damaged after the short circuit.

#### Coordination type 1

The fuseless load feeder can be inoperable after each short-circuit disconnection. Damage to the contactor and the circuit breaker is permissible.

#### Coordination type 2

After a short-circuit disconnection, there must not be any damage to the overload release or any other part. The 3RA1 fuseless load feeder can be put into operation again without the need for replacement. Only welding of the contactor contacts is permissible if they can be separated easily without any significant deformation.

#### Approvals/test reports

All the approvals and test certificates of the individual devices used in the feeders are valid.

## 5.2 Device descriptions

Fuseless load feeders are combinations of devices consisting of a circuit breaker for overload and short-circuit protection and a contactor for normal switching duty.

The 3RA fuseless feeders of SIRIUS are used to switch loads of up to 100 A and protect them against overload and short circuits.

The feeders always consist of a SIRIUS 3R circuit breaker for motor protection (3RV) and a motor contactor (3RT).

The different devices can be set up separately and connected electrically by means of cables. It is simpler to connect the circuit breakers and contactors mechanically and electrically using ready-made kits.

The circuit breaker and contactor in the combination must be compatible with each other. It is not permissible to combine contactors and circuit breakers that are not compatible.

The combinations described below have been tested individually in order to verify that the specified performance data are correct.

The 3RV circuit breaker provides overload and short-circuit protection; upstream protective devices are not required for short-circuit currents of up to 50 kA / 400 V.

The 3RT contactor takes on the normal switching of loads.

Depending on which device combination is selected, coordination type "1" or "2" is reached.

Coordination type "2", which is the more stringent test, always includes coordination type "1".

The specifications apply to direct starters and reversing starters.

### Device variants

The fuseless load feeders can be set up in 4 frame sizes:

- Frame size S00: width 45 mm; for three-phase induction motors up to 0.75 kW / 400 V, coordination type "2" and 5.5 kW / 400 V, coordination type "1"
- Frame size S0: width 45 mm; for three-phase induction motors up to 7.5 kW / 400 V, coordination type "2" and 11 kW / 400 V, coordination type "1"
- Frame size S2: width 55 mm; for three-phase induction motors up to 22 kW / 400 V, coordination type "2" and coordination type "1"
- Frame size S3: width 70 mm; for three-phase induction motors up to 45 kW / 400 V, coordination type "2" and coordination type "1"


### 5.2.1 Mounting systems

The possible types of mounting are as follows:

- On a 35 mm rail in acc. with DIN EN 50 022
- Screw-on attachment by means of the attachment openings integrated in the rail adapter
- On busbar systems with a busbar center-to-center clearance of 40 mm or 60 mm

The following illustrations show the adapters for rail and busbar mounting:

Rail adapter



Busbar adapter




Figure 5-1: Rail adapter/busbar adapter

## 5.2.2 Mounting kits for self-assembly

Because SIRIUS is a modular system, the standard devices fit together optically both mechanically and electrically. The fuseless load feeders can therefore be assembled quickly and easily in all four frame sizes. To this end, the circuit breaker and the contactor are connected to the corresponding kit.

### Kits

There are kits for reversing feeders for mounting on:

- Rail, frame sizes S0, S2, S3: mounting kit for reversing operation  
frame size S00: wiring kit for reversing operation
- Busbars, frame sizes S00, S0, S2: mounting kit for reversing operation

The following illustration shows how to assemble the fuseless load feeder of frame size S00 for reversing operation and rail mounting:




Figure 5-2: Self-assembly of a fuseless load feeder (frame size S00)

## 5.2.3 Complete devices

The fuseless load feeders are also available fully assembled:

- Up to 22 kW in the case of direct starters
- Up to 11 kW in the case of reversing starters

**Control supply voltage**

For control voltages of:

- 230 VAC / 50 Hz
- 24 VDC

Self-assembly on rails or busbar systems is recommended for other control voltages.

**Auxiliary contact elements**

- Direct feeders  
The contactors of frame size S00 contain a free normally open contact
- Reversing feeders  
S00/S0: electrical and mechanical interlocking



### **5.3 Application and areas of use**

The fuseless load feeders can be used in electrical installations wherever combinations of fuses, contactors, and overload relays have been used up to now. The greater functionality of the circuit breaker over fuses, and their suitability as emergency-stop and disconnecting switches, means that many requirements can be met more easily with a fuseless load feeder.

## 5.4 Accessories

### 5.4.1 Accessories for the individual devices

The accessories for the individual devices can also be used in the load feeder.

You will find information on the accessories of the contactors in Chapter 3, "Contactors" (Section 3.4, "Accessories").

You will find information on the accessories of the circuit breakers in Chapter 2, "Circuit breakers" (Section 2.4, "Accessories").

### 5.4.2 Accessories specifically for the SIRIUS 3RA fuseless load feeder

The following accessories facilitate the setup and wiring of the fuseless load feeder:

Accessory	Description
Auxiliary switch for the circuit breaker	<ul style="list-style-type: none"> <li>• Transverse and connectable from above</li> <li>• 1 changeover contact, 1 normally open contact + 1 normally closed contact or 2 normally open contacts</li> </ul>
Auxiliary switch blocks for the contactor	Snap-on and connectable from below
Link modules	<ul style="list-style-type: none"> <li>• Provide electrical connections between circuit breakers and link modules</li> <li>• Also provide a mechanical connection in frame sizes S00 and S0</li> </ul>
Wiring kits	<ul style="list-style-type: none"> <li>• Electrical and mechanical connection for reversing combinations</li> <li>• The wiring kit can be combined with the link module</li> <li>• In the case of frame size S00, the wiring module contains integrated cables for electrical interlocking</li> </ul>

Table 5-1: Fuseless load feeder, accessories

### 5.4.3 Instructions for self-assembly

#### Fuseless load feeder for rail mounting

##### Assembly

The following illustration and the table below it show how to assemble the fuseless load feeder:

- Rail mounting
- Frame size S00
- Reversing operation




Figure 5-3: Self-assembly, rail, reversing operation (frame size S00)

Step	Procedure
1	Hook the back of the right contactor of the contactor combination onto the link module
2	With a tilting movement, insert the connecting pins of the link module into the upper terminal openings of the contactor
3	Tighten the upper terminal screws of the contactor
4	Hook the link module onto the back of the circuit breaker
5	With a tilting movement, insert the connecting pins of the link module into the lower terminal openings of the circuit breaker
6	Tighten the lower terminal screws of the circuit breaker
7	Snap the circuit breaker and thus the feeder onto the rail

Table 5-2: Self-assembly of the reversing starter for rail (frame size S00)

The following illustrations show how to assemble the fuseless load feeder:

- Rail mounting
- Frame sizes S00 to S3
- Direct starters




Figure 5-4: Self-assembly, rail, direct starter (frame sizes S00 to S3)

The following illustrations show how to assemble the fuseless load feeder:

- Rail mounting
- Frame sizes S00 with Cage Clamp terminal system

Direct starter




Figure 5-5: Self-assembly, rail, direct starter (frame size S00, Cage Clamp)

The following illustrations show how to assemble the fuseless load feeder:

- Rail adapter
- Reversing operation
- Frame size S0




Figure 5-6: Self-assembly, rail, reversing operation (frame size S0)

The following illustrations show how to assemble the fuseless load feeder:

- Rail adapter
- Reversing operation
- Frame size S2 (assembly of frame size S3 is analogous)




Figure 5-7: Self-assembly, rail, reversing operation (frame sizes S2 and S3)

### Fuseless feeders for busbar mounting

There are kits available for reversing operation for frame sizes S00 to S2. The fuseless load feeders of frame size S3 are not suitable for busbar mounting.

#### Direct starters of frame sizes S00 to S2

The following illustrations show how to assemble the fuseless load feeder:

- Busbar adapter
- Direct starters
- Frame sizes S00 to S2




Figure 5-8: Self-assembly, busbars, direct starters (frame sizes S00 and S2)



The following illustrations show how to assemble the fuseless load feeder:

- Busbar adapter
- Direct starters
- Frame sizes S00 and S0 with Cage Clamp terminal system





Figure 5-9: Self-assembly, busbars, direct starters (frame size S00/S0, Cage Clamp)

**Reversing operation of frame sizes S00 to S2**

The following illustrations show how to assemble the fuseless load feeder:

- Busbar adapter
- Reversing operation
- Frame sizes S00 to S2

**S00**



**S0**




Figure 5-10: Self-assembly, busbars, reversing operation (frame sizes S00 and S0)

S2




Figure 5-11: Self-assembly, busbars, reversing operation (frame size S2)

## 5.5 Mounting and connection

### 5.5.1 Mounting

#### Snap-on attachment

The fuseless load feeders can be snapped onto a 35 mm rail in acc. with DIN EN 50 022.

#### Rail mounting without adapter

The fuseless direct feeders of frame sizes S00 and S0 and reversing feeders S00 can be snapped onto the rail without an adapter with the circuit breaker. No tools are required for either mounting or removal. A rail adapter is available as an accessory for frame sizes S00/S0. The reversing feeders of frame sizes S2/S3 are mounted with a rail adapter.

#### Rail mounting with adapter

To mount frame sizes S2 and S3 and reversing feeders S0 on a rail, adapters must be used for stability reasons. These are available as accessories. To remove them, the rail adapter is unlocked with a screwdriver. You will find information on this in Section 2.5.1 on how to mount circuit breakers.

All feeders can be mounted with a rail adapter.

## Screw-on attachment

Screw-on attachment is implemented in the case of sizes S00 and S0 by means of push-in lugs (see Section 2.4 for information on circuit-breaker accessories).

In the case of sizes S2 and S3, the holes for screw-on attachment are integrated in the mandatory rail adapter.

The following illustration shows screw-on attachment by means of push-in lugs in the case of the fuseless load feeder of frame size S00:.




Figure 5-12: Screw-on attachment, fuseless load feeder (frame size S00)

---

### Important


In the case of screw-on attachment without a rail adapter, the feeder must not be screwed onto a conductive surface. Insulation is necessary so that, in the event of a short circuit of the circuit breaker, there is no short circuit to the base plate.

---


### Busbar mounting

The following illustrations show busbar mounting and removal of the fuseless load feeders S00 to S2.


S00 (S0): Mounting



S00 (S0): Removal



S2: Mounting



Removal of the extension piece




Figure 5-13: Busbar system, mounting/removal (frame sizes S00 to S2)

## 5.5.2 Connection

The fuseless load feeders are available with the SIGUT<sup>®</sup> terminal system.

### Conductor cross-sections

The following table gives the permissible conductor cross-sections for fuseless load feeders. The specifications apply to main and auxiliary connections.

#### Frame sizes S00 and S0:




	<b>S00</b> <b>A1/A2; NO/NC</b> <b>L1 L2 L3</b> <b>T1 T2 T3</b>	<b>S0</b> <b>A1/A2; NO/NC</b> <b>L1 L2 L3</b> <b>T1 T2 T3</b>	
 Ø 5 ... 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	0.8 to 1.2 Nm 7 to 10.3 lb.in	2 to 2.5 Nm 18 to 22 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (18 to 14)	2 x (14 to 10)

Table 5-3: Conductor cross-sections (frame size S00/S0)

#### Frame size S2:








<b>S2</b>			
<b>A1/A2; NO/NC</b>		<b>L1 L2 L3</b> <b>T1 T2 T3</b>	
 Ø 5 ... 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	 Ø 5 ... 6 mm / PZ2	3 to 4.5 Nm 27 to 40 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> ) 1 x (0.75 to 25 mm <sup>2</sup> )
----	----		2 x (0.75 to 25 mm <sup>2</sup> ) 1 x (0.75 to 35 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	<b>AWG</b>	2 x (18 to 3) 1 x (18 to 2)

Table 5-4: Conductor cross-sections (frame size S2)

Frame size S3:








<b>S3</b>			
<b>A1/A2; NO/NC</b>		<b>L1, L2, L3 T1, T2, T3</b>	
 Ø 5 ... 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in		4 to 6 Nm 35 to 53 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )		2 x (2.5 to 16 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )		2 x (2.5 to 35 mm <sup>2</sup> ) 1 x (2.5 to 50 mm <sup>2</sup> )
----	----		2 x (10 to 50 mm <sup>2</sup> ) 1 x (10 to 70 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	<b>AWG</b>	2 x (10 to 1/0) 1 x (10 to 2/0)

Table 5-5: Conductor cross-sections (frame size S3)



### 5.5.3 Circuit diagrams

#### Direct starters




Figure 5-14: Circuit diagrams, direct starters (frame sizes S00 to S3)

#### Reversing starters




Figure 5-15: Circuit diagrams, reversing starters (frame sizes S00 to S3)

## 5.6 Dimensioned drawings (dimensions in mm)

### 3RA1 fuseless load feeders - frame size S00 for rail




Figure 5-16: 3RA11 10-..A.. for direct-on-line starting  
 1) Space above the arc chute  
 Clearance to grounded parts at the side at least 6 mm

3RA12 10-..A.. for reversing operation

### 3RA1 fuseless load feeders - frame size S00 for 40 mm and 60 mm busbar systems




Figure 5-17: 3RA11 10-..C.., 3RA11 10-..D.. for direct-on-line starting  
 1) Space above the arc chute  
 Clearance to grounded parts at the side at least 6 mm

3RA12 10-..C.., 3RA12 10-..D.. for reversing operation

**3RA1 fuseless load feeders - frame size S0 for rail**




Figure 5-18: 3RA11 20-..A.. for direct-on-line starting

3RA12 20-..B.. for reversing operation

- 1) Space above the arc chute
- 2) Lockable in zero position with a shackle diameter of 5 mm
- 3) Attached using two 35 mm rails with a depth of 7.5 mm in acc. with EN 50 022 or one 75 mm rail in acc. with EN 50 023. Clearance to grounded parts at the side at least 6 mm

**3RA1 fuseless load feeders - frame size S0 for 40 mm and 60 mm busbar systems**




Figure 5-19: 3RA11 20-..C.., 3RA11 20-..D.. for direct-on-line starting

3RA1220-..C.., 3RA1120-..D.. for reversing operation

- 1) Space above the arc chute
- 2) Lockable in zero position with a shackle diameter of 5 mm
- Clearance to grounded parts at the side at least 6 mm

**3RA1 fuseless load feeders - frame size S2 for rail**





Figure 5-20: 3RA1 direct-on-line starting (frame size S2)

3RA1 reversing operation (frame size S2)

- 1) Space above the arc chute
- 2) Lockable in zero position with a shackle diameter of 5 mm
- 3) Attached using two 35 mm rails with a depth of 7.5 mm in acc. with EN 50 022 or one 75 mm rail in acc. with EN 50 023. Clearance to grounded parts at the side at least 6 mm

**3RA1 fuseless load feeders - frame size S0 for 40 mm and 60 mm busbar systems**





Figure 5-21: 3RA1 direct-on-line starting (frame size S0)

3RA1 reversing operation (frame size S0)

- 1) Space above the arc chute
- 2) Lockable in zero position with a shackle diameter of 5 mm
- Clearance to grounded parts at the side at least 6 mm

## 3RA1 fuseless load feeders - frame size S3 for rail




Figure 5-22: 3RA1 direct-on-line starting (frame size S3)

3RA1 reversing operation (frame size S3)


- 1) Space above the arc chute
  - 2) Lockable in zero position with a shackle diameter of 5 mm
  - 3) Attached using two 35 mm rails with a depth of 7.5 mm in acc. with EN 50 022 or one 75 mm rail in acc. with EN 50 023.
  - 4) Hexagonal socket 4 mm
- Clearance to grounded parts at the side at least 6 mm

## 5.7 Technical specifications

### Installation regulations for 400/500 VAC

When installing the combinations, the following clearances must be maintained to grounded parts:

Circuit breakers combined with contactors			Clearances to grounded or live parts		
Circuit breaker	Contactor	Rated operational voltage	Y mm	X2 <sup>1)</sup> mm	Z mm
3RV1. 1 with 3RT10 1		400/500 V	20	10	9
3RV1. 2 with 3RT10 1	3RT1. 2	400/500 V	30	10	9
	3RT1. 3	400/500 V	30	10	9
	3RT1. 4	400/500 V	30	10	9
3RV1. 3 with 3RT10 2	3RT1. 3	400/500 V	50	10	10
	3RT1. 3	400/500 V	50	10	10
	3RT10 4	400/500 V	50	10	10
3RV1. 4 with 3RT10 4	3RT10 4	400 V	90	10	12
	3RT10 4	500 V	220	10	20



1) Minimum clearance to the contactor at the front. A minimum clearance at the front is not required for a circuit breaker.


### Installation regulations for 690 VAC

Frame size	Format	Standard format for frame sizes S0 to 5.5 kW, S2, and S3	Format for frame size S0 from 7.5 to 11 kW
<b>S0</b>	Mounted on an insulated base plate. In screw-on mounting, the screws must not be grounded. Alternatively, the rail adapter can be used without restrictions.		
<b>S2/S3</b>	Mounted on an insulated base plate. Alternatively, the rail adapter can also be used.		

When installing the combination, the following clearances must be maintained to grounded parts:

2 circuit breakers combined with contactors			Clearance to grounded or live parts					
Circuit breaker	Contactor	Rated operational voltage	Y1 mm	Y2 mm	Y3 mm	X1 mm	X2 mm	X3 mm
3RV1. 2 with 3RT10 1		690 V	80	10	95	20	14	20
3RV1. 3 with 3RT10 3		690 V	50	10	120	10	32	10
	3RT10 4	690 V	50	10	120	10	40	10

① 3-phase busbar  
S0: 3RV19 15-1A  
S2: 3RV19 35-1A




② In a combination involving a circuit breaker of frame size S2 and a contactor of frame size S3, a clearance of 10 cm must be maintained

## General specifications

Specifications		IEC 60 947-1, EN 60 947-1 (VDE 0660 Part 100) IEC 60 947-2, EN 60 947-2 (VDE 0660 Part 101) IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)				
Type		<b>3RA1. 1</b>	<b>3RA1. 2</b>	<b>3RA1. 3</b>	<b>3RA11 4</b>	
Frame size		<b>S00</b>	<b>S0</b>	<b>S2</b>	<b>S3</b>	
Number of poles		3	3	3	3	
<b>Max. rated current <math>I_{nmax}</math></b> (= max. rated operational current $I_n$ )	A	12	25	50	100	
<b>Permissible ambient temperature</b>	°C	–55 to +80 for storage/transportation				
	°C	–20 to +70 for operation (above +60 °C with restrictions)				
<b>Rated operating voltage <math>U_e</math></b>	V	690				
<b>Rated frequency</b>	Hz	50/60				
<b>Rated insulation voltage <math>U_i</math></b>	V	690				
<b>Rated impulse strength <math>U_{imp}</math></b>	kV	6				
<b>Tripping class (CLASS)</b>	In acc. with IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)	10				
<b>Rated short-circuit current <math>I_n</math> at 50/60 Hz 400 VAC</b> in acc. with IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)	kA	50				
<b>Coordination types in acc. with IEC 60 947-4-1, EN 60 947-4-1</b> (VDE 0660 Part 102)		1)				
<b>Power loss <math>P_{Vmax}</math> of all main conducting paths</b> depending on the rated current $I_n$ (upper setting range)		<ul style="list-style-type: none"> <li>• Up to 1.25 A W 6</li> <li>• 1.6 to 6.3 A W 7</li> <li>• 8 to 12 A W 10.5</li> <li>• 2 to 6.3 A W</li> <li>• 8 to 16 A W 7</li> <li>• 20 to 25 A W 13</li> <li>• 25 to 32 A W</li> <li>• 40 A W 19</li> <li>• 45 to 50 A W 28</li> <li>• 63 A W 35</li> <li>• 75 to 90 A W 29</li> <li>• 100 A W 45</li> </ul>			60	
<b>Power input of the magnet coils with contactors</b> (given a cold coil and $U_s$ , 50 Hz)						
• AC operation	Making capacity	VA	27	61	127	270
	cos $\varphi$		0.8	0.82	0.82	0.68
	Holding power	VA	4.6	7.8	13.5	22
	cos $\varphi$		0.27	0.24	0.34	0.27
• DC operation	Making capacity = holding power	W	3.2	5.4	11.50	15
<b>Operating range of the magnet coils with contactors</b>			0.8 to 1.1 x $U_s$			
	Lower limit at 55 °C		0.8 x $U_s$	–		
	at 60 °C		0.85 x $U_s$	–		
<b>Service life of circuit breakers</b>						
• Mechanical life	Operating cycles		100,000		50,000	
• Electrical life	Operating cycles		100,000		50,000	
• Max. switching frequency per hour (motor startups)	1/h		15		15	
<b>Service life of contactors</b>						
• Mechanical life	Operating cycles		30 million	10 million		
• Electrical life	Operating cycles		See the service life characteristic of the contactors (part 3).			
<b>Shock resistance (sinus)</b>	In acc. with IEC 60 068 Part 2-27	<i>g</i>	Up to 9.8	Up to 12.5	Up to 8	Up to 6
<b>Degree of protection</b>	In acc. with IEC 60 947-1		IP 20		IP 20	
					IP 00	terminal housing
<b>Shock protection</b>	In acc. with DIN VDE 0106 Part 100		Protected against touching by fingers			
<b>Phase loss sensitivity of the circuit breaker</b>	In acc. with IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)		Yes			
<b>Disconnecter properties of the circuit breaker</b>	In acc. with IEC 60 947-2, EN 60 947-2 (VDE 0660 Part 101)		Yes			
<b>Main and emergency-stop switch properties of the circuit breaker and accessories</b>	In acc. with IEC 60 204-1, EN 60 204-1 (VDE 0113 Part 1)		Yes, with undervoltage release to category 1 in the case of proper use			
<b>Safe isolation between the main and auxiliary circuits</b>	In acc. with DIN VDE 0160 Part 101		Up to 400 V			
<b>Positively driven operation with contactors</b>			Yes	Yes, from the main contact to the auxiliary normally closed contact		

**Conductor cross-sections - main circuit**

Specifications	IEC 60 947-1, EN 60 947-1 (VDE 0660 Part 100) IEC 60 947-2, EN 60 947-2 (VDE 0660 Part 101) IEC 60 947-4-1, EN 60 947-4-1 (VDE 0660 Part 102)			
<b>Type</b>	<b>3RA1.1</b>	<b>3RA1.2</b>	<b>3RA1.3</b>	<b>3RA1.4</b>
Frame size	<b>S00</b>	<b>S0</b>	<b>S2</b>	<b>S3</b>
Number of poles	3	3	3	3
<b>Connection type</b>	Screw-type terminal	Screw-type terminal	Box terminal	Box terminal
<b>Terminal screw</b>	Pozidriv 2	Pozidriv 2	Pozidriv 2	Allen screw
<b>Minimum/maximum conductor cross-sections</b>				
• Finely stranded with wire end ferrule				
- 1-wire	mm <sup>2</sup> 0.5/2.5	1/6	0.75/25	2.5/50 <sup>1)</sup>
- 2-wire	mm <sup>2</sup> 0.5/2.5	1/2.5 to 2.5/6	0.75/16	2.5/35 <sup>1)</sup>
• Single- or multi-core				
- 1-wire	mm <sup>2</sup> 0.5/4	1/6 (max. 10)	0.75/35	2.5/70 <sup>1)</sup>
- 2-wire	mm <sup>2</sup> 0.75/2.5 (max. 4)	1/2.5 to 2.5/6	0.75/25	2.5/50 <sup>1)</sup>
<b>Ribbon conductor</b>	-	-	yes	yes
<b>Bar connection</b>			-	yes
• Single- or multi-core	AWG 2 x (18 to 14)	2 x (14 to 10)	2 x (30 to 2)	-
• Multi-core	AWG -	-	-	2 x (10 to 1/0)
<b>Connection type</b>	Cage Clamp terminal			
	mm <sup>2</sup> 2 x (0.5 to 2.5)	-		
	AWG 2 x (18 to 14)			
<b>Permissible installation position</b>				
	Important: In acc. with DIN 43 602 Start command "I" right or above			

1) After the box terminals have been removed, lug or busbar connections are possible.



## 3RH, 3TX, LZX coupling links

Section	Subject	Page
<b>6.1</b>	<b>Specifications/regulations</b>	<b>6-2</b>
<b>6.2</b>	<b>Device description</b>	<b>6-3</b>
6.2.1	Relay coupling modules versus semiconductor coupling modules	6-4
6.2.2	Coupling links in two-tier and box terminal format	6-5
6.2.3	Plug-in relay coupling links	6-6
6.2.4	Coupling links for direct attachment	6-7
6.2.5	SIRIUS 3 R contactor relays	6-7
6.2.6	Installation	6-7
6.2.7	Notes on configuration	6-8
6.2.8	Explanation of terms	6-9
<b>6.3</b>	<b>Application and areas of use</b>	<b>6-10</b>
6.3.1	General information	6-10
6.3.2	Criteria for selection	6-10
<b>6.4</b>	<b>Accessories</b>	<b>6-12</b>
6.4.1	Accessories for two-tier coupling links	6-12
6.4.2	Accessories for LZX plug-in relay coupling links	6-13
<b>6.5</b>	<b>Mounting and connection</b>	<b>6-14</b>
6.5.1	Mounting	6-14
6.5.2	Connection	6-14
6.5.3	Device circuit diagrams	6-16
<b>6.6</b>	<b>Dimensioned drawings</b>	<b>6-20</b>
<b>6.7</b>	<b>Technical specifications</b>	<b>6-22</b>

## 6.1 Specifications/regulations

Degrees of protection offered by housing	EN 60 529
I/O interfaces	EN 61 131-2
Connection designations	EN 50 005
DIN standard rail	EN 50 022
Coordination of insulation	VDE 0110
Electrical relays, all-or-nothing relays	DIN VDE 0435 Part 201/IEC 60255-1-00
Control devices and switching elements	DIN VDE 0660 Part 200/IEC 60947-5-1
Optocoupler	DIN VDE 0884
Equipment of high-voltage installations	DIN VDE 0160
Shock protection	DIN VDE 0106 Part 100
Safe isolation	DIN VDE 0106 Part 101
Environmental conditions	IEC 60721
EMC emission immunity	EN 50081 EN 50082
General information	VDE 0660 Part 100/IEC 60947-1
Specifications for industrial control systems	UL 508
Specifications for industrial equipment	CSA C22.2-14

Table 6-1: Regulations and specifications

## 6.2 Device description

Coupling links are interface modules that enable optimal adaptation between electronic controllers and I/O devices, both on the sensor and the actuator side.

They also provide electrical isolation.

### Overview

The following table offers an overview of the device groups and their distinguishing features:

Device group	Distinguishing features
Two-tier coupling links 3TX7004/3TX7005	Relay couplers: 6.2 to 22.5 mm width, contact elements: 1 to 3 normally open contacts, 1 to 2 changeover contacts Multi-channel devices Semiconductor couplers: 6.2 to 12.5 mm width Long service life, high switching frequency Screw-type terminal (3TX7004) Cage Clamp terminal (3TX7005)
Box terminals 3TX7002/3TX7003	Relay couplers: Contact elements: 1 to 2 normally open contacts, 1 to 2 changeover contacts, low device height Semiconductor couplers: Long service life, high switching frequency Screw-type terminal (3TX7002) Cage Clamp terminal (3TX7003)
Plug-in relay coupling links LZX: RT/PT/MT	Plug-in relays (1 to 4 changeover contacts) High switching currents, rewiring possible
Coupling links for direct attachment to contactor coils 3RH1924/3TX4090/3TX7090	Space-saving, adapted to contactor type, reduced wiring 3RH1924 for frame sizes S0 to S3 3TX4090 for 3TH42/43 auxiliary contactors 3TX7090 for frame sizes 3 to 14
SIRIUS contactor relays 3RT10 3RH11	For main circuits: switching from motors to 11 kW directly For main circuits: up to 4 auxiliary switches

Table 6-2: 3RH, 3TX, LZX coupling links - overview of the device groups with their distinguishing features

### Contact material

Relay coupling links are offered with AgNi and hard gold-plated contacts. Hard gold-plated contacts have greater contact reliability at low voltages and currents. They can be used as of mV or  $\mu$ A. They can be used to switch low levels of power, such as those involved in measurement and control signals. In the case of input coupling links, they are to be recommended on account of the low currents of the input modules of controllers.

**6.2.1 Relay coupling modules versus semiconductor coupling modules**



Models	Advantages	Disadvantages
<p style="text-align: center;"><b>Relay coupling modules</b></p>  <ul style="list-style-type: none"> <li><b>6.2 mm</b> <ul style="list-style-type: none"> <li>• Single-channel</li> <li>• 1NO/1W</li> </ul> </li> <li><b>12.5</b> <ul style="list-style-type: none"> <li>• Single-channel</li> <li>• Multi-channel</li> <li>• With/without M-O-A switch</li> <li>• 1W/1NO/2NO</li> </ul> </li> <li><b>17.5</b> <ul style="list-style-type: none"> <li>• Single-channel</li> <li>• Multi-channel</li> <li>• Without switch</li> <li>• 3NO</li> </ul> </li> <li><b>22.5</b> <ul style="list-style-type: none"> <li>• Single-channel</li> <li>• Multi-channel</li> <li>• Without switch</li> <li>• 2W</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• Suitable for direct and alternating voltage</li> <li>• High switching capacity without heat generation</li> <li>• Virtually no transfer resistance (suitable as measured value transfer switch)</li> <li>• Electrical isolation</li> <li>• Safe isolation between contact and coil sides</li> <li>• No leakage current</li> <li>• High electromagnetic compatibility</li> <li>• High noise immunity</li> <li>• Insensitive to overloads and voltage peaks</li> <li>• Several switching levels</li> </ul>	<ul style="list-style-type: none"> <li>• Lower switching frequency</li> <li>• Contact erosion, particularly in the case of inductive loads</li> <li>• Inductivity of the coil (disturbance)</li> <li>• Mechanical wear (service life)</li> <li>• Low direct-current switching capacity</li> <li>• Bounce time of the relay contact</li> <li>• Danger of contact microwelding in the case of capacitive loads</li> </ul>
<p style="text-align: center;"><b>Semiconductor coupling modules</b></p>  <ul style="list-style-type: none"> <li><b>6.2 mm</b> <ul style="list-style-type: none"> <li>• Single-channel</li> </ul> </li> <li><b>12.5</b> <ul style="list-style-type: none"> <li>• Single-channel</li> <li>• With M-O-A switch</li> <li>• Without switch</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• No contact welding in the case of capacitive loads</li> <li>• High switching frequencies</li> <li>• High direct-current switching capacity</li> <li>• Long service life</li> <li>• Bounce-free switching</li> <li>• Insensitive to vibrations and impact</li> <li>• Defined transfer resistance and volume resistance</li> <li>• Safe isolation between drive circuit and load in acc. with DIN VDE 0884</li> <li>• Silent switching operation</li> </ul>	<ul style="list-style-type: none"> <li>• High temperature rise in the case of high loads</li> <li>• Leakage current at output</li> <li>• Sensitive to peaks in the power system</li> <li>• Not suitable as measured value transfer switch because of a voltage drop at the switching transistor</li> </ul>

Table 6-3: Comparison: Relay coupling modules and semiconductor coupling modules

## 6.2.2 Coupling links in two-tier and box terminal format

### Features

- Connections at two levels
- Very narrow design, as of 6.2 mm
- Terminal system: screw-type and Cage Clamp
- Labeling strip to identify equipment

### Models

The 3TX70 coupling links for SIRIUS are available as both input couplers and output couplers, which have their terminals in different positions:



Figure 6-1: Output coupler Input coupler

Input coupling links have hard gold-plated contacts for greater contact reliability at low voltages and currents.

### Status indication

A yellow status LED on the drive circuit side indicates whether there is any control supply voltage applied to the coupler.

### Protective circuit

There is an integrated rectifier at the input of each coupler. As a result, they are protected against polarity reversal. The rectifiers function as flywheeling diodes at disconnection. Semiconductor outputs are protected by suppressor or Zener diodes.

### Manual-0-automatic

Some coupling links are equipped with a manual-0-automatic switch that makes it easier to switch the system on and is used for test purposes.

- Manual: Relay is always on
- O (zero): Relay is always off
- Automatic: Relay follows the control supply voltage

### Power consumption

Following on from the technical specifications of the electronic systems, the coupling links have low power consumption. They can be controlled from a programmable controller and are suitable for continuous duty.

### Accessories

The following accessories are available for two-tier coupling links:

- 24-pole connecting lead or connection comb
- Screwdriver for Cage Clamp terminal system
- End holder and end plate

### 6.2.3 Plug-in relay coupling links

The Plug-in relay coupling links are modular coupling links. The plug-in format means the relays can be easily replaced.

#### Models

There are complete modules for 1 and 2 changeover contacts and individual modules for 1, 2, 3 or 4 changeover contacts for a rated control supply voltage of either 24 VDC or 230 VAC.

#### Widths

Plug-in relay coupling links are available in 3 widths:

- 15.5 mm print relays, LZX: RT variants
- 27 mm mini-industrial relays, LZX: PT variants
- 38 mm industrial relays, LZX: MT variants

#### Installation

The plug-in relay coupling links are plugged into the associated bases, and these are snapped onto a 35 mm rail in acc. with EN 50 022.

#### Surge suppression

To avoid high breaking voltage peaks, LZX: RT and PT plug-in relay coupling links are available for a rated control supply voltage of 24 VDC, with 1, 2, or 4 changeover contacts (Ws) and integrated surge suppression (flywheeling diode). RC elements are available for AC voltages.

#### Connection

The standard polarity must be taken into consideration when connecting up:

- At A1: positive voltage supply (+)
- At A2: negative voltage supply (-)

#### Test button

The LZX: PT and MT variants are equipped with a test button. The plug-in relay coupling link can thus be brought into the switching state and locked without the need for electrical triggering. When the test button is protruding, this indicates the locked switching position.

#### LED

An LED is available either as an individual plug-in module or is integrated in the relay, depending on the variant involved.

#### Power consumption

Following on from the technical specifications of the electronic systems, the coupling links have low power consumption.

#### Safe isolation

The drive circuit and contacts are electrically isolated. Safe isolation can also be achieved for the print relays (LZX:RT series) by means of a special base.

## 6.2.4 Coupling links for direct attachment

<b>Contactors S0 to S3</b>	The 3RH1924-1GP11 coupling relay, which is screwed directly onto the coil terminals, is available for direct attachment to the contactors of frame sizes S0 to S3. The 3TX4090-0C/-0D coupling links are suitable for attachment to 3TH42/43 auxiliary contactors.
<b>Contactors of up to 450 kW</b>	In the case of the large contactors of up to 450 kW (size 14), the 3TX7090 coupling link can be snapped on at the side like an auxiliary switch block, and the wires are connected to the contactor coil terminals.
<b>Variants</b>	There are variants with one normally open contact, 24 VDC, with and without surge suppression. The operating range is 17 to 30 VDC.
<b>Installation</b>	The 3TX 4090 and 3RH1924-1GP11 coupling links are screwed directly onto the contactor coil terminals, and the 3TX7090 coupling links are snapped on at the side like the auxiliary switches.
<b>Surge suppression</b>	The following coupling links have an integrated surge suppressor (varistor) for the contactor coil to be switched: <ul style="list-style-type: none"> <li>• 3RH1924-1GP11</li> <li>• 3TX4090-0D</li> <li>• 3TX7090-0D</li> </ul>
<b>Power consumption</b>	Following on from the technical specifications of the electronic systems, the coupling links have low power consumption.
<b>LED</b>	An LED is integrated in the coupler.

## 6.2.5 SIRIUS contactor relays

The SIRIUS 3RT10/3RH11 contactor relays are described in Chapter 3, "Contactors".

## 6.2.6 Installation

### Attachment

#### Snap-on attachment

The coupling links can be snapped onto a 35 mm rail in acc. with DIN EN 50 022.

Screw-on attachment is not possible.

**Connection**

**Screw-type terminals**

The two-tier coupling links are fitted with slotted screws for a maximum screwdriver blade width of 4 mm. Plug-in relay couplers have plus-minus POZIDRIV 2 screw-type terminals.

**Cage Clamp terminals**

The two-tier coupling links described in Section 6.2.1 are available with Cage Clamp terminals as well as screw-type terminals.

**6.2.7 Notes on configuration**

**Contact microwelding**

When capacitive loads are switched, a short-circuit current briefly occurs (for a period lasting only microseconds) if the capacitor is not connected in series with a resistor. This can result in contact microwelding and the contact being unable to open after the control supply voltage is removed. To prevent this from happening, a resistor can be connected in series, or a coupling link with a semiconductor output and short-circuit protection can be used.

**Switching inductive loads**

The contacts are tested in acc. with EN 60947-5-1, utilization category AC-15 and DC-13. Going beyond the requirements of the standard, a continuous test was carried out on the contacts with an AC-15 load for 100,000 operating cycles. The electrical service life of the contacts was thus tested over 100,000 operating cycles at the specified current under normal conditions. A lower load on the contacts or a protective circuit for the inductive load increases the service life of the contacts. If this service life is insufficient, a semiconductor coupler with an unlimited service life must be used.

**Max. line length in AC operation**

Each wire has a line capacitance that works like a capacitor connected in series to the coupling link. The effect of this in operation with alternating current is that so much current may flow due to the line capacitance that the coupling link does not fall in spite of a switch being open. To remedy this, a parallel resistor can be fitted to A1/A2 of the coupling link, or an RC combination can be used. Both of these measures change the performance and switching times of the coupling link.

The following basic circuit diagram shows the line capacitance:




Figure 6-2: Basic circuit diagram, line capacitance

The line lengths specified in the NSK catalog were calculated for a line capacitance of 0.3 nF/m. This depends on the wire used.



## 6.2.8 Explanation of terms

<b>Electrical isolation</b>	There is no conductive connection between the input circuit and the output circuit. Electrical isolation is ensured by the in-built relay and, in the case of semiconductor outputs, by means of optocouplers.
<b>Safe isolation</b>	Safe isolation provides protection against shock currents in different circuits. It is implemented by means of increased creepages and clearances.
<b>Distinction between terms</b>	<p>Electrical isolation is not necessarily safe isolation.</p> <p>Safe isolation is a protective measure against shock current, the primary purpose of which is to prevent injury. It prevents the voltage of one circuit crossing over into another.</p> <p>For the insulation coordination of equipment, the standard specifies values for the rating of the creepages and clearances.</p> <p>In the case of safe isolation, these values must be selected by means of double or reinforced insulation.</p>

## 6.3 Application and areas of use

### 6.3.1 General information

#### Advantages

The use of coupling links offers the following advantages:

- Galvanic isolation between two circuits
- Current gain
- Protects the controller from interference and overvoltage
- Substantially reduces the power input of switchgear
- Permits power gain or level adaptation

#### Applications

Coupling links are used in:

- Production engineering
- Machine setup
- Process control in power distribution
- Building services automation
- Process engineering

#### Usage

Coupling links are used for:

- Floating signal transmission
- Linking of different voltages (AC/DC) and currents
- Power gain
- Level adaptation
- Protection of the controller against EMC noise from the I/O
- Contact multiplication

#### Application example




Figure 6-3: Application example, coupling links in box terminal format

### 6.3.2 Criteria for selection

Coupling links are selected on the basis of a number of criteria:

#### Technical specifications

See Section 6.7:

- Rated control supply voltage  $U_s$
- Typical power input
- Output elements
- Rated operational currents  $I_e$
- Permissible line length

**Mechanical requirements**

- Construction type, width
- Mounting type
- Indicators
- Connection type
- Replaceability

**Selection table**

The following table provides an overview of the main criteria for selection from different device groups:

<b>Device group</b>	<b>Criteria for selection</b>
Two-tier coupling links	<ul style="list-style-type: none"> <li>• Space-saving due to narrow housing width</li> <li>• Test switches</li> </ul>
Coupling links in box terminal format	<ul style="list-style-type: none"> <li>• Low device height</li> <li>• For installation given narrow tier spacing</li> </ul>
Contactors relays for switching main and auxiliary circuits	<ul style="list-style-type: none"> <li>• High switching currents</li> <li>• Direct switching of motors up to 11 kW</li> <li>• Up to 4 auxiliary contacts</li> </ul>
Plug-in relay coupling links	<ul style="list-style-type: none"> <li>• High switching currents</li> <li>• Quickly interchangeable</li> <li>• Up to 4 changeover contacts</li> </ul>
Coupling links for attachment to contactors	<ul style="list-style-type: none"> <li>• Attachable directly onto the contactor</li> <li>• Technical specifications of the contactor to be controlled</li> </ul>

Table 6-4: Selection criteria for the 3RH, 3TX, and LZX coupling links

## 6.4 Accessories

### 6.4.1 Accessories for two-tier coupling links

#### Connecting lead

The 24-pole connecting lead 3TX7004-8BA00 can be used for all two-tier coupling links both with screw-type and Cage Clamp terminals:




Figure 6-4: 24-pole connection lead for two-tier coupling links

#### Connection comb

The 24-pole connection comb 3TX7004-8AA00 can be used for the 6.2 mm wide two-tier coupling links with screw-type terminals:




Figure 6-5: 24-pole connection comb for two-tier coupling links

<b>End holder</b>	The end holder 8WA2808 is snapped onto the rail (EN 50 022) without screws.
<b>Screwdriver for Cage Clamp terminal system</b>	The screwdriver 8WA2804 is suitable when wiring coupling links with Cage Clamp terminals.
<b>End plate</b>	In order to ensure shock protection in the case of the two-tier optocouplers having a width of 6.2 mm and with a housing opening (e.g. 3TX7 004-3AB04), the individual module or last module in a series must be fitted with an end plate 3TX7004-8CE00.
<b>Labeling strip</b>	Each coupling link has a labeling strip for the purpose of identification.

#### **6.4.2 Accessories for LZX plug-in relay coupling links**

<b>Retainer</b>	In situations where there is increased mechanical stress, a retainer can be fitted to plug-in relay coupling links to provide stability.
<b>LED module</b>	An LED can be fitted as an individual plug-in module with the variants LZX:RT and LZX:PT.
<b>Module with flywheeling diode</b>	A flywheeling diode for surge suppression can be fitted as a module (for DC voltages) with the variants LZX:RT and LZX:PT.
<b>RC module</b>	For AC voltages, there is a plug-in RC module available with the series LZX:RT and LZX:PT for surge suppression.

## 6.5 Mounting and connection

### 6.5.1 Mounting

#### Snap-on attachment

The coupling links are snapped onto 35 mm rails in acc. with EN 50 022. With a vertical rail and tightly packed devices, the permissible ambient temperature  $T_U$  is 60° C. Any installation position is possible.

### 6.5.2 Connection

The coupling links are available with the SIGUT® terminal system, with screw-type terminals, or with Cage Clamp terminals.

---

#### Cage Clamp terminals

##### **Important Risk of injury**

When making connections using the Cage Clamp terminal system, you should support your screwdriver with your finger to prevent the screwdriver slipping.

---




Figure 6-6: Cage Clamp terminals, coupling links

**Conductor cross-sections**

The following table shows the permissible conductor cross-sections for the coupling links. The specifications apply to main and auxiliary connections.






	<b>3TX7004 3TX7002 screw-type terminals</b>	<b>3TX7005 3TX7003 Cage Clamp terminals</b>	<b>LZX: RT/ZT/MT</b>	<b>3RH1924 3TX7090 Screw-type terminals</b>
 Ø 5 to 6 mm / PZ2	M3	-----	-----	M3
	1 x 0.25 to 4 mm <sup>2</sup>	1 x 0.08 to 2.5 mm <sup>2</sup>	2 x 2.5 mm <sup>2</sup>	2 x (0.5 to 2.5) mm <sup>2</sup>
	1 x 0.5 to 2.5 mm <sup>2</sup>	1 x 0.25 to 2.5 mm <sup>2</sup>	2 x 1.5 mm <sup>2</sup>	2 x (0.5 to 1.5) mm <sup>2</sup>

Table 6-5: Conductor cross-sections for the 3RH, 3TX, and LZX coupling links

### 6.5.3 Device circuit diagrams

The following circuit diagrams are examples:

#### 3RH1924




3RH1924-1GP11 with surge suppressor


① coupling link

② contactor


#### Relay coupling modules 3TX7002/3TX7003




3TX7002-.A.00  
-1AB00  
-2AF00  
3TX7003-1AB00




-1B.00



-1CB00




-1FB00




-2BF02


#### Semiconductor coupling modules 3TX7002




3TX7002-0AB00



-3AB01




-4AB00




4AG0.




**Relay coupling modules  
3TX7004/3TX7005  
Output coupling links**




3TX700.-1M.00




3TX700.-1AB10




3TX700.-1BB00




3TX700.-1L.0.




3TX700.-1BB10



3TX700.-1CB00




3TX700.-1HB00




3TX700.-1GB00

**Relay coupling modules  
3TX7004/3TX7005  
Input coupling links**




3TX700.-2M.02


**Semiconductor coupling modules**  
**3TX7004/3TX7005**  
**Output coupling links**




3TX700.-3AB04




3TX700.-3PB54



3TX700.-3AC04




3TX700.-3AC14




3TX700.-3AC03

**Semiconductor coupling modules**  
**3TX7004/7005**  
**Input coupling links**




3TX700.-4AB04


**Relay couplers**  
**LZX: RT/PT/MT**




LZX: RT3, 1-pole




LZX: RT4, 2-pole



LZX: PT370, 3-pole



LZX: PT570, 4-pole




LZX: MT32, 3-pole

Values in brackets: Plug-in base designations  
 Values without brackets: Contact/coil designations


## 6.6 Dimensioned drawings (dimensions in mm)

### Two-tier coupling links 3TX7 004/3TX7 005




Relay couplers  
 3TX7 00.-1MB00  
 3TX7 00.-1MF00  
 3TX7 00.-1L . 0 .  
 3TX7 00.-2M...

Optocouplers  
 3TX7 00.-3AB04  
 3TX7 00.-4AB04  
 3TX7 00.-3PB..  
 3TX7 00.-3PG74  
 3TX7 00.-3RB43  
 3TX7 00.-4P . 24




Relay couplers  
 3TX7 00.-1AB10  
 3TX7 00.-1BB00  
 3TX7 00.-1BB10  
 3TX7 00.-1CB00  
 3TX7 00.-1BF05

Optocouplers  
 3TX7 00.-3AC04  
 3TX7 00.-3AC14  
 3TX7 00.-3AC03




Relay couplers  
 3TX7 00.-1HB00




Relay couplers  
 3TX7 00.-1GB00

1) Dimension 3TX7 004 coupling links (screw-type terminals)  
 2) Dimension 3TX7 005 coupling links (Cage Clamp terminals)


### Coupling links in box terminal format 3TX7 002/3TX7 003




3TX7 00.-1AB..  
 3TX7 00.-2A...  
 3TX7 002-3AB01



3TX7 002-3AB00  
 3TX7 002-4A...




3TX7 00.-1BB00  
 3TX7 00.-1BF00  
 3TX7 002-2BF02




3TX7 00.-1CB00  
 3TX7 002-1BF02


### Plug-in relay coupling links LZX: RT




Complete device LZX: RT3/RT4



Print relay LZX: RT3/RT4




Plug-in base LZX: RT78625 for print relays



Plug-in base LZX: RT78626 with safe isolation for print relays


**Plug-in relay coupling links LZX: PT**



Industrial relay LZX: PT570

Plug-in base LZX: PT78703 for industrial relays


**Plug-in relay coupling links LZX: MT/MR**



Industrial relay LZX: MT32

Plug-in base LZX: MR78750 for industrial relays

**Coupling links 3RH/3TX**



3RH1924-1GP11

3TX4090-0C

3TX4090-0D

## 6.7 Technical specifications

### 3TX70 relay coupling links

Load side		3TX7 00 .-1A/-1B/-1C/-1H/-1G		3TX7 00 .-. L/- .M		
<b>Rated currents</b> Conventional free air thermal current $I_{th}$	A	6		6		
Rated operational current $I_e$ by utilization categories (DIN VDE 0660)	At 24 V	A	3	1.0	2	1.0
	110 V	A	3	0.2	2	0.2
	230 V	A	3	0.1	2	0.1
<b>Current switched</b>			AC-12	DC-12	AC-12	DC-12
For resistive load In acc. with DIN VDE 0435 (relay standard) and DIN VDE 0660	At 24V	A	6	6	6	6
	110 V	A	6	0.3	6	0.3
		A	6	0.2	6	0.2
<b>Min. contact loading for 3TX7 00 .-1 . . 00</b>			17 VAC/VDC, 5 mA		17 VAC/VDC, 5 mA	
<b>Min. contact loading for 3TX7 00 .- . . . 02</b> (hard gold-plating)			1 VAC/VDC, 0.1 mA		1 VAC/VDC, 0.1 mA	
<b>Performance limit/hard gold-plating</b>			30 V/20 mA		30 V/20 mA	
<b>Switching voltage</b>			17 to 250 VAC/VDC		17 to 250 VAC/VDC	
<b>Mechanical life</b>			20 x 10 <sup>6</sup> operating cycles		20 x 10 <sup>6</sup> operating cycles	
<b>Electrical service life at <math>I_e</math></b>			1 x 10 <sup>5</sup> operating cycles		0.5 x 10 <sup>5</sup> operating cycles	
<b>Switching frequency</b>	1/h		5000 operating cycles		5000 operating cycles	

Table 6-6: Technical specifications, 3TX70 relay coupling links

### 3TX7004/3TX7005 semiconductor coupling links

Load side		3TX7 004-/3TX7 005-		3AB04/4AB04	3AC.4	3AC03	4AB04	3PB54
<b>Type</b>		A						
<b>Rated operating current <math>I_e</math></b>		A	0,5	5	2	0,5	1,5	
<b>Short-term current carrying capacity</b>		A	1,5	Short circuit-proof	100	1,5	Short circuit-proof	
		ms	20		20	20		
<b>Contact elements</b>			1 NO contact Transistor	1 NO contact Transistor	1 NO contact Triac	1 NO contact Transistor	1 NO contact Transistor	
<b>Switching voltage</b> (operating range)			DC ≤ 48 V	DC ≤ 30 V	AC 50/60Hz 24 to 250 V	DC ≤ 48 V	DC ≤ 30 V	
<b>Minimum load current</b>		mA	–	–	50	–	–	
<b>Voltage drop switched through</b>		V	1	0,5	1,6	1	0,5	
<b>Leakage current of the electronics</b> (at 0 signal)		mA	< 0.1	< 0.1	< 6	< 0.1	< 0.1	
<b>Switching frequency</b> For resistive load		Hz	50	50	1	50	500	

Table 6-7: Technical specifications, 3TX7004/3TX7005 semiconductor coupling links

### 3TX7002/3TX7003 semiconductor coupling links

Load side		3TX7 002-		3AB00	3AB01	4AB00	4AG00
<b>Type</b>		A					
<b>Rated operating current <math>I_e</math></b>		A	1.8	1.5 (See derating diagram)	0.1	0.1	
<b>Short-term current carrying capacity</b>		A	20	4	1	1	
		ms	20	0.2	20	20	
<b>Contact elements</b>			1 NO contact Triac	1 NO contact Transistor	1 NO contact Transistor	1 NO contact Transistor	
<b>Switching voltage</b> (operating range)			Effective 50/60 Hz 48 to 264 VAC	≤ 60 VDC	≤ 30 VDC	≤ 60 VDC	
<b>Minimum load current</b>		mA	60	–	–	–	
<b>Voltage drop switched through</b>		V	≤ 1.5	≤ 1.1	≤ 1.7	≤ 0.3	
<b>Leakage current</b> of the electronic components (at 0 signal)		mA	<5	<0.1	<0.1	0.001	
<b>Switching frequency at <math>I_e</math></b>			1 Hz	1 Hz	5 Hz	5 Hz	

Table 6-8: Technical specifications, 3TX7002/3TX7003 semiconductor coupling links

**LZX: RT/PT**

Relay type	Print relay RT, 8-pole (12.7 mm) 1 W/2 W	Industrial relay PT, 14-pole (22.5 mm) 3 W/4 W
<b>Load side</b>		
<b>Switching voltage</b>	24 to 250 VAC/VDC	24 to 250 VAC/VDC
<b>Rated currents</b>		
Conventional free air thermal current $I_{th}$	16 A/8 A (1 W/2 W)	10 A/6 A (3 W/4 W)
Rated operating current $I_e$ by utilization categories (DIN VDE 0660)	AC-15	DC-13
	at 24 V	2 A
	230 V	0.27 A
<b>Short-circuit protection</b>		
Fuse links, performance class gL/gG DIAZED	10 A	–
<b>Min. contact loading (reliability: 1 ppm)</b>	12 VDC/10 mA	–
<b>Mechanical life</b>	30 x 10 <sup>6</sup> operating cycles	10 x 10 <sup>6</sup>
<b>Electrical life</b> (resistive load at 250 VAC)	1 x 10 <sup>5</sup> operating cycles	1 x 10 <sup>5</sup>

Table 6-9: Technical specifications, LZX: RT/PT

**LZX: MT**

Relay type	Industrial relay MT, 11-pole (35.5 mm) 3 W
<b>Load side</b>	
<b>Switching voltage</b>	24 to 250 VAC/VDC
<b>Rated currents</b>	
Conventional free air thermal current $I_{th}$	10A
Rated operating current $I_e$ by utilization categories (DIN VDE 0660)	AC-15
	AC-13
	at 24 V
230 V	5 A
	5 A
	2 A
	0.27 A
<b>Short-circuit protection</b>	
Fuse links, performance class gL/gG DIAZED	10A
<b>Min. contact loading (reliability: 1 ppm)</b>	12 VDC/10 mA
<b>Mechanical life</b>	20 x 10 <sup>6</sup> operating cycles
<b>Electrical service life (resistive load at 250 VAC)</b>	4 x 10 <sup>5</sup> operating cycles

Table 6-10: Technical specifications, LZX: MT

**3RH1924/3TX7090**

**Short-circuit protection**

(unwelded fuse at  $I_k$  W 1 kA)

Fuse links, performance class gL/gG A 6

NH Type 3NA

DIAZED Type 5SB

NEOZED Type 5SE

**Load side**

**Mechanical life** Operat- 20 x 10<sup>6</sup>  
ing  
cycles

**Electrical service life at  $I_e$**  Operat- 1 x 10<sup>5</sup>  
ing  
cycles

**Switching voltage** V 24 to 250 VAC/VDC

**Rated currents**

Conventional free air thermal current $I_{th}$	A	6		
			AC-15	DC-13
Rated operating current $I_e$	At 24 V A	3	1.0	
by utilization categories	110 V A	3	0.2	
(DIN VDE 0660)	230 V A	3	0.1	

Table 6-11: Technical specifications, 3RH1924/3TX7090



## 3RP10, 3RP15 solid-state time relays

<b>Section</b>	<b>Subject</b>	<b>Page</b>
<b>7.1</b>	<b>Specifications/regulations/approvals</b>	<b>7-2</b>
<b>7.2</b>	<b>Device description</b>	<b>7-3</b>
7.2.1	Device types	7-3
7.2.2	Installation	7-4
7.2.3	Special features	7-5
7.2.4	Notes on configuration	7-5
7.2.5	Explanation of terms	7-7
<b>7.3</b>	<b>Applications and uses (types of function)</b>	<b>7-8</b>
7.3.1	Multifunction (3RP10 00 solid-state time relay)	7-8
7.3.2	Multifunction (3RP15 05 solid-state time relay)	7-11
7.3.3	On-delay	7-16
7.3.4	Off-delay	7-17
7.3.5	Clock pulse generator (3RP15 55 solid-state time relay)	7-18
7.3.6	Star-delta function (3RP15 74/76 solid-state time relay)	7-19
7.3.7	Star-delta function with overtravel (3RP15 60 solid-state time relay)	7-19
<b>7.4</b>	<b>Accessories</b>	<b>7-20</b>
7.4.1	Accessories for 3RP10	7-20
7.4.2	Accessories for 3RP15 05	7-20
<b>7.5</b>	<b>Mounting and connection</b>	<b>7-22</b>
7.5.1	Mounting	7-22
7.5.2	Connection	7-23
7.5.3	Circuit diagrams	7-24
<b>7.6</b>	<b>Dimensioned drawings</b>	<b>7-25</b>
<b>7.7</b>	<b>Technical specifications</b>	<b>7-26</b>

## 7.1 Specifications/regulations/approvals

### Standards

The time relays comply with the following standards:

- IEC 61812-1/DIN VDE 0435 Part 2021 on electrical relays and time relays
- IEC 61000 on electromagnetic compatibility
- IEC 60947-5-1; DIN VDE 0660 Part 200 on low-voltage switchgear
- IEC 60721-3-1/-3 on environmental conditions
- IEC 60529 on degree of protection

### Electromagnetic compatibility

The time relays are tested in acc. with EN 50 081-1 (emission) and EN 50 082-2 (immunity) and are thus noise-free and surge-proof.

### Switching capacity

The switching capacity complies with IEC 60947-5-1

- In the case of utilization category AC-15 and 230 VAC: 3 A
- In the case of utilization category DC-13 and 24 VDC: 1 A
- In the case of utilization category DC-13 and 48 VDC: 0.45 A
- In the case of utilization category DC-13 and 60 VDC: 0.35 A
- In the case of utilization category DC-13 and 110 VDC: 0.2 A
- In the case of utilization category DC-13 and 230 VDC: 0.1 A

### UL/CSA/marine approval

The SIMIREL time relays are approved by UL and CSA for use worldwide and tested by the GL, LRS, DM marine authorities.

### Approvals/test reports

Confirmation of approvals, test certificates, and the declaration of conformity can be obtained on the Internet/intranet.

## 7.2 Device description

Time relays are used for different control tasks in automatic production lines and for processing machines.

They are suitable for all time-delayed switching operations in control, starting, protective, and regulating circuits and ensure high repeatability of the set run times.

### 7.2.1 Device types

#### Device types

The SIMIREL 3RP1 time relays are available in the following forms:

- Single-function devices, such as the on-delay function
- Multifunctional devices

#### Frame sizes

The SIMIREL 3RP1 time relays are available in two widths:

- 3RP10: 45 mm

The width, height, and depth of time relays and contactors of frame size S00 (3RT/3RH10) are identical. The terminals are therefore on the same level, and the tier spacing in the cubicle can be kept correspondingly low.

- 3RP15: 22.5 mm

Time relays with 1 changeover contact are 82 mm in height and have six possible terminals

Time relays with 2 changeover contacts are 102 mm in height and have a possible twelve terminals

#### View of the 3RP10




Figure 7-1: 3RP1000 solid-state time relay, multifunctional

#### 3RP10 features

The features of the 3RP10 solid-state time relay:

- 1 changeover contact
- Eight selectable time ranges
- Adjustable runtime from 0.05 s to 10 hr
- Contact position and voltage indication by means of LED
- Safe isolation between the control and load sides in acc. with DIN VDE 0106 Part 101
- Combination voltage 24 VAC/VDC / 200-240 VAC and 24 VAC/VDC / 100-127 VAC
- Single-function device for the on-delay function
- Multifunctional device with 7 functions

**View of the 3RP15**




Figure 7-2: 3RP15 solid-state time relay, multifunctional with 2 changeover contacts

**3RP15 features**

The features of the 3RP15 solid-state time relays are:

- 1 changeover contact (8 functions)
- 2 changeover contacts (16 functions)
- Single or up to 15 selectable time ranges
- Contact position and voltage indication by means of LEDs
- Combination voltage 24 VAC/VDC / 200-240 VAC, and 24 VAC/VDC / 100-127 VAC
- Wide-range voltage variant for 24-240 VAC/VDC
- Single-function devices for the following functions:
  - On-delay with 1 or 2 changeover contacts
  - Off-delay with auxiliary supply and 1 changeover contact
  - Off-delay without auxiliary supply and 1 or 2 changeover contacts
  - Clock pulse generator with 1 changeover contact
  - Star-delta with 2 NO contacts
  - 2-wire, on-delay with semiconductor output
- Multifunctional time relay with 8 (1 changeover contact) or 16 functions (2 changeover contacts)

**Accessories**

**3RP10**

Coding plug set for the multifunctional time relay with 7 functions

**3RP15**

- Label sets for the multifunctional time relay with 8 or 16 functions
- Sealable cap
- Push-in lugs for screw-type terminal

**7.2.2 Installation**

**Attachment**

**Snap-on attachment**

All the time relays can be snapped onto 35 mm rails and removed without tools in acc. with EN 50 022.

**Screw-on attachment**

3RP10: attachment openings are integrated in the device

3RP15: push-in lugs for screw-type attachment are available as accessories

<b>Connection</b>	<p>The terminals of the 3RP1 time relays are designed for connections of the control cables with a maximum stripped length of 10 mm. Cross-sections of 2 x 0.5 to 2.5 mm<sup>2</sup> (single-coil) and 2 x 0.5 to 1.5 mm<sup>2</sup> (single-coil) can be clamped with a wire end ferrule.</p> <p><b>Screw-type terminal (SIGUT<sup>®</sup> terminal)</b> The 3RP10 and 3RP15 time relays are available with plus-minus Pozidriv 2 screw-type connections.</p> <p><b>Cage Clamp terminal</b> The 3RP10 and 3RP15 time relays are available with Cage Clamp terminals.</p>
-------------------	---

### 7.2.3 Special features

<b>Operating temperature</b>	There are no restrictions on the control supply voltage, switching current, or duty cycle for operation between -25 °C to +60 °C.
<b>Time ranges</b>	There are up to 15 time settings, ranging from 0.05 s to 100 hr. The 3RP15 has additional time settings between the decade scales (1/10/100 s/min/h) that make high setting accuracy possible.
<b>Wide-range voltage</b>	There are multifunctional relays with a wide voltage range of 24 VAC/VDC to 240 VAC/VDC.
<b>Electrical service life</b>	<p>The electrical service life with contactor load (e.g. 3RT1016 contactor) is 10 million operating cycles.</p> <p>The electrical service life at AC voltage of 230 V, utilization category AC-15/3 A, and at DC voltage, utilization category DC-13/1 A, is 100,000 operating cycles.</p>
<b>Start contact</b>	In the case of functions that require a continuous auxiliary supply to terminals A1/A2 and A3/A2, the time function can be started by a control supply voltage to terminal B1 or B3.

### 7.2.4 Notes on configuration

<b>Start input</b>	<p>The following specifications must be complied with to ensure error-free operation of the solid-state time relays:</p> <p>Only apply the control supply voltage from start input B1 or B3 once the supply voltage has already been applied to A1/A2 or A3/A2.</p>
<b>Identical potential</b>	Identical potential must be applied to terminals A1 and B1 or A3 and B3.

- Combination voltage** In the case of combination voltage types, only one voltage range can be connected. Never apply the two control supply voltages simultaneously.
- Parallel load at the start contact** The start contact is under voltage and rectified. There is a connection in the time relay to the A1 and A2 terminals. The control of loads parallel to the start input is therefore not permissible at AC 50/60 Hz control supply voltage.
- The following information facilitates configuration of SIMIREL 3RP time relays:
- Combination/wide-range voltages** 80% of the time relay types are combination and wide-range voltage types because they are flexible in their uses:
- Combination voltage: two operating voltage ranges (e.g. 24 VAC/VDC and 200 to 240 VAC) at different terminals
  - Wide-range voltage: one operating voltage range from 24 VAC/VDC to 240 VAC/VDC at the same terminals
- Two-wire time relay** Two-wire time relays have the following advantages over conventional time relays in connection with contactors:
- Reduced wiring
  - Bounce-free control
  - The electronic output increases service life because no mechanical wear occurs.
  - Greater switching frequency
- Special functions**
- Pulsing function: pulse and idle time can be set separately.
  - Flashing: the pulse/break ratio is 1:1.
  - The timing period starts with the "off-delay without auxiliary supply" function if the time relay is separated from the supply voltage.
  - In the case of the 3RP15 time relay with 15 selectable time settings, there is a  $\infty$  switch position. This means an endless timing period. If this setting is chosen for the on-delay function, the output relay never switches through after the supply voltage has been applied (off function). In the case of the "making pulse contact" function, the output relay always remains on (on function). This can be used for test purposes.
  - In the case of the "additive on-delay with auxiliary supply" function, the time is added for as long as the start contact is activated. If the start contact is interrupted, the timing period stops and is then continued once the start contact is closed again.  
This function is not non-volatile and requires a continuous auxiliary power supply.
  - In the case of the "shaping pulse contact with auxiliary supply" function, an activated start contact triggers a timing period that can be set. The control signal for this can be shorter or longer than the desired runtime.
- Cable ducts** If you use cable ducts for wiring, the position and dimensions of the terminal blocks must be taken into consideration (see pages 7-27).

## 7.2.5 Explanation of terms

### **Setting accuracy**

Setting accuracy is the accuracy in relation to the end value of the scale in line with the specified tolerance.

### **Repeatability**

Repeatability describes the accuracy with which the set value can be reproduced with the specified tolerance.

## 7.3 Applications and uses (types of function)

### 7.3.1 Multifunction (3RP10 00 solid-state time relay)

The time relay contains a changeover contact.

#### Operating time adjustment

Eight time ranges can be set by means of a rotary switch. The desired runtime can be set accurately by means of a potentiometer (rotary switch for fine adjustment).

#### Important

Changes to the time range are only effective if they are made in a deenergized state.

#### Example

You want to set a duration of 5 seconds:



Step	Procedure
1	 <p>Rotate the time range selector switch to 10 s. This means runtimes of up to 10 seconds can be set.</p>
2	 <p>Rotate the potentiometer to 50% for fine adjustment. In other words, 50% (= 5 seconds) of the maximum value (10 seconds) is set.</p>

Table 7-1: 3RP10 00 (multifunctional) operating time adjustment




Figure 7-3: 3RP10 00 (multifunctional) operating time adjustment

#### Functions

You can select 7 different functions with the coding plug set (7PX9904) provided.

#### Important

Changes to the function are only effective if they are made in a deenergized state.

Without the coding plug the multifunctional time relay (3RP10 00) is programmed for the on-delay.



**Function setting**

The connector with the function you want is removed from the coding plug set and put on the time relay as shown in the following diagram:




Figure 7-4: 3RP10 00 (multifunctional) function setting

The name of the function and the corresponding circuit diagram are printed on the coding plugs in German and English.

**Function diagrams**

The coding plug set contains the functions for the 3RP1000 solid-state time relay listed in the following table:

Function	Circuit diagram	Function diagram
<b>On-delay</b>		
<b>Off-delay with auxiliary supply</b>		
<b>On-delay and off-delay with auxiliary supply</b>		
<b>Flashing, start with break</b>		
<b>Making pulse contact</b>		
<b>Breaking pulse contact with auxiliary supply</b>		
<b>Shaping pulse contact with auxiliary supply</b>		

Table 7-2: 3RP10 00 (multifunctional) circuit diagrams and function diagrams

**Important**

The same potential must be applied to terminals A and B.

A./A2 ≙ A1/A2 or A3/A2, depending on the voltage level connected  
 B./A2 ≙ B1/A2 or B3/A2, depending on the voltage level connected

### 7.3.2 Multifunctional (3RP15 05 solid-state time relay)

#### Operating time adjustment

Fifteen time ranges can be set using a rotary switch, ensuring very precise adjustment. The set time range is displayed in a window next to the rotary switch.

The desired runtime can be set accurately by means of a potentiometer (rotary switch for fine adjustment).

In the time range position  $\infty$  the function is executed with an endless time period. This means, for example, that the output relay never switches through when "on-delay" is set and the supply voltage is applied or that the output relay remains continuously on when "making pulse contact" is set.

#### Important

Changes to the time range are only effective if they are made in a deenergized state.

#### Example

You want to set a 90 second period:



Step	Procedure
1	 Rotate the time range selector switch until 100 s appears in the adjacent window. This means run-times of up to 100 seconds can be set.
2	 Rotate the potentiometer to 90%. In other words 90% (= 90 seconds) of the maximum value (= 100 seconds) is set.

Table 7-3: 3RP15 05 (multifunctional) operating time adjustment




Figure 7-5: 3RP15 05 (multifunctional) operating time adjustment

### Functions

The following can be set by means of a rotary switch.

- Time relay with 1 changeover contact: 8 functions
- Time relay with 2 changeover contacts: 16 functions

---

### Important

Changes to the function are only effective if they are made in a deenergized state.

---

### Function setting

The function is set using a rotary switch and is indicated by an identifying letter in the adjacent window.

The set function can be labeled distinctly with an identification plate with the corresponding function diagram. At the same time, a mechanical code ensures that the correct function is set by ensuring that a label can only be clipped on if the corresponding function is set using the rotary switch.

A label set with function diagrams of all the functions that can be set for the time relay is available as an accessory.

Break the label of the set function out of the label set, and snap it firmly onto the time relay as shown in the following diagram:




Figure 7-6: 3RP15 05 (multifunctional) function identification

**Identifying letters**

The following table lists the identifying letters for the 8 or 16 functions of the solid-state multifunctional 3RP15 05 time relay:

<b>Function</b>	<b>Identifying letter with time relay with 1 changeover contact</b>	<b>Identifying letter with time relay with 2 changeover contacts</b>
On-delay	A	A
Off-delay with auxiliary supply	B	B
On-delay and off-delay with auxiliary supply	C	C
Flashing, start with break	D	D
Making pulse contact	E	E
Breaking pulse contact with auxiliary supply	F	F
Shaping pulse contact with auxiliary supply	G	G
Additive on-delay with auxiliary supply (and immediate switching only H•)	H	H•
On-delay and immediate switching		A•
Off-delay with auxiliary supply		B•
On-delay and off-delay with auxiliary supply and immediate switching		C•
Flashing, start with break, and immediate switching		D•
Making pulse contact and immediate switching		E•
Breaking pulse contact with auxiliary supply and immediate switching		F•
Shaping pulse contact with auxiliary supply and immediate switching		G•
Star-delta function		YΔ

Table 7-4: 3RP15 05 (multifunctional) assignment of the identifying letters

The • after the identifying letter indicates that the second changeover contact present reacts as an immediate switching contact (controlled by the supply voltage or the start contact depending on the function). If this • is not present, the second changeover contact reacts with a time delay like the first changeover contact.

**Function diagrams**  
**Circuit diagrams**

The following table explains the 8 or 16 functions of the solid-state multi-functional 3RP15 05 time relay using circuit diagrams and function diagrams:

Identifying letter	Device circuit diagrams	Function diagram
<b>A</b> <b>On-delay</b>		
<b>B</b> <b>Off-delay with auxiliary supply</b>		
<b>C</b> <b>On-delay and off-delay with auxiliary supply (<math>t=t_{on}=t_{off}</math>)</b>		
<b>D</b> <b>Flashing, start with break (pulse/break 1:1)</b>		
<b>E</b> <b>Making pulse contact</b>		
<b>F</b> <b>Breaking pulse contact with auxiliary supply</b>		
<b>G</b> <b>Shaping pulse contact with auxiliary supply (creates a pulse at the output irrespective of the length of excitation)</b>		
<b>H</b> <b>Additive on-delay with auxiliary supply and immediate switching</b>		

\* Only with devices with 2 changeover contacts

Table continued: Function diagrams (3RP15)

Identifying letter	Device circuit diagrams	Function diagram
<b>A.</b> <b>On-delay and immediate switching</b>		
<b>B.</b> <b>Off-delay with auxiliary supply and immediate switching</b>		
<b>C.</b> <b>On-delay and off-delay with auxiliary supply and immediate switching (t=t<sub>on</sub>=t<sub>off</sub>)</b>		
<b>D.</b> <b>Flashing, start with break (pulse/break 1:1) and immediate switching</b>		
<b>E.</b> <b>Making pulse contact and immediate switching</b>		
<b>F.</b> <b>Breaking pulse contact with auxiliary supply and immediate switching</b>		
<b>G.</b> <b>Shaping pulse contact with auxiliary supply and immediate switching (creates a pulse at the output irrespective of the duration of excitation)</b>		
$\Upsilon\Delta$ <b>Star-delta function</b>		

\* Only with devices with 2 changeover contacts

Table 7-5: Function diagrams and circuit diagrams

### 7.3.3 On-delay

#### The 3RP10 20 solid-state time relay

The time relay contains 1 changeover contact.

#### Time ranges

Eight time ranges can be set by means of a rotary switch.

---

#### Important

Changes to the time range are only effective if they are made in a deenergized state.

---

#### Function diagram




Figure 7-7: 3RP10 function diagram

#### The 3RP15 11/12/13 solid-state time relay

The time relay contains 1 changeover contact.

#### Time ranges

Fixed time ranges are offered: 10 s, 30 s, 100 s

#### Function diagram




Figure 7-8: 3RP15 1. function diagram

#### The 3RP15 25 solid-state time relay

The time relay is available with either 1 or 2 changeover contacts.

#### Time ranges

Fifteen time ranges can be set by means of a rotary switch.

---

#### Important

Changes to the time range are only effective if they are made in a deenergized state.

---



**Function diagrams**

The function diagram for the time relay with 1 changeover contact and with 2 changeover contacts:




Figure 7-9: 3RP15 25 function diagram

**The 3RP15 27 solid-state time relay (two-wire time relay)**

The two-wire time relay is connected in series with the load. The timing period begins after the control supply voltage has been applied. The semiconductor output then becomes live, and voltage is applied to the load. Four time ranges can be set by means of a rotary switch.

**Time ranges**

**Important**

Attention must be paid to the rated operational current, residual current with unswitched output, and voltage drop in the case of a switched output.

**Function diagram**




Figure 7-10: 3RP15 27 function diagram

**7.3.4 Off-delay**

**The 3RP15 31/32/33 solid-state time relay with auxiliary supply**

The time relay contains 1 changeover contact.

**Time ranges**

Fixed time ranges are offered: 10 s, 30 s, 100 s

**Function diagram**




Figure 7-11: 3RP15 3. function diagram

There is continuous auxiliary voltage (A./A2) at the time relay. If a control supply voltage is applied to the start contact, the output relay switches over. After the start contact is disconnected, the set runtime starts. The minimum on-time of  $\geq 35$  ms must be adhered to.

**The 3RP15 40 solid-state time relay without auxiliary supply**

The time relay is available with either 1 or 2 changeover contacts.

**Time ranges**

Seven time ranges can be set by means of a rotary switch. Times ranging from 0.05 to 100 s are possible.

**Important**

Changes to the time range are only effective if they are made in a deenergized state.

**Function diagrams**

The function diagram for the time relay with 1 changeover contact and with 2 changeover contacts:




Figure 7-12: 3RP15 40 function diagram

**Mode of operation**

When the rated control supply voltage is applied, the time relay switches over. After the rated control supply voltage has been disconnected, the runtime  $t$  starts. After  $t$  has finished, the relay switches back to the quiet state. If the minimum on-time is not adhered to, it is ensured that either the timing period will not start or that a started timing period will always be properly completed.

Intermediate states in the function process, such as the relay getting stuck, are successfully prevented.

**7.3.5 Clock pulse generator (3RP15 55 solid-state time relay)**

**Description**

The idle time and the pulse time of the clock pulse generator and the time ranges must be set separately. The pulsing function begins with the break.

The time relay contains a changeover contact.

**Time ranges**

Fifteen time ranges can be set by means of a rotary switch.

**Important**

Changes to the time range are only effective if they are made in a deenergized state. A pulse, for example, can be output cyclically for 1 second after a break of 1 hour.

**Function diagram**




Figure 7-13: 3RP15 55 function diagram

**7.3.6 Star-delta function (3RP15 74/76 solid-state time relay)**

**Description**

The instantaneous star contact and the time-delayed delta contact have a shared contact root. To avoid phase short circuits, the switchover break from star to delta is 50 ms.

**Time ranges**

The time relay offers a fixed time range: 20 s, 60 s

**Function diagram**




Figure 7-14: 3RP15 74/76 function diagram

**7.3.7 Star-delta function with overtravel (3RP15 60 solid-state time relay)**


**Description**

Supply voltage is applied to A./A2 and there is no control signal at B./A2. This starts the  $\Upsilon\Delta$  timing period. By applying the control signal to B./A2, the idling time (overtravel time) is started. When the set time  $t_{\text{idling}}$  (30 s to 600 s) is completed, the output relays (17/16 and 17/28) are reset. If the control signal is switched off at B./A2 (minimum off-time 270 ms), a new timing period is started.

**Time ranges**

Star-delta time 1 s to 20 s  
Overtravel time: 30 s to 600 s

**Function diagram**



## 7.4 Accessories

### 7.4.1 Accessories for 3RP10

#### Coding plug set

Included with the 3RP10 00 solid-state time relay is a coding plug set for 7 functions. The function is set by clipping on a label with that function on it. The following diagrams show you how to affix the coding labels:




Figure 7-15: Coding plug set (3RP10 00)

This coding plug set is also available separately as 7PX9904.

### 7.4.2 Accessories for 3RP15 05

#### Label set

Two label sets are available to the 3RP15 05 solid-state time relay, multi-function device for labeling, depending on the version (8 functions with 1 changeover contact, 16 functions with 2 changeover contacts):

- 3RP19 01-0A for the 3RP15 05-1A electronic relay, 1 changeover contact
- 3RP19 01-0B for the 3RP15 05-1B electronic relay, 2 changeover contacts

The following table shows you how to set the function on the time relay and put on the label:

Illustration	Procedure
<p>3RP19 01-0A (3RP15 05-.A) 3RP19 01-0B (3RP15 05-.B)</p>	<p><b>1</b> The desired function is set on the potentiometer of the time relay using a screwdriver.</p> <p><b>2</b> The corresponding label identifying the set function is clipped on.</p>

Figure 7-16: Label set (3RP15)

**Sealable cover**

All 3RP15 solid-state time relays can be secured against unauthorized adjustment by means of a sealable cover (3RP19 02). The following table and illustration explain how to do this:



Illustration	Procedure
 <p>3RP19 02</p>	<p><b>1</b> Break off the key for interlocking from the upper edge of the cover.</p> <p><b>2</b> Use the hook to put the cover in the openings to the side of the device identification label.</p> <p><b>3</b> Move the cover toward the time relay.</p>
	<p><b>4</b> Hook the key onto the time relay through the slit in the cover to attach the cover to the time relay.</p> <p><b>5/6</b> Pull the seal through the opening of the key.</p>

Table 7-6: Sealable cover

**Push-in lugs for screw-type attachment**

Push-in lugs (3RP19 03) are available for the screw-type attachment:




Figure 7-17: Screw-on attachment

## 7.5 Mounting and connection

### 7.5.1 Mounting

#### 3RP10

##### Snap-on attachment

The 3RP10 time relays can be snapped onto the 35 mm rails and removed without tools in acc. with EN 50 022. Place the time relay on the upper edge of the rail, and press it downward until it snaps onto the lower edge of the rail. To remove the time relay, press it downward to release the tension of the spring, and the time relay can be removed.




Figure 7-18: 3RP10: mounting on and removal from a 35 mm rail

##### Screw-on attachment

The following is required for screw-type attachment of the 3RP10 time relay:

- 2 M4 screws, diagonal
- Maximum tightening torque of 10.5 Nm
- Washers and spring lock washers must always be used
- The distance to grounded parts at the side must be more than 6 mm

#### 3RP15

##### Snap-on attachment

The 3RP15 time relays can be snapped onto the 35 mm rails and removed without tools in acc. with EN 50 022. Place the time relay on the upper edge of the rail, and press it downward until it snaps onto the lower edge of the rail. To remove the time relay, press it downward to release the tension of the spring, and the time relay can be removed.




Figure 7-19: Rail mounting

**Screw-on attachment**

Screw-on attachment is possible by means of push-in lugs for M4 screws (application, see under Section 7.4 Accessories)

**7.5.2 Connection**

The 3RP10 solid-state time relays are available with SIGUT® terminals with plus/minus Pozidriv 2 screws and also with Cage Clamp terminals. The 3RP15 solid-state time relays are available:

- With SIGUT® terminals with plus/minus Pozidriv 2 screws
- With Cage Clamp terminals

**Conductor cross-sections**

The following table lists the permissible conductor cross-sections for the 3RP1 solid-state time relays. The specifications apply to control and load current connections.





	3RP10.0-1	3RP10.0-2 (Cage Clamp)	3RP15	3RP15..-2 (Cage Clamp)
 Ø 5 to 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	-----	0.8 to 1.2 Nm 7 to 10.3 lb.in	-----
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 4 mm <sup>2</sup> )	2 x (0.25 to 2.5 mm <sup>2</sup> )	1 x (0.5 to 4 mm <sup>2</sup> ) 2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1.5 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (0.25 to 1 mm <sup>2</sup> )	1 x (0.5 to 2.5 mm <sup>2</sup> ) 2 x (0.5 to 1.5 mm <sup>2</sup> )	2 x (0.25 to 1 mm <sup>2</sup> )
	-----	2 x (0.25 to 1.5 mm <sup>2</sup> )	-----	2 x (0.25 to 1.5 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (24 to 14)	2 x (20 to 14)	2 x (24 to 16)

Table 7-7: Permissible conductor cross-sections for control and load current connections:

The following illustration shows you the Cage Clamp terminal:





Figure 7-20: Cage Clamp terminals


### 7.5.3 Circuit diagrams

#### 3RP10



3RP10 circuit diagrams

#### 3RP15




3RP15 circuit diagrams




## 7.6 Dimensioned drawings (dimensions in mm)


### 3RP1 time relay



3RP10



3RP15, 1 changeover contact without auxiliary supply<sup>5)</sup>, clock pulse generator, star-delta function



3RP15 1 and 2 changeover contact devices with auxiliary supply

- 1) Push-in lug for screw-type attachment
- 3) Coding plug (with 3RP10) or identification label
- 4) Drilling pattern
- 5) Except 3RP15 05-1A.30 two-wire design
- 6) Identification label

## 7.7 Technical specifications

### Technical specifications in acc. with IEC 61812-1/DIN VDE 0435 Part 2021

Type		3RP10 00	3RP15 05	3RP15 11	3RP15 40	3RP15 60	3RP15 74	3RP15 27
		3RP10 20	3RP15 31	3RP15 12			3RP15 76	
			3RP15 32	3RP15 13				
			3RP15 33	3RP15 25				
				3RP15 55				
<b>Rated insulation voltage</b>	VAC	300; 500 with 3RP1505-1BT20						
Pollution degree 3								
Overvoltage category III in acc. with DIN VDE 0110								
<b>Excitation operating range</b> <sup>1)</sup>		0.85 to 1.1 x $U_N$ with AC; 0.8 to 1.25 x $U_N$ with DC						
		0.95 to 1.05 times the rated frequency						
<b>Rated power</b>	W	1	2	2	2	2	2	1
Power input at 230 VAC, 50 Hz	VA	4	6	6	2 <sup>2)</sup>	6	6	1
<b>Rated operational currents</b> $I_e$								
AC-15 at 230 VAC, 50 Hz	A	3 <sup>3)</sup>						
AC-14; DC-13		-						
DC-13 at 24 V		1						
DC-13 at 48 V		0.45						
DC-13 at 60 V		0.35						
DC-13 at 110 V		0.2						
DC-13 at 230 V		0.1						
<b>DIAZED fuse</b> <sup>4)</sup>								
Performance class	gL/gG	A	4					
<b>Switching frequency</b>								
• Loaded with $I_e$ 230 VAC	1/h	2500						5000
• Loaded with 3RT10 16 contactor, 230 VAC	1/h	5000						5000
<b>Recovery time</b>	ms	150 <sup>5)</sup>				300	150	50
<b>Minimum on-time</b>	ms	35	35 <sup>6)</sup>	-	200 <sup>7)</sup>	-	-	-
<b>Residual current</b>	mA							
With output not switched through								
<b>Voltage drop</b>	V							
Switched through								
<b>Short-term current-carrying capacity</b>	A							
<b>Setting accuracy</b>		Typically ±5%						
Related to the end of scale value								
<b>Repeatability</b>		≤ ±1%						
<b>Mechanical service life</b>	Operating cycles	30 x 10 <sup>6</sup>						100 x 10 <sup>6</sup>
<b>Permissible ambient temperature</b>	In operation	°C	-25 to +60					
	During storage	°C	-40 to +85					
<b>Degree of protection</b>		IP 40 lid						
In acc. with EN 60 529		IP 20 terminals						
<b>Shock resistance</b>	g/ms	15/11						
Half-sine in acc. with IEC 60 068-2-27								
<b>Vibration resistance in acc. with IEC 60 068-2-6</b>	Hz/mm	10-55/0.35						
<b>EMC tests</b>		IEC 61 000-6-2/EN 50 081-1						
In acc. with the basic specification								

Table 7-8: Technical specifications for the time relay

1) If not specified otherwise

2) Maximum making current peak 1 A/100 ms

3) With 3RP15 05- R: NC contact →  $I_e = 1$  A

4) Without any welding in acc. with IEC 60 947-5-1.

5) With RP15 05-.BW30/.AW30/.RW30 and 3RP15 25-.BW30 voltage-dependent 10 to 250 ms.

6) Minimum on-time with 3RP15 00-. BW30 150 ms until instantaneous contact is switched.

7) Adhere to minimum on-time for problem-free functioning.

# 3RW3 semiconductor motor control unit (soft starter)

Section	Subject	Page
<b>8.1</b>	<b>Specifications/regulations/approvals</b>	<b>8-3</b>
<b>8.2</b>	<b>Device description</b>	<b>8-5</b>
8.2.1	Physical principles	8-6
8.2.2	General device description	8-10
8.2.3	Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the SIKOSTART 3RW22 motor control units	8-14
8.2.4	Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the 3RA star-delta combination	8-16
8.2.5	Notes on configuration	8-16
<b>8.3</b>	<b>Application and use</b>	<b>8-18</b>
8.3.1	Areas of application and criteria for selection	8-18
8.3.2	Installation guidelines	8-18
8.3.3	Overview tables: correction factors	8-21
8.3.3.1	3RW30/31 soft starters in a stand-alone installation	8-21
8.3.3.2	3RW30/31 soft starters in combination with the 3RV1 circuit breaker	8-22
8.3.3.3	Combining the 3RT contactor with the 3RU1 thermal overload relay and 3RW3 soft starter	8-24
8.3.3.4	Combining the 3RT contactor with the 3RB10 electronic overload relay and 3RW3 soft starter	8-26
8.3.4	Circuit examples	8-29
8.3.5	Commissioning	8-30

<b>Section</b>	<b>Subject</b>	<b>Page</b>
8.3.6	Event messages and diagnostics	8-32
8.3.7	Timing diagram	8-33
<b>8.4</b>	<b>Accessories</b>	<b>8-35</b>
<b>8.5</b>	<b>Mounting and connection</b>	<b>8-37</b>
8.5.1	Mounting	8-37
8.5.2	Connection	8-37
8.5.3	Circuit diagrams	8-38
<b>8.6</b>	<b>Dimensioned drawings</b>	<b>8-41</b>
<b>8.7</b>	<b>Technical specifications</b>	<b>8-42</b>
8.7.1	Control electronics/power electronics	8-42
8.7.2	Short-circuit protection and fuse coordination	8-45
8.7.3	Site altitude	8-50
8.7.4	Specifications in acc. with IEC	8-51
8.7.5	Specifications in acc. with NEMA	8-52

## 8.1 Specifications/regulations/approvals

The 3RW3 semiconductor motor control units, referred to below more succinctly as soft starters, meet the UL and CSA requirements.

UL/CSA	UL 508
Degrees of protection offered by housings	EN
DIN standard rail	EN 50 022
Electronic Motor control units	IEC 60947 - 4-2
Shock protection	IEC 60947 - 1 and DIN 40050
EMC	IEC 60801 - 4 -2 (draft)
General specifications	EN 602 69 - 1A1
Control devices and switching elements	EN 602 69 - 1A1
Gost	Approved by Gost
CTic	EMC compliance marking for Australia (similar to CE marking)

Table 8-1: Standards, certificates, and approvals, 3RW3

### Normal switching duty

The 3RW3 soft starters can be used for normal switching duty in acc. with DIN VDE 0100 Part 460:

A switch for normal switching duty must be provided for all circuits that are to be switched independently of other parts. Switches for normal switching duty do not **necessarily all switch active conductors** of a circuit.


### Isolation


The soft starters do not meet the requirements for isolation in acc. with DIN VDE 0100 Part 460 and EN 60 947-1:

Every circuit must be capable of being isolated from the active conductors of the power supply.

Circuit groups can be isolated by a common device if this is permitted by the operating conditions. In the open position, devices with an isolating function must have a corresponding isolating distance and an indicator showing the positions of the moving contacts.

## Warnings

	<b>Caution</b>
<p>The devices are all carefully tested at the factory and are not shipped unless they are found to be in proper working order. However, they may be subjected to stresses during transportation over which we have no control.</p> <p>Consequently, the impulse series relays in the main circuit may be in an undefined switching state.</p> <p>In the interests of complete safety, the following procedure should be used at commissioning or after the replacement of the SIRIUS soft starter:</p> <p><b>First</b>, apply the supply voltage in order to put the impulse series relays in a defined switching state.</p> <p><b>Then</b>, switch the main circuit on.</p> <p>If you deviate from this procedure, the motor can be switched on inadvertently and cause damage to people or parts of the system.</p>	

	<b>Important</b>
<p>The 3RW3...-1.B1. soft starter was built as a class A device. Using this product in residential buildings could cause radio interference.</p>	

## 8.2 Device description

The SIRIUS 3RW3 soft starters are part of the SIRIUS modular system. They are compatible with the other SIRIUS switching devices.

The possible combinations are:

- 3RW3 soft starter + 3RV circuit breaker
- 3RW3 soft starter + 3RU/3RB overload relay + 3RT contactor

The link modules used for combinations of contactors and circuit breakers are used for this (see Section 8.3.2, "Installation guidelines").




Figure 8-1: 3RW3 soft starter

### 3RW30/31 frame sizes

The 3RW30 soft starter is available in four frame sizes: S00, S0, S2, and S3. The 3RW31 soft starter is available in frame size S0.

The following table contains the power ranges of the various frame sizes (all specifications apply to  $U_N = 400\text{ V}$  and  $40^\circ\text{ C}$  ambient temperature):

Frame size S00	Frame size S0	Frame size S2	Frame size S3
1.1 - 4 kW	5.5 - 11 kW	15 - 22 kW	30 - 55 kW
6 - 9 A	12.5 - 25 A	32 - 45 A	63 - 100 A
(W x H x D) (mm) 45 x 97.5 x 93	(W x H x D) (mm) 45x125x119	(W x H x D) (mm) 55 x 160 x 143	(W x H x D) (mm) 70x170x178

Table 8-2: 3RW3, frame sizes

## 8.2.1 Physical principles

### Starting current

Three-phase current asynchronous motors have a high inrush current  $I_{\text{starting}}$ . This inrush current can be between three and fifteen times as high as the rated operational current, depending on the type of motor. A figure between seven and eight times the rated operational current can be postulated as typical.




Figure 8-1: Typical current and torque curve of a three-phase asynchronous motor

### Important

This starting current must be taken into consideration in the design of the supply network, among other things by adapting the supply (high heat development) and the fusing (inadvertent tripping of the fuses).

### Reducing the starting current

There are various ways of reducing the starting current:

- By star-delta starter
- By frequency converter
- By soft starter



### Star-delta starter

After a delay, the motor windings are switched from a star to a delta configuration. The motor current for star starting is only about 1/3 of that required for delta starting (motor torque, too, is reduced to approximately 1/3 of the delta torque).

#### Disadvantages:

- 6 motor cables are necessary
- Switching surges occur (in the current and torque transients)
- The startup cannot be adapted to the system environment
- Installation is relatively complicated and time-consuming
- More space is needed in the cubicle




Figure 8-2: Current and torque curves for star-delta starting

**Frequency converter**

A frequency converter converts the AC voltage from the grid to direct voltage, which can then be converted to any voltage and frequency. The illustration below shows how a frequency converter works:




Figure 8-3: Method of operation of a frequency converter

**Disadvantages:**

- Relatively complicated wiring needed in order to meet radio interference suppression requirements; filters are often essential
- Line capacitances limit the lengths of motor feeder cables; it may be necessary to use chokes, sinus filters, or even  $dV/dt$  filters.
- Expensive
- System startup is complex and time-consuming on account of the multiplicity of operating parameters
- It can be necessary to use shielded motor feeder cables

**Advantages:**

- Motor speed is variable; speed can be accurately pegged at constant levels.

The  $U/f$  ratio remains virtually constant. It is therefore possible to achieve high torques at relatively low currents.

## Soft starter

With a soft starter, motor voltage is increased from a selectable starting voltage to the rated voltage by phase firing within a defined starting time. Motor current is proportional to the motor voltage, so the starting current is reduced by the factor of the defined starting voltage.

The illustration below shows how the 3RW3 soft starter works:




Figure 8-4: Phase firing of the supply voltage by semiconductor elements in the 3RW3 soft starter

### Example:

Starting voltage 50% of  $U_e$  => starting current equals 50% of the motor starting current for direct-on-line starting.

A soft starter also reduces motor torque. This is the reason why a soft-started motor does not jerk into action.

The relationship is as follows: The motor torque is proportional to the square of the motor voltage.

### Example:

Starting voltage 50% of  $U_e$  => starting torque 25% of the starting torque for direct-on-line starting.

### Advantages:

- Less space needed in the cubicle
- No protective circuits (e.g. filters) necessary to comply with the radio interference suppression specifications (class A; in UC 24 V control voltage version also class B)
- Lower installation costs
- Straightforward system startup
- Only 3 motor feeder cables, half as many as are needed for a star-delta starter
- Adjustment options permit adaptation to the system.

### Disadvantages:

- Long-term speed settings not possible.
- Lower torque at reduced voltage




Figure 8-5: Current and torque curves for a soft starter

## 8.2.2 General device description

The SIRIUS modular system offers a variety of alternatives for load feeders. In addition to the star-delta starters (see Chapter 5, "3RA fuseless load feeders"), the SIRIUS 3RW3 soft starters are also available.

The 3RW3 soft starters can be combined with the following SIRIUS devices:

- 3RT contactors
- 3RV circuit breakers
- 3RU thermal overload relays
- 3RB10 electronic overload relays

They are all mounted and connected up in the same way.

Please note the relevant guidelines in Section 8.3.2.

### Functions of the load feeder

#### Normal switching duty

Normal switching duty of a circuit can, according to the definitions of isolation and normal switching data in DIN VDE 0100 (see Section 8.1), be implemented with a contactor or a soft starter alone.

**Isolation**

According to DIN VDE 0100, isolation from the supplying network cannot be provided by a semiconductor element (i.e. soft starter, frequency converter, contactor, or similar).

To implement isolation from the supplying network, a 3RV circuit breaker (or another isolating device that fulfills the requirements of DIN VDE 0100) must be used in addition to the contactor or soft starter. A contactor alone in combination with the soft starter is not enough.

Both isolation and normal switching duty can be implemented quickly and easily with the 3RW3 soft starter in combination with the modules from the SIRIUS modular system.

**Variants**

The electronic soft starters are available in two variants:

**Standard 3RW30 variant**

The standard 3RW30 variant is used for single-speed motors. This variant is available in all four frame sizes. The starting voltage  $U_s$ , starting time  $t_{R0n}$ , and coasting-down time  $t_{R0ff}$  can be set independently of each other on the device. The device is switched on by means of a cycling contact IN.

**3RW31 special variant**

The 3RW31 special variant cycles pole-changing motors (Dahlander winding). The following can be set independently of each other:

- Starting voltage  $U_s$
- Starting time of initial speed  $t_{R1}$
- Starting time of second speed  $t_{R2}$

The device does not have a coasting-down function. The set starting voltage applies to both ramp times  $t_{R1}$  and  $t_{R2}$ .

The ramp time is selected by means of two inputs, IN1 and IN2, that switch the soft starter on.

The devices of the 3RW31 series are only available in frame size S0.

**Settings**

The devices can be set as follows:

**3RW30**

By means of 3 potentiometers for setting:

- Starting time in the range from 0 to 20 seconds
- Starting voltage in the range from approx. 30 to 100% of the rated voltage of the motor
- Coasting-down time in the range from 0 to 20 seconds

**3RW31**

By means of 3 potentiometers for setting:

- Starting time 1 in the range from 0 to 20 seconds
- Starting voltage in the range from approx. 30 to 100% of the rated voltage of the motor
- Starting time 2 in the range from 0 to 20 seconds

A special software program ensures that progressive ramp times are set.

Short times of up to 5 seconds can thus be set very precisely.

**Auxiliary contacts**

**3RW30**

In the case of frame sizes S0 to S3, the following auxiliary contacts are integrated:

- "ON": When triggered, the latching signal is used for locking by means of a simple on/off pushbutton (contact designation 13/14).
- "BYPASSED": With the end-of-startup signal, control valves can be addressed after soft starting of a pump, for example, in order to enable pumping (contact designation 23/24).

The devices of frame size S00 do not have any auxiliary switches.

**3RW31**

The 3RW31 does not have any auxiliary contacts.

**Soft starting function**

Torque-reduced start for three-phase asynchronous motors:

Triggering is two-phase, which means that the current is kept low throughout the run-up phase. Current peaks such as those that occur in a star-delta start at the changeover from star to delta are prevented by continuous voltage management.

Transient current peaks (inrush peaks) are automatically avoided in each switch-on procedure by a special control function of the power semiconductors.

**Soft coasting-down function**

The integrated soft coasting-down function prevents the drive coming to an abrupt halt when the motor is switched off.

**3RW30 time ramps**

The following graphics show the time ramp of the 3RW30 and the timing diagram of the auxiliary contacts:




Figure 8-6: Time ramp/timing diagram, 3RW30

The graphic below shows the time ramp of the 3RW31:




Figure 8-7: Time ramp, 3RW31

**Accessories**

A fan can be snapped into the soft starter housing of frame sizes S0 to S3 from below. This brings the following benefits:

- Improved range of options for the installation position
- Increase in the switching frequency (see Section 8.3.2, "Installation guidelines")

In the case of frame sizes S0 and S2, extended terminal covers can be mounted on the box covers in order to cover the cable ends and keep them safe from fingers. These are identical to the extended terminal covers of the SIRIUS 3RT contactors of the same frame sizes.

In the case of frame size S3, terminal covers are available for lug connection or bar connection. These, too, are identical to the accessory parts of the corresponding SIRIUS contactor size.

See Section 8.4 for details of other accessories.

**Mounting**

The devices are attached to the 3RV circuit breakers by means of a link module and are thus connected mechanically and electrically. This link module is identical to the one that is used for the corresponding contactor/circuit-breaker combinations. This installation variant offers all the advantages of a fuseless load feeder.

**Link modules**

The following link modules are used to combine 3RW3 soft starters and 3RV1 circuit breakers:

Frame size	Link module
S00	3RA1911-1A
S0	3RA1921-1A
S2	3RA1931-1A
S3	3RA1941-1A

Table 8-3: Link modules

**Connection**

The 3RW3 electronic soft starters are available with screw-type terminals. Plus-minus POZIDRIV 2 screws are used.

The SIGUT terminal system is used (captive screws, contacts open on delivery, etc.).

### 8.2.3 Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the SIKOSTART 3RW22 and SIKOSTART 3RW34 motor control units

Soft starters are available for different applications.  
The following graphic provides an overview of the different soft starters:




Figure 8-8: Overview of soft starters

#### SIKOSTART 3RW22

The SIKOSTART 3RW22 is suitable for drives that place high demands on the functionality of the starter. It covers a power range from 3 kW to 710 kW (at 400 V).

SIKOSTART 3RW22 offers the following:

- Soft starting and soft coasting down
- Break-loose torque
- DC brakes
- Energy-saving operation
- Temperature monitoring
- Operation using a PC and an RS232 interface
- Selection and configuration program
- Current and voltage limitation
- Pump functionalities (e.g. pump coasting down)
- Startup detection
- Three parameter sets
- Different coasting-down types
- Electronic device overload protection

The SIKOSTART 3RW22 application manual presents the various application areas and circuit variants (order no. E20001-P285-A484-V3).



**SIKOSTART 3RW34**

The SIKOSTART 3RW34 is suitable for drives with low demands in terms of the functionality of the soft starter. The SIKOSTART 3RW34 is very similar to the SIRIUS 3RW3 soft starter in terms of its operation and configuration. It covers a power range of up to 1000 kW (400 V).

The functions of the 3RW34 are as follows:

- Soft starting and soft coasting down
- 2 circuit variants: standard and root 3 circuits
- Three-phase control
- Optional AS-i bus control

You will find the technical specifications and a detailed description of the 3RW34 in the document describing SIKOSTART 3RW22/3RW34 solid-state motor controllers (order no.: E20001-A200-P302).

**SIRIUS 3RW3 soft starter**

The SIRIUS 3RW3 soft starter covers the power range from 1.5 kW to 45 kW.

Power semiconductors always exhibit power loss. This manifests itself in heat generation. In order to keep this power loss as low as possible, the semiconductors are bypassed by relay contacts after the motor has started up. The device's heat sink and its dimensions can thus be smaller than they otherwise would be. In addition, it is necessary to use a bypass contactor, which bypasses the line semiconductors in the conventional configuration. For further processing in the system controller, the device offers two relay outputs:

- "ON" contact (terminals 13/14), which can be used, for example, to control the soft starter by button (locking)
- "BYPASSED" contact (terminals 23/24), which signals the completion of startup (e.g. in order to switch a solenoid valve after a soft-started pump has started up)

For drives in this power range, good motor startups can be achieved with a two-phase controller.

In the case of a two-phase controller, semiconductor elements are only used in two phases in order to reduce motor current and motor voltage in all three phases. The third phase is bypassed internally in the soft starter.

### 8.2.4 Comparison of the 3RW3 semiconductor motor control unit (soft starter) with the 3RA star-delta combination

The comparison of soft starter and star-delta combinations shows that the 3RW3 has the following advantages (example here 22 kW):

3RW3 soft starter	3RA star-delta starter
Width: 55 mm	Width: 165 mm
Wiring: 3 motor supply leads	Wiring: 6 motor supply leads
Selectable startup parameters	None
Minimum current values at startup	Fixed current ratios ( $I_{\gamma} = 1/3I_{\Delta}$ )
No dangerous switchover current peaks	Switchover current peaks when switching from star to delta
Special variant for Dahlander motors	-----
Soft coasting-down function	-----

Table 8-4: Comparison of 3RW3/3RA

### 8.2.5 Notes on configuration

In order for a motor to reach its rated speed, motor torque at any given time during startup must be greater than the torque needed by the load, since otherwise a stable operating point would be reached before the motor achieved its rated speed (the motor would "drag to a stop"). The difference between motor torque and load torque is the accelerating torque that is responsible for the increase in the speed of the drive. The lower the accelerating torque, the longer the motor needs to run up to its operating speed.

#### Starting torque

Reducing the terminal voltage of a three-phase asynchronous motor reduces the motor's starting current and the starting torque. Current is directly proportional to voltage, whereas voltage is proportional to the square root of motor torque.

#### Example:

Motor = 55 kW, rated current = 100 A, starting current = 7 x rating current, motor torque = 355 Nm, starting torque = 2.4 x rated torque  
Settings for the soft starter: starting voltage 50% of rated voltage for motor  
The reductions are thus as follows:

- The starting current is reduced to half the starting current for a direct start: 50% of (7 x 100 A) = 350 A
- Starting torque is reduced to  $0.5 \times 0.5 = 25\%$  of the starting torque for a direct start: 25% of 2.4 x 355 Nm = 213 Nm

#### Note

On account of the fact that the starting voltage is proportional to the square root of the motor torque, it is important to ensure that the starting voltage is not too low. This applies particularly for a pronounced saddle torque, the lowest motor torque that occurs during run-up to rated speed.




Figure 8-9: Load and motor torques and motor terminal voltage for operation with soft starter

### Criteria for selection

### Note

In the case of the SIRIUS 3RW30/31 soft starters, the corresponding soft starter must be selected on the basis of the rated current for the motor (the rated current of the soft starter must be  $\geq$  the rated current for the motor).

The 3 potentiometers on the starter are for setting the starting voltage, the starting time, and the coasting-down time.

The soft starter is correctly set when the motor starts smoothly and runs up rapidly to its rated speed.

Ramp times of up to 20 seconds can be set.

## 8.3 Application and use

### 8.3.1 Areas of application and criteria for selection

The SIRIUS 3RW3 soft starters offer an alternative to star-delta starters (see Section 8.2.4 for a comparison and the advantages).

The most important advantages are soft starting and soft coasting-down, interruption-free switching without current spikes that could interfere with the supply system, and compact dimensions.

Many drives that needed frequency converters in the past can be changed to soft-start operation with the 3RW3, if the applications do not call for variations in speed.

#### Applications

Typical applications include, for example:

Conveyor belts, conveyor systems:

- Smooth starting
- Smooth slowing
- Use of better-value conveyor material

Rotary pumps, piston-type pumps

- Avoidance of pressure surges
- Extended service life of the piping system

Agitators, mixers:

- Reduced starting current

Fans:

- Less strain on gearing and drive belts

#### Cooling time

---

**Note:**

The cooling time must be taken into consideration in the starting frequency.

---

### 8.3.2 Installation guidelines

On account of the heat generated, certain installation guidelines must be adhered to when combining 3RW30/31 soft starters with other SIRIUS switching devices.

#### Stand-alone installation

Stand-alone installation is when minimum vertical **and** lateral clearances between the mounted devices are not violated. This applies both to individual devices and complete load feeders.

The following minimum clearances must be adhered to in stand-alone installation (these minimum clearances depend on the frame size):

Frame size	Minimum clearance on both sides in mm
S00	15
S0	20
S2	30
S3	40




Table 8-5: Stand-alone installation, minimum clearances at the side, 3RW3

Frame size	Vertical clearance a	Vertical clearance b
S00	50	50
S0	60	40
S2	50	30
S3	60	30




Table 8-6: Stand-alone installation, minimum clearances at the side, 3RW3

### Line lengths for the drive circuit

The control inputs for starting and stopping are not rated for longer distances. This means:

- In the case of a drive circuit that goes beyond the control cubicle, coupling relays must be used.
- The control cables in the cubicle should not be laid together with main circuit cables.

When electronic output modules are used in the drive circuit (e.g. Triac outputs at 230 VAC), RC elements (e.g. 3TX7462-3T or similar with  $C > 100$  nF) may be required at the control inputs under certain circumstances.

**Correction factors**

If the minimum clearances are violated, in a combination of a soft starter with a circuit breaker, fixed correction factors must be used to determine the rated current for the device and the switching frequency.

The following variables can be modified by means of correction factors:

- Rated current for the device
- Switching frequency
- Current setting of the circuit breaker
- Current setting of the overload relay

**Correction factor for the rated current of the device**

A factor is specified by which the device rated current of the soft starter is reduced.

**Example:**

Correction factor for the rated current of the device = 0.9

Selected device = 3RW3014-1CB14 (under normal conditions at 40 °C a device rated current of 6 A)

This results in an actual device rated current of:

$$0.9 \times 6 \text{ A} = 5.4 \text{ A}$$

**Correction factor for switching frequency**

The switching frequency is the maximum permissible number of starts per hour. This value must be adjusted by the specified correction factor. The number of permissible starts per hour is given in Table 8.7.1, Control electronics/power electronics, in Section 8.7, Technical specifications.

The specified correction factors refer to the following operating conditions: S4 operation, 40 °C ambient temperature, 30% duty cycle

**Example:**

Correction factor for the switching frequency = 1.5

Selected device = 3RW3014-1CB14 (has a maximum switching frequency of 30 starts per hour under the conditions specified above)

This results in a corrected switching frequency of:

$$1.5 \times 30 = 45 \text{ starts per hour}$$

To increase the switching frequency, it is also possible to use a larger device.

**Correction factor for the current setting of the circuit breaker**

In combinations of a 3RW30 soft starter and a 3RV1 circuit breaker, the set value of the circuit breaker may have to be corrected appropriately. The correction factor specifies the extent of the change.

**Example:**

Correction for the current setting of the circuit breaker: 1.1

Selected device = 3RW3014-1CB14

The connected motor has a motor rated current of 5 A.

The set value of the circuit breaker must be changed to:

$$1.1 \times 5 \text{ A} = 5.5 \text{ A}$$

**Correction factor for the current setting of the overload relay**

In combinations of a 3RW30 soft starter + 3RU1 thermal overload relay or 3RW30 software starter + 3RB10 electronic overload relay, the set value of the overload relay must be corrected appropriately. The correction factor specifies the extent of the change.

**Example:**

Correction factor for the current setting of the overload relay 0.9  
 Selected device = 3RW3014-1CB14  
 The connected motor has a motor rated current of 5 A.  
 The set value of the overload relay now has to be changed to:  
 $0.9 \times 5 \text{ A} = 4.5 \text{ A}$

**8.3.3 Overview tables: correction factors**

The tables below give the correction factors for the circuit-breaker current setting, the device rated current, and the switching frequency.

The values indicate the difference between use with a fan (accessory) and use without a fan.

All correction fans apply throughout the entire temperature range (i.e. for 40 °C, 50 °C, and 60 °C).

The various tables specify the values in turn for the following:

3RW30/31 soft starters in a stand-alone installation

3RW30/31 soft starter + 3RV1 circuit breaker

3RW30/31 soft starter + 3RT1 contactor + 3RU1 thermal overload relay

3RW30/31 soft starter + 3RT1 contactor + 3RB10 electronic overload relay

**8.3.3.1 3RW30/31 soft starters in a stand-alone installation****Minimum clearance**

In the case of frame size S00 (3RW301..), the following applies to stand-alone, vertical installation without directly attached switching devices: In order to maintain the required space above the arc chute, clearance of at least 50 mm must be maintained to grounded parts above and below.

**3RW30/31 correction factors**      3RW30/31 soft starters not combined with any other switching devices:

			Without fan				With fan	
			Stand-alone installation		Installed side by side		Stand-alone installation or side by side	
			Correction factor		Correction factor		Correction factor	
Order number	Frame size	Device rated current in A at 40 °C	Rated current for the device	Switching frequency	Rated current for the device	Switching frequency	Rated current for the device	Switching frequency
3RW3014-1CB..	S00	6	1	1	1	0,75	- 1)	- 1)
3RW3016-1CB..	S00	9	1	1	1	0.75	- 1)	- 1)
3RW3.24-1AB..	S0	12.5	1	1	1	0.65	1	1.8
3RW3.25-1AB..	S0	16	1	1	1	0.65	1	1.8
3RW3.26-1AB..	S0	25	1	1	1	0.65	1	1.8
3RW3034-1AB..	S2	32	1	1	1	0.65	1	1.8
3RW3035-1AB..	S2	38	1	1	1	0.65	1	1.8
3RW3036-1AB..	S2	45	1	1	1	0.65	1	1.8
3RW3044-1AB..	S3	63	1	1	1	0.8	1	1.6
3RW3045-1AB..	S3	75	1	1	1	0.75	1	1.6
3RW3046-1AB..	S3	100	1	1	1	0.7	1	1.6

Table 8-7: Correction factors, 3RW30/31

- 1) The SIRIUS 3RW301.. soft starters cannot be operated with a fan.

**8.3.3.2 3RW30/31 soft starters in combination with the 3RV1 circuit breaker**




Figure 8-10: 3RW3 soft starter + 3RV1 circuit breaker

**Dimensioning of the circuit breaker**

The frame size selected for the circuit breaker should be large enough so that the current value calculated can just be set. In the event of current values that are lower than can be set for the specified circuit breaker, the next smaller circuit breaker must be used.



**Correction factors:  
3RV1 + 3RW30/31**

Combination of a 3RV1 circuit breaker + 3RW30/31 soft starter:

					Without fan Stand-alone installation			Without fan Installed side by side			With fan Stand-alone installation			With fan Installed side by side		
					Correction factor Rated current for the device	Correction factor Switching frequency	Correction factor Current setting of the circuit breaker	Correction factor Rated current for the device	Correction factor Switching frequency	Correction factor Current setting of the circuit breaker	Correction factor Rated current for the device	Correction factor Switching frequency	Correction factor Current setting of the circuit breaker	Correction factor Rated current for the device	Correction factor Switching frequency	Correction factor Current setting of the circuit breaker
3RW3014-1CB..	S00	6	3RV1011-1GA10	(4.5 - 6.3) A	1	0.9	1	1	0.5	1.	- 1)	- 1)	- 1)	- 1)	- 1)	- 1)
3RW3016-1CB..	S00	9	3RV1011-1JA10	(7 - 10) A	1	0.9	1	1	0.5	1.	- 1)	- 1)	- 1)	- 1)	- 1)	- 1)
3RW3.24-1AB..	S0	12.	3RV1021-1KA10	(9 - 12.) A	1	0.5	1	1	0.5	1.	1	1.	1	1	1.7	1.1
3RW3.25-1AB..	S0	16	3RV1021-4AA10	(11 - 16) A	1	0.5	1	1	0.5	1.	1	1.	1	1	1.7	1.1
3RW3.26-1AB..	S0	25	3RV1021-4DA10	(20 - 25) A	1	0.75	1	0.	0.5	1.	1	1.	1	1	1.7	1.1
3RW3034-1AB..	S2	32	3RV1031-4EA10	(22 - 32) A	1	0.65	1	0.9	0.45	1.1	1	2.2	1	1	1.9	1.1
3RW3035-1AB..	S2	38	3RV1031-4FA10	(28 - 40) A	1	0.85	1	0.95	0.35	1.1	1	1.8	1	1	1.7	1.1
3RW3036-1AB..	S2	45	3RV1031-4GA10	(36 - 45) A	1	0.85	1	0.9	0.4	1.1	1	1.8	1	1	1.7	1.1
3RW3044-1AB..	S3	63	3RV1041-4JA10	(45 - 63) A	1	0.85	1	0.95	0.6	1.1	1	1.6	1	1	1.3	1.1
3RW3045-1AB..	S3	75	3RV1041-4KA10	(57 - 75) A	1	0.8	1	0.9	0.5	1.1	1	1.6	1	1	1.3	1.1
3RW3046-1AB..	S3	100	3RV1041-4MA10	(80 - 100) A	1	0.75	1	0.85	0.55	1.1	1	1.6	1	1	1.2	1.1

1) = SIRIUS 3RW301 .. soft starters cannot be used with a fan

Table 8-8: Correction factors: 3RV1 circuit breaker + 3RW3 soft starter

### 8.3.3.3 Combining the 3RT contactor with the 3RU1 thermal overload relay and 3RW3 soft starter

**Frame size of the overload relay**

The frame size selected for the overload relay should be large enough so that it is just possible to set the current value calculated. In the event of current values that are lower than can be set for the specified overload relay, the next smaller overload relay must be used.

**Important**

It is not permissible to mount the thermal overload relay under the contactor/connecting lead/soft starter combination. The overload relay must be integrated in the feeder before the contractor/connecting lead/soft starter combination. The specified correction factors apply only to this permissible mounting sequence.




Figure 8-11: 3RT+3RU1+3RW3 combination

**Minimum clearance**

For thermal reasons, a minimum clearance is necessary between the contactor/overload relay combination and the soft starter, as is a minimum length of the connecting leads. The following table specifies the minimum clearances and minimum lengths of the connecting leads for the various frame sizes:

Frame size	Minimum clearance between rail 1 and rail 2 (center to center) in mm	Minimum length of the connecting lead in mm
S00	160	100
S0	200	150
S2	240	200
S3	300	250

Table 8-9: 3RW3 installation guidelines, minimum clearances/lengths

**Correction factors: 3RT + 3RU1 + 3RW30/31**

Combination of the 3RT1 contactor with an attached 3RU1 thermal overload relay/connecting lead/3RW30/31 soft starter:

					Without fan Stand-alone installation			Without fan Installed side by side			With fan Stand-alone installation			With fan Installed side by side			
					Correction factor Rated current for the device	Correction factor for switching frequency	Correction factor Set value for th. overload relay	Correction factor Rated current for the device	Correction factor for switching frequency	Correction factor Set value for th. overload relay	Correction factor Rated current for the device	Correction factor for switching frequency	Correction factor Current setting of the circuit breaker	Correction factor Rated current for the device	Correction factor for switching frequency	Correction factor Set value for th. overload relay	
3RW3014-1CB..	S00	6	3RT1015-1A..	3RU1116-1GBO	(4.5 - 6.3) A	0.95	1	1	0.9	0.75	1	1)	1)	1)	1)	1)	1)
3RW3016-1CB..	S00	9	3RT1016-1A..	3RU1116-1JBO	(7 - 10) A	0.9	0.95	1	0.8	0.8	1	1)	1)	1)	1)	1)	1)
3RW3.24-1AB..	S0	12.5	3RT1024-1A..	3RU1126-1KBO	(9-12.5)A	0.95	0.9	1	0.9	0.55	1	1	1.8	0.95	1	1.7	0.95
3RW3.25-1AB..	S0	16	3RT1025-1A..	3RU1126-4ABO	(11-16)A	0.95	0.9	1	0.9	0.55	1	1	1.8	0.95	1	1.7	0.95
3RW3.26-1AB..	S0	25	3RT1026-1A..	3RU1126-4DBO	(22-25)A	0.9	0.8	1	0.8	0.55	1	1	1.8	0.95	1	1.7	0.95
3RW3034-1AB..	S2	32	3RT1034-1A..	3RU1136-4EBO	(22-32)A	0.95	0.7	1	0.9	0.45	1	1	2.2	0.92	1	1.9	0.92
3RW3035-1AB..	S2	38	3RT1035-1A..	3RU1136-4FBO	(28-40)A	0.95	0.9	1	0.9	0.35	1	1	1.8	0.92	1	1.7	0.92
3RW3036-1AB..	S2	45	3RT1036-1A..	3RU1136-4HBO	(36-45)A	0.9	0.95	1	0.8	0.45	1	1	1.8	0.92	1	1.7	0.92
3RW3044-1AB..	S3	63	3RT1044-1A..	3RU1146-4JBO	(45-63) A	0.95	0.9	1	0.9	0.65	1	1	1.6	0.92	1	1.5	0.92
3RW3045-1AB..	S3	75	3RT1045-1A..	3RU1146-4KBO	(57-75) A	0.95	0.85	1	0.9	0.5	1	1	1.6	0.92	1	1.5	0.92
3RW3046-1AB..	S3	100	3RT1046-1A..	3RU1146-1MBO	(80-100) A	0.9	0.8	1	0.8	0.55	1	1	1.6	0.92	1	1.5	0.92

1) = SIRIUS 3RW301 .. soft starters cannot be used with a fan.

Table 8-10: Correction factors, 3RT contactor + 3RU therm. overload relay + 3RW soft starter

**8.3.3.4 Combining the 3RT contactor with the 3RB10 electronic overload relay and 3RW3 soft starter**

The contactor, electronic overload relay, and soft starter can be connected in two ways:

- Combining a 3RT1 contactor with an attached 3 RB10 electronic overload relay, a connecting lead, and a 3RW30/31 soft starter
- Combining a 3RT1 contactor with a connecting lead and a combination of a 3RW30/01 soft starter with an attached 3RB10 electronic overload relay

**3RT + 3RB10 + connecting lead + 3RW3**

Rail 1:  
Combination of a 3RT1 contactor and a 3RB10 electronic overload relay

Rail 2:  
3RW30/31 soft starter




Figure 8-12: 3RT+3RB10+3RW3 combination

**Minimum clearance**

For thermal reasons, a minimum clearance is necessary between the contactor/overload relay combination and the soft starter, as is a minimum length of the connecting leads.

The following table specifies the minimum clearances and minimum lengths of the connecting leads for the various frame sizes:

Frame size	Minimum clearance between rail 1 and rail 2 (center to center) in mm	Minimum length of the connecting lead in mm
S00	160	100
S0	200	150
S2	240	200
S3	300	250

Table 8-11: 3RT + 3RB10 + 3RW3 installation guidelines, minimum clearances/minimum lengths

**3RT + connecting lead +  
3RB10 + 3RW3**

Rail 1:  
3RT1 contactor

Rail 2:  
Combination of 3RW30/31 soft  
starter and 3RB10 electronic  
overload relay




Figure 8-13: 3RT+3RW3+3RB10 combination

**Minimum clearances**

Frame size	Minimum clearance between rail 1 and rail 2 (center to center) in mm	Minimum length of the connecting lead in mm
S00	100	100
S0	140	150
S2	180	200
S3	240	250

Table 8-12: 3RT1 + 3RW30/31 + 3RB10 installation guidelines, minimum clearances/minimum lengths

**Correction factors: 3RT + 3RB10 + 3RW3**

Combining a 3RT1 contactor with an attached 3RB10 electronic overload relay, a connecting lead, and a 3RW30/31 soft starter

Order number	Frame size	Device rated current in A at an ambient temperature of 40 °C	Contactor order number	Order number of electronic overload relay	Setting range of the overload relay	Without fan			With fan		
						Stand-alone installation	Installed side by side	Without fan Stand-alone installation	Installed side by side	Stand-alone installation	Installed side by side
3RW3014-1CB..	S00	6	3RT1015-1A..	3RB1016-1SBO	(3-12)/A	1	1	1	1	1	1
3RW3016-1CB..	S00	9	3RT1016-1A..	3RB1016-1SBO	(3-12)/A	1	1	1	1	1	1
3RW3.24-1AB..	S0	12.5	3RT1024-1A..	3RB1026-1OBO	(6-25)/A	1	1	1	1	1	1
3RW3.25-1AB..	S0	16	3RT1025-1A..	3RB1026-1OBO	(6-25)/A	1	1	1	1	1	1
3RW3.26-1AB..	S0	25	3RT1026-1A..	3RB1026-1OBO	(6-25)/A	1	1	1	1	1	1
3RW3034-1AB..	S2	32	3RT1034-1A..	3RB1036-1UBO	(15-50)/A	1	1	1	1	1	1
3RW3035-1AB..	S2	38	3RT1035-1A..	3RB1036-1UBO	(15-50)/A	1	1	1	1	1	1
3RW3036-1AB..	S2	45	3RT1036-1A..	3RB1036-1UBO	(15-50)/A	1	1	1	1	1	1
3RW3044-1AB..	S3	63	3RT1044-1A..	3RB1046-1EBO	(25-100)/A	1	1	1	1	1	1
3RW3045-1AB..	S3	75	3RT1045-1A..	3RB1046-1EBO	(25-100)/A	1	1	1	1	1	1
3RW3046-1AB..	S3	100	3RT1046-1A..	3RB1046-1EBO	(25-100)/A	1	1	1	1	1	1

1) = SIRIUS 3RW301 .. soft starters cannot be used with a fan.

Table 8-13: Correction factors, 3RT contactor + 3RB10 electronic overload relay + 3RW soft starter

### 8.3.4 Circuit example

Circuit example (variant with UC110-230 V):




Figure 8-14: Circuit example, 3RW3

### 8.3.5 Commissioning

Every SIRIUS 3RW soft starter comes with the following warning, which it is imperative to heed:



**Caution**

This device has been tested carefully at the factory and found to be in working order.

During transportation, however, it may have been subject to stresses over which we have no control. The bypass relays in the main circuit may be in an undefined state.

In the interests of complete safety, the following procedure should be used at commissioning or after the replacement of the SIRIUS soft starter:

**First**, apply the supply voltage to A1/A2 in order to put the impulse series relays in a defined switching state.

**Then**, switch on the main circuit (L1/L2/L3).

If you do not do this, the motor can be switched on inadvertently and cause damage to people or parts of the system.

### Settings




Figure 8-15: Settings, 3RW3

**Note**

At commissioning, the settings of the potentiometers for the ramp time and the starting voltage should remain unchanged. These set values must be obtained in a trial.




<b>Changing settings</b>	<p>The potentiometer settings are scanned before each switching operation ("ON" or "OFF").</p> <p>If, for example, the setting of the potentiometer for starting time is changed while the motor is running up, the change does not come into effect until the next start.</p>
<b>Starting voltage</b>	<p>The starting voltage should be set to a value at which the motor starts rapidly.</p>
<b>Ramp time</b>	<p>The ramp time should be set such that the motor can run up within the time defined in this way.</p> <p>If the star time for star-delta starting is known, the ramp time can be set to this value.</p>
<b>Coasting-down time</b>	<p>The potentiometer for the coasting-down time is for setting the duration of the voltage ramp for coasting down. This parameter can be used to make the motor run-down longer than it would be if the motor were merely to coast to a stop.</p> <p>The motor coasts to a stop on its own if this potentiometer is set to a value of 0.</p>
<b>Switching frequency</b>	<p>To prevent thermal overloading of the devices, the maximum permissible switching frequency must be adhered to and the correction factor tables must be used (see the installation guidelines in Section 8.3.2).</p>
<b>Starting time</b>	<p>In order to obtain optimum operating conditions for the 3RW3 soft starter, the setting for the starting time should be approx. 1 second longer than the resultant motor run-up time, in order to ensure that the internal jumpering contacts do not have to carry the starting current. This protects the internal jumpering contacts and increases their service life. Longer starting times increase the thermal load on the devices and the motor unnecessarily and lead to a reduction in the permissible switching frequency.</p>

**Position of the terminals**

**3RW30**

The following graphic illustrates the position of the terminals and the potentiometers for adjustment.

**Frame size S00  
3RW301.**



**Frame size S0 to S3  
3RW302./303./304.**




Figure 8-16: Position of the terminals and the potentiometers for adjustment

**3RW31**

The 3RW31 soft starters are available in frame size S0. Outwardly, they differ from the 3RW30 in the labeling of the contacts and the terminals:

- There is no BYPASSED auxiliary contact. The free contact is used to enable the necessary drive contact IN2 to switch between the ramp times  $t_{R1}$  and  $t_{R2}$ .
- The 3RW31 does not have a coasting-down ramp. The potentiometer with which the coasting-down time is adjusted on the 3RW30 is used here to set the second ramp time  $t_{R2}$ .
- There is no ON auxiliary contact.

**Line length of the control cable**

To eliminate problems with the cable coupler capacitances, the control cable should be shorter than 15 m. (This is based on devices with a rated control supply voltage of UC 24 V to 50 m.)

To eliminate problems in control cables that are fed out of the cubicle, coupling links must be used.

**8.3.6 Event messages and diagnostics**

**Event messages**

READY LED	Continuous Flashing	Ready for operation while starting up or coasting down
BYPASSED LED	Continuous	Bypassed

Table 8-14: 3RW30/31 event messages

## Diagnostics

Malfunction	Possible cause	Remedy
READY LED off	<ul style="list-style-type: none"> <li>Supply voltage too low</li> </ul>	<ul style="list-style-type: none"> <li>Check and adapt the supply voltage at A1, A2</li> </ul>
No reaction to control input IN (READY LED on)	<ul style="list-style-type: none"> <li>No supply voltage</li> </ul>	<ul style="list-style-type: none"> <li>Check fuses/line contactor</li> </ul>
	<ul style="list-style-type: none"> <li>Phase loss</li> </ul>	<ul style="list-style-type: none"> <li>Check fuses/line contactor</li> <li>Check voltages at L1 to L3</li> </ul>
	<ul style="list-style-type: none"> <li>Wrong cable connected to IN</li> </ul>	<ul style="list-style-type: none"> <li>Connect to IN as shown in the graphic of the terminals</li> </ul>
	<ul style="list-style-type: none"> <li>No load</li> </ul>	<ul style="list-style-type: none"> <li>Connect the motor</li> </ul>
Start the motor directly (BYPASSED LED on)	<ul style="list-style-type: none"> <li>The line voltage is switched off and on in continuous operation without operation of the control input IN</li> </ul>	<ul style="list-style-type: none"> <li>Always switch the line contactor off and on in conjunction with control input IN</li> </ul>

Table 8-15: 3RW30/31 diagnostics

### 8.3.7 Timing diagram

#### Starting and coasting-down behavior

The following timing diagram shows the switchover times when the device is switched on/off:




Figure 8-17: Starting and coasting-down behavior

**Supply interruption in bypassed state**

If the load voltage is switched off in the bypassed state while the auxiliary supply continues to be applied at terminals A1/A2, the soft starter performs a direct start of the motor after the load voltage is switched on again. To prevent this, the "on" command must be removed in the event of the loss of the main voltage.

The following graphic illustrates what happens when the supply is interrupted in the bypassed state:




Figure 8-18: Supply interruption in the bypassed state

## 8.4 Accessories

The following accessories are available for the 3RW3 soft starters:

Description	Order number
Fan for 3RW3.2..	3RW3926-8A
Fan for 3RW303.. and 3RW304..	3RW3936-8A
Terminal covers for box covers for 3RW303..	3RT1936-4EA2
Terminal covers for box covers for 3RW304..	3RT1946-4EA2
Terminal cover for bar connection for 3RW304..	3RT1946-4EA1
Link modules for combination with 3RV1 circuit breaker	3RA19.1-1A (frame sizes S00 to S3)
RC element for control from PLC	3TX7462-3T

Table 8-16: Accessories, 3RW30/31

### Control of the fan

The fan is controlled by the control electronics of the soft starter.

It runs at the following times:

- When the fan is switched on: approx. 0.5 seconds after the bypass contacts close (end-of-startup signal)
- When the fan is switched off: approx. 0.5 hours after the soft starter is switched off

### Attachment of the fan

The fan is snapped into the recess provided on the underside of the soft starter, and the plug-in cable is inserted in the corresponding connector. The direction of installation is indicated on the fan by an arrow.

Additional parameter assignment is not necessary.

These fan modules mean that the starter can be installed in any position.

The only exception to this is when the fan cannot blow against the convection downward from above.

**Attachment of the fan**




Figure 8-19: Accessories: attachment of the fan

**Terminal covers**

To provide additional finger protection, for frame sizes S2 and S3 the terminal covers of the 3RT1 contactors of the same frame sizes can be used. Installation on the soft starter is analogous to that on the contactors.

**Link modules**

The same link modules are available for building fuseless feeders (soft starter + 3RV circuit breaker) as are used for the 3RT contactor + 3RV circuit breaker combinations. Refer to the information and assignment tables in Section 8.3.2, "Installation guidelines".

**RC element**

If the 3RW30/31 soft starter is to be controlled from a PLC with a Triac or thyristor output, malfunctioning can be avoided with an RC element. If there is leakage current of more than 1 mA, without an RC element the soft starter may interpret the drop in voltage that occurs at the input as an "ON" command.

**Connection example for an RC element**




Figure 8-20: Connection example with an RC element

## 8.5 Mounting and connection

### 8.5.1 Mounting

#### Snap-on attachment

The 3RW30 soft starters are snapped onto 35 mm rails in acc. with DIN EN 50 022 without a tool.

The starter is placed on the upper edge of the rail and pressed downward until it snaps onto the lower edge of the rail.

Frame sizes S00 and S0 can be removed just as easily: The starters are pressed downward so that the tension of the attachment springs is loosened, and the starters can be removed.

In the case of frame sizes S2 and S3, these attachment springs are released by a lug on the underside of the starter that can be moved using a screwdriver.

### 8.5.2 Connection

#### Screw-type terminals

The 3RW3 electronic soft starters are available with the SIGUT<sup>®</sup> terminal system and plus-minus POZIDRIV 2 screws.

#### Conductor cross-sections

The following table shows the permissible conductor cross-sections for the 3RW30 electronic soft starters:












	<b>3RW301.</b> <b>L1 L2 L3</b> <b>A1/A2; NO/NC</b>	<b>3RW302.</b> <b>3RW312.</b> <b>L1 L2 L3</b>		<b>3RW303.</b> <b>L1 L2 L3</b>		<b>3RW304..</b> <b>L1 L2 L3</b>
 Ø 5 ... 6 mm / PZ2	0.8 to 1.2 Nm 7 to 10.3 lb.in	2 to 2.5 Nm 18 to 22 lb.in	 Ø 5 ... 6 mm / PZ2	3 to 4.5 Nm 27 to 40 lb.in		4 to 6 Nm 35 to 53 lb.in
	2 x (0.5 to 1.5 mm <sup>2</sup> ) 2 x (0.75 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> )		2 x (2.5 to 16 mm <sup>2</sup> )
	2 x (0.5 to 2.5 mm <sup>2</sup> )	2 x (1 to 2.5 mm <sup>2</sup> ) 2 x (2.5 to 6 mm <sup>2</sup> )		2 x (0.75 to 16 mm <sup>2</sup> ) 1 x (0.75 to 25 mm <sup>2</sup> )		2 x (2.5 to 35 mm <sup>2</sup> ) 1 x (2.5 to 50 mm <sup>2</sup> )
----	----	----		2 x (0.75 to 25 mm <sup>2</sup> ) 1 x (0.75 to 35 mm <sup>2</sup> )		2 x (10 to 50 mm <sup>2</sup> ) 1 x (10 to 70 mm <sup>2</sup> )
<b>AWG</b>	2 x (18 to 14)	2 x (14 to 10)	<b>AWG</b>	2 x (18 to 3) 1 x (18 to 2)	<b>AWG</b>	2 x (10 to 1/0) 1 x (10 to 2/0)

Table 8-17: Conductor cross-sections, 3RW30/31

### 8.5.3 Circuit diagrams

There are two ways to connect up the 3RW3 soft starter:

- Control by button and locking of the ON button via the "ON" auxiliary contact of the 3RW3
- Control by switch




Figure 8-21: Circuit diagrams, 3RW3

### L3RW30

3RW302.  
3RW303./3RW304




Figure 8-22: Circuit diagrams, 3RW30




**3RW31**

Figure 8-23: Circuit diagrams, 3RW31

**Automatic operation**

Direct starting of the soft starter is possible as long as the auxiliary supply is applied at terminals A1 and A2. To this end, a jumper is required between the auxiliary supply contact A1 and the control contact IN.

The following must be taken into consideration:

- An on delay of up to 4 seconds can occur, depending on the frame size.
- Soft coasting down is no longer possible after the auxiliary supply is switched off.

**Control via PLC**

The 3RW3 soft starter can be controlled by means of a programmable controller (PLC). It is connected up in the same way as for control via switch.

**Important**

Always ensure that A1 and A2 are connected up correctly. Although polarity reversal cannot damage the device, it can lead to malfunctioning.

**Control of a motor with an electromechanical brake**

An electromechanical brake with infeed from the main voltage (L1/L2/L3) should not be connected directly to the output of the soft starter. An electromechanical brake should be controlled by means of a separate contactor (K1 in the circuit diagram below):





Figure 8-24: Motor control with an electromechanical brake

### 8.6 Dimensioned drawings (dimensions in mm)



mm	a	b	c	d	e	f	g	h	i	j	k	l	m	n
<b>3RW301.</b>	97.5	45	93	95	66	51	--	7.5	76	--	86	--	90	35
<b>3RW302./3RW312.</b>	125	45	119	125	81	63	96	7	101	63	14	7	115	35
<b>3RW303.</b>	160	55	143	141	95	63	115	8	119	77	18	7	150	30
<b>3RW304.</b>	170	70	183	162	108	87	156	8	132	87	22.5	7	160	60

## 8.7 Technical specifications

### 8.7.1 Control electronics/power electronics

#### Control electronics

Type	3RW3. ...-1.B0.		3RW3. ...-1.B1.
Rated control supply voltage	V	UC 24	UC 110 to 230
Rated control supply current	mA	Approx. 50	Approx. 25 to 20
Rated frequency at AC	Hz	50/60 ± 10%	

#### Power electronics

Type	3RW3. ...-1.B.4		3RW3. ...-1.B.5	3RW30 ...-1AA12
Voltage operating range	V	200 AC to 460 AC, three-phase (± 10%)	460 AC to 575 AC, three phase (± 10% - 15%)	115 AC to 240 AC, single-phase (±10%)
Rated frequency	Hz	50/60 ± 10%		
Permissible site altitude	Reduction of $I_E$			
	<ul style="list-style-type: none"> <li>• Up to 1000 m above sea level</li> <li>• Up to 2000 m above sea level</li> <li>• Up to 3000 m above sea level</li> <li>• Up to 4000 m ab. sea level<sup>1)</sup></li> </ul>		100%	92%
			85%	78%
Installation position	Without additional fan With additional fan <sup>3)</sup>		The soft starters are designed for operation when mounted in a vertical position. Any installation position (except vertical rotated by 180 °)	

Type	3RW30 1.	3RW3. 2.	3RW30 3.	3RW30 4.
Frame size	S00	S0	S2	S3
Continuous operation (% of $I_E$ )	%	100		
Minimum load <sup>2)</sup> (% of $I_E$ ); At 40 °C	%	4		
Permissible ambient temperature	°C	-25 to +60 (derating as of 40 °C, see below)		
Switching capacity of the auxiliary contacts	230 V/AC-15 230 V/DC-13 24 V/DC-13	A <sup>4)</sup> A <sup>4)</sup> A <sup>4)</sup>	3 0.1 1	3 0.1 1

Type	3RW30 14	3RW30 16	3RW30 24	3RW30 25	3RW30 26	
<b>Current-carrying capacity</b>						
Rated operational current $I_E$ in acc. with IEC	At 40/50/60 °C, AC-53b	A 6/5/4	9/8/7	12.5/11/9	16/14/12	25/21/18
Rated operational current $I_E$ in acc. with UL/CSA	At 40/50/60 °C, AC-53b	A 4.8/4.8/4	7.8/7.8/7	11/11/9	17.5/14/12	25/21/18
<b>Power loss</b> at continuous rated operational current (40 °C) approx.	W	5	7	7	9	13
<b>Power loss</b> when the max. switching frequency is exploited	W	5	6	7	8	9
<b>Permissible starts per hour without the use of a fan</b>						
Given intermittent duty S4, $T_U = 40$ °C	1/h	60	40	30		12
Duty cycle = 30%; stand-alone installation	%	250 x $I_E$ , 2 s		300 x $I_E$ , 2 s		
<b>Permissible starts per hour with the use of a fan</b>						
Given intermittent duty S4, $T_U = 40$ °C	1/h	- <sup>3)</sup>		54		21
Duty cycle = 30%; stand-alone installation						
<b>Idle time after continuous operation</b>	s	0				200
With $I_E$ before a new start						
<b>Degree of protection</b>	In acc. with IEC 60 529	IP 20 (terminal housing IP 00)				

**Conductor cross-sections****Screw-type terminals**

(1 or 2 conductors connectable)  
for standard screwdrivers  
size 2 and Pozidriv 2

**Auxiliary conductors:**

- Single-core  $\text{mm}^2$  2 x (0.5 to 1.5); 2 x (0.75 to 2.5) in acc. with IEC 60 947; max. 2 x (0.75 to 4)
- Finely stranded with wire end ferrule  $\text{mm}^2$  2 x (0.5 to 1.5); 2 x (0.75 to 2.5)
- AWG cables, single- or multi-core AWG 2 x (18 to 14)  
M 3, PZ2
- Terminal screws Nm 0.8 to 1.0 0.8 to 1.0  
lb.in 7.1 to 8.9 7.1 to 8.9
- Tightening torque

**Main conductors:**

- Single-core  $\text{mm}^2$  2 x (0.5 to 1.5); 2 x (0.75 to 2.5) 2 x (1 to 2.5)  
2 x (2.5 to 6)
- Finely stranded with wire end ferrule  $\text{mm}^2$  2 x (0.5 to 2.5) 2 x (1 to 2.5)  
2 x (2.5 to 6)
- Multi-core  $\text{mm}^2$  – –

Type		3RW30 14	3RW30 16	3RW30 24	3RW30 25	3RW30 26
	• AWG cables, single- or multi-core	AWG 2 x (18 to 14)		2 x (14 to 10)		
	- Terminal screws	M 3, PZ2		M 4, PZ2		
	- Tightening torque	Nm 0.8 to 1.2 lb.in 7 to 10.3		2 to 2.2 18 to 22		

1) Over 4000 m on request

2) The rated current for the motor (specified on the motor's type plate) should amount at least to the specified percentage of the SIRIUS soft starter's device rated current  $I_e$ .

3) In the case of frame size S00, it is not possible to install the fan provided as an accessory.

4) Frame size S00 does not have any auxiliary contacts.

**Power electronics**

Type		3RW30 34	3RW30 35	3RW30 36	3RW30 44	3RW30 45	3RW30 46
<b>Current-carrying capacity</b>							
Rated operational current $I_e$ in acc. with IEC	At 40/50/60 °C, AC-53b	A 32/27/23	38/32/27	45/38/32	63/54/46	75/64/54	100/85/72
Rated operational current $I_e$ in acc. with UL/CSA	At 40/50/60 °C, AC-53b	A 27/27/23	34/32/27	42/38/32	62/54/46	68/64/54	99/85/72
<b>Power loss</b> at continuous rated operational current (40 °C) approx.	W	10	13	17	13	16	26
<b>Permissible starts per hour</b>							
Given interm. duty S4, $T_u = 40$ °C	1/h	20	15	5	20	30	15
Duty cycle = 30%	%	300 x $I_e$ , 3 s			300 x $I_e$ , 4 s		
<b>Permissible starts per hour with the use of a fan</b>							
Given interm. duty S4, $T_u = 40$ °C	1/h	44	27	9	32	48	24
Duty cycle = 30%; stand-alone installation							
<b>Idle time after cont. operation</b> with $I_e$ before a new start	s	0		400	0		
<b>Degree of protection</b>	In acc. with IEC 60 529	IP 20 (terminal housing IP 00)			IP 20 <sup>1)</sup>		

**Conductor cross-sections**

**Screw-type terminals**

(1 or 2 conductors connectable)  
for standard screwdrivers

size 2 and Pozidriv 2

**Auxiliary conductors:**

- Single-core mm<sup>2</sup> 2 x (0.5 to 1.5); 2 x (0.75 to 2.5) in acc. with IEC 60 947; max. 2 x (0.75 to 4)
- Finely stranded with wire end ferrule mm<sup>2</sup> 2 x (0.5 to 1.5); 2 x (0.75 to 2.5)
- AWG cables, single- or multi-core AWG 2 x (18 to 14)
- Terminal screws M 3
- Tightening torque Nm 0.8 to 1.0  
lb.in 7.1 to 8.9

**Main conductors:**

- Single-core mm<sup>2</sup> 2 x (0.75 to 16)
- Finely stranded with wire end ferrule mm<sup>2</sup> 2 x (0.75 to 16)  
1 x (0.75 to 25)
- Multi-core mm<sup>2</sup> 2 x (0.75 to 25) 2 x (10 to 50)  
1 x (0.75 to 35) 1 x (10 to 70)
- AWG cables, single- or multi-core AWG 2 x (18 to 3) 2 x (10 to 1/0)  
1 x (18 to 2) 1 x (10 to 2/0)
- Terminal screws M 6, box terminal, PZ2 M6 (Allan screw)
- Tightening torque Nm 3 to 4.5 4 to 6  
lb.in 27 to 40 35 to 53

General specifications		
	Standard	Parameters
<b>EMC noise immunity</b>		
<b>Electrostatic discharge (ESD)</b>	IEC 1000-4-2,	Severity 3: 6/8 kV
<b>El. magn. RF fields</b>	IEC 1000-4-3	Frequency range: 80 to 1000 MHz with 80% at 1 kHz Severity 3, 10 V/m
<b>Conducted RF disturbance</b>	IEC 61000-4-6 EN 60 947-4-2 SN-IACS	Frequency range: 80 MHz to 1000 MHz with 80 % at 1 kHz 10 V at 0.15 MHz to 80 MHz 3 V at 10 kHz to 80 MHz
<b>Burst</b>	IEC 1000-4-4	Severity 3: 1/2 kV
<b>Surge</b>	IEC 1000-4-5	Severity 3: 1/2 kV
<b>EMC emitted interference</b>		
<b>EMC radio interference intensity</b>	CISPR 11/09.1990	Limit value of class B at 30 MHz to 1000 MHz
<b>Radio interference voltage</b>	CISPR 11/09.1990 EN 60 947-4-2	(0.15 MHz to 30 MHz): device class A (industry)

<sup>1)</sup> IP 20 only with attached box terminal (delivery state). Without box terminal IP 00.

<sup>2)</sup> Device class B (public power supply networks) is complied with only in the case of variants 3RW3.-1AB0. with control supply voltage UC of 24 V. For the 3RW3.-1A.1. variants with a control supply voltage UC of 110 V to 230 V, single-stage filters (e.g. type B84143-A...) must be connected upstream.

## 8.7.2 Short-circuit protection and fuse coordination

IEC 60947-4-1/DIN VDE 0660 Part 102 draws a distinction between two coordination types, known as coordination type 1 and coordination type 2. In both coordination types, the short circuit to be dealt with is reliably disconnected. The differences lie only in the degree to which the device is damaged after a short circuit.

### Coordination type 1

The motor feeder can be operable after each short-circuit disconnection. Damage to the soft starter is possible. The circuit breaker itself always attains coordination type 1.

### Coordination type 2

After a short-circuit event there must be no damage to the soft starter or any other switching device; only the backup fuse may be destroyed. The actual motor feeder can be put into operation again immediately once the short circuit fuse has been replaced.

### Maximum short-circuit current

All the specified fuse configurations are designed for a maximum short-circuit current of 50 kA. This ensures that short circuits of 50 kA can be disconnected without posing a threat to persons or the system.

### Motor feeder: coordination type 1

Note on configuration

A fuseless configuration is recommended for motor feeders (i.e. the combination of a 3RV circuit breakers and a 3RW30 soft starter). Coordination type 1 is thus attained.

### Motor feeder: coordination type 2

To set up a motor feeder of coordination type 2, the feeder must be fused (i.e. the motor must be provided with overload protection).

The following can be used:

- The 3NE1 all-range fuse, which unifies line protection and semiconductor protection
- The 3NE8 semiconductor protection fuse, in which case additional protection must be provided for the line

### Comparison of coordination types 1 and 2

The configuration variant on the basis of coordination type 2 is associated with higher costs than that of coordination type 1, which is why the fuseless configuration (coordination type 1) is recommended. The advantages are:

- Fewer components in the cubicle
- Less effort required for wiring
- Less cubicle space required
- Lower price

**Fuse configurations  
with SITOR 3NE1..-0**

The following table specifies the fuse configuration (coordination type 2) for 3RW30/31 with SITOR fuses 3NE1..-0 (short-circuit and line protection); max. short-circuit current 50 kA:

Order number Soft starter	Order number of the fuse	Rated current of the fuse	Frame size of the fuse
MLFB	MLFB	A	
3RW3014	3NE1814-0 <sup>1)</sup>	20	000
3RW3016	3NE1815-0 <sup>1)</sup>	25	000
3RW3024/3RW3124	3NE1815-0 <sup>2)</sup>	25	000
3RW3025/3RW3125	3NE1815-0 <sup>2)</sup>	25	000
3RW3026/3RW3126	3NE1802-0 <sup>2)</sup>	40	000
3RW3034	3NE1818-0 <sup>2)</sup>	63	000
3RW3035	3NE1820-0 <sup>2)</sup>	80	000
3RW3036	3NE1820-0 <sup>2)</sup>	80	000
3RW3044	3NE1820-0 <sup>2)</sup>	80	000
3RW3045	3NE1021-0 <sup>2)</sup>	100	00
3RW3046	-- <sup>3)</sup>	--	--

Table 8-18: Fuse configurations (SITOR)

1) Fuse coordination for max. 400 V

2) Fuse coordination for max. 500 V

3) Fuse coordination with all-range fuses not possible;  
pure semiconductor protection fuses plus circuit breakers  
can be used instead (see following table)



### Fuse configurations with SITOR 3NE8

The following table specifies the fuse configuration (coordination type 2) for 3RW30/31 with SITOR fuses 3NE8 (semiconductor protection is provided by the fuse; line protection and overload protection are provided by the circuit breaker); max. short-circuit current 50 kA/400 V:

Order number Soft starter	Order number of the fuse	Rated current of the fuse	Frame size of the fuse	Order number of the circuit breaker <sup>2)</sup>	Link module 3RW - 3RV
MLFB	MLFB	A	Size	MLFB	MLFB <sup>3)</sup>
3RW3014	3NE8003	35	00	3RV1011	3RA1911-1A
3RW3016	3NE8003	35	00	3RV1011	3RA1911-1A
3RW3024/3RW3124	3NE8003	35	00	3RV1021	3RA1921-1A
3RW3025/3RW3125	3NE8003	35	00	3RV1021	3RA1921-1A
3RW3026/3RW3126	-- <sup>1)</sup>	--	--	--	--
3RW3034	3NE8022	125	00	3RV1031	3RA1931-1A
3RW3035	3NE8024	160	00	3RV1031	3RA1931-1A
3RW3036	3NE8024	160	00	3RV1031	3RA1931-1A
3RW3044	3NE8024	160	00	3RV1041	3RA1941-1A
3RW3045	3NE8024	160	00	3RV1041	3RA1941-1A
3RW3046	3NE8024	160	00	3RV1041	3RA1941-1A

Table 8-19: Fuse configurations (SITOR)

- 1) Coordination with pure semiconductor protection fuses is not possible; all-range fuses 3NE1..0 can be used (see the table above)
- 2) The selection and setting of the circuit breaker is based on the rated current for the motor
- 3) Note the unit of quantity

If the motor is to be configured to meet UL requirements, the order number of the fuse must be specified (3NE80..-1).

**Fuseless configuration**

The following table specifies the components of the fuseless configuration (coordination type 1) for 3RW30/31; short-circuit current of 50 kA/400 V:

Order number of the soft starter	Order number of the circuit breaker <sup>1)</sup>	Link module
MLFB	MLFB	MLFB <sup>3)</sup>
3RW3014	3RV1011 <sup>2)</sup>	3RA1911-1A
3RW3016	3RV1011 <sup>2)</sup>	3RA1911-1A
3RW3024/3RW3124	3RV1021	3RA1921-1A
3RW3025/3RW3125	3RV1021	3RA1921-1A
3RW3026/3RW3126	3RV1021	3RA1921-1A
3RW3034	3RV1031	3RA1931-1A
3RW3035	3RV1031	3RA1931-1A
3RW3036	3RV1031	3RA1931-1A
3RW3044	3RV1041	3RA1941-1A
3RW3045	3RV1041	3RA1941-1A
3RW3046	3RV1041	3RA1941-1A

Table 8-20: Motor feeder: fuseless configuration

- 1) The selection and setting of the circuit breaker is based on the rated current for the motor
- 2) 50 mm clearance is required above and below between the 3RW and grounded parts
- 3) Note the unit of quantity

**Fused configuration**

The following table specifies the components of the fused configuration (coordination type 1) for 3RW30/31; short-circuit current of 50 kA/400 V:

Order number of the soft starter	Order number of the fuse	Fuse rated current/ frame size	Order number of the therm. overload relay <sup>1)</sup>	Order number of the electron. overload relay <sup>1)</sup>	Order number of the contactor
MLFB	MLFB	A / size	MLFB	MLFB	MLFB
3RW3014	3NA3810	25 / 00	3RU1116 <sup>2)4)</sup>	3RB1016 <sup>2)4)</sup>	3RT1015
3RW3016	3NA3810	25 / 00	3RU1116 <sup>2)4)</sup>	3RB1016 <sup>2)4)</sup>	3RT1016
3RW3024/ 3RW3124	3NA3822	63 / 00	3RU1126 <sup>3)</sup>	3RB1026 <sup>3)</sup>	3RT1024
3RW3025/ 3RW3125	3NA3822	63 / 00	3RU1126 <sup>3)</sup>	3RB1026 <sup>3)</sup>	3RT1025
3RW3026/ 3RW3126	3NA3824	80 / 00	3RU1126 <sup>3)</sup>	3RB1026 <sup>3)</sup>	3RT1026
3RW3034	3NA3830	100 / 00	3RU1136 <sup>3)</sup>		3RT1034
3RW3035	3NA3830	100 / 00	3RU1136 <sup>3)</sup>		3RT1035
3RW3036	3NA3830	100 / 00	3RU1136 <sup>3)</sup>		3RT1036
3RW3044	3NA3144	250 / 1	3RU1146 <sup>3)</sup>		3RT1044
3RW3045	3NA3144	250 / 1	3RU1146 <sup>3)</sup>		3RT1045
3RW3046	3NA3144	250 / 1	3RU1146 <sup>3)</sup>		3RT1046

Table 8-21: Motor feeder: fused configuration

- 1) The selection and setting of the overload relay is based on the rated current for the motor
- 2) Short-circuit current of 50 kA to max. 400 V
- 3) Short-circuit current of 50 kA to max. 500 V
- 4) 50 mm clearance is required above and below between the 3RW and grounded parts

### 8.7.3 Site altitude

If the site altitude is above 1000 m, the following are necessary:

- A reduction in the rated current for thermal reasons
- A reduction in the rated voltage on account of the diminished dielectric strength

#### Reductions as a function of site altitude

The diagram below plots the reductions in rated current and rated operating voltage as a function of site altitude:




Figure 8-25: Reductions as a function of site altitude

### 8.7.4 Specifications in acc. with IEC

The specified motor ratings are guide values.

The soft starter must be selected on the basis of the rated current  $I_e$ .

The motor ratings are based on the values specified in DIN 42 973 (kW) and NEC 96 / UL 508 (hp).

#### Ambient temperature = 40 °C

230 V	400 V	$I_e$	Order number	500 V	$I_e$	Order number
Pe in kW	Pe in kW	In A	MLFB	Pe in kW	In A	MLFB
1.5	3	6	3RW3014-1CB.4	-	-	-
2.2	4	9	3RW3016-1CB.4	-	-	-
3	5.5	12.5	3RW3024-1AB.4	7.5	12.5	3RW3024-1AB.5
4	7.5	16	3RW3025-1AB.4	7.5	16	3RW3025-1AB.5
5.5	11	25	3RW3026-1AB.4	15	25	3RW3026-1AB.5
7.5	15	32	3RW3034-1AB.4	18.5	32	3RW3034-1AB.5
11	18.5	38	3RW3035-1AB.4	22	38	3RW3035-1AB.5
11	22	45	3RW3036-1AB.4	30	45	3RW3036-1AB.5
19	30	63	3RW3044-1AB.4	37	63	3RW3044-1AB.5
22	37	75	3RW3045-1AB.4	45	75	3RW3045-1AB.5
30	55	100	3RW3046-1AB.4	70	100	3RW3046-1AB.5

Table 8-22: 3RW3 motor ratings in acc. with IEC at 40° C

#### Ambient temperature = 50 °C

230 V	400V	$I_e$	Order number	500 V	$I_e$	Order number
Pe in kW	Pe in kW	In A	MLFB	Pe in kW	In A	MLFB
1.1	2.2	5	3RW3014-1CB.4	-	-	-
1.5	4	8	3RW3016-1CB.4	-	-	-
3	5.5	11	3RW3024-1AB.4	5.5	11	3RW3024-1AB.5
4	5-5	14	3RW3025-1AB.4	7.5	14	3RW3025-1AB.5
5.5	11	21	3RW3026-1AB.4	11	21	3RW3026-1AB.5
7.5	11	27	3RW3034-1AB.4	15	27	3RW3034-1AB.5
7.5	15	32	3RW3035-1AB.4	18.5	32	3RW3035-1AB.5
11	18.5	38	3RW3036-1AB.4	22	38	3RW3036-1AB.5
15	22	54	3RW3044-1AB.4	30	54	3RW3044-1AB.5
18.5	30	64	3RW3045-1AB.4	37	64	3RW3045-1AB.5
22	45	85	3RW3046-1AB-4	55	85	3RW3046-1AB.5

Table 8-23: 3RW3 motor ratings in acc. with IEC at 50° C

#### Ambient temperature = 60 °C

230 V	400 V	$I_e$	Order number	500 V	$I_e$	Order number
Pe in kW	Pe in kW	In A	MLFB	Pe in kW	In A	MLFB
0.75	1.5	4	3RW3014-1CB.4	-	-	-
1.5	3	7	3RW3016-1CB.4	-	-	-
2.2	4	9	3RW3024-1AB.4	5.5	9	3RW3024-1AB.5
3	5.5	12	3RW3025-1AB.4	7.5	12	3RW3025-1AB.5
4	7.5	18	3RW3026-1AB.4	11	18	3RW3026-1AB.5
5.5	11	23	3RW3034-1AB.4	15	23	3RW3034-1AB.5
7.5	11	27	3RW3035-1AB.4	15	27	3RW3035-1AB.5
7.5	15	32	3RW3036-1AB.4	18.45	32	3RW3036-1AB.5
11	22	46	3RW3044-1AB.4	30	46	3RW3044-1AB.5
15	22	54	3RW3045-1AB.4	30	54	3RW3045-1AB.5
18.5	37	72	3RW3046-1AB.4	45	72	3RW3046-1AB.5

Table 8-24: 3RW3 motor ratings in acc. with IEC at 60° C

## 8.7.5 Specifications in acc. with NEMA

The specified motor ratings are guide values.

The soft starter must be selected on the basis of the rated current  $I_e$ .

The motor ratings are based on the values specified in DIN 42 973 (kW) and NEC 96 / UL 508 (hp).

### Ambient temperature = 40 °C

200V	230 V	460V	$I_e$	Order number	460V	575V	$I_e$	Order number
Pe in hp	Pe in hp	Pe in hp	In A	MLFB	Pe in hp	Pe in hp	In A	MLFB
1	1	3	4.8	3RW3014-1CB.4	-	-	-	-
2	2	5	7.8	3RW3016-1CB.4	-	-	-	-
3	3	7.5	11	3RW3024-1AB.4	7.5	10	11	3RW3024-1AB.5
5	5	10	17.5	3RW3025-1AB.4	10	15	17.5	3RW3025-1AB.5
7.5	7.5	15	25.3	3RW3026-1AB.4	15	20	25.3	3RW3026-1AB.5
7.5	7.5	20	27	3RW3034-1AB.4	20	25	27	3RW3034-1AB.5
10	10	25	34	3RW3035-1AB.4	25	30	34	3RW3035-1AB.5
10	15	30	42	3RW3036-1AB.4	30	40	42	3RW3036-1AB.5
20	20	40	62.1	3RW3044-1AB.4	40	60	62.1	3RW3044-1AB.5
20	25	50	68	3RW3045-1AB.4	50	60	68	3RW3045-1AB.5
30	30	75	99	3RW3046-1AB.4	75	100	99	3RW3046-1AB.5

Table 8-25: 3RW3 motor ratings in acc. with NEMA at 40° C

### Ambient temperature = 50 °C

200V	230 V	460V	$I_e$	Order number	460V	575V	$I_e$	Order number
Pe in hp	Pe in hp	Pe in hp	In A	MLFB	Pe in hp	Pe in hp	In A	MLFB
1	1	3	4.8	3RW3014-1CB.4	-	-	-	-
2	2	5	7.8	3RW3016-1CB.4	-	-	-	-
3	3	7.5	11	3RW3024-1AB.4	7.5	10	11	3RW3024-1AB.5
3	3	10	14	3RW3025-1AB.4	10	10	14	3RW3025-1AB.5
5	5	15	21	3RW3026-1AB.4	15	15	21	3RW3026-1AB.5
7.5	7.5	20	27	3RW3034-1AB.4	20	25	27	3RW3034-1AB.5
7.5	10	20	32	3RW3035-1AB.4	20	30	32	3RW3035-1AB.5
10	10	25	38	3RW3036-1AB.4	25	30	38	3RW3036-1AB.5
15	20	40	54	3RW3044-1AB.4	40	50	54	3RW3044-1AB.5
20	20	40	64	3RW3045-1AB.4	40	60	64	3RW3045-1AB.5
25	30	60	85	3RW3046-1AB.4	60	75	85	3RW3046-1AB.5

Table 8-26: 3RW3 motor ratings in acc. with NEMA at 50° C

### Ambient temperature = 60 °C

200 V	230 V	460 V	$I_e$	Order number	460 V	575 V	$I_e$	Order number
Pe in hp	Pe in hp	Pe in hp	In A	MLFB	Pe in hp	Pe in hp	In A	MLFB
0.75	0.75	2	4	3RW3014-1CB.4	-	-	-	-
1.5	1.5	3	7	3RW3016-1CB.4	-	-	-	-
2	2	5	9	3RW3024-1AB.4	5	7.5	9	3RW3024-1AB.5
3	3	7.5	12	3RW3025-1AB.4	7.5	10	12	3RW3025-1AB.5
5	5	10	18	3RW3026-1AB.4	10	15	18	3RW3026-1AB.5
5	7.5	15	23	3RW3034-1AB.4	15	20	23	3RW3034-1AB.5
7.5	7.5	20	27	3RW3035-1AB.4	20	25	27	3RW3035-1AB.5
7.5	10	20	32	3RW3036-1AB.4	20	30	32	3RW3036-1AB.5
10	15	30	46	3RW3044-1AB.4	30	40	46	3RW3044-1AB.5
15	20	40	54	3RW3045-1AB.4	40	50	54	3RW3045-1AB.5
20	25	50	72	3RW3046-1AB.4	50	60	72	3RW3046-1AB.5

Table 8-27: 3RW3 motor ratings in acc. with NEMA at 60° C

# Index

## Numerics

- 35 mm rail 6-14
- 3-phase busbars 2-41, 2-42
- 3-phase feed-in terminal 2-42
- 3RB10 electronic overload relay 4-11
- 3RB12 electronic overload relay 4-11
- 3RU11 thermal overload relays 4-10
- 3RW3 soft starter 8-15
- 3RW31 special variant 8-11

## A

- Adding to the auxiliary contacts 3-53
- Adjustment scale 4-16
- Automatic reset 4-20
- Auxiliary conducting path, integrated 3-52
- Auxiliary contact, BYPASSED 8-32
- Auxiliary contactors 3-29
- Auxiliary contacts 4-16, 8-12
- Auxiliary switch 2-19
- Auxiliary switch blocks 3-52
- Auxiliary switch repetition terminal 4-13
- Auxiliary switch, at side 3-55
- Auxiliary switch, at the front 3-54

## B

- Banks of capacitors 3-25
- Base plate 2-45
- Bay 2-32
- Bistable 4-20
- Box terminal construction type 6-5
- Busbar adapter 2-37
- Busbar mounting 5-14, 5-20
- Busbar systems 2-37

## C

- Cable coupler capacitances 8-32
- Cage Clamp terminal 1-18
- Cage-type clamping unit 1-18
- Capacitor switching capacity 3-26
- Capacitor-switching contactors 3-25
- Circuit breaker 3RV1 2-5
- Circuit diagrams 4-31, 5-23, 7-24, 8-38
- Circuit example 8-29
- Clock pulse generator 7-18
- Coasting-down time 8-31

- Coding plug set 7-20
- Coding plug set (7PX9904) 7-8
- Coil repeat terminals 4-13
- Combination and wide-range voltages 7-6
- Combination voltage 7-6
- Commissioning 8-30
- Components 1-11
- Conductor cross-sections 5-21, 6-15
- Connecting lead 6-12
- Connection comb 6-12
- Connection example, 3RU10 4-32
- Connection example, 3RU11 4-32
- Connection plans for single-phase motors 4-33
- Contactors with an extended operating range 3-26
- Control supply voltage, failure 4-20
- Coordination type 1 5-2
- Coordination type 2 5-2
- Correction factors 8-20
- Cover 7-21
- Current gain 6-10
- Current setting 8-20

## D

- DC feedback 2-15
- Device holder 2-40
- Diagnostics 8-33
- Dimension drawings for the 3RV1 2-49
- Direct attachment 6-7
- Direct current loads 2-11
- Direct starters 5-14
- Disconnecting module 2-26
- Disconnecter specifications 2-3

## E

- Electrical isolation 6-9
- Electromagnetic compatibility 7-2
- Electromagnetic overcurrent release 2-12
- Electromechanical remote reset 4-23
- EMC suppression module 3-80
- End holder 6-13
- End plate, coupling links 6-13
- Event messages 8-32
- Explosion-proof motors 2-4, 4-14
- Extended terminal covers 8-13
- External current transformers 4-13

## F

Fan 8-13, 8-35  
Feed-in terminal block 3-44  
Frequency converter 8-8  
Front plates 2-33, 2-34  
Function diagrams 7-10, 7-14  
Function setting 7-9, 7-12  
Functions 7-12  
Fuse monitoring 2-14

## G

Galvanic isolation 6-10  
Ground fault 4-20

## H

Heavy starting 4-10  
Holder for stand-alone installation 4-27  
Housing 2-32  
Housings 2-10

## I

Identifying letters 7-13  
Indicator light installation 2-36  
Input modules 6-5  
Inrush current 2-10  
Inrush currents 2-13  
Installation guidelines 8-18  
Interface modules 6-3  
Interference 6-10  
Isolating distance 8-3  
Isolation 8-11

## K

KTA certificate 2-4

## L

Label set 7-12, 7-20  
Level adaptation 6-10  
Line lengths 8-19  
Link modules 5-8  
Load control 7-6  
Locking during maintenance work 2-30

## M

Main and emergency stop switches 2-17  
Making/breaking capacity 3-83  
Manual/auto RESET 4-15  
Manual/automatic switchover 4-17  
Meshed networks 2-16  
Modular system 1-10  
Molded plastic 2-33  
Molded-plastic front plates 2-33  
Monostable 4-20  
Mounting kits 5-5  
Mounting onto contactors 4-26  
Mounting systems 5-4  
Multifunction 7-8

## N

No load 8-33  
Normal switching duty 8-3, 8-11  
Number of auxiliary switches, maximum 3-55

## O

Off-delay 7-17  
On-delay 7-16  
Operating limits 4-2  
Operating temperature 7-5  
Operating time adjustment 7-8, 7-11  
Outgoing terminal rail 2-40  
Output modules 6-5  
Overcurrent release 2-6  
Overload release 2-6

## P

Parallel connection 3-83  
Phase firing 8-9  
Phase loss 8-33  
Phase loss sensitivity 2-11, 2-13  
Plug-in relay coupling links 6-6  
Pole-changing motors 8-11  
Potentiometers 8-17  
Power gain 6-10  
Precharging resistors 3-25  
Push-in lugs 7-21

## R

Railway vehicles 2-4  
Ramp time 8-31  
Ramp times 8-17  
Rated current 4-16  
Recovery time 4-17, 4-19  
Reduction in starting current 8-6  
Reductions 8-16  
Relay coupling modules 6-4  
Remote reset, mechanical 4-24  
Remote-controlled mechanism 2-23  
Repeatability 7-7  
RESET button 4-15  
Reset, automatic 4-20  
Response threshold 2-16  
Retainer, coupling links 6-13  
Rotary switch extension for door 2-28

## S

Safe isolation 6-9  
Screw-on attachment 5-19  
Screw-type terminal 7-5  
Screw-type terminals 6-8  
Sealing cover 4-16  
Second ramp time 8-32  
Self-monitoring 4-20  
Semiconductor coupling modules 6-4  
Series resistor 3-27  
Setting 8-41



---

Setting accuracy 7-7  
Setting ranges 4-10  
Settings 8-11  
Shipbuilding certificates 2-4  
Ships 4-3  
Ships' systems 4-3  
Shock protection 2-3, 4-2  
Short-circuit breaking capacity 2-10  
Short-circuit release 2-11  
Side module 2-40  
Signal transmission 6-10  
SIKOSTART 3RW22 8-14  
SIKOSTART 3RW34 8-15  
Single-phase loads 2-11  
Snap-on attachment 3-87, 5-18, 6-7, 6-14, 8-37  
Soft coasting-down function 8-12  
Soft starting function 8-12  
Stand-alone installation 8-18  
Standard 3RW30 variant 8-11  
Standards 2-3, 4-2, 7-2  
Star starting 8-7  
Star-delta combinations 8-16  
Star-delta function 7-19  
Start contact 7-5  
Starter circuit breakers 4-9  
Starter combinations 2-13  
Starting current 8-6  
Starting time 8-31  
Starting torque 8-16  
Starting voltage 8-16, 8-31  
Stop button 4-15  
Supply interruption in the bypassed state 8-34  
Supply voltage 8-33  
Surface casing 2-32  
Switching capacitive loads 6-8  
Switching capacity 7-2  
Switching direct current 2-16  
Switching frequency 8-20  
Switching inductive loads 6-8

**T**

Technical specifications 2-58, 4-37, 8-41  
Terminal covers 3-84, 8-13  
Terminals for contactor coils 3-44  
Thermal overload release 2-11, 2-13  
Thermistor detector 4-19  
Thermistor motor protection 4-12  
Three-phase current asynchronous motors 8-6  
Three-phase induction motors 2-13  
Three-pole load 2-11  
Time ranges 7-16  
Time-current characteristics 2-3, 4-17, 4-18, 4-21  
Time-delayed overload release 4-2  
Timing diagram 8-33  
Transformer protection 2-13  
Tripping characteristic 4-18

Tripping characteristics 2-13  
Tripping classes 4-2, 4-14  
Tripping times 4-21  
Two-conductor connection 3-90  
Two-tier construction type 6-5  
Two-wire time relay 7-6, 7-17

## U

Undervoltage release 2-19  
Uniformity 1-10  
Utilization category 4-9

## V

Vertical installation position 3-88

## W

Wide-range voltage 7-5  
Wire release 4-25  
Wiring kits 5-8